cisco.



Cisco DNA Center Upgrade Guide

First Published: 2019-02-20 **Last Modified:** 2021-03-23

Americas Headquarters

Cisco Systems, Inc. 170 West Tasman Drive San Jose, CA 95134-1706 USA http://www.cisco.com Tel: 408 526-4000 800 553-NETS (6387) Fax: 408 527-0883



CONTENTS

CHAPTER 1	Introduction 1
	About Cisco DNA Center 1
	Upgrade Paths 1
	Prerequisites for Upgrading 5
PART I	Upgrade Cisco DNA Center 7
CHAPTER 2	Upgrade to Cisco DNA Center 2.2.1.3 9
	Set Up NIC Bonding 9
	Enable NIC Bonding on a 44 or 56-Core Appliance 10
	Enable NIC Bonding Now 10
	Enable NIC Bonding Later 11
	Enable NIC Bonding on a 112-Core Appliance 12
	Upgrade from Release 2.2.1.0 to Release 2.2.1.3 12
	Upgrade from Release 2.1.2.x to Release 2.2.1.3 13
	Upgrade from Release 2.1.1.0 or 2.1.1.3 to Release 2.2.1.3 14
	Upgrade from Release 1.3.3.x to Release 2.2.1.3 14
	Upgrade from Release 1.3.1.x to Release 2.2.1.3 15
	Upgrade from Release 1.3.0.x to Release 2.2.1.3 16
	Upgrade from Release 1.2.12.x to Release 2.2.1.3 17
	Upgrade from Release 1.2.10.x to Release 2.2.1.3 18
	Upgrade from Release 1.2.8 to Release 2.2.1.3 19
	Upgrade from Release 1.2.6 to Release 2.2.1.3 19
	Upgrade from Release 1.2.5 to Release 2.2.1.3 20
	Upgrade from Release $1.2 - 1.2.4$ to Release $2.2.1.3$ 21

CHAPTER 3	Upgrade to Cisco DNA Center 2.1.2.6 25
	Upgrade from Release 2.1.2.x to Release 2.1.2.6 25
	Upgrade from Release 2.1.1.0 or 2.1.1.3 to Release 2.1.2.6 26
	Upgrade from Release 1.3.3.x to Release 2.1.2.6 27
	Upgrade from Release 1.3.1.x to Release 2.1.2.6 28
	Upgrade from Release 1.3.0.x to Release 2.1.2.6 29
	Upgrade from Release 1.2.12.x to Release 2.1.2.6 30
	Upgrade from Release 1.2.10.x to Release 2.1.2.6 30
	Upgrade from Release 1.2.8 to Release 2.1.2.6 31
	Upgrade from Release 1.2.6 to Release 2.1.2.6 32
	Upgrade from Release 1.2.5 to Release 2.1.2.6 33
	Upgrade from Release $1.2 - 1.2.4$ to Release $2.1.2.6$ 33
	Upgrade from Release 1.1.7 or 1.1.8 to Release 2.1.2.6 34
CHAPTER 4	Upgrade to Cisco DNA Center 1.3.3.9 37
	Upgrade from Release 1.3.3.0–1.3.3.8 to Release 1.3.3.9 37
	Upgrade from Release 1.3.1.0 – 1.3.1.7 to Release 1.3.3.9 38
	Upgrade from Release 1.3.0.x to Release 1.3.3.9 39
	Upgrade from Release 1.2.12.x to Release 1.3.3.9 40
	Upgrade from Release 1.2.10.x to Release 1.3.3.9 41
	Upgrade from Release 1.2.8 to Release 1.3.3.9 41
	Upgrade from Release 1.2.6 to Release 1.3.3.9 42
	Upgrade from Release 1.2.5 to Release 1.3.3.9 43
	Upgrade from Release $1.2 - 1.2.4$ to Release $1.3.3.9$ 44
	Upgrade from Release 1.1.7 or 1.1.8 to Release 1.3.3.9 44
CHAPTER 5	Upgrade to Cisco DNA Center 1.3.1.7 47
	Cisco ISE Is Required with Cisco DNA Center 1.3.1.0 and Later 47
	Upgrade from Release 1.3.1.6 to Release 1.3.1.7 48
	Upgrade from Release 1.3.1.0–1.3.1.5 to Release 1.3.1.7 48
	Upgrade from Release 1.3.0.x to Release 1.3.1.7 49
	Upgrade from Release 1.2.12.x to Release 1.3.1.7 49

Upgrade from Release 1.1.7 or 1.1.8 to Release 2.2.1.3 **22**

iii

	Upgrade from Release 1.2.10.x to Release 1.3.1.7 50
	Upgrade from Release 1.2.8 to Release 1.3.1.7 51
	Upgrade from Release 1.2.6 to Release 1.3.1.7 52
	Upgrade from Release 1.2.5 to Release 1.3.1.7 52
	Upgrade from Release $1.2 - 1.2.4$ to Release $1.3.1.7$ 53
	Upgrade from Release 1.1.7 or 1.1.8 to Release 1.3.1.7 54
CHAPTER 6	Upgrade to Cisco DNA Center 1.3.0.7 57
	Upgrade from Release 1.3–1.3.0.6 to Release 1.3.0.7 57
	Upgrade from Release 1.2.12.x to Release 1.3.0.7 58
	Upgrade from Release 1.2.10.x to Release 1.3.0.7 59
	Upgrade Procedure for Deployments Not Running Cisco SD-Access 59
	Upgrade Procedure for Deployments Running Cisco SD-Access 59
	Upgrade from Release 1.2.8 to Release 1.3.0.7 60
	Upgrade from Release 1.2.6 to Release 1.3.0.7 61
	Upgrade from Release 1.2.5 to Release 1.3.0.7 62
	Upgrade from Release $1.2 - 1.2.4$ to Release $1.3.0.7$ 62
	Upgrade from Release 1.1.7 or 1.1.8 to Release 1.3.0.7 63
CHAPTER 7	Upgrade to Cisco DNA Center 1.2.12.x 67
	Upgrade from Release 1.2.10.x to Release 1.2.12.x 67
	Upgrade from Release 1.2.8 to Release 1.2.12.x 68
	Upgrade from Release 1.2.6 to Release 1.2.12.x 69
	Upgrade from Release 1.2.5 to Release 1.2.12.x 69
	Upgrade from Release $1.2 - 1.2.4$ to Release $1.2.12.x$ 70
	Upgrade from Release 1.1.7 or 1.1.8 to Release 1.2.12.x 71
CHAPTER 8	Upgrade to Cisco DNA Center 1.2.10.x 73
	Upgrade from Release 1.2.8 to Release 1.2.10.x 73
	Upgrade from Release 1.2.6 to Release 1.2.10.x 74
	Upgrade from Release 1.2.5 to Release 1.2.10.x 74
	Upgrade from Release $1.2 - 1.2.4$ to Release $1.2.10.x$ 75
	Upgrade from Release 1.1.7 or 1.1.8 to Release 1.2.10.x 76

I

APPENDIX A

Appendix79Recover from Premature Package Downloads79Related Documentation79

Contents

I



Introduction

- About Cisco DNA Center, on page 1
- Upgrade Paths, on page 1
- Prerequisites for Upgrading, on page 5

About Cisco DNA Center

Cisco Digital Network Architecture offers centralized, intuitive management that makes it fast and easy to design, provision, and apply policies across your network environment. The Cisco DNA Center GUI provides end-to-end network visibility and uses network insights to optimize network performance and deliver the best user and application experience.

Upgrade Paths



Note

Click any of these diagrams to view a full-sized version.



Figure 1: Upgrade Paths to Cisco DNA Center 2.2.1.x







Figure 3: Upgrade Paths to Cisco DNA Center 1.3.3.x

Figure 4: Upgrade Paths to Cisco DNA Center 1.3.1.x





Figure 5: Upgrade Paths to Cisco DNA Center 1.3.0.x

Figure 6: Upgrade Paths to Cisco DNA Center 1.2.12.x



Prerequisites for Upgrading

You must complete the system updates before you can perform package updates. Do not download or install any package updates until all system updates have been installed.

Note the following points:

- You cannot upgrade the packages individually. You must follow all of the steps that are described in this guide.
- Before you upgrade, make sure that the cluster link interface is connected to a switch port and is in the up state. To confirm that the interface is up, complete these steps:
- 1. In an SSH client, log in to Cisco DNA Center on your appliance.
- 2. Run the ifconfig interface-name command:
 - For a 44 core first-generation appliance (Cisco part number DN1-HW-APL), specify **enp10s0** as the interface name.
 - For a 44 or 56 core second-generation appliance (Cisco part number DN2-HW-APL or DN2-HW-APL-L), specify **enp94s0f1** as the interface name.
 - For a 112 core second-generation appliance (Cisco part number DN2-HW-APL-XL), specify **enp69s0f1** as the interface name.
- **3.** In the resulting output, check the last line and verify that data has been received and transmitted. Non-zero values indicate that the interface is up and operational.

Review the following list of prerequisites before upgrading your installed instance of Cisco DNA Center:

- Only a user with SUPER-ADMIN-ROLE permissions can perform this procedure. For more information, see the *Cisco Digital Network Architecture Center Administrator Guide*.
- Create a backup of your Cisco DNA Center database. For more information, see the Cisco Digital Network Architecture Center Administrator Guide.
- If you have a firewall, allow Cisco DNA Center to access the following location on each node in your cluster for all system and package downloads: https://www.ciscoconnectdna.com:443. To ensure that you have cloud connectivity to AWS, log in to the cluster and run the following CLI command: maglev catalog settings validate. For more information, see the Internet Connectivity Traffic table in the Cisco Digital Network Architecture Center Second-Generation Appliance Installation Guide.
- Have the username and password for a cisco.com user account available during the upgrade. You might be prompted, once, for the account credentials during package installations. This can be any valid cisco.com user account.
- Allocate enough time for the upgrade process. Upgrading can take longer than 6 hours to complete.
- We strongly recommend that you do not use Cisco DNA Center or any of its applications or tools while the upgrade is in process.
- Confirm that the minimum disk requirements are met:
 - The / partition has at least 2 GB of free space.

• The /data partition has at least 35 GB of free space and is not more than 70% full.

If you receive a storage validations failed error, contact the Cisco TAC.

• If the Cisco DNA Center download, update, or install procedures fail for any reason, always retry the procedure a second time using the GUI.

In a three-node cluster, you can trigger an upgrade of the entire cluster from the Cisco DNA Center GUI (the GUI represents the entire cluster and not just a single host). An upgrade triggered from the GUI automatically upgrades all hosts in the cluster.



Note

To upgrade a three-node cluster, Service Distribution (or high availability) must be enabled.



PART

Upgrade Cisco DNA Center

- Upgrade to Cisco DNA Center 2.2.1.3, on page 9
- Upgrade to Cisco DNA Center 2.1.2.6, on page 25
- Upgrade to Cisco DNA Center 1.3.3.9, on page 37
- Upgrade to Cisco DNA Center 1.3.1.7, on page 47
- Upgrade to Cisco DNA Center 1.3.0.7, on page 57
- Upgrade to Cisco DNA Center 1.2.12.x, on page 67
- Upgrade to Cisco DNA Center 1.2.10.x, on page 73



Upgrade to Cisco DNA Center 2.2.1.3

To complete any of the upgrade procedures described in this chapter, you'll need to know the latest version of the System package for the relevant Cisco DNA Center release. To determine the latest version, do the following:

- 1. From the release notes landing page, open the release notes for the appropriate Cisco DNA Center release.
- 2. In the "New and Changed Information" topic, refer to the "Updated Packages and Versions in Cisco DNA Center Release *number*" table and note the System package version that's listed for the release.



Important Before you complete any of the following upgrade procedures, see Cisco ISE Is Required with Cisco DNA Center 1.3.1.0 and Later, on page 47 for a description of the Cisco ISE requirements that need to be in place before you upgrade.

- Set Up NIC Bonding, on page 9
- Upgrade from Release 2.2.1.0 to Release 2.2.1.3, on page 12
- Upgrade from Release 2.1.2.x to Release 2.2.1.3, on page 13
- Upgrade from Release 2.1.1.0 or 2.1.1.3 to Release 2.2.1.3, on page 14
- Upgrade from Release 1.3.3.x to Release 2.2.1.3, on page 14
- Upgrade from Release 1.3.1.x to Release 2.2.1.3, on page 15
- Upgrade from Release 1.3.0.x to Release 2.2.1.3, on page 16
- Upgrade from Release 1.2.12.x to Release 2.2.1.3, on page 17
- Upgrade from Release 1.2.10.x to Release 2.2.1.3, on page 18
- Upgrade from Release 1.2.8 to Release 2.2.1.3, on page 19
- Upgrade from Release 1.2.6 to Release 2.2.1.3, on page 19
- Upgrade from Release 1.2.5 to Release 2.2.1.3, on page 20
- Upgrade from Release 1.2 1.2.4 to Release 2.2.1.3, on page 21
- Upgrade from Release 1.1.7 or 1.1.8 to Release 2.2.1.3, on page 22

Set Up NIC Bonding

Cisco DNA Center 2.2.1.3 provides network interface controller (NIC) bonding support. If you want to enable and use this functionality on your appliance, do the following:

1. Confirm that you have one of the following second-generation Cisco DNA Center appliances:

- 44-core appliance: Cisco part number DN2-HW-APL
- 44-core promotional appliance: Cisco part number DN2-HW-APL-U
- 56-core appliance: Cisco part number DN2-HW-APL-L
- 56-core promotional appliance: Cisco part number DN2-HW-APL-L-U
- 112-core appliance: Cisco part number DN2-HW-APL-XL
- 112-core promotional appliance: Cisco part number DN2-HW-APL-XL-U
- 2. On the switch that you will connect to your appliance, do the following:
 - Ensure that it supports dynamic interface aggregation.
 - Enable LACP on the switch and then specify the following settings:
 - LACP mode: **active**—This places the switch port connected to your appliance into an active negotiating state, in which the port initiates negotiations with remote ports by sending LACP packets.
 - LACP rate: **fast**—This changes the rate at which the LACP control packets are sent to an LACP-supported interface. Instead of the default every 30 seconds, control packets are sent once every second.
- 3. Complete the procedure that's specific to your appliance:
 - Enable NIC Bonding on a 44 or 56-Core Appliance, on page 10
 - Enable NIC Bonding on a 112-Core Appliance, on page 12

Enable NIC Bonding on a 44 or 56-Core Appliance

If you are upgrading either a 44 or 56-core appliance to Cisco DNA Center 2.2.1.3, you have two options available when it comes to NIC bonding:

- If you have decided to enable NIC bonding on your appliance, complete the steps described in Enable NIC Bonding Now, on page 10. The advantage of this option is that it will result in less downtime.
- If you are undecided about enabling NIC bonding, complete Step 1 in Enable NIC Bonding Later, on page 11. If you decide to enable NIC bonding at some point in the future, complete the rest of this procedure starting with Step 2.

Enable NIC Bonding Now

Procedure

Step 1 Upgrade to Cisco IMC 4.1(1h).

Step 2 Enable your appliance's Intel X710-DA4 NIC.

Complete the steps described in Enable NIC on an Upgraded Appliance.

Step 3 Upgrade to Cisco DNA Center 2.2.1.3 by completing the procedure that's specific to your current version:

- Upgrade from Release 2.1.2.x to Release 2.2.1.3, on page 13
- Upgrade from Release 2.1.1.0 or 2.1.1.3 to Release 2.2.1.3, on page 14
- **Step 4** Enable the interfaces that reside on your appliance's Intel X710-DA4 NIC for configuration and use.

Complete the steps described in Reconfigure the Appliance Using the Configuration Wizard.

Note the following points:

• When completing the wizard, the only information you need to enter is the maglev user's Linux password in the **User Account Settings** screen. Choose **Next** to skip through the various wizard screens.

The primary and secondary instances of your appliance's interfaces are properly bonded after you complete the wizard.

• By default, your appliance's interfaces are set to Active-Backup mode after you enable NIC bonding. If desired, you can set LACP mode for the Enterprise and Intracluster interfaces instead. The Internet and Management interfaces do not support this mode.

For a description of the Active-Backup and LACP modes, see NIC Bonding Overview.

Enable NIC Bonding Later

Procedure

Step 1	Upgrade to Cisco DNA Center 2.2.1.3 by completing the procedure that's specific to your current version: • Upgrade from Release 2.1.2.x to Release 2.2.1.3, on page 13
	• Upgrade from Release 2.1.1.0 or 2.1.1.3 to Release 2.2.1.3, on page 14
Step 2	Upgrade to Cisco IMC 4.1(1h).
Step 3	Enable your appliance's Intel X710-DA4 NIC.
	Complete the steps described in Enable NIC on an Upgraded Appliance.
Step 4	Power-Cycle the Appliance.
Step 5	Enable the interfaces that reside on your appliance's Intel X710-DA4 NIC for configuration and use.
	Complete the steps described in Reconfigure the Appliance Using the Configuration Wizard.
	Note the following points:
	• When completing the wizard, the only information you need to enter is the maglev user's Linux password in the User Account Settings screen. Choose Next to skip through the various wizard screens.
	The primary and secondary instances of your appliance's interfaces are properly bonded after you complete the wizard.

• By default, your appliance's interfaces are set to Active-Backup mode after you enable NIC bonding. If desired, you can set LACP mode for the Enterprise and Intracluster interfaces instead. The Internet and Management interfaces do not support this mode.

For a description of the Active-Backup and LACP modes, see NIC Bonding Overview.

Enable NIC Bonding on a 112-Core Appliance

Procedure

Step 1	Upgrade to Cisco DNA Center 2.2.1.3 by completing the procedure that's specific to your current version:
	• Upgrade from Release 2.1.2.x to Release 2.2.1.3, on page 13
	• Upgrade from Release 2.1.1.0 or 2.1.1.3 to Release 2.2.1.3, on page 14
Step 2	Upgrade to Cisco IMC 4.1(1h).
Step 3	Enable your appliance's Intel X710-DA4 NIC.
	Complete the steps described in Enable NIC on an Upgraded Appliance.
Step 4	Power-Cycle the Appliance.
Step 5	Enable the interfaces that reside on your appliance's Intel X710-DA4 NIC for configuration and use.
	Complete the steps described in Reconfigure the Appliance Using the Configuration Wizard.
	Note the following points:
	• When completing the wizard, the only information you need to enter is the maglev user's Linux password in the User Account Settings screen. Choose Next to skip through the various wizard screens.
	The primary and secondary instances of your appliance's interfaces are properly bonded after you complete the wizard.
	• By default, your appliance's interfaces are set to Active-Backup mode after you enable NIC bonding. If desired, you can set LACP mode for the Enterprise and Intracluster interfaces instead. The Internet and Management interfaces do not support this mode.
	For a description of the Active-Backup and LACP modes, see NIC Bonding Overview.

Upgrade from Release 2.2.1.0 to Release 2.2.1.3

By completing this procedure, you can upgrade directly to Cisco DNA Center 2.2.1.3 from 2.2.1.0.

After you upgrade to 2.2.1.3, you cannot switch back to an earlier release.

Procedure

Step 1	In the Cisco DNA Center GUI, click the Menu icon (\equiv) and choose System > Software Updates .
Step 2	A system update appears on the Software Updates page. Click Update.
Step 3	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.
Step 4	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.
Step 5	Ensure that each application has been updated by reviewing its version in the Installed Apps page.

Upgrade from Release 2.1.2.x to Release 2.2.1.3

By completing this procedure, you can upgrade directly to Cisco DNA Center 2.2.1.3 from the following versions:

- 2.1.2.0
- 2.1.2.3
- 2.1.2.4
- 2.1.2.5
- 2.1.2.6

After you upgrade to 2.2.1.3, you cannot switch back to an earlier release.

Procedure

Step 1 In the Cisco DNA Center GUI, click the **Menu** icon (\equiv) and choose **System** > **Software Updates**.

A Cisco DNA Center 2.2.1.3 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.

Step 2 Click Switch Now.

Step 3 At the prompt, click **OK** to proceed with the upgrade.

Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.

- Step 4 A system update appears on the Software Updates page. Click Update.
- **Step 5** After the system update is complete, at the top of the **Application Updates** field, click **Download All**. The packages begin downloading.
- **Step 6** After the packages are downloaded, at the top of the **Application Updates** field, click **Update All**. The packages begin updating.
- **Step 7** Ensure that each application has been updated by reviewing its version in the **Installed Apps** page.

Upgrade from Release 2.1.1.0 or 2.1.1.3 to Release 2.2.1.3

By completing this procedure, you can upgrade directly to Cisco DNA Center 2.2.1.3 from version 2.1.1.0 or 2.1.1.3.

After you upgrade to 2.2.1.3, you cannot switch back to an earlier release.

Procedure

Ste	D 1	Depending on which	Cisco DNA C	Center version vou	currently have installed.	do one of the following:
	-					

Cisco DNA Center 2.1.1.3

Download and update the latest hot fix for the Cisco DNA Center UI package: platform-ui:1.5.0.555.

Cisco DNA Center 2.1.1.0

- a) SSH to the Cisco DNA Center cluster IP address.
- b) Enter the following commands:
 - maglev catalog package pull platform-ui:1.5.0.555
 - maglev package upgrade platform-ui:1.5.0.555
- **Important** Ensure that you complete Step 2. Otherwise, the upgrade banner appears as a black band and its text is not readable.
- **Step 2** In the Cisco DNA Center GUI, click the **Menu** icon (\equiv) and choose **System** > **Software Updates**.

A Cisco DNA Center 2.2.1.3 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.

- Step 3 Click Switch Now.
- **Step 4** At the prompt, click **OK** to proceed with the upgrade.

Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.

- **Step 5** A system update appears on the **Software Updates** page. Click **Update**.
- **Step 6** After the system update is complete, at the top of the **Application Updates** field, click **Download All**. The packages begin downloading.
- **Step 7** After the packages are downloaded, at the top of the **Application Updates** field, click **Update All**. The packages begin updating.
- **Step 8** Ensure that each application has been updated by reviewing its version in the **Installed Apps** page.

Upgrade from Release 1.3.3.x to Release 2.2.1.3

You cannot upgrade directly from the following Cisco DNA Center versions to 2.2.1.3:

- 1.3.3.0
- 1.3.3.1
- 1.3.3.3
- 1.3.3.4
- 1.3.3.5
- 1.3.3.6
- 1.3.3.7
- 1.3.3.8
- 1.3.3.9

You must first upgrade to 2.1.2.6. From there, you can upgrade directly to 2.2.1.3.

After you upgrade to 2.2.1.3, you cannot switch back to an earlier release.

Procedure

Step 1	From the Cisco DNA Center home page, choose $\Rightarrow $ System Settings > Software Updates.
	A Cisco DNA Center 2.1.2.6 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.
Step 2	Click Switch Now.
Step 3	At the prompt, click OK to proceed with the upgrade.
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
Step 4	A system update appears on the Software Updates page. Click Update.
Step 5	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.
Step 6	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.
Step 7	Ensure that each application has been updated by reviewing its version in the Installed Apps page.
Step 8	After the upgrade to 2.1.2.6 is complete, see Upgrade from Release 2.1.2.x to Release 2.2.1.3, on page 13.

Upgrade from Release 1.3.1.x to Release 2.2.1.3

You cannot upgrade directly from the following Cisco DNA Center versions to 2.2.1.3:

- 1.3.1.0
- 1.3.1.1
- 1.3.1.2

- 1.3.1.3
- 1.3.1.4
- 1.3.1.5
- 1.3.1.6
- 1.3.1.7

You must first upgrade to 1.3.3.9 and then to 2.1.2.6. From there, you can upgrade directly to 2.2.1.3. After you upgrade to 2.2.1.3, you cannot switch back to an earlier release.

Procedure

Step 1	From the Cisco DNA Center home page, choose $\Rightarrow >$ System Settings $>$ Software Updates.
	A Cisco DNA Center 1.3.3.9 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.
Step 2	Click Switch Now.
Step 3	At the prompt, click OK to proceed with the upgrade.
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
Step 4	A system update appears on the Software Updates page. Click Update.
Step 5	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.
Step 6	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.
Step 7	Ensure that each application has been updated by reviewing its version in the Installed Apps page.
Step 8	After the upgrade to 1.3.3.9 is complete, see Upgrade from Release 1.3.3.x to Release 2.2.1.3, on page 14.

Upgrade from Release 1.3.0.x to Release 2.2.1.3

You cannot upgrade directly to Cisco DNA Center 2.2.1.3 from the following versions:

- 1.3.0
- 1.3.0.2
- 1.3.0.3
- 1.3.0.4
- 1.3.0.5
- 1.3.0.6
- 1.3.0.7

You must first upgrade to 1.3.3.9 and then to 2.1.2.6. From there, you can upgrade directly to 2.2.1.3. After you upgrade to 2.2.1.3, you cannot switch back to an earlier release.

Procedure

Step 1	From the Cisco DNA Center home page, choose 🌣 > System Settings > Software Updates.
	A Cisco DNA Center 1.3.1.7 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.
Step 2	Click Switch Now in the banner.
Step 3	At the prompt, click OK to proceed, but do not download, update, and install the 1.3.1.7 system and application packages.
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
Step 4	Click Switch Now in the Cisco DNA Center 1.3.3.9 is Here! banner that appears.
Step 5	At the prompt, click OK to proceed with the upgrade.
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
Step 6	A system update appears on the Software Updates page. Click Update.
Step 7	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.
Step 8	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.
Step 9	Ensure that each application has been updated by reviewing its version in the Installed Apps page.
Step 10	After the upgrade to 1.3.3.9 is complete, see Upgrade from Release 1.3.3.x to Release 2.2.1.3, on page 14.

Upgrade from Release 1.2.12.x to Release 2.2.1.3

You cannot upgrade directly from Cisco DNA Center 1.2.12.x to 2.2.1.3. You must first upgrade to 1.3.1.x, then to 1.3.3.x, and then to 2.1.2.6. From there, you can upgrade directly to 2.2.1.3.

After you upgrade to 2.2.1.3, you cannot switch back to an earlier release.

|--|

Step 1 From the Cisco DNA Center home page, choose \Rightarrow **System Settings** > **Software Updates**.

A Cisco DNA Center 1.3.0.7 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.

Step 2 Click **Switch Now** in the banner.

Step 3	At the prompt, click OK to proceed, but do not download, update, and install the 1.3.0.7 system and application packages.
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
Step 4	Click Switch Now in the Cisco DNA Center 1.3.1.7 is Here! banner that appears.
Step 5	At the prompt, click OK to proceed with the upgrade.
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
Step 6	A system update appears on the Software Updates page. Click Update.
Step 7	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.
Step 8	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.
Step 9	Ensure that each application has been updated by reviewing its version in the Installed Apps page.
Step 10	After the upgrade to 1.3.1.7 is complete, see Upgrade from Release 1.3.1.x to Release 2.2.1.3, on page 15.

Upgrade from Release 1.2.10.x to Release 2.2.1.3

You cannot upgrade directly from Cisco DNA Center 1.2.10.x to 2.2.1.3. You must first upgrade to 1.2.12.x, then to 1.3.1.x, then to 1.3.3.x, and then to 2.1.2.6. From there, you can upgrade directly to 2.2.1.3.

After you upgrade to 2.2.1.3, you cannot switch back to an earlier release.

Procedure

Step 1 Step 2	From the Cisco DNA Center home page, choose $\Rightarrow $ System Settings > Software Updates. Download, update, and install the packages that appear at the top of the page.
	A Cisco DNA Center 1.2.12 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.
Step 3 Step 4	Click Switch Now in the banner. At the prompt, click OK to proceed with the upgrade. Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
Step 5 Step 6	A system update appears on the Software Updates page. Click Update . After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.
Step 7	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.

Important Don't update individual applications unless the Cisco TAC instructs you to do so.

- **Step 8** Ensure that each application has been updated by reviewing its version in the **Installed Apps** page.
- Step 9 After the upgrade to 1.2.12.x is complete, see Upgrade from Release 1.2.12.x to Release 2.2.1.3, on page 17.

Upgrade from Release 1.2.8 to Release 2.2.1.3

You cannot upgrade directly from Cisco DNA Center 1.2.8 to 2.2.1.3. You must first upgrade to 1.2.10.x, then to 1.2.12.x, then to 1.3.1.x, then to 1.3.3.x, and then to 2.1.2.6. From there, you can upgrade directly to 2.2.1.3.

After you upgrade to 2.2.1.3, you cannot switch back to an earlier release.

Procedure

Sten	1	From the Cisco	DNA Cente	r home nage	choose 🦉 >	System S	Settings >	Software I	Indates
δισμ		FIOID THE CISCO	J DINA CEIILE	i nome page.		System S	ocumes -	Sultwale C	puates

A **Cisco DNA Center 1.2.10 is Here!** banner appears at the top of the page with a **Switch Now** button. **Switch Now** lets you see the system and application packages that are available to update.

- Step 2 Click Switch Now in the banner.
- **Step 3** At the prompt, click **OK** to proceed with the upgrade.

Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.

At this point in the procedure, **do not** click **Switch Now** in the **Cisco DNA Center 1.2.12 is Here!** banner that appears at the top of the page.

- **Step 4** A system update appears on the **Software Updates** page. Click **Update**.
- **Step 5** After the system update is complete, at the top of the **Application Updates** field, click **Download All**. The packages begin downloading.
- **Step 6** After the packages are downloaded, at the top of the **Application Updates** field, click **Update All**. The packages begin updating.

Don't update individual applications unless the Cisco TAC instructs you to do so.

Step 7 After the upgrade to 1.2.10.x is complete, see Upgrade from Release 1.2.10.x to Release 2.2.1.3, on page 18.

Upgrade from Release 1.2.6 to Release 2.2.1.3

You cannot upgrade directly from Cisco DNA Center 1.2.6 to 2.2.1.3. You must first upgrade to 1.2.8, to 1.2.10.x, then to 1.2.12.x, then to 1.3.1.x, then to 1.3.3.x, and then to 2.1.2.6. From there, you can upgrade directly to 2.2.1.3.

After you upgrade to 2.2.1.3, you cannot switch back to an earlier release.

Procedure
Do one of the following:
• If you installed Cisco DNA Center 1.2.6 as a fresh installation, you must apply a system update patch (1.1.0.659.1) before you can upgrade to 1.2.8. From the Cisco DNA Center home page, choose System Settings > Software Updates.
After you apply the system update patch, a Cisco DNA Center 1.2.8 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update. Click Switch Now and OK .
• If you upgraded to 1.2.6 (system update 1.1.0.659.1) from a previous Cisco DNA Center release, you see a Cisco DNA Center 1.2.8 is Here! banner. Click Switch Now and OK .
At the prompt, click OK to proceed with the upgrade.
Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
At this point in the procedure, do not click Switch Now in the Cisco DNA Center 1.2.10 is Here! banner that appears at the top of the page.
A system update appears on the Software Updates page. Click Update.
After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.
After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.
Don't update individual applications unless the Cisco TAC instructs you to do so.
Ensure that each application has been updated by reviewing its version in the Installed Apps page. After the upgrade to 1.2.8 is complete, see Upgrade from Release 1.2.8 to Release 2.2.1.3, on page 19
There are upgrade to 1.2.6 is complete, see Opgrade nom refease 1.2.6 to refease 2.2.1.5, on page 19.

Upgrade from Release 1.2.5 to Release 2.2.1.3

You cannot upgrade directly from Cisco DNA Center 1.2.5 to 2.2.1.3. You must first upgrade to 1.2.6, then to 1.2.8, then to 1.2.10.x, then to 1.2.12.x, then to 1.3.1.x, then to 1.3.3.x, and then to 2.1.2.6. From there, you can upgrade directly to 2.2.1.3.

After you upgrade to 2.2.1.3, you cannot switch back to an earlier release.

Step 1 From the Cisco DNA Center home page, choose ***** > **System Settings** > **Software Updates**.

A Cisco DNA Center 1.2.6 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.

Step 2 Click Switch Now in the banner.

Step 3	At the prompt, click OK to proceed with the upgrade.				
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.				
	At this point in the procedure, do not click Switch Now in the Cisco DNA Center 1.2.8 is Here! banner that appears at the top of the page.				
Step 4	A system update appears on the Software Updates page. Click Update.				
Step 5	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.				
Step 6	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.				
	Don't update individual applications unless the Cisco TAC instructs you to do so.				
Step 7 Step 8	Ensure that each application has been updated by reviewing its version in the Installed Apps page. After the upgrade to 1.2.8 is complete, see Upgrade from Release 1.2.8 to Release 2.2.1.3, on page 19.				

Upgrade from Release 1.2 – 1.2.4 to Release 2.2.1.3

You cannot upgrade directly from Cisco DNA Center 1.2 - 1.2.4 to 2.2.1.3. You must first upgrade to 1.2.6, then to 1.2.8, then to 1.2.10.x, then to 1.2.12.x, then to 1.3.1.x, then to 1.3.3.x, and then to 2.1.2.6. From there, you can upgrade directly to 2.2.1.3.

After you upgrade to 2.2.1.3, you cannot switch back to an earlier release.

Procedure

Step 1 From the Cisco DNA Center home page, choose System Settings > Software Updates.

A Cisco DNA Center 1.2.6 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.

- Step 2 Click Switch Now in the banner.
- **Step 3** At the prompt, click **OK** to proceed with the upgrade.

Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.

At this point in the procedure, **do not** click **Switch Now** in the **Cisco DNA Center 1.2.8 is Here!** banner that appears at the top of the page.

- Step 4 A system update appears on the Software Updates page. Click Update.
- **Step 5** After the system update is complete, at the top of the **Application Updates** field, click **Download All**. The packages begin downloading.
- **Step 6** After the packages are downloaded, at the top of the **Application Updates** field, click **Update All**. The packages begin updating.

Don't update individual applications unless the Cisco TAC instructs you to do so.

Step 7 Ensure that each application has been updated by reviewing its version in the Installed Apps page.Step 8 After the upgrade to 1.2.6 is complete, see Upgrade from Release 1.2.6 to Release 2.2.1.3, on page 19.

Upgrade from Release 1.1.7 or 1.1.8 to Release 2.2.1.3

You cannot upgrade directly from Cisco DNA Center 1.1.7 or 1.1.8 to 2.2.1.3. You must first upgrade to 1.2.6, then to 1.2.8, then to 1.2.10.x, then to 1.2.12.x, then to 1.3.1.x, then to 1.3.3.x, and then to 2.1.2.6. From there, you can upgrade directly to 2.2.1.3.

After you upgrade to 2.2.1.3, you cannot switch back to an earlier release.

Procedure

Step 1 From the Cisco DNA Center home page, choose ***** > **System Settings** > **App Management**.

A Cisco DNA Center 1.2.6 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.

The **App Management** page also displays the following side tabs:

- Packages & Updates: Shows the packages that are currently installed and the updates that are available for installation from the Cisco cloud.
- System Updates: Shows the system updates that are currently installed and the updates that are available for installation from the Cisco cloud.
- **Step 2** Click **Switch Now** in the banner.
- **Step 3** At the prompt, click **OK** to proceed with the upgrade.

Clicking **OK** changes the release train in the back end. The message "Connecting to... cloud catalog" with a progress bar appears.

Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.

At this point in the procedure, **do not** click **Switch Now** in the **Cisco DNA Center 1.2.8 is Here!** banner that appears at the top of the page.

Step 4 After the release train change finishes, review the **System Updates** page.

The following information is displayed:

- Package: System package
- Status: Running
- Installed Version: Current system package installed
- Available Update: System package available for installation
- Step 5Click Install in the Available Update column.During the install process, the following Cisco DNA Center GUI changes are made:

	• Ap	p Management tab: Changes to the Software Updates tab				
	• System Updates side panel: Changes to the Updates side panel					
	• Pa	ckages & Updates side panel: Changes to the Installed Apps side panel				
Step 6	After the system installation is finished and is in Running state, refresh the page.					
	A new	Updates page displays the following information:				
	• Platform Update : Displays the updated system version with a statement that the system is currently up to date. Additionally, a green check mark indicates a successful system upgrade.					
	• Ap	ps Updates : Displays groupings of applications with their current file size and version.				
	Note	After performing system updates, clear your browser cache and log in to Cisco DNA Center again.				
Step 7	At the top of the Apps Updates field, click the Download All button.					
	After cl	icking this button, all the application upgrade packages are downloaded.				
	Note	There are additional Download All buttons for different application groups (for example, Automation , and Assurance). You need to only click the Download All button at the top of the page.				
Step 8	After al Update	l the application packages have been downloaded, click the Update All button at the top of the Apps s field.				
	After cl	icking this button, all the applications are updated.				
	Note	There are additional Update All buttons for different application groups (for example, Automation , and Assurance). You need to only click the Update All button at the top of the page.				
Step 9	Ensure that each application has been updated by reviewing its version in the Installed Apps page.					
	The application versions should be updated in this page.					
	Note	There may be some new application packages that were not part of your previous Cisco DNA Center configuration, and for this reason have not been installed by this procedure.				
Step 10	After th	e upgrade to 1.2.6 is complete, see Upgrade from Release 1.2.6 to Release 2.2.1.3, on page 19.				

I



Upgrade to Cisco DNA Center 2.1.2.6

To complete any of the upgrade procedures described in this chapter, you'll need to know the latest version of the System package for the relevant Cisco DNA Center release. To determine the latest version, do the

1. From the release notes landing page, open the release notes for the appropriate Cisco DNA Center release.

2. In the "New and Changed Information" topic, refer to the "Updated Packages and Versions in Cisco DNA Center Release *number*" table and note the System package version that's listed for the release.



following:

Important Before you complete any of the following upgrade procedures, see Cisco ISE Is Required with Cisco DNA Center 1.3.1.0 and Later, on page 47 for a description of the Cisco ISE requirements that need to be in place before you upgrade.

- Upgrade from Release 2.1.2.x to Release 2.1.2.6, on page 25
- Upgrade from Release 2.1.1.0 or 2.1.1.3 to Release 2.1.2.6, on page 26
- Upgrade from Release 1.3.3.x to Release 2.1.2.6, on page 27
- Upgrade from Release 1.3.1.x to Release 2.1.2.6, on page 28
- Upgrade from Release 1.3.0.x to Release 2.1.2.6, on page 29
- Upgrade from Release 1.2.12.x to Release 2.1.2.6, on page 30
- Upgrade from Release 1.2.10.x to Release 2.1.2.6, on page 30
- Upgrade from Release 1.2.8 to Release 2.1.2.6, on page 31
- Upgrade from Release 1.2.6 to Release 2.1.2.6, on page 32
- Upgrade from Release 1.2.5 to Release 2.1.2.6, on page 33
- Upgrade from Release 1.2 1.2.4 to Release 2.1.2.6, on page 33
- Upgrade from Release 1.1.7 or 1.1.8 to Release 2.1.2.6, on page 34

Upgrade from Release 2.1.2.x to Release 2.1.2.6

By completing this procedure, you can upgrade directly to Cisco DNA Center 2.1.2.6 from the following versions:

- 2.1.2.0
- 2.1.2.3

TT **1** 4

. . .

• 2.1.2.4

• 2.1.2.5

After you upgrade to 2.1.2.6, you cannot switch back to an earlier release.

Procedure

Step 1	In the Cisco DNA Center GUI, click the Menu icon (\equiv) and choose System > Software Updates.
Step 2	A system update appears on the Software Updates page. Click Update.

- **Step 3** After the system update is complete, at the top of the **Application Updates** field, click **Download All**. The packages begin downloading.
- **Step 4** After the packages are downloaded, at the top of the **Application Updates** field, click **Update All**. The packages begin updating.
- **Step 5** Ensure that each application has been updated by reviewing its version in the **Installed Apps** page.

Upgrade from Release 2.1.1.0 or 2.1.1.3 to Release 2.1.2.6

By completing this procedure, you can upgrade directly to Cisco DNA Center 2.1.2.6 from version 2.1.1.0 or 2.1.1.3.

After you upgrade to 2.1.2.6, you cannot switch back to an earlier release.

Procedure

Step 1 Depending on which Cisco DNA Center version you currently have installed, do one of the following:

Cisco DNA Center 2.1.1.3

Download and update the latest hot fix for the Cisco DNA Center UI package: platform-ui:1.5.0.555.

Cisco DNA Center 2.1.1.0

- a) SSH to the Cisco DNA Center cluster IP address.
- b) Enter the following commands:
 - maglev catalog package pull platform-ui:1.5.0.555
 - maglev package upgrade platform-ui:1.5.0.555

Important Ensure that you complete Step 1. Otherwise, the upgrade banner appears as a black band and its text is not readable.

Step 2 In the Cisco DNA Center GUI, click the **Menu** icon (\equiv) and choose **System** > **Software Updates**.

A Cisco DNA Center 2.1.2.6 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.

L

Step 3	Click Switch Now.				
Step 4	At the prompt, click OK to proceed with the upgrade.				
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.				
Step 5	A system update appears on the Software Updates page. Click Update.				
Step 6	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.				
Step 7	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.				
Step 8	Ensure that each application has been updated by reviewing its version in the Installed Apps page.				

Upgrade from Release 1.3.3.x to Release 2.1.2.6

By completing the following procedure, you can upgrade directly to Cisco DNA Center 2.1.2.6 from the following versions:

- 1.3.3.0
- 1.3.3.1
- 1.3.3.3
- 1.3.3.4
- 1.3.3.5
- 1.3.3.6
- 1.3.3.7
- 1.3.3.8
- 1.3.3.9

After you upgrade to 2.1.2.6, you cannot switch back to an earlier release.

Procedure

Step 1 From the Cisco DNA Center home page, choose $\Rightarrow >$ **System Settings** > **Software Updates**.

A Cisco DNA Center 2.1.2.6 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.

- Step 2 Click Switch Now.
- **Step 3** At the prompt, click **OK** to proceed with the upgrade.

Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.

Step 4	A system update appears on the Software Updates page. Click Update.
Step 5	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.
Step 6	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.
Step 7	Ensure that each application has been updated by reviewing its version in the Installed Apps page.

Upgrade from Release 1.3.1.x to Release 2.1.2.6

You cannot upgrade directly from the following Cisco DNA Center versions to 2.1.2.6:

- 1.3.1.0
- 1.3.1.1
- 1.3.1.2
- 1.3.1.3
- 1.3.1.4
- 1.3.1.5
- 1.3.1.6
- 1.3.1.7

You must first upgrade to 1.3.3.9. From there, you can upgrade directly to 2.1.2.6.

After you upgrade to 2.1.2.6, you cannot switch back to an earlier release.

Procedure

Step 1	From the Cisco DNA Center home page, choose $\Rightarrow $ System Settings > Software Updates .				
	A Cisco DNA Center 1.3.3.9 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.				
Step 2	Click Switch Now.				
Step 3	At the prompt, click OK to proceed with the upgrade.				
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.				
Step 4	A system update appears on the Software Updates page. Click Update.				
Step 5	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.				
Step 6	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.				
Step 7	Ensure that each application has been updated by reviewing its version in the Installed Apps page.				

Upgrade from Release 1.3.0.x to Release 2.1.2.6

You cannot upgrade directly to Cisco DNA Center 2.1.2.6 from the following versions:

- 1.3.0
- 1.3.0.2
- 1.3.0.3
- 1.3.0.4
- 1.3.0.5
- 1.3.0.6
- 1.3.0.7

You must first upgrade to 1.3.3.9. From there, you can upgrade directly to 2.1.2.6.

After you upgrade to 2.1.2.6, you cannot switch back to an earlier release.

Procedure

Step 1	From the Cisco DNA Center home page, choose 🌣 > System Settings > Software Updates.				
	A Cisco DNA Center 1.3.1.7 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.				
Step 2	Click Switch Now in the banner.				
Step 3	At the prompt, click OK to proceed, but do not download, update, and install the 1.3.1.7 system and application packages.				
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.				
Step 4	Click Switch Now in the Cisco DNA Center 1.3.3.9 is Here! banner that appears.				
Step 5	At the prompt, click OK to proceed with the upgrade.				
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.				
Step 6	A system update appears on the Software Updates page. Click Update.				
Step 7	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.				
Step 8	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.				
Step 9	Ensure that each application has been updated by reviewing its version in the Installed Apps page.				

Step 10 After the upgrade to 1.3.3.9 is complete, see Upgrade from Release 1.3.3.x to Release 2.1.2.6, on page 27.

Upgrade from Release 1.2.12.x to Release 2.1.2.6

You cannot upgrade directly from Cisco DNA Center 1.2.12.x to 2.1.2.6. You must first upgrade to 1.3.1.x and then to 1.3.3.x. From there, you can upgrade directly to 2.1.2.6.

After you upgrade to 2.1.2.6, you cannot switch back to an earlier release.

	Procedure
Step 1	From the Cisco DNA Center home page, choose \Rightarrow > System Settings > Software Updates.
	A Cisco DNA Center 1.3.0.7 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.
Step 2	Click Switch Now in the banner.
Step 3	At the prompt, click OK to proceed, but do not download, update, and install the 1.3.0.7 system and application packages.
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
Step 4	Click Switch Now in the Cisco DNA Center 1.3.1.7 is Here! banner that appears.
Step 5	At the prompt, click OK to proceed with the upgrade.
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
Step 6	A system update appears on the Software Updates page. Click Update.
Step 7	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.
Step 8	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.
Step 9	Ensure that each application has been updated by reviewing its version in the Installed Apps page.
Step 10	After the upgrade to 1.3.1.7 is complete, see Upgrade from Release 1.3.1.x to Release 2.1.2.6, on page 28.

Upgrade from Release 1.2.10.x to Release 2.1.2.6

You cannot upgrade directly from Cisco DNA Center 1.2.10.x to 2.1.2.6. You must first upgrade to 1.2.12.x, then to 1.3.1.x, and then to 1.3.3.x. From there, you can upgrade directly to 2.1.2.6.

After you upgrade to 2.1.2.6, you cannot switch back to an earlier release.
Procedure

Step 1	From the Cisco DNA Center home page, choose 🌞 > System Settings > Software Updates.
Step 2	Download, update, and install the packages that appear at the top of the page.
	A Cisco DNA Center 1.2.12 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.
Step 3	Click Switch Now in the banner.
Step 4	At the prompt, click OK to proceed with the upgrade.
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
Step 5	A system update appears on the Software Updates page. Click Update.
Step 6	After the system update is complete, at the top of the Application Updates field, click Download All.
	The packages begin downloading.
Step 7	After the packages are downloaded, at the top of the Application Updates field, click Update All.
	The packages begin updating.
	Important Don't update individual applications unless the Cisco TAC instructs you to do so.
Step 8	Ensure that each application has been updated by reviewing its version in the Installed Apps page.
Step 9	After the upgrade to 1.2.12.x is complete, see Upgrade from Release 1.2.12.x to Release 2.1.2.6, on page 30.

Upgrade from Release 1.2.8 to Release 2.1.2.6

You cannot upgrade directly from Cisco DNA Center 1.2.8 to 2.1.2.6. You must first upgrade to 1.2.10.x, then to 1.2.12.x, then to 1.3.1.x, and then to 1.3.3.x. From there, you can upgrade directly to 2.1.2.6.

After you upgrade to 2.1.2.6, you cannot switch back to an earlier release.

Step 1	From the Cisco DNA Center home page, choose 🌣 > System Settings > Software Updates.			
	A Cisco DNA Center 1.2.10 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.			
Step 2	Click Switch Now in the banner.			
Step 3	At the prompt, click OK to proceed with the upgrade.			
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.			
	At this point in the procedure, do not click Switch Now in the Cisco DNA Center 1.2.12 is Here! banner that appears at the top of the page.			

Step 4	A system update appears on the Software Updates page. Click Update.		
Step 5	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.		
Step 6	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.		
	Don't update individual applications unless the Cisco TAC instructs you to do so.		
Step 7	After the upgrade to 1.2.10.x is complete, see Upgrade from Release 1.2.10.x to Release 2.1.2.6, on page 30.		

Upgrade from Release 1.2.6 to Release 2.1.2.6

You cannot upgrade directly from Cisco DNA Center 1.2.6 to 2.1.2.6. You must first upgrade to 1.2.8, to 1.2.10.x, then to 1.2.12.x, then to 1.3.1.x, and then to 1.3.3.x. From there, you can upgrade directly to 2.1.2.6.

After you upgrade to 2.1.2.6, you cannot switch back to an earlier release.

Procedure

If you installed Cisco DNA Center 1.2.6 as a fresh installation, you must apply a system update patch (1.1.0.659.1) before you can upgrade to 1.2.8. From the Cisco DNA Center home page, choose \$\$\$ > System Settings > Software Updates.

After you apply the system update patch, a **Cisco DNA Center 1.2.8 is Here!** banner appears at the top of the page with a **Switch Now** button. **Switch Now** lets you see the system and application packages that are available to update. Click **Switch Now** and **OK**.

• If you upgraded to 1.2.6 (system update 1.1.0.659.1) from a previous Cisco DNA Center release, you see a **Cisco DNA Center 1.2.8 is Here!** banner. Click **Switch Now** and **OK**.

Step 2	At the prompt, click OK to proceed with the upgrade.			
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.			
	At this point in the procedure, do not click Switch Now in the Cisco DNA Center 1.2.10 is Here! banner that appears at the top of the page.			
Step 3	A system update appears on the Software Updates page. Click Update.			
Step 4	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.			
Step 5	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.			
	Don't update individual applications unless the Cisco TAC instructs you to do so.			
Step 6	Ensure that each application has been updated by reviewing its version in the Installed Apps page.			

Step 7 After the upgrade to 1.2.8 is complete, see Upgrade from Release 1.2.8 to Release 2.1.2.6, on page 31.

Upgrade from Release 1.2.5 to Release 2.1.2.6

You cannot upgrade directly from Cisco DNA Center 1.2.5 to 2.1.2.6. You must first upgrade to 1.2.6, then to 1.2.8, then to 1.2.10.x, then to 1.3.1.x, and then to 1.3.3.x. From there, you can upgrade directly to 2.1.2.6.

After you upgrade to 2.1.2.6, you cannot switch back to an earlier release.

Procedure

Step 1	From the Cisco DNA Center home page, choose 🌣 > System Settings > Software Updates.
	A Cisco DNA Center 1.2.6 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.
Step 2	Click Switch Now in the banner.
Step 3	At the prompt, click OK to proceed with the upgrade.
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
	At this point in the procedure, do not click Switch Now in the Cisco DNA Center 1.2.8 is Here! banner that appears at the top of the page.
Step 4	A system update appears on the Software Updates page. Click Update.
Step 5	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.
Step 6	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.
	Don't update <i>individual</i> applications unless the Cisco TAC instructs you to do so.
Step 7	Ensure that each application has been updated by reviewing its version in the Installed Apps page.
Step 8	After the upgrade to 1.2.8 is complete, see Upgrade from Release 1.2.8 to Release 2.1.2.6, on page 31.

Upgrade from Release 1.2 – 1.2.4 to Release 2.1.2.6

You cannot upgrade directly from Cisco DNA Center 1.2 - 1.2.4 to 2.1.2.6. You must first upgrade to 1.2.6, then to 1.2.8, then to 1.2.10.x, then to 1.2.12.x, then to 1.3.1.x, and then to 1.3.3.x. From there, you can upgrade directly to 2.1.2.6.

After you upgrade to 2.1.2.6, you cannot switch back to an earlier release.

Procedure
From the Cisco DNA Center home page, choose 🌣 > System Settings > Software Updates.
A Cisco DNA Center 1.2.6 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.
Click Switch Now in the banner.
At the prompt, click OK to proceed with the upgrade.
Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
At this point in the procedure, do not click Switch Now in the Cisco DNA Center 1.2.8 is Here! banner that appears at the top of the page.
A system update appears on the Software Updates page. Click Update.
After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.
After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.
Don't update individual applications unless the Cisco TAC instructs you to do so.
Ensure that each application has been updated by reviewing its version in the Installed Apps page. After the upgrade to 1.2.6 is complete, see Upgrade from Release 1.2.6 to Release 2.1.2.6, on page 32.

Upgrade from Release 1.1.7 or 1.1.8 to Release 2.1.2.6

You cannot upgrade directly from Cisco DNA Center 1.1.7 or 1.1.8 to 2.1.2.6. You must first upgrade to 1.2.6, then to 1.2.8, then to 1.2.10.x, then to 1.2.12.x, then to 1.3.1.x, and then to 1.3.3.x. From there, you can upgrade directly to 2.1.2.6.

After you upgrade to 2.1.2.6, you cannot switch back to an earlier release.

Step 1	From the Cisco DNA Center home page, choose 🌣 > System Settings > App Management.			
	A Cisco DNA Center 1.2.6 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.			
	The App Management page also displays the following side tabs:			
	• Packages & Updates : Shows the packages that are currently installed and the updates that are available for installation from the Cisco cloud.			
	• System Updates : Shows the system updates that are currently installed and the updates that are available for installation from the Cisco cloud.			

Step 2	Click Sw	vitch Now in the banner.		
Step 3	At the pr	compt, click OK to proceed with the upgrade.		
	Clicking progress	OK changes the release train in the back end. The message "Connecting to cloud catalog" with a bar appears.		
	Wait for to displa	approximately 90 seconds for the progress bar to finish and the updated system version and banner y. Refresh the page several times if the updated system version and banner do not appear.		
	At this p appears	oint in the procedure, do not click Switch Now in the Cisco DNA Center 1.2.8 is Here! banner that at the top of the page.		
Step 4	After the	e release train change finishes, review the System Updates page.		
	The follo	owing information is displayed:		
	• Pac	kage: System package		
	• Sta	tus: Running		
	• Ins	talled Version: Current system package installed		
	• Ava	ilable Update: System package available for installation		
Ctor F				
Step 5	Click Install in the Available Update column.			
	During the install process, the following Cisco DNA Center GUI changes are made:			
	• Apj	p Management tab: Changes to the Software Updates tab		
	• Sys	tem Updates side panel: Changes to the Updates side panel		
	• Pac	kages & Updates side panel: Changes to the Installed Apps side panel		
Step 6	After the	e system installation is finished and is in Running state, refresh the page.		
	A new Updates page displays the following information:			
	• Platform Update : Displays the updated system version with a statement that the system is currently up to date. Additionally, a green check mark indicates a successful system upgrade.			
• Apps U		ps Updates: Displays groupings of applications with their current file size and version.		
	Note	After performing system updates, clear your browser cache and log in to Cisco DNA Center again.		
Step 7	At the to	p of the Apps Updates field, click the Download All button.		
	After clicking this button, all the application upgrade packages are downloaded.			
	Note	There are additional Download All buttons for different application groups (for example, Automation , and Assurance). You need to only click the Download All button at the top of the page.		
Step 8	After all the application packages have been downloaded, click the Update All button at the top of the Apps Updates field.			
	After clicking this button, all the applications are updated.			

I

	Note	There are additional Update All buttons for different application groups (for example, Automation , and Assurance). You need to only click the Update All button at the top of the page.
Step 9	Ensure	that each application has been updated by reviewing its version in the Installed Apps page.
	The app	plication versions should be updated in this page.
	Note	There may be some new application packages that were not part of your previous Cisco DNA Center configuration, and for this reason have not been installed by this procedure.
Step 10	After th	e upgrade to 1.2.6 is complete, see Upgrade from Release 1.2.6 to Release 2.1.2.6, on page 32.



Upgrade to Cisco DNA Center 1.3.3.9

To complete any of the upgrade procedures described in this chapter, you'll need to know the latest version of the System package for the relevant Cisco DNA Center release. To determine the latest version, do the following:

- 1. From the release notes landing page, open the release notes for the appropriate Cisco DNA Center release.
- 2. In the "New and Changed Information" topic, refer to the "Updated Packages and Versions in Cisco DNA Center Release *number*" table and note the System package version that's listed for the release.

```
C)
```

Important Before you complete any of the following upgrade procedures, see Cisco ISE Is Required with Cisco DNA Center 1.3.1.0 and Later, on page 47 for a description of the Cisco ISE requirements that need to be in place before you upgrade.

- Upgrade from Release 1.3.3.0–1.3.3.8 to Release 1.3.3.9, on page 37
- Upgrade from Release 1.3.1.0 1.3.1.7 to Release 1.3.3.9, on page 38
- Upgrade from Release 1.3.0.x to Release 1.3.3.9, on page 39
- Upgrade from Release 1.2.12.x to Release 1.3.3.9, on page 40
- Upgrade from Release 1.2.10.x to Release 1.3.3.9, on page 41
- Upgrade from Release 1.2.8 to Release 1.3.3.9, on page 41
- Upgrade from Release 1.2.6 to Release 1.3.3.9, on page 42
- Upgrade from Release 1.2.5 to Release 1.3.3.9, on page 43
- Upgrade from Release 1.2 1.2.4 to Release 1.3.3.9, on page 44
- Upgrade from Release 1.1.7 or 1.1.8 to Release 1.3.3.9, on page 44

Upgrade from Release 1.3.3.0–1.3.3.8 to Release 1.3.3.9

By completing this procedure, you can upgrade directly to Cisco DNA Center 1.3.3.9 from the following versions:

- 1.3.3.0
- 1.3.3.1
- 1.3.3.3

- 1.3.3.4
- 1.3.3.5
- 1.3.3.6
- 1.3.3.7
- 1.3.3.8

After you upgrade to 1.3.3.9, you cannot switch back to an earlier release.

Procedure

Step 1	From the Cisco DNA Center home page, choose 🌣 > System Settings > Software Updates.
Step 2	A system update appears on the Software Updates page. Click Update.
Step 3	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.
Step 4	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.
Step 5	Ensure that each application has been updated by reviewing its version in the Installed Apps page.

Upgrade from Release 1.3.1.0 – 1.3.1.7 to Release 1.3.3.9

By completing the following procedure, you can upgrade directly to Cisco DNA Center 1.3.3.9 from the following versions:

- 1.3.1.0
- 1.3.1.1
- 1.3.1.2
- 1.3.1.3
- 1.3.1.4
- 1.3.1.5
- 1.3.1.6
- 1.3.1.7

After you upgrade to 1.3.3.9, you cannot switch back to an earlier release.

Procedure

Step 1 From the Cisco DNA Center home page, choose 🏶 > System Settings > Software Updates.

A Cisco DNA Center 1.3.3.9 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.

Step 2	Click Switch Now.		
Step 3	At the prompt, click OK to proceed with the upgrade.		
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.		
Step 4	A system update appears on the Software Updates page. Click Update.		
Step 5	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.		
Step 6	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.		
Step 7	Ensure that each application has been updated by reviewing its version in the Installed Apps page.		

Upgrade from Release 1.3.0.x to Release 1.3.3.9

By completing the following procedure, you can upgrade directly to 1.3.3.9 from the following Cisco DNA Center versions:

- 1.3.0
- 1.3.0.2
- 1.3.0.3
- 1.3.0.4
- 1.3.0.5
- 1.3.0.6
- 1.3.0.7

After you upgrade to 1.3.3.9, you cannot switch back to an earlier release.

Procedure

Step 1 From the Cisco DNA Center home page, choose 🏶 > System Settings > Software Updates.

A Cisco DNA Center 1.3.1.7 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.

- Step 2 Click Switch Now in the banner.
- **Step 3** At the prompt, click **OK** to proceed, but **do not** download, update, and install the 1.3.1.7 system and application packages.

Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.

Step 4	Click Switch Now in the Cisco DNA Center 1.3.3.9 is Here! banner that appears.		
Step 5	At the prompt, click OK to proceed with the upgrade.		
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.		
Step 6	A system update appears on the Software Updates page. Click Update.		
Step 7	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.		
Step 8	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.		
Step 9	Ensure that each application has been updated by reviewing its version in the Installed Apps page.		

Upgrade from Release 1.2.12.x to Release 1.3.3.9

You cannot upgrade directly from Cisco DNA Center 1.2.12.x to 1.3.3.9. You must first upgrade to 1.3.1.x. From there, you can upgrade directly to 1.3.3.9.

After you upgrade to 1.3.3.9, you cannot switch back to an earlier release.

Step 1	From the Cisco DNA Center home page, choose 🌣 > System Settings > Software Updates.
	A Cisco DNA Center 1.3.0.7 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.
Step 2	Click Switch Now in the banner.
Step 3	At the prompt, click OK to proceed, but do not download, update, and install the 1.3.0.7 system and application packages.
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
Step 4	Click Switch Now in the Cisco DNA Center 1.3.1.7 is Here! banner that appears.
Step 5	At the prompt, click OK to proceed with the upgrade.
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
Step 6	A system update appears on the Software Updates page. Click Update.
Step 7	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.
Step 8	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.
Step 9	Ensure that each application has been updated by reviewing its version in the Installed Apps page.

L

Step 10 After the upgrade to 1.3.1.7 is complete, see Upgrade from Release 1.3.1.0 – 1.3.1.7 to Release 1.3.3.9, on page 38.

Upgrade from Release 1.2.10.x to Release 1.3.3.9

You cannot upgrade directly from Cisco DNA Center 1.2.10.x to 1.3.3.9. You must first upgrade to 1.2.12.x and then to 1.3.1.7. From there, you can upgrade directly to 1.3.3.9.

After you upgrade to 1.3.3.9, you cannot switch back to an earlier release.

Procedure

Step 1	From the Cisco DNA Center home page, choose 🏶 > System Settings > Software Updates.	
Step 2	Download, update, and install the packages that appear at the top of the page.	
	A Cisco DNA Center 1.2.12 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.	
Step 3	Click Switch Now in the banner.	
Step 4	At the prompt, click OK to proceed with the upgrade.	
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.	
Step 5	A system update appears on the Software Updates page. Click Update.	
Step 6	After the system update is complete, at the top of the Application Updates field, click Download All.	
	The packages begin downloading.	
Step 7	After the packages are downloaded, at the top of the Application Updates field, click Update All.	
	The packages begin updating.	
	Important Don't update individual applications unless the Cisco TAC instructs you to do so.	
Step 8	Ensure that each application has been updated by reviewing its version in the Installed Apps page.	
Step 9	After the upgrade to 1.2.12.x is complete, see Upgrade from Release 1.2.12.x to Release 1.3.3.9, on page 40.	

Upgrade from Release 1.2.8 to Release 1.3.3.9

You cannot upgrade directly from Cisco DNA Center 1.2.8 to 1.3.3.9. You must first upgrade to 1.2.10.x and then to 1.3.1.x. From there, you can upgrade directly to 1.3.3.9.

After you upgrade to 1.3.3.9, you cannot switch back to an earlier release.

	Procedure
Step 1	From the Cisco DNA Center home page, choose \approx > System Settings > Software Updates.
	A Cisco DNA Center 1.2.10 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.
Step 2	Click Switch Now in the banner.
Step 3	At the prompt, click OK to proceed with the upgrade.
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
	At this point in the procedure, do not click Switch Now in the Cisco DNA Center 1.2.12 is Here! banner that appears at the top of the page.
Step 4	A system update appears on the Software Updates page. Click Update.
Step 5	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.
Step 6	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.
	Don't update individual applications unless the Cisco TAC instructs you to do so.
Step 7	After the upgrade to 1.2.10.x is complete, see Upgrade from Release 1.2.10.x to Release 1.3.3.9, on page 41.

Upgrade from Release 1.2.6 to Release 1.3.3.9

You cannot upgrade directly from Cisco DNA Center 1.2.6 to 1.3.3.9. You must first upgrade to 1.2.8, to 1.2.10.x, and then to 1.3.1.x. From there, you can upgrade directly to 1.3.3.9.

After you upgrade to 1.3.3.9, you cannot switch back to an earlier release.

Step 1 Do one of the following:

If you installed Cisco DNA Center 1.2.6 as a fresh installation, you must apply a system update patch (1.1.0.659.1) before you can upgrade to 1.2.8. From the Cisco DNA Center home page, choose \$\$\$> System Settings > Software Updates.

After you apply the system update patch, a **Cisco DNA Center 1.2.8 is Here!** banner appears at the top of the page with a **Switch Now** button. **Switch Now** lets you see the system and application packages that are available to update. Click **Switch Now** and **OK**.

• If you upgraded to 1.2.6 (system update 1.1.0.659.1) from a previous Cisco DNA Center release, you see a **Cisco DNA Center 1.2.8 is Here!** banner. Click **Switch Now** and **OK**.

Step 2 At the prompt, click **OK** to proceed with the upgrade.

Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.

At this point in the procedure, **do not** click **Switch Now** in the **Cisco DNA Center 1.2.10 is Here!** banner that appears at the top of the page.

- Step 3 A system update appears on the Software Updates page. Click Update.
- **Step 4** After the system update is complete, at the top of the **Application Updates** field, click **Download All**. The packages begin downloading.
- **Step 5** After the packages are downloaded, at the top of the **Application Updates** field, click **Update All**. The packages begin updating.

Don't update *individual* applications unless the Cisco TAC instructs you to do so.

- **Step 6** Ensure that each application has been updated by reviewing its version in the **Installed Apps** page.
- **Step 7** After the upgrade to 1.2.8 is complete, see Upgrade from Release 1.2.8 to Release 1.3.3.9, on page 41.

Upgrade from Release 1.2.5 to Release 1.3.3.9

You cannot upgrade directly from Cisco DNA Center 1.2.5 to 1.3.3.9. You must first upgrade to 1.2.6, then to 1.2.8, then to 1.2.10.x, and then to 1.3.1.x. From there, you can upgrade directly to 1.3.3.9.

After you upgrade to 1.3.3.9, you cannot switch back to an earlier release.

Step 1	From the Cisco DNA Center home page, choose 🌣 > System Settings > Software Updates.
	A Cisco DNA Center 1.2.6 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.
Step 2	Click Switch Now in the banner.
Step 3	At the prompt, click OK to proceed with the upgrade.
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
	At this point in the procedure, do not click Switch Now in the Cisco DNA Center 1.2.8 is Here! banner that appears at the top of the page.
Step 4	A system update appears on the Software Updates page. Click Update.
Step 5	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.
Step 6	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.
	Don't update individual applications unless the Cisco TAC instructs you to do so.
Step 7	Ensure that each application has been updated by reviewing its version in the Installed Apps page.

Procedure

Step 8 After the upgrade to 1.2.8 is complete, see Upgrade from Release 1.2.8 to Release 1.3.3.9, on page 41.

Upgrade from Release 1.2 – 1.2.4 to Release 1.3.3.9

You cannot upgrade directly from Cisco DNA Center 1.2 - 1.2.4 to 1.3.3.9. You must first upgrade to 1.2.6, then to 1.2.10.x, and then to 1.3.1.x. From there, you can upgrade directly to 1.3.3.9.

After you upgrade to 1.3.3.9, you cannot switch back to an earlier release.

From the Ciaco DNA Contar have no constant should be Supton Softing a Softing and Undertag
From the Cisco DNA Center nome page, choose $w > $ System Settings > Software Updates.
A Cisco DNA Center 1.2.6 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.
Click Switch Now in the banner.
At the prompt, click OK to proceed with the upgrade.
Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
At this point in the procedure, do not click Switch Now in the Cisco DNA Center 1.2.8 is Here! banner that appears at the top of the page.
A system update appears on the Software Updates page. Click Update.
After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.
After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.
Don't update individual applications unless the Cisco TAC instructs you to do so.
Ensure that each application has been updated by reviewing its version in the Installed Apps page.
After the upgrade to 1.2.6 is complete, see Upgrade from Release 1.2.6 to Release 1.3.3.9, on page 42.

Upgrade from Release 1.1.7 or 1.1.8 to Release 1.3.3.9

You cannot upgrade directly from Cisco DNA Center 1.1.7 or 1.1.8 to 1.3.3.9. You must first upgrade to 1.2.6, then to 1.2.8, then to 1.2.10.x, and then to 1.3.1.x. From there, you can upgrade directly to 1.3.3.9.

After you upgrade to 1.3.3.9, you cannot switch back to an earlier release.

Procedure

Step 1 From the Cisco DNA Center home page, choose *> System Settings > App Management.

A Cisco DNA Center 1.2.6 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.

The App Management page also displays the following side tabs:

- **Packages & Updates**: Shows the packages that are currently installed and the updates that are available for installation from the Cisco cloud.
- **System Updates**: Shows the system updates that are currently installed and the updates that are available for installation from the Cisco cloud.
- Step 2 Click Switch Now in the banner.
- **Step 3** At the prompt, click **OK** to proceed with the upgrade.

Clicking **OK** changes the release train in the back end. The message "Connecting to... cloud catalog" with a progress bar appears.

Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.

At this point in the procedure, **do not** click **Switch Now** in the **Cisco DNA Center 1.2.8 is Here!** banner that appears at the top of the page.

Step 4 After the release train change finishes, review the **System Updates** page.

The following information is displayed:

- Package: System package
- Status: Running
- Installed Version: Current system package installed
- Available Update: System package available for installation
- Step 5 Click Install in the Available Update column.

During the install process, the following Cisco DNA Center GUI changes are made:

- App Management tab: Changes to the Software Updates tab
- System Updates side panel: Changes to the Updates side panel
- Packages & Updates side panel: Changes to the Installed Apps side panel
- **Step 6** After the system installation is finished and is in **Running** state, refresh the page.

- **Platform Update**: Displays the updated system version with a statement that the system is currently up to date. Additionally, a green check mark indicates a successful system upgrade.
- Apps Updates: Displays groupings of applications with their current file size and version.
- **Note** After performing system updates, clear your browser cache and log in to Cisco DNA Center again.

Step 7 At the top of the **Apps Updates** field, click the **Download All** button.

After clicking this button, all the application upgrade packages are downloaded.

A new **Updates** page displays the following information:

I

	Note	There are additional Download All buttons for different application groups (for example, Automation , and Assurance). You need to only click the Download All button at the top of the page.
Step 8	After al Update	l the application packages have been downloaded, click the Update All button at the top of the Apps s field.
	After cl	icking this button, all the applications are updated.
	Note	There are additional Update All buttons for different application groups (for example, Automation , and Assurance). You need to only click the Update All button at the top of the page.
Step 9	Ensure	that each application has been updated by reviewing its version in the Installed Apps page.
	The app	lication versions should be updated in this page.
	Note	There may be some new application packages that were not part of your previous Cisco DNA Center configuration, and for this reason have not been installed by this procedure.
Step 10	After th	e upgrade to 1.2.6 is complete, see Upgrade from Release 1.2.6 to Release 1.3.3.9, on page 42.



Upgrade to Cisco DNA Center 1.3.1.7

To complete any of the upgrade procedures described in this chapter, you'll need to know the latest version of the System package for the relevant Cisco DNA Center release. To determine the latest version, do the following:

- 1. From the release notes landing page, open the release notes for the appropriate Cisco DNA Center release.
- 2. In the "New and Changed Information" topic, refer to the "Updated Packages and Versions in Cisco DNA Center Release *number*" table and note the System package version that's listed for the release.
 - Cisco ISE Is Required with Cisco DNA Center 1.3.1.0 and Later, on page 47
 - Upgrade from Release 1.3.1.6 to Release 1.3.1.7, on page 48
 - Upgrade from Release 1.3.1.0–1.3.1.5 to Release 1.3.1.7, on page 48
 - Upgrade from Release 1.3.0.x to Release 1.3.1.7, on page 49
 - Upgrade from Release 1.2.12.x to Release 1.3.1.7, on page 49
 - Upgrade from Release 1.2.10.x to Release 1.3.1.7, on page 50
 - Upgrade from Release 1.2.8 to Release 1.3.1.7, on page 51
 - Upgrade from Release 1.2.6 to Release 1.3.1.7, on page 52
 - Upgrade from Release 1.2.5 to Release 1.3.1.7, on page 52
 - Upgrade from Release 1.2 1.2.4 to Release 1.3.1.7, on page 53
 - Upgrade from Release 1.1.7 or 1.1.8 to Release 1.3.1.7, on page 54

Cisco ISE Is Required with Cisco DNA Center 1.3.1.0 and Later

Installation of or upgrade to Cisco DNA Center 1.3.1.0 and later checks to see if Cisco ISE is configured as an authentication and policy (AAA) server. If the correct version of Cisco ISE is already configured, you can start migration of group policy data from Cisco ISE to Cisco DNA Center.

If Cisco ISE is not configured, or if the required version of Cisco ISE is not present, Cisco DNA Center installs, but Group-Based Policy is not enabled. You must install or upgrade Cisco ISE and connect it to Cisco DNA Center. You can then start the data migration.

For more information, see the following:

- To learn how to integrate Cisco DNA Center with Cisco ISE, see the "Integrate Cisco ISE with Cisco DNA Center" topic in the Cisco DNA Center Second-Generation Appliance Installation Guide.
- To view the required versions of Cisco ISE, see the Release Notes for Cisco DNA Center.

• To learn about migrating policy data to Cisco DNA Center, see the "Group-Based Access Control: Policy Data Migration" topic in the Cisco DNA Center Second-Generation Appliance Installation Guide.

Upgrade from Release 1.3.1.6 to Release 1.3.1.7

By completing this procedure, you can upgrade directly to Cisco DNA Center 1.3.1.7.

After you upgrade, you cannot switch back to an earlier release.

Procedure

Step 1	At the top of the Application Updates field, click Download All . The packages begin downloading.
Step 2	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.
Step 3	Ensure that each application has been updated by reviewing its version in the Installed Apps page.

Upgrade from Release 1.3.1.0–1.3.1.5 to Release 1.3.1.7

By completing this procedure, you can upgrade directly to Cisco DNA Center 1.3.1.7 from the following versions:

- 1.3.1.0
- 1.3.1.1
- 1.3.1.2
- 1.3.1.3
- 1.3.1.4
- 1.3.1.5

After you upgrade to 1.3.1.7, you cannot switch back to an earlier release.

Step 1	From the Cisco DNA Center home page, choose $\Rightarrow >$ System Settings $>$ Software Updates.		
	A system update appears on the Software Updates page.		
Step 2	Click Update.		
Step 3	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.		
Step 4	After the packages are downloaded, at the top of the Application Updates field, click Update All.		

The packages begin updating.

Step 5

Ensure that each application has been updated by reviewing its version in the Installed Apps page.

Upgrade from Release 1.3.0.x to Release 1.3.1.7

By completing the following procedure, you can upgrade directly to 1.3.1.7 from the following Cisco DNA Center versions:

- 1.3.0
- 1.3.0.2
- 1.3.0.3
- 1.3.0.4
- 1.3.0.5
- 1.3.0.6
- 1.3.0.7

After you upgrade to 1.3.1.7, you cannot switch back to an earlier release.

Procedure

Step 1	From the Cisco DNA Center home page, choose 🌞 > System Settings > Software Updates.		
	A Cisco DNA Center 1.3.1.7 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.		
Step 2	Click Switch Now in the banner.		
Step 3	At the prompt, click OK to proceed with the upgrade.		
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.		
Step 4	A system update appears on the Software Updates page. Click Update.		
Step 5	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.		
Step 6	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.		
Step 7	Ensure that each application has been updated by reviewing its version in the Installed Apps page.		

Upgrade from Release 1.2.12.x to Release 1.3.1.7

From Cisco DNA Center 1.2.12.x, you can upgrade directly to 1.3.1.7 by completing the following procedure.

After you upgrade to 1.3.1.7, you cannot switch back to an earlier release.

	Procedure
p 1	From the Cisco DNA Center home page, choose 🌣 > System Settings > Software Updates.
	A Cisco DNA Center 1.3.0.7 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.
p 2	Click Switch Now in the banner.
p 3	At the prompt, click OK to proceed, but do not download, update, and install the 1.3.0.7 system and application packages.
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
p 4	Click Switch Now in the Cisco DNA Center 1.3.1.7 is Here! banner that appears.
p 5	At the prompt, click OK to proceed with the upgrade.
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
p 6	A system update appears on the Software Updates page. Click Update.
p 7	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.
) 8	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.
9 נ	Ensure that each application has been updated by reviewing its version in the Installed Apps page.

Upgrade from Release 1.2.10.x to Release 1.3.1.7

You cannot upgrade directly from Cisco DNA Center 1.2.10.x to 1.3.1.7. You must first upgrade to 1.2.12.x. From there, you can upgrade directly to 1.3.1.7.

After you upgrade to 1.3.1.7, you cannot switch back to an earlier release.

Step 1	From the Cisco DNA Center home page, choose 🏶 > System Settings > Software Updates.	
	A Cisco DNA Center 1.2.12 is Here! banner appears at the top of the page with a Switch Now button.	
Step 2	Click Switch Now in the banner.	
Step 3	At the prompt, click OK to proceed with the upgrade.	
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner	

Step 4	A system update appears on the Software Updates page. Click Update.
Step 5	At the top of the Application Updates field, click Download All . The packages begin downloading.
Step 6	After the packages are downloaded, at the top of the Application Updates field, click Update All.
	The packages begin updating.
	Important Don't update individual applications unless the Cisco TAC instructs you to do so.
Step 7	Ensure that each application has been updated by reviewing its version in the Installed Apps page.
Step 8	After the upgrade to 1.2.12.x is complete, see Upgrade from Release 1.2.12.x to Release 1.3.1.7, on page 49.

Upgrade from Release 1.2.8 to Release 1.3.1.7

You cannot upgrade directly from Cisco DNA Center 1.2.8 to 1.3.1.7. You must first upgrade to 1.2.10.x and then to 1.2.12.x. From there, you can upgrade directly to 1.3.1.7.

After you upgrade to 1.3.1.7, you cannot switch back to an earlier release.

Step 1	From the Cisco DNA Center home page, choose 🏶 > System Settings > Software Updates.		
	A Cisco DNA Center 1.2.10 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.		
Step 2	Click Switch Now in the banner.		
Step 3	At the prompt, click OK to proceed with the upgrade.		
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.		
	At this point in the procedure, do not click Switch Now in the Cisco DNA Center 1.2.12 is Here! banner that appears at the top of the page.		
Step 4	A system update appears on the Software Updates page. Click Update.		
Step 5	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.		
Step 6	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.		
	Don't update individual applications unless the Cisco TAC instructs you to do so.		
Step 7	After the upgrade to 1.2.10.x is complete, see Upgrade from Release 1.2.10.x to Release 1.3.1.7, on page 50.		

Upgrade from Release 1.2.6 to Release 1.3.1.7

You cannot upgrade directly from Cisco DNA Center 1.2.6 to 1.3.1.7. You must first upgrade to 1.2.8, and then to 1.2.10.x. From there, you can upgrade directly to 1.3.1.7.

After you upgrade to 1.3.1.7, you cannot switch back to an earlier release.

Procedure

Step 1 Do one of the follow	ving
-----------------------------	------

If you installed Cisco DNA Center 1.2.6 as a fresh installation, you must apply a system update patch (1.1.0.659.1) before you can upgrade to 1.2.8. From the Cisco DNA Center home page, choose \$\$\$ > System Settings > Software Updates.

After you apply the system update patch, a **Cisco DNA Center 1.2.8 is Here!** banner appears at the top of the page with a **Switch Now** button. **Switch Now** lets you see the system and application packages that are available to update. Click **Switch Now** and **OK**.

• If you upgraded to 1.2.6 (system update 1.1.0.659.1) from a previous Cisco DNA Center release, you see a **Cisco DNA Center 1.2.8 is Here!** banner. Click **Switch Now** and **OK**.

Step 2 At the prompt, click **OK** to proceed with the upgrade.

Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.

At this point in the procedure, **do not** click **Switch Now** in the **Cisco DNA Center 1.2.10 is Here!** banner that appears at the top of the page.

- **Step 3** A system update appears on the **Software Updates** page. Click **Update**.
- **Step 4** After the system update is complete, at the top of the **Application Updates** field, click **Download All**. The packages begin downloading.
- **Step 5** After the packages are downloaded, at the top of the **Application Updates** field, click **Update All**. The packages begin updating.

Don't update individual applications unless the Cisco TAC instructs you to do so.

- **Step 6** Ensure that each application has been updated by reviewing its version in the **Installed Apps** page.
- **Step 7** After the upgrade to 1.2.8 is complete, see Upgrade from Release 1.2.8 to Release 1.3.1.7, on page 51.

Upgrade from Release 1.2.5 to Release 1.3.1.7

You cannot upgrade directly from Cisco DNA Center 1.2.5 to 1.3.1.7. You must first upgrade to 1.2.6, then to 1.2.8, and then to 1.2.10.x. From there, you can upgrade directly to 1.3.1.7.

After you upgrade to 1.3.1.7, you cannot switch back to an earlier release.

From the Cisco DNA Center home page, choose 🌼 > System Settings > Software Updates.
A Cisco DNA Center 1.2.6 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.
Click Switch Now in the banner.
At the prompt, click OK to proceed with the upgrade.
Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
At this point in the procedure, do not click Switch Now in the Cisco DNA Center 1.2.8 is Here! banner that appears at the top of the page.
A system update appears on the Software Updates page. Click Update.
After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.
After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.
Don't update individual applications unless the Cisco TAC instructs you to do so.
Ensure that each application has been updated by reviewing its version in the Installed Apps page.
After the upgrade to 1.2.8 is complete, see Upgrade from Release 1.2.8 to Release 1.3.1.7, on page 51.

Upgrade from Release 1.2 – 1.2.4 to Release 1.3.1.7

You cannot upgrade directly from Cisco DNA Center 1.2 - 1.2.4 to 1.3.1.7. You must first upgrade to 1.2.6, then to 1.2.8, and then to 1.2.10.x. From there, you can upgrade directly to 1.3.1.7.

After you upgrade to 1.3.1.7, you cannot switch back to an earlier release.

Procedure

Step 1 From the Cisco DNA Center home page, choose *> System Settings > Software Updates.

A Cisco DNA Center 1.2.6 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.

- **Step 2** Click **Switch Now** in the banner.
- **Step 3** At the prompt, click **OK** to proceed with the upgrade.

Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.

At this point in the procedure, **do not** click **Switch Now** in the **Cisco DNA Center 1.2.8 is Here!** banner that appears at the top of the page.

Step 4	A system update appears on the Software Updates page. Click Update.
Step 5	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.
Step 6	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.
	Don't update <i>individual</i> applications unless the Cisco TAC instructs you to do so.
Step 7 Step 8	Ensure that each application has been updated by reviewing its version in the Installed Apps page. After the upgrade to 1.2.6 is complete, see Upgrade from Release 1.2.6 to Release 1.3.1.7, on page 52.

Upgrade from Release 1.1.7 or 1.1.8 to Release 1.3.1.7

You cannot upgrade directly from Cisco DNA Center 1.1.7 or 1.1.8 to 1.3.1.7. You must first upgrade to 1.2.6, then to 1.2.8, and then to 1.2.10.x. From there, you can upgrade directly to 1.3.1.7.

After you upgrade to 1.3.1.7, you cannot switch back to an earlier release.

Procedure

Step 1	From the Cisco DNA Center home page, choose 🏶 > System Settings > App Management.
	A Cisco DNA Center 1.2.6 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.
	The App Management page also displays the following side tabs:
	• Packages & Updates : Shows the packages that are currently installed and the updates that are available for installation from the Cisco cloud.
	• System Updates: Shows the system updates that are currently installed and the updates that are available for installation from the Cisco cloud.
Step 2	Click Switch Now in the banner.
Step 3	At the prompt, click OK to proceed with the upgrade.
	Clicking OK changes the release train in the back end. The message "Connecting to cloud catalog" with a progress bar appears.
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
	At this point in the procedure, do not click Switch Now in the Cisco DNA Center 1.2.8 is Here! banner that appears at the top of the page.
Step 4	After the release train change finishes, review the System Updates page.
	The following information is displayed:
	Package: System package
	Status: Running

Cisco DNA Center Upgrade Guide

	• Inst	alled Version: Current system package installed	
	• Ava	ilable Update: System package available for installation	
Step 5	Click Ins	stall in the Available Update column.	
	During the	ne install process, the following Cisco DNA Center GUI changes are made:	
	• App	Management tab: Changes to the Software Updates tab	
	• Syst	tem Updates side panel: Changes to the Updates side panel	
	• Pac	kages & Updates side panel: Changes to the Installed Apps side panel	
Step 6	After the system installation is finished and is in Running state, refresh the page.		
	A new U	pdates page displays the following information:	
	• Plat to da	form Update: Displays the updated system version with a statement that the system is currently up ate. Additionally, a green check mark indicates a successful system upgrade.	
	• App	bs Updates: Displays groupings of applications with their current file size and version.	
	Note	After performing system updates, clear your browser cache and log in to Cisco DNA Center again.	
Step 7	At the top	p of the Apps Updates field, click the Download All button.	
	After clic	king this button, all the application upgrade packages are downloaded.	
	Note	There are additional Download All buttons for different application groups (for example, Automation , and Assurance). You need to only click the Download All button at the top of the page.	
Step 8	After all Updates	the application packages have been downloaded, click the Update All button at the top of the Apps field.	
	After clicking this button, all the applications are updated.		
	Note	There are additional Update All buttons for different application groups (for example, Automation , and Assurance). You need to only click the Update All button at the top of the page.	
Step 9	Ensure th	nat each application has been updated by reviewing its version in the Installed Apps page.	
	The appl	ication versions should be updated in this page.	
	Note	There may be some new application packages that were not part of your previous Cisco DNA Center configuration, and for this reason have not been installed by this procedure.	
Step 10	After the	upgrade to 1.2.6 is complete, see Upgrade from Release 1.2.6 to Release 1.3.1.7, on page 52.	

I



Upgrade to Cisco DNA Center 1.3.0.7

To complete any of the upgrade procedures described in this chapter, you'll need to know the latest version of the System package for the relevant Cisco DNA Center release. To determine the latest version, do the following:

- 1. From the release notes landing page, open the release notes for the appropriate Cisco DNA Center release.
- In the "New and Changed Information" topic, refer to the "Updated Packages and Versions in Cisco DNA Center Release *number*" table and note the System package version that's listed for the release.
 - Upgrade from Release 1.3–1.3.0.6 to Release 1.3.0.7, on page 57
 - Upgrade from Release 1.2.12.x to Release 1.3.0.7, on page 58
 - Upgrade from Release 1.2.10.x to Release 1.3.0.7, on page 59
 - Upgrade from Release 1.2.8 to Release 1.3.0.7, on page 60
 - Upgrade from Release 1.2.6 to Release 1.3.0.7, on page 61
 - Upgrade from Release 1.2.5 to Release 1.3.0.7, on page 62
 - Upgrade from Release 1.2 1.2.4 to Release 1.3.0.7, on page 62
 - Upgrade from Release 1.1.7 or 1.1.8 to Release 1.3.0.7, on page 63

Upgrade from Release 1.3–1.3.0.6 to Release 1.3.0.7

By completing the following procedure, you can upgrade directly to 1.3.0.7 from the following Cisco DNA Center versions:

- 1.3
- 1.3.0.2
- 1.3.0.3
- 1.3.0.4
- 1.3.0.5
- 1.3.0.6

After you upgrade to 1.3.0.7, you cannot switch back to an earlier release.

Procedure

Step 1	From the Cisco DNA Center home page, choose $\overset{\infty}{\sim} >$ System Settings $>$ Software Updates.		
Step 2	A system update appears on the Software Updates page. Click Update.		
	Refresh the page several times if the system update does not appear.		
Step 3	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.		
Step 4	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.		
	Don't update individual applications unless the Cisco TAC instructs you to do so.		
Step 5	Ensure that each application has been updated by reviewing its version in the Installed Apps page.		

Upgrade from Release 1.2.12.x to Release 1.3.0.7

You can upgrade directly from Cisco DNA Center 1.2.12.x to 1.3.0.7.

After you upgrade to 1.3.0.7, you cannot switch back to an earlier release.

Step 1	From the Cisco DNA Center home page, choose 🌣 > System Settings > Software Updates.		
	A Cisco DNA Center 1.3.0.7 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.		
Step 2	Click Switch Now in the banner.		
Step 3	At the prompt, click OK to proceed with the upgrade.		
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version to display. Refresh the page several times if the updated system version does not appear.		
Step 4	A system update appears on the Software Updates page. Click Update.		
Step 5	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.		
Step 6	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.		
Step 7	Ensure that each application has been updated by reviewing its version in the Installed Apps page.		

Upgrade from Release 1.2.10.x to Release 1.3.0.7

There are two Cisco DNA Center 1.2.10.x to 1.3.0.7 upgrade procedures: one for networks that are not running Cisco SD-Access and one for networks that are. Complete the upgrade procedure that's appropriate for your network.

Upgrade Procedure for Deployments Not Running Cisco SD-Access

If Cisco SD-Access is not running in your network, you can upgrade directly from Cisco DNA Center 1.2.10.x to 1.3.0.7.

After you upgrade to 1.3.0.7, you cannot switch back to an earlier release.

Procedure

Step 1	From the Cisco DNA Center home page, choose \Rightarrow > System Settings > Software Updates.
Step 2	Download, update, and install the packages that appear at the top of the page.
	A Cisco DNA Center 1.2.12 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.
Step 3	At the prompt, click OK to proceed, but do not download, update, and install the 1.2.12.x system and application packages.
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
Step 4	Click Switch Now in the Cisco DNA Center 1.3.0.7 is Here! banner that appears.
Step 5	At the prompt, click OK to proceed with the upgrade.
Step 6	A system update appears on the Software Updates page. Click Update.
Step 7	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.
Step 8	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.
Step 9	Ensure that each application has been updated by reviewing its version in the Installed Apps page.

Upgrade Procedure for Deployments Running Cisco SD-Access

If Cisco SD-Access is running in your network, you cannot upgrade directly from Cisco DNA Center 1.2.10.x to 1.3.0.7. You must first upgrade to 1.2.12.x. From there, you can upgrade directly to 1.3.0.7.

After you upgrade to 1.3.0.7, you cannot switch back to an earlier release.

Procedure

Step 1	From the Cisco DNA Center home page, choose 🌣 > System Settings > Software Updates.	
	A Cisco DNA Center 1.2.12 is Here! banner appears at the top of the page with a Switch Now button.	
Step 2	Click Switch Now in the Cisco DNA Center 1.2.12 is Here! banner.	
Step 3	At the prompt, click OK to proceed with the upgrade.	
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.	
Step 4	A system update appears on the Software Updates page. Click Update.	
Step 5	At the top of the Application Updates field, click Download All.	
	The packages begin downloading.	
Step 6	After the packages are downloaded, at the top of the Application Updates field, click Update All.	
	The packages begin updating.	
	Important Don't update individual applications unless the Cisco TAC instructs you to do so.	
Step 7	Ensure that each application has been updated by reviewing its version in the Installed Apps page.	
Step 8	After the upgrade to 1.2.12.x is complete, see Upgrade from Release 1.2.12.x to Release 1.3.0.7, on page 58.	

Upgrade from Release 1.2.8 to Release 1.3.0.7

You cannot upgrade directly from Cisco DNA Center 1.2.8 to 1.3.0.7. You must first upgrade to 1.2.10.x and then to 1.3.0.7.

After you upgrade to 1.3.0.7, you cannot switch back to an earlier release.

Procedure

Step 1 From the Cisco DNA Center home page, choose $\frac{1}{2}$ >	System Settings > Software Updat	tes.
---	----------------------------------	------

A Cisco DNA Center 1.2.10 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.

- **Step 2** Click **Switch Now** in the banner.
- **Step 3** At the prompt, click **OK** to proceed with the upgrade.

Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.

At this point in the procedure, **do not** click **Switch Now** in the **Cisco DNA Center 1.2.12 is Here!** banner that appears at the top of the page.

Step 4 A system update appears on the **Software Updates** page. Click **Update**.

Step 5	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.
Step 6	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.
	Don't update <i>individual</i> applications unless the Cisco TAC instructs you to do so.
Step 7	After the upgrade to 1.2.10.x is complete, see Upgrade Procedure for Deployments Not Running Cisco SD-Access, on page 59.

Upgrade from Release 1.2.6 to Release 1.3.0.7

You cannot upgrade directly from Cisco DNA Center 1.2.6 to 1.3.0.7. You must first upgrade to 1.2.8, then to 1.2.10, and then to 1.3.0.7.

After you upgrade to 1.3.0.7, you cannot switch back to an earlier release.

Procedure

Step 1	Do one	of the	follo	wing:
--------	--------	--------	-------	-------

If you installed Cisco DNA Center 1.2.6 as a fresh installation, you must apply a system update patch (1.1.0.659.1) before you can upgrade to 1.2.8. From the Cisco DNA Center home page, choose \$\$\$ > System Settings > Software Updates.

After you apply the system update patch, a **Cisco DNA Center 1.2.8 is Here!** banner appears at the top of the page with a **Switch Now** button. **Switch Now** lets you see the system and application packages that are available to update. Click **Switch Now** and **OK**.

- If you upgraded to 1.2.6 (system update 1.1.0.659.1) from a previous Cisco DNA Center release, you see a **Cisco DNA Center 1.2.8 is Here!** banner. Click **Switch Now** and **OK**.
- **Step 2** At the prompt, click **OK** to proceed with the upgrade.

Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.

At this point in the procedure, **do not** click **Switch Now** in the **Cisco DNA Center 1.2.10 is Here!** banner that appears at the top of the page.

- Step 3 A system update appears on the Software Updates page. Click Update.
- **Step 4** After the system update is complete, at the top of the **Application Updates** field, click **Download All**. The packages begin downloading.
- **Step 5** After the packages are downloaded, at the top of the **Application Updates** field, click **Update All**. The packages begin updating.

Don't update individual applications unless the Cisco TAC instructs you to do so.

Step 6 Ensure that each application has been updated by reviewing its version in the **Installed Apps** page.

Procedure

Step 7 After the upgrade to 1.2.8 is complete, see Upgrade from Release 1.2.8 to Release 1.3.0.7, on page 60.

Upgrade from Release 1.2.5 to Release 1.3.0.7

You cannot upgrade directly from Cisco DNA Center 1.2.5 to 1.3.0.7. You must first upgrade to 1.2.6, then to 1.2.8, then to 1.2.10, and then to 1.3.0.7.

After you upgrade to 1.3.0.7, you cannot switch back to an earlier release.

From the Cisco DNA Center home page, choose 🏶 > System Settings > Software Updates.			
You will see a system update for 1.2.6; accept the update, download the 1.2.6 packages, and upgrade to 1.2.6.			
After the upgrade to 1.2.6 is complete, a Cisco DNA Center 1.2.8 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.			
Click Switch Now in the banner.			
At the prompt, click OK to proceed with the upgrade.			
Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.			
At this point in the procedure, do not click Switch Now in the Cisco DNA Center 1.2.10 is Here! banner that appears at the top of the page.			
A system update appears on the Software Updates page. Click Update.			
After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.			
After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.			
Don't update individual applications unless the Cisco TAC instructs you to do so.			
Ensure that each application has been updated by reviewing its version in the Installed Apps page.			
After the upgrade to 1.2.8 is complete, see Upgrade from Release 1.2.8 to Release 1.3.0.7, on page 60.			

Upgrade from Release 1.2 – 1.2.4 to Release 1.3.0.7

You cannot upgrade directly from Cisco DNA Center 1.2 - 1.2.4 to 1.3.0.7. You must first upgrade to 1.2.6, then to 1.2.8, then to 1.2.10, and then to 1.3.0.7.

After you upgrade to 1.3.0.7, you cannot switch back to an earlier release.

From the Cisco DNA Center home page, choose 🏶 > System Settings > Software Updates.
A Cisco DNA Center 1.2.6 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.
Click Switch Now in the banner.
At the prompt, click OK to proceed with the upgrade.
Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
At this point in the procedure, do not click Switch Now in the Cisco DNA Center 1.2.8 is Here! banner that appears at the top of the page.
A system update appears on the Software Updates page. Click Update.
After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.
After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.
Don't update individual applications unless the Cisco TAC instructs you to do so.
Ensure that each application has been updated by reviewing its version in the Installed Apps page.
After the ungrade to 1.2.6 is complete, see Ungrade from Release 1.2.6 to Release 1.3.0.7 on page 61

Upgrade from Release 1.1.7 or 1.1.8 to Release 1.3.0.7

You cannot upgrade directly from Cisco DNA Center 1.1.7 or 1.1.8 to 1.3.0.7. You must first upgrade to 1.2.6, then to 1.2.8, then to 1.2.10, and then to 1.3.0.7.

After you upgrade to 1.3.0.7, you cannot switch back to an earlier release.

Procedure

Step 1	From the Cisco DNA Center home page, choose 🌣 > System Settings > App Management.				
	A Cisco DNA Center 1.2.6 is Here! banner appears at the top of the page with a Switch Now button. Switch Now lets you see the system and application packages that are available to update.				
	The App Management page also displays the following side tabs:				
	• Packages & Updates : Shows the packages that are currently installed and the updates that are available for installation from the Cisco cloud.				
	• System Updates : Shows the system updates that are currently installed and the updates that are available for installation from the Cisco cloud.				

Step 2 Click **Switch Now** in the banner.

Step 3	At the p	prompt, click OK to proceed with the upgrade.				
	Clicking progres	g OK changes the release train in the back end. The message "Connecting to cloud catalog" with a s bar appears.				
	Wait for to displa	approximately 90 seconds for the progress bar to finish and the updated system version and banner ay. Refresh the page several times if the updated system version and banner do not appear.				
	At this papears	point in the procedure, do not click Switch Now in the Cisco DNA Center 1.2.8 is Here! banner that at the top of the page.				
Step 4	After th	e release train change finishes, review the System Updates page.				
	The foll	owing information is displayed:				
	• Pa	ckage: System package				
	• Sta	atus: Running				
	• Ins	stalled Version: Current system package installed				
	• Av	ailable Update: System package available for installation				
Step 5	Click Install in the Available Update column.					
	During the install process, the following Cisco DNA Center GUI changes are made:					
	App Management tab: Changes to the Software Updates tab					
	• System Updates side panel: Changes to the Updates side panel					
	• Pa	ckages & Updates side panel: Changes to the Installed Apps side panel				
Step 6	After the system installation is finished and is in Running state, refresh the page.					
	A new Updates page displays the following information:					
	• Platform Update : Displays the updated system version with a statement that the system is currently up to date. Additionally, a green check mark indicates a successful system upgrade.					
	• Apps Updates: Displays groupings of applications with their current file size and version.					
	Note	After performing system updates, clear your browser cache and log in to Cisco DNA Center again.				
Step 7	At the top of the Apps Updates field, click the Download All button.					
	After clicking this button, all the application upgrade packages are downloaded.					
	Note	There are additional Download All buttons for different application groups (for example, Automation , and Assurance). You need to only click the Download All button at the top of the page.				
Step 8	After all the application packages have been downloaded, click the Update All button at the top of the Apps Updates field.					
	After clicking this button, all the applications are updated.					
	Note	There are additional Update All buttons for different application groups (for example, Automation , and Assurance). You need to only click the Update All button at the top of the page.				

Step 9	Ensure that each application l	as been updated by r	reviewing its version	in the Installed Apps page.
--------	--------------------------------	----------------------	-----------------------	-----------------------------

The application versions should be updated in this page.

- **Note** There may be some new application packages that were not part of your previous Cisco DNA Center configuration, and for this reason have not been installed by this procedure.
- **Step 10** After the upgrade to 1.2.6 is complete, see Upgrade from Release 1.2.6 to Release 1.3.0.7, on page 61.

I


Upgrade to Cisco DNA Center 1.2.12.x

To complete any of the upgrade procedures described in this chapter, you'll need to know the latest version of the System package for the relevant Cisco DNA Center release. To determine the latest version, do the following:

- 1. From the release notes landing page, open the release notes for the appropriate Cisco DNA Center release.
- 2. In the "New and Changed Information" topic, refer to the "Updated Packages and Versions in Cisco DNA Center Release *number*" table and note the System package version that's listed for the release.
 - Upgrade from Release 1.2.10.x to Release 1.2.12.x, on page 67
 - Upgrade from Release 1.2.8 to Release 1.2.12.x, on page 68
 - Upgrade from Release 1.2.6 to Release 1.2.12.x, on page 69
 - Upgrade from Release 1.2.5 to Release 1.2.12.x, on page 69
 - Upgrade from Release 1.2 1.2.4 to Release 1.2.12.x, on page 70
 - Upgrade from Release 1.1.7 or 1.1.8 to Release 1.2.12.x, on page 71

Upgrade from Release 1.2.10.x to Release 1.2.12.x

You can upgrade directly from Cisco DNA Center 1.2.10.x to 1.2.12.x.

Step 1	From the Cisco DNA Center home page, choose 🌣 > System Settings > Software Updates.		
	A Cisco DNA Center 1.2.12 is Here! banner appears at the top of the page with a Switch Now button.		
	The Switch Now button becomes active only after you download and update any packages that appear on the page.		
Step 2	At the top of the Application Updates field, click Download All . The packages begin downloading.		
Step 3	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.		
	Don't update individual applications unless the Cisco TAC instructs you to do so.		
Step 4	Ensure that each application has been updated by reviewing its version in the Installed Apps page.		

Step 5	Click Switch Now in the Cisco DNA Center 1.2.12 is Here! banner.			
Step 6	At the prompt, click OK to proceed with the upgrade.			
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.			
Step 7	A system update appears on the Software Updates page. Click Update.			
Step 8	At the top of the Application Updates field, click Download All . The packages begin downloading.			
Step 9	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.			
	Don't update individual applications unless the Cisco TAC instructs you to do so.			
Step 10	Ensure that each application has been updated by reviewing its version in the Installed Apps page.			

Upgrade from Release 1.2.8 to Release 1.2.12.x

You cannot upgrade directly from Cisco DNA Center 1.2.8 to 1.2.12.x. You must first upgrade to 1.2.10.x and then to 1.2.12.x.

Procedure
From the Cisco DNA Center home page, choose \Rightarrow > System Settings > Software Updates.
A Cisco DNA Center 1.2.10 is Here! banner appears at the top of the page with a Switch Now button.
Click Switch Now in the banner.
At the prompt, click OK to proceed with the upgrade.
Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
At this point in the procedure, do <i>not</i> click Switch Now in the Cisco DNA Center 1.2.12 is Here! banner that appears at the top of the page.
A system update appears on the Software Updates page. Click Update.
After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.
After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.
Don't update individual applications unless the Cisco TAC instructs you to do so.
Ensure that each application has been updated by reviewing its version in the Installed Apps page.
After the upgrade to 1.2.10.x is complete, see Upgrade from Release 1.2.10.x to Release 1.2.12.x, on page 67.

Upgrade from Release 1.2.6 to Release 1.2.12.x

You cannot upgrade directly from Cisco DNA Center 1.2.6 to 1.2.12.x. You must first upgrade to 1.2.8, then to 1.2.10.x, and then to 1.2.12.x.

Procedure

Step 1	Do one	of the	follo	wing
				<u> </u>

If you installed Cisco DNA Center 1.2.6 as a fresh installation, you must apply a system update patch (1.1.0.659.1) before you can upgrade to 1.2.8. From the Cisco DNA Center home page, choose \$\$\$ > System Settings > Software Updates.

After you apply the system update patch, a **Cisco DNA Center 1.2.8 is Here!** banner appears at the top of the page with a **Switch Now** button. Click **Switch Now** and **OK**.

• If you upgraded to 1.2.6 (system update 1.1.0.659.1) from a previous Cisco DNA Center release, you see a **Cisco DNA Center 1.2.8 is Here!** banner. Click **Switch Now** and **OK**.

Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.

At this point in the procedure, do *not* click **Switch Now** in the **Cisco DNA Center 1.2.10 is Here!** banner that appears at the top of the page.

- **Step 2** A system update appears on the **Software Updates** page. Click **Update**.
- **Step 3** After the system update is complete, at the top of the **Application Updates** field, click **Download All**. The packages begin downloading.
- **Step 4** After the packages are downloaded, at the top of the **Application Updates** field, click **Update All**. The packages begin updating.

Don't update *individual* applications unless the Cisco TAC instructs you to do so.

- **Step 5** Ensure that each application has been updated by reviewing its version in the **Installed Apps** page.
- **Step 6** After the upgrade to 1.2.8 is complete, see Upgrade from Release 1.2.8 to Release 1.2.12.x, on page 68.

Upgrade from Release 1.2.5 to Release 1.2.12.x

You cannot upgrade directly from Cisco DNA Center 1.2.5 to 1.2.12.x. You must first upgrade to 1.2.6, then to 1.2.8, then to 1.2.10.x, and then to 1.2.12.x.

Procedure

Step 1 From the Cisco DNA Center home page, choose * > **System Settings** > **Software Updates**.

You will see a system update for 1.2.6; accept the update, download the 1.2.6 packages, and upgrade to 1.2.6.

After the upgrade to 1.2.6 is complete, a **Cisco DNA Center 1.2.8 is Here!** banner appears at the top of the page with a **Switch Now** button.

Step 2	Click Switch Now in the banner.			
Step 3	At the prompt, click OK to proceed with the upgrade.			
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.			
	At this point in the procedure, do <i>not</i> click Switch Now in the Cisco DNA Center 1.2.10 is Here! banner that appears at the top of the page.			
Step 4	A system update appears on the Software Updates page. Click Update.			
Step 5	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.			
Step 6	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.			
	Don't update individual applications unless the Cisco TAC instructs you to do so.			
Step 7 Step 8	Ensure that each application has been updated by reviewing its version in the Installed Apps page. After the upgrade to 1.2.8 is complete, see Upgrade from Release 1.2.8 to Release 1.2.12.x, on page 68.			

Upgrade from Release 1.2 – 1.2.4 to Release 1.2.12.x

You cannot upgrade directly from Cisco DNA Center 1.2 - 1.2.4 to 1.2.12.x. You must first upgrade to 1.2.6, then to 1.2.10.x, and then to 1.2.12.x.

Procedure

Step 1	From the Cisco DNA Center home page, choose 🌣 > System Settings > Software Updates.			
	A Cisco DNA Center 1.2.6 is Here! banner appears at the top of the page with a Switch Now button.			
Step 2	Click Switch Now in the banner.			
Step 3	At the prompt, click OK to proceed with the upgrade.			
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.			
	At this point in the procedure, do <i>not</i> click Switch Now in the Cisco DNA Center 1.2.8 is Here! banner that appears at the top of the page.			
Step 4	A system update appears on the Software Updates page. Click Update.			
Step 5	After the system update is complete, at the top of the Application Updates field, click Download All . The packages begin downloading.			
Step 6	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.			

Don't update *individual* applications unless the Cisco TAC instructs you to do so.

Step 7	Ensure that each application has been updated by reviewing its version in the Installed Apps page.
Step 8	After the upgrade to 1.2.6 is complete, see Upgrade from Release 1.2.6 to Release 1.2.12.x, on page 69.

Upgrade from Release 1.1.7 or 1.1.8 to Release 1.2.12.x

You cannot upgrade directly from Cisco DNA Center 1.1.7 or 1.1.8 to 1.2.12.x. You must first upgrade to 1.2.6, then to 1.2.10.x, and then to 1.2.12.x.

	Procedure
Step 1	From the Cisco DNA Center home page, choose 🌣 > System Settings > App Management.
	A Cisco DNA Center 1.2.6 is Here! banner appears at the top of the page with a Switch Now button.
	The App Management page also displays the following side tabs:
	• Packages & Updates : Shows the packages currently installed and updates available for installation from the Cisco cloud.
	• System Updates: Shows the system updates currently installed and updates available for installation from the Cisco cloud.
tep 2	Click Switch Now in the banner.
tep 3	At the prompt, click OK to proceed with the upgrade.
	Clicking OK changes the release train in the back end. The message "Connecting to 1.2.6 cloud catalog" with a progress bar appears.
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
	At this point in the procedure, do <i>not</i> click Switch Now in the Cisco DNA Center 1.2.8 is Here! banner that appears at the top of the page.
Step 4	After the release train change finishes, review the System Updates page.
	The following information is displayed:
	Package: System package
	Status: Running
	• Installed Version: Current system package installed
	Available Update: System package available for installation
Step 5	Click Install in the Available Update column.
	During the install process, the following Cisco DNA Center GUI changes are made:
	App Management tab: Changes to the Software Updates tab
	• System Updates side panel: Changes to the Updates side panel

I

	• Pac	kages & Updates side panel: Changes to the Installed Apps side panel			
Step 6	After the system installation is finished and is in Running state, refresh the page.				
	A new U	pdates page displays the following information:			
	• Plat to da	form Update : Displays the updated system version with a statement that the system is currently up ate. Additionally, a green check mark indicates a successful system upgrade.			
	• Apps Updates: Displays groupings of applications with their current file size and version.				
	Note	After performing system updates, clear your browser cache and log in to Cisco DNA Center 1.2.6 again.			
Step 7	At the top of the Apps Updates field, click the Download All button.				
	After clicking this button, all the application upgrade packages are downloaded.				
	Note	There are additional Download All buttons for different application groups (for example, Automation , and Assurance). You need to only click the Download All button at the top of the page.			
Step 8	After all of the application packages have been downloaded, click the Update All button at the top of the Apps Updates field.				
	After clicking this button, all of the applications are updated.				
	Note	There are additional Update All buttons for different application groups (for example, Automation , and Assurance). You need to only click the Update All button at the top of the page.			
Step 9	Ensure that each application has been updated by reviewing its version in the Installed Apps page.				
	The application versions should be updated in this page.				
	Note	There may be some new application packages that were not part of your previous Cisco DNA Center configuration, and for this reason have not been installed by this procedure (for example, the Test Support package listed on this page).			
Step 10	After the	upgrade to 1.2.6 is complete, see Upgrade from Release 1.2.6 to Release 1.2.12.x, on page 69.			



Upgrade to Cisco DNA Center 1.2.10.x

To complete any of the upgrade procedures described in this chapter, you'll need to know the latest version of the System package for the relevant Cisco DNA Center release. To determine the latest version, do the following:

- 1. From the release notes landing page, open the release notes for the appropriate Cisco DNA Center release.
- 2. In the "New and Changed Information" topic, refer to the "Updated Packages and Versions in Cisco DNA Center Release *number*" table and note the System package version that's listed for the release.
 - Upgrade from Release 1.2.8 to Release 1.2.10.x, on page 73
 - Upgrade from Release 1.2.6 to Release 1.2.10.x, on page 74
 - Upgrade from Release 1.2.5 to Release 1.2.10.x, on page 74
 - Upgrade from Release 1.2 1.2.4 to Release 1.2.10.x, on page 75
 - Upgrade from Release 1.1.7 or 1.1.8 to Release 1.2.10.x, on page 76

Upgrade from Release 1.2.8 to Release 1.2.10.x

You can upgrade directly from Cisco DNA Center 1.2.8 to 1.2.10.x.

Step 1	From the Cisco DNA Center home page, choose $\Rightarrow $ System Settings > Software Updates .		
	A Cisco DNA Center 1.2.10 is Here! banner appears at the top of the page with a Switch Now button.		
Step 2	Click Switch Now in the banner.		
Step 3	At the prompt, click OK to proceed with the upgrade.		
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.		
Step 4	A system update appears on the Software Updates page. Click Update.		
Step 5	At the top of the Application Updates field, click Download All . The packages begin downloading.		
Step 6	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.		

Don't update individual applications unless the Cisco TAC instructs you to do so.

Step 7 Ensure that each application has been updated by reviewing its version in the **Installed Apps** page.

Upgrade from Release 1.2.6 to Release 1.2.10.x

You cannot upgrade directly from Cisco DNA Center 1.2.6 to 1.2.10 x. You must first upgrade to 1.2.8 and

then to 1.2.10.x.
Procedure
Do one of the following:
• If you installed Cisco DNA Center 1.2.6 as a fresh installation, you must apply a system update patch (1.1.0.659.1) before you can upgrade to 1.2.8. From the Cisco DNA Center home page, choose * > System Settings > Software Updates .
After you apply the system update patch, a Cisco DNA Center 1.2.8 is Here! banner appears at the top of the page with a Switch Now button. Click Switch Now and OK .
• If you upgraded to 1.2.6 (system update 1.1.0.659.1) from a previous Cisco DNA Center release, you see a Cisco DNA Center 1.2.8 is Here! banner. Click Switch Now and OK .
Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
At this point in the procedure, do <i>not</i> click Switch Now in the Cisco DNA Center 1.2.10 is Here! banner that appears at the top of the page.
A system update appears on the Software Updates page. Click Update.
At the top of the Application Updates field, click Download All . The packages begin downloading.
After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.
Don't update individual applications unless the Cisco TAC instructs you to do so.
Ensure that each application has been updated by reviewing its version in the Installed Apps page.
After the upgrade to 1.2.8 is complete, see Upgrade from Release 1.2.8 to Release 1.2.10.x, on page 73.

Upgrade from Release 1.2.5 to Release 1.2.10.x

You cannot upgrade directly from Cisco DNA Center 1.2.5 to 1.2.10.x. You must first upgrade to 1.2.6, then to 1.2.8, and then to 1.2.10.x.

Procedure

Step 1	From the Cisco DNA Center home page, choose 🌣 > System Settings > Software Updates.			
	You will see a system update for 1.2.6; accept the update, download the 1.2.6 packages, and upgrade to 1.2.6.			
	After the upgrade to 1.2.6 is complete, a Cisco DNA Center 1.2.8 is Here! banner appears at the top of the page with a Switch Now button.			
Step 2	Click Switch Now in the banner.			
Step 3	At the prompt, click OK to proceed with the upgrade.			
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.			
	At this point in the procedure, do <i>not</i> click Switch Now in the Cisco DNA Center 1.2.10 is Here! banner that appears at the top of the page.			
Step 4	A system update appears on the Software Updates page. Click Update.			
Step 5	At the top of the Application Updates field, click Download All . The packages begin downloading.			
Step 6	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.			
	Don't update individual applications unless the Cisco TAC instructs you to do so.			
Step 7	Ensure that each application has been updated by reviewing its version in the Installed Apps page.			
Step 8	After the upgrade to 1.2.8 is complete, see Upgrade from Release 1.2.8 to Release 1.2.10.x, on page 73.			

Upgrade from Release 1.2 – 1.2.4 to Release 1.2.10.x

You cannot upgrade directly from Cisco DNA Center 1.2 - 1.2.4 to 1.2.10.x. You must first upgrade to 1.2.6, then to 1.2.8, and then to 1.2.10.x.

Step 1	From the Cisco DNA Center home page, choose 🌼 > System Settings > Software Updates.
	A Cisco DNA Center 1.2.6 is Here! banner appears at the top of the page with a Switch Now button.
Step 2	Click Switch Now in the banner.
Step 3	At the prompt, click OK to proceed with the upgrade.
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.
	At this point in the procedure, do <i>not</i> click Switch Now in the Cisco DNA Center 1.2.8 is Here! banner that appears at the top of the page.
Step 4	A system update appears on the Software Updates page. Click Update.

Step 5	At the top of the Application Updates field, click Download All . The packages begin downloading.	
Step 6	After the packages are downloaded, at the top of the Application Updates field, click Update All . The packages begin updating.	
	Don't update individual applications unless the Cisco TAC instructs you to do so.	
Step 7 Step 8	Ensure that each application has been updated by reviewing its version in the Installed Apps page. After the upgrade to 1.2.6 is complete, see Upgrade from Release 1.2.6 to Release 1.2.10.x, on page 74	

Upgrade from Release 1.1.7 or 1.1.8 to Release 1.2.10.x

You cannot upgrade directly from Cisco DNA Center 1.1.7 or 1.1.8 to 1.2.10.x. You must first upgrade to 1.2.6, then to 1.2.8, and then to 1.2.10.x.

Step 1	From the Cisco DNA Center home page, choose $\Rightarrow >$ System Settings > App Management. A Cisco DNA Center 1.2.6 is Here! banner appears at the top of the page with a Switch Now button. The App Management page also displays the following side tabs:		
	• Packages & Updates: Shows the packages that are currently installed and the updates that are available for installation from the Cisco cloud.		
	• System Updates: Shows the System updates that are currently installed and the updates that are available for installation from the Cisco cloud.		
Step 2	Click Switch Now in the banner.		
Step 3	At the prompt, click OK to proceed with the upgrade.		
	Clicking OK changes the release train in the back end. The message "Connecting to cloud catalog" with a progress bar appears.		
	Wait for approximately 90 seconds for the progress bar to finish and the updated system version and banner to display. Refresh the page several times if the updated system version and banner do not appear.		
	At this point in the procedure, do <i>not</i> click Switch Now in the Cisco DNA Center 1.2.8 is Here! banner that appears at the top of the page.		
Step 4	After the release train change finishes, review the System Updates page.		
	The following information is displayed:		
	Package: System package		
	Status: Running		
	Installed Version: Current system package installed		
	• Available Update: System package available for installation		

Step 5	stall in the Available Update column.				
	During the install process, the following Cisco DNA Center GUI changes are made:				
	• App Management tab: Changes to the Software Updates tab				
	• System Updates side panel: Changes to the Updates side panel				
	• Packages & Updates side panel: Changes to the Installed Apps side panel				
Step 6	After the system installation is finished and is in Running state, refresh the page.				
	A new Updates page displays the following information:				
	• Platform Update : Displays the updated system version with a statement that the system is currently up to date. Additionally, a green check mark indicates a successful system upgrade.				
	• Apps Updates: Displays groupings of applications with their current file size and version.				
	Note	After performing system updates, clear your browser cache and log in to Cisco DNA Center again.			
Step 7	At the top of the Apps Updates field, click the Download All button.				
	After clicking this button, all the application upgrade packages are downloaded.				
	Note	There are additional Download All buttons for different application groups (for example, Automation , and Assurance). You need to only click the Download All button at the top of the page.			
Step 8	After all the application packages have been downloaded, click the Update All button at the top of the Apps Updates field.				
	After clicking this button, all the applications are updated.				
	Note	There are additional Update All buttons for different application groups (for example, Automation , and Assurance). You need to only click the Update All button at the top of the page.			
Step 9	Ensure that each application has been updated by reviewing its version in the Installed Apps page.				
	The application versions should be updated in this page.				
	Note	There may be some new application packages that were not part of your previous Cisco DNA Center configuration, and for this reason have not been installed by this procedure.			
Step 10	p 10 After the upgrade to 1.2.6 is complete, see Upgrade from Release 1.2.6 to Release 1.2.10.x, on pa				

I



APPENDIX **F**

Appendix

- Recover from Premature Package Downloads, on page 79
- Related Documentation, on page 79

Recover from Premature Package Downloads

Successful migration to this release requires that you install all system updates before downloading or installing package updates. Due to dependencies among the updates, failure to observe this rule can make it impossible to install both system updates and package updates. Problem indicators include messages that a system update has failed and package update downloads that never exit the "Downloading" state.

As an admin user with Maglev SSH access privileges, complete the following steps to recover and install the system update.

Procedure

Step 1	Using an SSH client, log in to the Cisco DNA Center appliance using the IP address of the out-of-band management network adapter, on port 2222. Use the maglev login command and log in with an admin userna and password (which is the same login used for the admin user on the Cisco DNA Center GUI).			
Step 2	At the command line, delete all prematurely downloaded package updates by entering the following command:			
for pkg in \$(maglev package status -o json jq -r '.[] select(.available! .name,.available tostring] join (":")'); do maglev catalog package dele 2>/dev/null; done				
	Important You must enter the preceding command as one line.			
Step 3 Step 4	Trigger the downloaded system update from the Cisco DNA Center GUI. After the system update installs successfully, download and install the package updates.			

Related Documentation

We recommend that you read the following documents relating to Cisco DNA Center.



Note

The documentation set for this product strives to use bias-free language. For purposes of this documentation set, bias-free is defined as language that does not imply discrimination based on age, disability, gender, racial identity, ethnic identity, sexual orientation, socioeconomic status, and intersectionality. Exceptions may be present in the documentation due to language that is hardcoded in the user interfaces of the product software, language used based on RFP documentation, or language that is used by a referenced third-party product.

For This Type of Information	See This Document
Release information, including new features, limitations, and open and resolved bugs.	Cisco DNA Center Release Notes
Installation and configuration of Cisco DNA Center, including postinstallation tasks.	Cisco DNA Center Installation Guide
Upgrade information for your current release of Cisco DNA Center.	Cisco DNA Center Upgrade Guide
Use of the Cisco DNA Center GUI and its applications.	Cisco DNA Center User Guide
Configuration of user accounts, security certificates, authentication and password policies, and backup and restore.	Cisco DNA Center Administrator Guide
Security features, hardening, and best practices to ensure a secure deployment.	Cisco DNA Center Security Best Practices Guide
Supported devices, such as routers, switches, wireless access points, NFVIS platforms, and software releases.	Supported Devices
Hardware and software support for Cisco SD-Access.	Cisco SD-Access Hardware and Software Compatibility Matrix
Use of the Cisco DNA Assurance GUI.	Cisco DNA Assurance User Guide
Use of the Cisco DNA Center platform GUI and its applications.	Cisco DNA Center Platform User Guide
Cisco DNA Center platform release information, including new features, deployment, and bugs.	Cisco DNA Center Platform Release Notes
Use of the Cisco Wide Area Bonjour Application GUI.	Cisco Wide Area Bonjour Application User Guide
Use of the Stealthwatch Security Analytics Service on Cisco DNA Center.	Cisco Stealthwatch Analytics Service User Guide
Use of Rogue Management functionality as a dashboard within Cisco DNA Assurance in the Cisco DNA Center GUI.	Cisco DNA Center Rogue Management Application Quick Start Guide

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: https://www.cisco.com/c/en/us/about/legal/trademarks.html. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2019-2021 Cisco Systems, Inc. All rights reserved.