

!Command: show running-config
!Time: Thu Sep 9 18:08:11 2010

```
version 4.2(1)N1(1)
feature telnet
feature interface-vlan
feature lacp
feature lldp
feature fex

logging level aaa 5
logging level cdp 6
logging level radius 5
logging level monitor 6
logging level port-channel 6
logging level spanning-tree 6
logging level interface vlan 5
username admin password 5 xxxxxx role network-admin
no password strength-check
ip domain-lookup
ip host EAS-N5K-1 10.0.254.5
hostname EAS-N5K-1
logging event link-status default
snmp-server user admin network-admin auth md5 xxxxxx priv yyyy localizedkey
snmp-server host 10.0.128.23 traps version 2c public
snmp-server enable traps callhome event-notify
snmp-server enable traps callhome smtp-send-fail
snmp-server enable traps aaa server-state-change
snmp-server enable traps snmp authentication
snmp-server community private group network-admin
snmp-server community public group network-operator

vrf context management
  ip route 0.0.0.0/0 10.0.254.1
vlan 1
vlan 2
  name HostMgmt-Nexus1k
vlan 3
  name vMotion-ESXDefaultGW
vlan 11
  name NFS-NetApp
vlan 12,128
vlan 232
  name CitrixUserTraffic
vlan 240
  name UserDataTraffic
vlan 254
spanning-tree vlan 1-3,11,128,232,240,254 priority 12288

interface Vlan1
```

```
interface port-channel10
  switchport mode trunk

interface Ethernet1/1
  description N7K-Inside
  switchport mode trunk
  speed 1000

interface Ethernet1/2
  shutdown

interface Ethernet1/3
  switchport access vlan 254
  speed 1000

interface Ethernet1/4
  switchport access vlan 128
  speed 1000

interface Ethernet1/5
  shutdown
  switchport mode trunk
  switchport trunk allowed vlan 254
  speed 1000

interface Ethernet1/6
  switchport mode trunk
  speed 1000

interface Ethernet1/7
  description EMC FC A (mgmt)
  switchport access vlan 254
  speed 1000

interface Ethernet1/8
  switchport access vlan 2
  speed 1000

interface Ethernet1/9
  description EAS-6120-A:e1/20
  switchport mode trunk

interface Ethernet1/10

interface Ethernet1/11
  description NetApp
  switchport access vlan 11

interface Ethernet1/12

interface Ethernet1/13

interface Ethernet1/14
```

```
interface Ethernet1/15
```

```
interface Ethernet1/16
  description EAS-N5k-2:e1/16
  switchport mode trunk
  switchport trunk allowed vlan 2-3,11,128,232,240,254
```

```
interface Ethernet1/17
  description connection to 6120-TME
  switchport mode trunk
  channel-group 10 mode active
```

```
interface Ethernet1/18
  description connection to 6120-TME
  switchport mode trunk
  channel-group 10 mode active
```

```
interface Ethernet1/19
```

```
interface Ethernet1/20
  switchport mode trunk
```

```
interface mgmt0
  ip address 10.0.254.5/24
  cli alias name wr copy run start
  line console
    exec-timeout 30
  boot kickstart bootflash:/n5000-uk9-kickstart.4.2.1.N1.1.bin
  boot system bootflash:/n5000-uk9.4.2.1.N1.1.bin
  logging logfile messages 6
  logging server 10.0.128.23
  logging server 10.0.128.25
```