

Introduction



Note

Explore the Content Hub, the all new portal that offers an enhanced product documentation experience.

- Use faceted search to locate content that is most relevant to you.
- Create customized PDFs for ready reference.
- Benefit from context-based recommendations.

Get started with the Content Hub at content.cisco.com to craft a personalized documentation experience.

Do provide feedback about your experience with the Content Hub.

This Release Notes contain information about downloading and installing Cisco 1x2 / Compact Shelf RPD Software 6.5 and its maintenance releases. It also provides new and changed information, hardware support, limitations and restrictions, and caveats for Cisco 1x2 / Compact Shelf RPD Software 6.5 and its maintenance releases.

We recommend that you view the field notices for this release to see if your software or hardware platforms are affected. If you have an account at Cisco.com, you can find the field notices at http://www.cisco.com/en/US/customer/support/tsd products field notice summary.html.

If you do not have an account at Cisco.com, you can find the field notices at http://www.cisco.com/en/US/support/tsd_products_field_notice_summary.html.



Note

Cisco 1x2 / Compact Shelf RPD Software 6.5 is generally available for field deployment. To ensure a smoother, faster, and successful field deployment, we recommend that you validate and qualify the software in a limited field trial.

This chapter includes the following sections:

- System Requirements, on page 2
- New and Changed Information, on page 3
- MIBs, on page 4
- Obtaining Documentation and Submitting a Service Request, on page 4

System Requirements

These sections describe the system requirements for Cisco 1x2 / Compact Shelf RPD Software 6.5 and its maintenance releases:

Memory Requirements for Cisco 1x2 / Compact Shelf RPD Software 6.5



Note

Memory is not configurable for the Cisco Remote PHY device.

Table 1: Memory Recommendations for the Cisco Remote PHY Device

Feature Set	Cisco RPHY Processor	Software Image	Fixed Memory	Runs From
CISCO RPHY 6.5	NXP LS1043A	RPD-V6-5.itb.SSA	1G Bytes	Bootflash:

Hardware Supported

For detailed information about the hardware supported in Cisco 1x2 / Compact Shelf RPD Software 6.5 and its maintenance releases, see:

http://www.cisco.com/c/en/us/td/docs/cable/cbr/installation/guide/b_cbr_how_and_what_to_order.html.

Determining the Software Version of Cisco 1x2 / Compact Shelf RPD Software 6.5

To determine the version of the Cisco 1x2 RPD software running on your Cisco Remote PHY Device, log in and enter the **show version** EXEC command:

```
R-PHY#show version
Cisco RPD Software, version v6.5, build by rpd-release, on 2019-04-29 03:28:18
Branch information:

RPD branch: (detached from RPD_V6_5_20190429)
OpenRPD branch: (detached from RPD_V6_5_20190429)
SeresRPD branch: (detached from RPD_V6_5_20190429)
```



Note

The system image file name of the factory installed image is

/bootflash/RPD-V6.5_hardware_certificate.itb.rel.sign.SSA. The system image file name of the Secure Software Download (SSD) from the Cisco software download page is /bootflash/RPD-V6-5.itb.SSA.act.

New and Changed Information

The following sections list the new hardware and software features supported on the Cisco Remote PHY Device in this release:

New Software Features in Cisco 1x2 / Compact Shelf RPD Software 6.5

The new software features for Cisco 1x2 / Compact Shelf RPD Software 6.5 release are:

View Downstream Channel Traffic Rate for Each Downstream Channel

You can view the downstream channel traffic rate for each downstream channel using the **show downstream channel counter** command. The downstream channel traffic rate is calculated every 60 seconds for SC-QAM and every 15 seconds for OFDM.

The downstream channel traffic rate is displayed in the Rate-in-Mbps column.

R-PHY#show downstream channel counter Packets counter in TPMI							
Level Node Rcv Depi Pkt	446941	Rx-sum-pkts 1117839 11382					
		(dec/hex) /0x00430000					
		/0x00430000 /0x00430001					
DS_0 1	4390914	/0x00430001	43	79	710		
DS 0 3	4390915	/0x00430002 /0x00430003	42	82			
DS 0 4	4390916	/0x00430004	43	83			
		/0x00430005		75			
DS_0 6	4390918	/0x00430006	41	81			
DS_0 7	4390919	/0x00430007	42	78			
		Rx-sum-pkts		=	o-sum-pkts		
DS_0		763590	0	0			
US_0	74316 73842	152292 152967	0	0			
US_1	13842	132967	U	U			
		Packets coun	ter in D	PMI			
Field	Pkts	Sum-pkts					
Dpmi Ingr		603482					
Pkt Delet		0					
Data Len	Err 0	0					
Chan Flow	v_id Session	nId(dec/hex)	Oct	s	Sum-octs	SeqErr-pkts	SeqErr-sum-pkts
0 0	4390912	2 / 0x0043 2 / 0x0043	0000 2	2464	2464	1	1
0 1	439091	2 / 0x0043	0000 1	.5087	29660	0	1
0 2		2 / 0x0043					1
0 3	4390912	2 / 0x0043	0000 C		0	0	0
1 0 1 1	439091.	3 / 0x0043 3 / 0x0043	0001 1	.232	2464	0	1 1
1 2	439091.	3 / 0x0043 3 / 0x0043	0001 1 0001 4	.5038 1766316	30479 9825238	-	0
1 3		3 / 0x0043)	0	0	0
2 0	439091	4 / 0x0043	0002 5		552	1	1
2 1	439091	4 / 0x0043 4 / 0x0043	0002 1	292	2516	0	1
2 2	439091)	0	0	0

2	3	4390914	/ 0x00430002	0	0	0	0
3	0	4390915	/ 0x00430003	444	444	1	1
3	1	4390915	/ 0x00430003	1292	2652	0	1
3	2	4390915	/ 0x00430003	0	0	0	0
3	3	4390915	/ 0x00430003	0	0	0	0

----- Packets counter in DPS -----

Chan	Tx-packets	Tx-octets	Drop-pkts	Tx-sum-pkts	Tx-sum-octs	Drop-sum-pkts	Rate-in-Mbps
0	75249	4888241	0	150734	9790374	0	0.653
1	74756	4853154	0	152791	9921209	0	0.675
2	43	1844	0	79	3068	0	0.000
3	42	1736	0	82	3096	0	0.000

Modified Software Features in Cisco 1x2 / Compact Shelf RPD Software 6.5

There are no modified software features for Cisco 1x2 / Compact Shelf RPD Software 6.5 release.

Integrated Software Features in Cisco 1x2 / Compact Shelf RPD Software 6.5

There are no new integrated software features for Cisco 1x2 / Compact Shelf RPD Software 6.5 release.

New Hardware Features in Cisco 1x2 / Compact Shelf RPD Software 6.5

There are no new hardware features for Cisco 1x2 / Compact Shelf RPD Software 6.5 release.

MIBs

To locate and download MIBs for selected platforms, Cisco IOS XE releases, and feature sets, use Cisco MIB Locator found at the following URL:

http://tools.cisco.com/ITDIT/MIBS/servlet/index

To access Cisco MIB Locator, you must have an account on Cisco.com. If you have forgotten or lost your account information, send a blank e-mail to cco-locksmith@cisco.com. An automatic check verifies that your e-mail address is registered with Cisco.com. If the check is successful, account details with a new random password is e-mailed to you. Qualified users can establish an account on Cisco.com by following the directions found at this URL:

http://tools.cisco.com/RPF/register/register.do

MIBs in Cisco 1x2 / Compact Shelf RPD Software 6.5

There are no new MIBs in Cisco 1x2 / Compact Shelf RPD Software 6.5.

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see What's New in Cisco Product Documentation.

To receive new and revised Cisco technical content directly to your desktop, you can subscribe to the What's New in Cisco Product Documentation RSS feed. The RSS feeds are a free service.

Obtaining Documentation and Submitting a Service Request