

# **System Configuration**

- Information About New Configuration Model, on page 1
- Configuring a Wireless Profile Policy (GUI), on page 3
- Configuring a Wireless Profile Policy (CLI), on page 4
- Configuring a Flex Profile, on page 5
- Configuring an AP Profile (GUI), on page 6
- Configuring an AP Profile (CLI), on page 9
- Configuring an RF Profile (GUI), on page 10
- Configuring an RF Profile (CLI), on page 10
- Configuring Policy Tag (GUI), on page 11
- Configuring a Policy Tag (CLI), on page 11
- Configuring Wireless RF Tag (GUI), on page 13
- Configuring Wireless RF Tag (CLI), on page 13
- Attaching a Policy Tag and Site Tag to an AP (GUI), on page 14
- Attaching Policy Tag and Site Tag to an AP (CLI), on page 14
- AP Filter, on page 15

# Information About New Configuration Model

The configuration of Cisco Embedded Wireless Controller on Catalyst Access Points is simplified using different tags, namely rf-tag, policy-tag, and site-tag. The access points would derive their configuration from the profiles that are contained within the tags.

Profiles are a collection of feature-specific attributes and parameters applied to tags. The rf-tag contains the radio profiles, the policy-tag contains the WLAN profile and policy profile, and the site-tag contains the flex profile and ap-join profile.

#### **Policy Tag**

The policy tag constitutes mapping of the WLAN profile to the policy profile. The WLAN profile defines the wireless characteristics of the WLAN. The policy profile defines the network policies and the switching policies for the client (Quality of Service [QoS] is an exception which constitutes AP policies as well).

The policy tag contains the map of WLAN policy profile. There can be a maximum of 16 such entries per policy tag. Changes to the map entries are effected based on the status of the WLAN profile and policy profile. For example, if a map (WLAN1 and Policy1) is added to the policy tag, and both the WLAN profile and the policy profile are enabled, the definitions are pushed to the APs using the policy tag. However, if one of them

is in disabled state, the definition is not pushed to the AP. Similarly, if a WLAN profile is already being broadcast by an AP, it can be deleted using the no form of the command in the policy tag.

#### Site Tag

The site tag defines the properties of a site and contains the flex profile and the AP join profile. The attributes that are specific to the corresponding flex or remote site are part of the flex profile. Apart from the flex profile, the site tag also comprises attributes that are specific to the physical site (and hence cannot be a part of the profile that is a reusable entity). For example, the list of primary APs for efficient upgrade is a part of a site tag rather than that of a flex profile.

If a flex profile name or an AP profile name is changed in the site tag, the AP is forced to rejoin the controller by disconnecting the Datagram Transport Layer Security (DTLS) session. When a site tag is created, the AP and flex profiles are set to default values (default-ap-profile and default-flex-profile).

### **RF Tag**

The RF tag contains the 2.4 GHz and 5 GHz RF profiles. The default RF tag contains the global configuration. Both these profiles contain the same default values for global RF profiles for the respective radios.

#### **Profiles**

Profiles are a collection of feature-specific attributes and parameters applied to tags. Profiles are reusable entities that can be used across tags. Profiles (used by tags) define the properties of the APs or its associated clients.

#### **WLAN Profile**

WLAN profiles are configured with same or different service set identifiers (SSIDs). An SSID identifies the specific wireless network for the controller to access. Creating WLANs with the same SSID allows to assign different Layer 2 security policies within the same wireless LAN.

To distinguish WLANs having the same SSID, create a unique profile name for each WLAN. WLANs with the same SSID must have unique Layer 2 security policies so that clients can select a WLAN based on the information advertised in the beacon and probe responses. The switching and network policies are not part of the WLAN definition.

#### **Policy Profile**

Policy profile broadly consists of network and switching policies. Policy profile is a reusable entity across tags. Anything that is a policy for a client that is applied on an AP or controller is moved to the policy profile, for example, VLAN, ACL, QoS, session timeout, idle timeout, AVC profile, bonjour profile, local profiling, device classification, BSSID QoS, and so on. However, all the wireless-related security attributes and features on the WLAN are grouped under the WLAN profile.

### **Flex Profile**

Flex profile contains policy attributes and remote site-specific parameters. For example, the EAP profiles that can be used when the AP acts as an authentication server for local RADIUS server information, VLAN-ACL mapping, VLAN name-to-ID mapping, and so on.

#### **AP Join Profile**

The default AP join profile values will have the global AP parameters and the AP group parameters. The AP join profile contains attributes that are specific to AP, such as CAPWAP, IPv4 and IPv6, UDP Lite, High Availability, Retransmit config parameters, Global AP failover, Hyperlocation config parameters, Telnet and SSH, 11u parameters, and so on.



Note

Telnet is not supported for the following Cisco AP models: 1542D, 1542I, 1562D, 1562E, 1562I, 1562PS, 1800S, 1800T, 1810T, 1810W,1815M, 1815STAR, 1815TSN, 1815T, 1815T, 1815W, 1832I, 1840I, 1852E, 1852I, 2802E, 2802I, 2802H, 3700C, 3800, 3802E, 3802I, 3802P, 4800, IW6300, ESW6300, 9105AXI, 9105AXW, 9115AXI, 9115AXE, 9117I, APVIRTUAL, 9120AXI, 9120AXE, 9130AXI, and 9130AXE.

#### **RF Profile**

RF profile contains the common radio configuration for the APs. RF profiles are applied to all the APs that belong to an AP group, where all the APs in that group have the same profile settings.

Some of the 6-GHz band specific 802.11ax features like Unsolicited Broadcast Probe Response, FILS Discovery, Multi-BSSID reduce the overhead of management traffic in 6-GHz band channels. Prefered Scanning Channels is another feature in 6-GHz band which helps RRM to choose PSC channels to 6-GHz radios.

#### **Association of APs**

APs can be associated using different ways. The default option is by using Ethernet MAC address, where the MAC is associated with policy-tag, site tag, and RF tag.

In filter-based association, APs are mapped using regular expressions. A regular expression (regex) is a pattern to match against an input string. Any number of APs matching that regex will have policy-tag, site tag, and RF tag mapped to them, which is created as part of the AP filter.

In AP-based association, tag names are configured at the PnP server and the AP stores them and sends the tag name as part of discovery process.

In location-based association, tags are mapped as per location and are pushed to any AP Ethernet MAC address mapped to that location.

### **Modifying AP Tags**

Modifying an AP tag results in DTLS connection reset, forcing the AP to rejoin the controller. If only one tag is specified in the configuration, default tags are used for other types, for example, if only policy tag is specified, the default-site-tag and default-rf-tag will be used for site tag and RF tag.

# **Configuring a Wireless Profile Policy (GUI)**

- **Step 1** Choose Configuration > Tags & Profiles > Policy.
- Step 2 On the Policy Profile page, click Add.

- **Step 3** In the **Add Policy Profile** window, in **General** tab, enter a name and description for the policy profile. The name can be ASCII characters from 32 to 126, without leading and trailing spaces. Do not use spaces as it causes system instability.
- **Step 4** To enable the policy profile, set **Status** as **Enabled**.
- **Step 5** In the WLAN Switching Policy section, choose the following, as required:
  - No Central Switching: Tunnels both the wireless user traffic and all control traffic via CAPWAP to the centralized controller where the user traffic is mapped to a dynamic interface/VLAN on the controller. This is the normal CAPWAP mode of operation.
  - Central Authentication: Tunnels client data to the controller, as the controller handles client authentication.
  - No Central DHCP: The DHCP packets received from AP are centrally switched to the controller and then forwarded to the corresponding VLAN based on the AP and the SSID.
  - Central Association Enable: When central association is enabled, all switching is done on the controller.
  - Flex NAT/PAT: Enables Network Address Translation(NAT) and Port Address Translation (PAT) mode.
- Step 6 Click Save & Apply to Device.

# **Configuring a Wireless Profile Policy (CLI)**

Follow the procedure given below to configure a wireless profile policy:



Note

When a client moves from an old controller to a new controller (managed by Cisco Prime Infrastructure), the old IP address of the client is retained, if the IP address is learned by ARP or data gleaning. To avoid this scenario, ensure that you enable **ipv4 dhcp required** command in the policy profile. Otherwise, the IP address gets refreshed only after a period of 24 hours.

	Command or Action	Purpose	
Step 1	configure terminal	Enters global configuration mode.	
	Example:		
	Device# configure terminal		
Step 2	wireless profile policy profile-policy	Configures WLAN policy profile and enter	
	Example:	wireless policy configuration mode.	
	Device(config)# wireless profile policy rr-xyz-policy-1		
Step 3	idle-timeout timeout	(Optional) Configures the duration of idle	
	Example:	timeout, in seconds.	

	Command or Action	Purpose
	Device(config-wireless-policy)# idle-timeout 1000	
Step 4	vlan vlan-id	Configures VLAN name or VLAN ID.
	Example:  Device(config-wireless-policy)# vlan 24	
Step 5	no shutdown  Example:  Device(config-wireless-policy) # no shutdown	Saves the configuration and exits configuration mode and returns to privileged EXEC mode.
Step 6	show wireless profile policy summary  Example:  Device# show wireless profile policy summary	Displays the configured policy profiles.  Note (Optional) To view detailed information about a policy profile, use the show wireless profile policy detailed policy-profile-name command.

# **Configuring a Flex Profile**

Follow the procedure given below to set a flex profile:

	Command or Action	Purpose	
Step 1	configure terminal	Enters global configuration mode.	
	Example:		
	Device# configure terminal		
Step 2	wireless profile flex flex-profile	Configures a Flex profile and enters Flex profile	
	Example:	configuration mode.	
	Device(config)# wireless profile flex rr-xyz-flex-profile		
Step 3	description	(Optional) Enables default parameters for the	
	Example:	flex profile.	
	Device(config-wireless-flex-profile)# description xyz-default-flex-profile		
Step 4	arp-caching	(Optional) Enables ARP caching.	
	Example:		
	Device(config-wireless-flex-profile)# arp-caching		

	Command or Action	Purpose
· · · · · · · · · · · · · · · · · · ·	end	Saves the configuration and exits configuration
	mode and returns to privileged EXEC mode.	
Step 6	show wireless profile flex summary	(Optional) Displays the flex-profile parameters.
	Example:	<b>Note</b> To view detailed parameters about
	Device# show wireless profile flex summary	the flex profile, use the <b>show wireless profile flex detailed</b> flex-profile-name command.
		flex-profile-name command.

# **Configuring an AP Profile (GUI)**

### Before you begin

The default AP join profile values will have the global AP parameters and the AP group parameters. The AP join profile contains attributes that are specific to AP, such as CAPWAP, IPv4/IPv6, UDP Lite, High Availability, retransmit configuration parameters, global AP failover, Hyperlocation configuration parameters, Telnet/SSH, 11u parameters, and so on.

### **Procedure**

- Step 1 Choose Configuration > Tags & Profiles > AP Join.
- Step 2 On the AP Join Profile page, click Add.

The **Add AP Join Profile** page is displayed.

- **Step 3** In the **General** tab, enter a name and description for the AP join profile.
- Step 4 Check the LED State check box to set the LED state of all APs connected to the device to blink so that the APs are easily located.
- **Step 5** In the **Client** tab and **Statistics Timer** section, enter the time in seconds that the AP sends its 802.11 statistics to the controller.
- In the **TCP MSS Configuration** section, check the **Adjust MSS Enable** check box to enter value for Adjust MSS. You can enter or update the maximum segment size (MSS) for transient packets that traverse a router. TCP MSS adjustment enables the configuration of the maximum segment size (MSS) for transient packets that traverse a router, specifically TCP segments with the SYN bit set.

In a CAPWAP environment, a lightweight access point discovers a device by using CAPWAP discovery mechanisms, and then sends a CAPWAP join request to the device. The device sends a CAPWAP join response to the access point that allows the access point to join the device.

When the access point joins the device, the device manages its configuration, firmware, control transactions, and data transactions.

**Step 7** In the **AP** tab, you can configure the following:

- General
- a) In the General tab, check the Switch Flag check box to enable switches.
- b) Check the **Power Injector State** check box if power injector is being used. Power Injector increases wireless LAN deployment flexibility of APs by providing an alternative powering option to local power, inline power-capable multiport switches, and multiport power patch panels.
- c) From the **Power Injector Type** drop-down list, choose power injector type from the following options:
  - Installed: If you want the AP to examine and remember the MAC address of the currently connected switch port. (This selection assumes that a power injector is connected.)
  - Override: To enable the AP to operate in high-power mode without first verifying a matching MAC address.
- d) In the **Injector Switch MAC** field, enter the MAC address of the switch.
- e) From the **EAP Type** drop-down list, choose the EAP type as *EAP-FAST*, *EAP-TLS*, or *EAP-PEAP*.
- f) From the **AP Authorization Type** drop-down list, choose the type as either *CAPWAP DTLS* + or *CAPWAP DTLS*.
- g) In the **Client Statistics Reporting Interval** section, enter the interval for 5 GHz and 2.4 GHz radios in seconds.
- h) Check the **Enable** check box to enable extended module.
- i) From the **Profile Name** drop-down list, choose a profile name.
- j) Click Save & Apply to Device.
  - Hyperlocation: Cisco Hyperlocation is a location solution that allows to track the location of wireless
    clients with the accuracy of one meter. Selecting this option disables all other fields in the screen, except
    NTP Server.
- a) In the **Hyperlocation** tab, check the **Enable Hyperlocation** check box.
- b) Enter the **Detection Threshold** value to filter out packets with low RSSI. The valid range is -100 dBm to -50 dBm.
- c) Enter the **Trigger Threshold** value to set the number of scan cycles before sending a BAR to clients. The valid range is 0 to 99.
- d) Enter the **Reset Threshold** value to reset value in scan cycles after trigger. The valid range is 0 to 99.
- e) Enter the **NTP Server** IP address.
- f) Click Save & Apply to Device.
  - BLE: If your APs are Bluetooth Low Energy (BLE) enabled, they can transmit beacon messages that are packets of data or attributes transmitted over a low energy link. These BLE beacons are frequently used for health monitoring, proximity detection, asset tracking, and in-store navigation. For each AP, you can customize BLE Beacon settings configured globally for all APs.
- a) In the **BLE** tab, enter a value in the **Beacon Interval** field to indicate how often you want your APs to send out beacon advertisements to nearby devices. The range is from 1 to 10, with a default of 1.
- b) In the **Advertised Attenuation Level** field, enter the attenuation level. The range is from 40 to 100, with a default of 59.
- c) Click Save & Apply to Device.
- **Step 8** In the **Management** tab, you can configure the following:
  - Device

- a) In the **Device** tab, enter the **IPv4/IPv6 Address** of the TFTP server, **TFTP Downgrade** section.
- b) In the **Image File Name** field, enter the name of the software image file.
- c) From the **Facility Value** drop-down list, choose the appropriate facility.
- d) Enter the IPv4 or IPv6 address of the host.
- e) Choose the appropriate Log Trap Value.
- f) Enable Telnet and/or SSH configuration, if required.
- g) Enable core dump, if required.
- h) Click Save & Apply to Device.
  - User
- a) In the **User** tab, enter username and password details.
- b) Choose the appropriate password type.
- c) In the **Secret** field, enter a custom secret code.
- d) Choose the appropriate secret type.
- e) Choose the appropriate encryption type.
- f) Click Save & Apply to Device.
  - Credentials
- a) In the **Credentials** tab, enter local username and password details.
- b) Choose the appropriate local password type.
- c) Enter 802.1x username and password details.
- d) Choose the appropriate 802.1x password type.
- e) Enter the time in seconds after which the session should expire.
- f) Enable local credentials and/or 802.1x credentials as required.
- g) Click Save & Apply to Device.
- a) In the **CDP Interface** tab, enable the CDP state, if required.
- b) Click Save & Apply to Device.
- **Step 9** In the **Rogue AP** tab, check the **Rogue Detection** check box to enable rogue detection.
- **Step 10** In the **Rogue Detection Minimum RSSI** field, enter the RSSI value.

This field specifies the minimum RSSI value for which a Rogue AP should be reported. All Rogue APs with RSSI lower than what is configured will not be reported to controller.

**Step 11** In the **Rogue Detection Transient Interval** field, enter the transient interval value.

This field indicates how long the Rogue AP should be seen before reporting the controller.

**Step 12** In the **Rogue Detection Report Interval** field, enter the report interval value.

This field indicates the frequency (in seconds) of Rogue reports sent from AP to controller.

Step 13 Check the Rogue Containment Automatic Rate Selection check box to enable rogue containment automatic rate selection.

Here, the AP selects the best rate for the target Rogue, based on its RSSI.

Step 14 Check the Auto Containment on FlexConnect Standalone check box to enable the feature.

Here, the AP will continue containment in case it moves to flexconnect standalone mode.

### Step 15 Click Save & Apply to Device.

# **Configuring an AP Profile (CLI)**

Follow the procedure given below to configure and AP profile:

	Command or Action	Purpose	
Step 1	configure terminal	Enters global configuration mode.	
	Example:		
	Device# configure terminal		
Step 2	ap profile ap-profile	Configures an AP profile and enters AP profile	
	Example:	configuration mode.	
	Device(config)# ap profile xyz-ap-profile	Note In an AP profile, the <b>EAP-FAST</b> is the default EAP type.	
		Note When you delete a named profile, the APs associated with that profile will not revert to the default profile.	
Step 3	description ap-profile-name	Adds a description for the ap profile.	
	Example:		
	Device(config-ap-profile)# description "xyz ap profile"		
Step 4	cdp	Enables CDP for all Cisco APs.	
	Example:		
	Device(config-ap-profile)# cdp		
Step 5	end	Saves the configuration and exits configuration mode and returns to privileged EXEC mode.	
	Example:		
	Device(config-ap-profile)# end		
Step 6	show ap profile nameprofile-name detailed	(Optional) Displays detailed information about	
	Example:	an AP join profile.	
	Device# show ap profile name xyz-ap-profile detailed		

# **Configuring an RF Profile (GUI)**

#### **Procedure**

- Step 1 Choose Configuration > Tags & Profiles > RF.
- Step 2 On the RF Profile page, click Add.
- **Step 3** In the **General** tab, enter a name for the RF profile. The name can be ASCII characters from 32 to 126, without leading and trailing spaces.
- **Step 4** Choose the appropriate **Radio Band**.
- **Step 5** To enable the profile, set the status as **Enable**.
- **Step 6** Enter a **Description** for the RF profile.
- Step 7 Click Save & Apply to Device.

# **Configuring an RF Profile (CLI)**

Follow the procedure given below to configure an RF profile:

### Before you begin

Ensure that you use the same RF profile name that you create here, when configuring the wireless RF tag too. If there is a mismatch in the RF profile name (for example, if the RF tag contains an RF profile that does not exist), the corresponding radios will not come up.

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:  Device# configure terminal	
Step 2	<pre>ap dot11 24ghz rf-profile rf-profile Example: Device(config) # ap dot11 24ghz rf-profile rfprof24_1</pre>	Configures an RF profile and enters RF profile configuration mode.  Note Use the 24ghz command to configure the 802.11b parameters. Use the 5ghz command to configure the 802.11a parameters.
Step 3	<pre>default Example:    Device(config-rf-profile)# default</pre>	(Optional) Enables default parameters for the RF profile.

	Command or Action	Purpose	
Step 4	no shutdown	Enables the RF profile on the device.	
	Example:		
	Device(config-rf-profile)# no shutdown		
Step 5	end	Exits configuration mode and returns to	
	Example:	privileged EXEC mode.	
	Device(config-rf-profile)# end		
Step 6	show ap rf-profile summary	(Optional) Displays the summary of the	
	Example:	available RF profiles.	
	Device# show ap rf-profile summary		
Step 7	show ap rf-profile name rf-profile detail	(Optional) Displays detailed information about	
	Example:	a particular RF profile.	
	Device# show ap rf-profile name rfprof24_1 detail		

# **Configuring Policy Tag (GUI)**

### **Procedure**

Step 1	Choose Configuration > Tags & Profiles > Tags > Policy.	
Step 2	Click Add to view the Add Policy Tag window.	
Step 3	Enter a name and description for the policy tag. The name can be ASCII characters from 32 to 126, without leading and trailing spaces.	
Step 4	Click Add to map WLAN and policy.	
Step 5	Choose the WLAN profile to map with the appropriate policy profile, and click the tick icon.	
Step 6	Click Save & Apply to Device.	

# **Configuring a Policy Tag (CLI)**

Follow the procedure given below to configure a policy tag:

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.

	Command or Action	Purpose
	Device> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 3	wireless tag policy policy-tag-name  Example:	Configures policy tag and enters policy tag configuration mode.
	Device (config-policy-tag) # wireless tag policy default-policy-tag	Note When performing LWA, the clients connected to a controller gets disconnected intermittently before session timeout.
		As a workaround it is recommended to include all policy profiles with central association or no central association under a given policy tag.
Step 4	description description	Adds a description to a policy tag.
	Example:	
	<pre>Device(config-policy-tag)# description "default-policy-tag"</pre>	
Step 5	remote-lan name policy profile-policy-name {ext-module  port-id }	Maps a remote-LAN profile to a policy profile.
	Example:	
	<pre>Device(config-policy-tag)# remote-lan rr-xyz-rlan-aa policy rr-xyz-rlan-policy1 port-id 2</pre>	
Step 6	wlan wlan-name policy profile-policy-name	Maps a policy profile to a WLAN profile.
	Example:	
	Device(config-policy-tag)# wlan rr-xyz-wlan-aa policy rr-xyz-policy-1	
Step 7	end	Exits policy tag configuration mode, and returns
	Example:	to privileged EXEC mode.
	Device(config-policy-tag)# end	
Step 8	show wireless tag policy summary	(Optional) Displays the configured policy tags.
	Example:	<b>Note</b> To view detailed information about
	Device# show wireless tag policy summary	a policy tag, use the <b>show wireless tag policy detailed</b> <i>policy-tag-name</i> command.

# **Configuring Wireless RF Tag (GUI)**

#### **Procedure**

- Step 1 a) Choose Configuration > Tags & Profiles > Tags > RF.
- Step 2 Click Add to view the Add RF Tag window.
- **Step 3** Enter a name and description for the RF tag. The name can be ASCII characters from 32 to 126, without leading and trailing spaces.
- Step 4 Choose the required 5 GHz Band RF Profile and 2.4 GHz Band RF Profile to be associated with the RF tag.
- Step 5 Click Update & Apply to Device.

# **Configuring Wireless RF Tag (CLI)**

Follow the procedure given below to configure a wireless RF tag:

### Before you begin

- You can use only two profiles (2.4-GHz and 5-GHz band RF profiles) in an RF tag.
- Ensure that you use the same AP tag name that you created when configuring the AP tag task too.

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	wireless tag rf rf-tag	Creates an RF tag and enters wireless RF tag
	Example:	configuration mode.
	Device(config)# wireless tag rf rftagl	
Step 3	24ghz-rf-policy rf-policy	Attaches an IEEE 802.11b RF policy to the RF
	Example:	tag.
	Device(config-wireless-rf-tag)# 24ghz-rf-policy rfprof24_1	To configure a dot11a policy, use the <b>5ghz-rf-policy</b> command.
Step 4	description policy-description	Adds a description for the RF tag.
	Example:	
	<pre>Device(config-wireless-rf-tag)# description Test</pre>	

	Command or Action	Purpose
Step 5	end	Exits configuration mode and returns to
	Example:	privileged EXEC mode.
	Device(config-wireless-rf-tag)# end	
Step 6	show wireless tag rf summary	Displays the available RF tags.
	Example:	
	Device# show wireless tag rf summary	
Step 7	show wireless tag rf detailed rf-tag	Displays detailed information of a particular
	Example:	RF tag.
	Device# show wireless tag rf detailed rftag1	

# Attaching a Policy Tag and Site Tag to an AP (GUI)

#### **Procedure**

**Step 1** Choose Configuration > Wireless > Access Points.

The **All Access Points** section displays details of all the APs on your network.

**Step 2** To edit the configuration details of an AP, select the row for that AP.

The **Edit AP** window is displayed.

Step 3 In the General tab and Tags section, specify the appropriate policy, site, and RF tags, that you created on the Configuration > Tags & Profiles > Tags page.

configuration - rags & fromes -

Step 4 Click Update & Apply to Device.

# Attaching Policy Tag and Site Tag to an AP (CLI)

Follow the procedure given below to attach a policy tag and a site tag to an AP:

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	

	Command or Action	Purpose	
Step 2	ap mac-address  Example:	Configures a Cisco AP and enters AP profile configuration mode.	
	Device(config)# ap F866.F267.7DFB	Note The <i>mac-address</i> should be a wired mac address.	
Step 3	policy-tag policy-tag-name	Maps a policy tag to the AP.	
	Example:		
	Device(config-ap-tag)# policy-tag rr-xyz-policy-tag		
Step 4	site-tag site-tag-name	Maps a site tag to the AP.	
	Example:		
	Device(config-ap-tag)# site-tag rr-xyz-site		
Step 5	rf-tag rf-tag-name	Associates the RF tag.	
	Example:		
Step 6	end	Saves the configuration, exits configuration	
	Example:	mode, and returns to privileged EXEC mode.	
	Device(config-ap-tag)# end		
Step 7	show ap tag summary	(Optional) Displays AP details and the tags	
	Example:	associated to it.	
	Device# show ap tag summary		
Step 8	show ap name <ap-name> tag info</ap-name>	(Optional) Displays the AP name with tag information.	
	Example:		
	Device# show ap name ap-name tag info		
Step 9	show ap name <ap-name> tag detail</ap-name>	(Optional) Displays the AP name with tag	
	Example:	detals.	
	Device# show ap name ap-name tag detail		

# **AP Filter**

## **Introduction to AP Filter**

The introduction of tags in the new configuration model in the Cisco Embedded Wireless Controller on Catalyst Access Points has created multiple sources for tags to be associated with access points (APs). Tag sources can be static configuration, AP filter engine, per-AP PNP, or default tag sources. In addition to this,

the precedence of the tags also plays an important role. The AP filter feature addresses these challenges in a seamless and intuitive manner.

AP filters are similar to the access control lists (ACLs) used in the controller and are applied at the global level. You can add AP names as filters, and other attributes can be added as required. Add the filter criteria as part of the discovery requests.

The AP Filter feature organizes tag sources with the right priority, based on the configuration.

You cannot disable the AP filter feature. However, the relative priority of a tag source can be configured using **ap filter-priority** *priority filter-name* command.



Note

You can configure tag names at the PnP server (similar to the Flex group and AP group) and the AP stores and send the tag name as part of discovery and join requests.

### **Set Tag Priority (GUI)**

#### **Procedure**

- **Step 1** Choose Configuration > Tags & Profiles > Tags > AP > Tag Source.
- **Step 2** Drag and Drop the Tag Sources to change priorities.

### **Set Tag Priority**

Multiple tag sources might result in ambiguity for network administrators. To address this, you can define priority for tags. When an AP joins the controller, the tags are picked based on priority. If precedence is not set, the defaults are used.

Use the following procedure to set tag priority:

	Command or Action	Purpose		
Step 1	configure terminal	Enters the global configuration mode.		
	Example:  Device# configure terminal			
Step 2	ap tag-source-priority source-priority source {filter   pnp}	Configures AP tag source priority.  Note It is not mandatory to configure AP		
	<pre>Example:   Device(config)# ap tag-source-priority 2 source pnp</pre>	filter. It comes with default priorities		

Command or Action	Purpose	
end	Exits configuration mode and returns to	
Example:	privileged EXEC mode.	
Device(config)# end		
ap tag-sources revalidate	Revalidates AP tag sources. The priorities	
Example:	become active only after this command is run.	
Device# ap tag-sources revalidate	Note If you change the priorities for Filter and PnP, and want to evaluate them, run the <b>revalidate</b> command.	
	end Example: Device(config)# end ap tag-sources revalidate Example:	

### **Create an AP Filter (GUI)**

### **Procedure**

- Step 1 Choose Configuration > Tags & Profiles > Tags > AP > Filter.
- Step 2 Click Add.
- Step 3 In the Associate Tags to AP dialog box which is displayed, enter the Rule Name, the AP name regex and the Priority. Optionally, you can also choose the policy tag from the Policy Tag Name drop-down list, the site tag from the Site Tag Name drop-down list and the RF tag from the RF Tag Name drop-down list.
- Step 4 Click Apply to Device.

## **Create an AP Filter (CLI)**

	Command or Action	Purpose	
Step 1	configure terminal	Enters the global configuration mode.	
	Example:		
	Device# configure terminal		
Step 2	ap filter name filter_name	Configures an AP filter.	
	Example:		
	Device(config)# ap filter filter-1		
Step 3	ap name-regex regular-expression	Configures the AP filter based on regular	
	Example:	expression.	
	Device(config-ap-filter)# ap name-regex testany		

	Command or Action	Purpose	
Step 4	tag policy policy-tag	Configures a policy tag for this filter.	
	Example:		
	Device(config-ap-filter)# tag policy pol-tag1		
Step 5	tag rf rf-tag	Configures an RF tag for this filter.	
	Example:		
	Device(config-ap-filter)# tag rf rf-tag1		
Step 6	tag site site-tag	Configures a site tag for this filter.	
	Example:		
	Device(config-ap-filter)# tag site site1		
Step 7	end	Exits configuration mode and returns to	
	Example:	privileged EXEC mode.	
	Device(config-ap-filter)# end		

### **Set Up and Update Filter Priority (GUI)**

#### **Procedure**

### Step 1 Choose Configuration > Tags & Profiles > Tags > AP > Filter.

Step 2

- a) If you want to setup a new AP filter, then click **Add**. In the **Associate Tags to AP** dialog box which is displayed, enter the **Rule Name**, the **AP name regex** and the **Priority**. Optionally, you can also select the **Policy Tag Name**, the **Site Tag Name** and the **RF Tag Name**. Click **Apply to Device**.
- b) If you want to update the priority of an existing AP filter, click on the Filter and in the **Edit Tags** dialog box and change the **Priority**. In case the Filter is Inactive, no priority can be set to it. Click **Update and Apply to Device**.

### **Set Up and Update Filter Priority**

Follow the procedure given below to set and update filter priority:

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	

	Command or Action	Purpose	
Step 2		Configure AP filter priority.	
	filter-name Example:	Note A filter without a priority is not active. Similarly, you cannot set a	
	Device(config)# ap filter priority 10 filter-name test1	filter priority without a filter.	
Step 3	end	Exits configuration mode and returns to	
	Example:	privileged EXEC mode.	
	Device(config-ap)# end		

## **Verify AP Filter Configuration**

The following show commands are used to display tag sources and filters, and their priorities.

To view the tag source priorities, use the following command:

Device# show ap tag sources

Priority Tag source

O Static

Filter

AP

Default

To view the available filters, use the following command:

### Device# show ap filter all

Filter Name Tag	regex	Policy Tag	RF Tag	Site
first site-tag1	abcd	pol-tag1	rf-tag1	
test1	testany			sitel
filter1	testanv			

To view the list of active filters, use the following command:

#### Device# show ap filters active

Priority Site Tag	Filter Name	regex	Policy Tag	RF Tag
10 site1	test1	testany		

To view the source of an AP tag, use the following command:

```
Device# show ap tag summary
```

Number of APs: 4

AP Name AP Mac Site Tag Name Policy Tag Name RF Tag Name

#### Misconfigured Tag Source

AP002A.1034.CA78 002a.1034.ca78 named-site-tag named-policy-tag named-rf-tag No Filter

AP00A2.891C.2480 00a2.891c.2480 named-site-tag named-policy-tag named-rf-tag No Filter

AP58AC.78DE.9946 58ac.78de.9946 default-site-tag default-policy-tag default-rf-tag No AP AP0081.C4F4.1F34 0081.c4f4.1f34 default-site-tag default-policy-tag default-rf-tag No Default