

WPA3 Deployment Guide


Introduction to WPA3

Wi-Fi Protected Access 3 (WPA3) is the latest generation of Wi-Fi security protocol and is a successor to WPA2. WPA3 is an enhancement to WPA2 and enforces 802.11i and 802.11w IEEE standards. WPA3 introduces new features on enterprise, personal, and open security networks through an increase in cryptographic strength, allowing for a more secure authentication process for all WPA3-supported endpoints.

It is designed to:

- Strengthen Wireless Security
- Simplify secure connectivity for users
- Provide robust protection even with weak passwords
- Secure public/open Wi-Fi networks.

Figure 1. Wi-Fi Security Standards Timeline



Overall, WPA3 significantly raises the security baseline of Wi-Fi networks, protecting users against common attacks like brute-force password guessing, passive snooping, and session hijacking, while also making setup more user-friendly.

Supported WPA3 Modes

- WPA3-Enterprise, for 802.1X security networks. This leverages IEEE 802.1X with SHA-256 as the Authentication and Key Management (AKM).
- WPA3-Personal, which uses the Simultaneous Authentication of Equals (SAE) method for personal security networks. There are two sub-methods to derive the Password Element in SAE:
 - Hunting and Pecking (HnP)
 - Hash-to-Element (H2E)

Note: Wi-Fi 6E (6 GHz) and Wi-Fi 7 requires Hash-to-Element as mandatory, as HnP is prone to brute force dictionary attacks.
- WPA3 Transition Mode (WPA2+WPA3 security-based WLANs for both personal and enterprise). {Starting 17.12.1, this can be used with 1 SSID and 1 Profile and support 6GHz band.}
- Opportunistic Wireless Encryption (OWE) for open security networks.

WPA3 Requirements for Wi-Fi 6E (6 GHz) and Wi-Fi 7

Wi-Fi Alliance mandated WPA3 for 6 GHz band and Wi-Fi 7 to ensure modern security and protect from vulnerabilities and provide a secure foundation for new device ecosystems.

WPA3 Requirements in Wi-Fi 6E (6 GHz) :

- WPA3 is mandatory for all Wi-Fi 6E devices operating in 6 GHz band.
- WPA3-Personal (SAE) with H2E for home/personal use.
- WPA3-Enterprise (802.1X, with optional 192-bit security suite) for enterprise deployments.
- Enhanced Open (OWE) for open networks requiring encryption without passwords
- Protected Management Frames (PMF) is mandatory in 6 GHz.
- WPA2 is **not** permitted in 6 GHz operation.

Note: While, as per the [WPA3 v3.4](#) specifications (Section 11.2), Enhanced Open transition mode is not supported with Wi-Fi 6E (6 GHz) and deprecated in Wi-Fi 7, a lot of vendors (including Cisco up to IOS® XE 17.18) do not enforce that yet. Therefore, it is technically possible to configure, for example, an Open SSID on 5 GHz, a corresponding Enhanced Open SSID on 5 and 6 GHz, with Transition Mode enabled and without complying to the standards specifications.

WPA3 Requirements in Wi-Fi 7:

- WPA3 is mandatory for all Wi-Fi 7 devices for features like Multi Link Operation and 802.11be data rates.
- WPA3-Personal (SAE) with GCMP256 as Cipher and SAE-EXT-KEY or the FT equivalent of it FT-SAE-EXT-KEY as AKMs.

Note: AKM or Authentication and Key Management (AKM) refers to the mechanism used to authenticate clients to establish the cryptographic keys that protect wireless communications. Consider it as the “handshake + key exchange” part of the security process.

- WPA3-Enterprise with GCMP256 as the cipher and 802.1X-SHA256 or the FT equivalent of it FT+802.1X (which still uses SHA256, though it's not explicit in naming) as AKM.
 - **Note:** Cipher requirement of GCMP256 is required for WPA3-Enterprise. However, it's not strictly enforced in the Access Point and Wireless clients and CCMP128 is allowed for backwards compatibility
- Enhanced Open (OWE) with GCMP256 as Cipher for open networks requiring encryption without passwords
- Protected Management Frames (PMF) is mandatory.
- Beacon Protection is mandatory.
 - **Note:** Beacon Protection is implicitly enabled in the controller.

Note: Similar to Wi-Fi 6E, Enhanced Transition Mode is not supported for Wi-Fi 7 operation in 6 GHz band. It is technically possible to configure a Enhanced Transition Mode with Wi-Fi 7, but to comply to the standards, it is recommended to configure a pure OWE only WLAN for Wi-Fi 7 operation in 6 GHz band.

Note: Because Wi-Fi 7 is still a recent certification at the time of this writing, with an as early as possible release, many vendors did not enforce all these security requirements from the beginning.

The table below provides the security requirements for different Wi-Fi standards.

Table 1. Security requirements for different Wi-Fi standards

Legacy (Wi-Fi 5)	Wi-Fi 6	Wi-Fi 6E (6 GHz)	Wi-Fi 7
Open	Open (OWE support required)	Enhanced Open (AKM: OWE) (Cipher: CCMP128)	Enhanced Open (AKM: OWE) (Cipher: CCMP128 and GCMP256)
WPA1/WPA2/WPA3 Transition WPA3-Personal, PMF Optional	WPA2/WPA3 Transition/WPA3-Personal, PMF Optional (WPA2 – AKM – PSK, FT+PSK, PSK (SHA-256)) (WPA3 – AKM – SAE, FT+SAE) (Cipher: CCMP128 or AES)	WPA3-Personal, PMF Mandatory (AKM: SAE, FT+SAE) (Cipher: CCMP128 or AES)	WPA3-Personal, PMF Mandatory (AKM: SAE-EXT-KEY, FT- SAE-EXT-KEY) (Cipher: CCMP128 and GCMP256)
WPA1/WPA2/WPA3 Transition/WPA3-802.1X (Enterprise), PMF Optional	WPA2/WPA3 Transition/WPA3-802.1X (Enterprise), PMF Optional (AKM 802.1X, FT+802.1X, and 802.1X-SHA256, 802.1X-SuiteB) (Cipher: AES, CCMP128, GCMP128, GCMP256)	WPA3 Enterprise, PMF Mandatory (AKM: FT+802.1X, 802.1X- SHA256, 802.1X-SuiteB) (Cipher: AES, CCMP128, GCMP128, and GCMP256)	WPA3 Enterprise, PMF Mandatory (AKM: FT+802.1X, 802.1X- SHA256, 802.1X-SuiteB) (Cipher: AES, CCMP128, GCMP128, and GCMP256)

Required Software Versions

- For WPA3-Personal SAE hash-to-element method for password element generation - minimum software version 17.7.1 should be used.

- For WPA3-Enterprise and WPA3-Personal Transition disabled - minimum software version 17.7.1 should be used.
- For WPA3-Personal with SAE as AKM + Fast Transition (FT) - minimum software version 17.9 should be used.
- For WPA-Personal with SAE-EXT-KEY and FT-SAE-EXT-KEY for Wi-Fi 7 - minimum software version 17.15.2 should be used.

More recently, Cisco has been progressively enforcing the configuration options to be compliant with the Wi-Fi 7 certification. Here are the version-specific behaviors:

IOS XE 17.15.3 and later 17.15.x versions

In this software release, all the WLANs are broadcasted as Wi-Fi 7 SSIDs, provided that Wi-Fi 7 is enabled globally and regardless of the security settings.

A client can associate as Wi-Fi 7 capable and achieve Wi-Fi 7 data rates regardless of the security method it uses, provided it's still supported by the WLAN. However, the client can only associate as MLO capable (on one or more bands) if it respects the strict requirements for Wi-Fi 7 security, or else it is rejected.

4. This could potentially cause issues when some early Wi-Fi 7 clients unable to support more secure ciphers, like GCMP256, try to associate as Wi-Fi 7 MLO capable to a WLAN, whose security settings do not match the Wi-Fi 7 requirements. In such a situation, the client is rejected because of the invalid security settings (still allowed to be configured under the WLAN).

Cisco Device Compatibility

Table 2. Cisco® Catalyst® 9800 Series Wireless Controller WPA3 support matrix

9800-L-F	9800-L-C	9800-L	9800-40	9800-80
Yes, starting with 16.12.1s				

Table 3. Catalyst 9100 Access Points WPA3 support matrix

9105AX	9115AX	9117AX	9120AX	9130AX	9124AXE	9136AX	9166/9164/9162
Yes*	Yes*	Yes*	Yes*	Yes	Yes	Yes	Yes


*SuiteB192-1X is not supported

The purpose of this deployment guide is to provide details of the different WPA3 modes and steps to configure them on the Cisco Catalyst 9800 Series controller, using either the GUI or the Command-Line Interface (CLI).

WPA3-Enterprise

WPA3-Enterprise builds upon the foundation of WPA2-Enterprise with the additional requirement of using Protected Management Frames on all WPA3 connections with 802.1X for user authentication with a RADIUS server. By default, WPA3 uses 128-bit encryption, but it also introduces an optionally configurable SuiteB-192 bit cryptographic strength encryption using GMCP-256, which gives additional protection to any network transmitting sensitive data. The WPA3-Enterprise is highly preferred and recommended to be used and commonly seen in enterprises, financial institutions, government, and other market sectors where network security is most critical.

Figure 2. WPA3-Enterprise Endpoint and Network Handshake Process




WPA3-Enterprise GUI Configuration

The following steps create a WLAN with WPA3-Enterprise security:

1. Choose Configuration > Tags and Profiles > WLANs.
2. Click **Add**.
3. In the **General** tab, enter the **Profile Name** (friendly identifier). Both the SSID and WLAN ID are populated automatically.
4. Enable the **Status** and **Broadcast SSID** toggle buttons to have APs associated with this profile begin broadcasting this configured WLAN.

Figure 3. Radio/Slot Configuration




5. Click the **Security** tab > **Layer 2** tab. From the **Layer 2 Security Mode** drop-down list, choose **WPA3**.
6. Confirm that the **PMF** is set to **Required**.

Figure 4. WLAN Security Configurations

The screenshot shows the WLAN Security Configurations interface with the following tabs: General, **Security**, Advanced, and Add To Policy Tags. The **Security** tab is selected, and the **Layer2** tab is active. The **AAA** tab is also visible. A note at the top right of the **Security** tab area says: "⚠ To review the necessary considerations for ensuring WLAN compatibility with Wi-Fi 7 security [click here](#)." Below this note are five radio buttons for selecting a security mode: WPA + WPA2, WPA2 + WPA3, **WPA3**, Static WEP, and None. The **WPA3** option is selected. Under the **Layer2** tab, there are two checkboxes: MAC Filtering and Lobby Admin Access, both of which are unselected (unchecked). The **WPA Parameters** section contains three pairs of checkboxes: WPA Policy (unchecked), WPA2 Policy (unchecked); GTK Randomize (unchecked), WPA3 Policy (checked); and Transition Disable (unchecked), Beacon Protection (unchecked). The **WPA2/WPA3 Encryption** section contains four pairs of checkboxes: AES(CCMP128) (checked), CCMP256 (unchecked); GCMP128 (unchecked), GCMP256 (unchecked). The **Protected Management Frame** section contains three input fields: PMF (set to Required), Association Comeback Timer* (set to 1), and SA Query Time* (set to 200). The **Fast Transition** section contains three fields: Status (set to Disabled), Over the DS (unchecked), and Reassociation Timeout* (set to 20). The **Auth Key Mgmt (AKM)** section contains four pairs of checkboxes: FT + 802.1X (unchecked), 802.1X-SHA256 (checked); OWE (unchecked), SAE (unchecked); FT + SAE (unchecked), SAE-EXT-KEY (unchecked); and FT + SAE-EXT-KEY (unchecked), SAE-EXT-KEY (unchecked).

7. Check the **WPA3 Policy**, **AES**, and **802.1X-SHA256** check boxes, then unselect any other selected parameters.
8. Click the **Security** tab and click the **AAA** tab and from the **Authentication List** drop-down list, choose the preconfigured RADIUS Server Authentication List.

Figure 5. WLAN AAA Configuration



9. Click **Apply to Device** to save and finish the WLAN creation process.

WPA3-Enterprise CLI Configuration

The following steps create a WLAN with WPA3-Enterprise security:

Table 4. WPA3-Enterprise CLI Configuration

	Command	Purpose
Step 1	configure terminal	Enters global configuration mode.
Step 2	wlan wlan-name wlan-id SSID-name Example: Device(config)# wlan WPA3-Enterprise 8 WPA3-Enterprise	Enters the WLAN configuration sub-mode.
Step 3	no security wpa akm dot1x	Disables Security Auth Key Management (AKM) 802.1X-SHA1.
Step 4	no security wpa wpa2	Disables WPA2 security.
Step 5	security wpa akm dot1x-sha256	Enables Security Auth Key Management

	Command	Purpose
		(AKM) 802.1X-SHA2.
Step 6	security wpa wpa3	Enables WPA3 support.
Step 7	no security ft adaptive	Disables FT adaptive.
Step 7	security dot1x authentication-list list-name Example: Device(config-wlan)# security dot1x authentication-list dot1x	Configures security authentication list for 802.1X security.
Step 8	no shutdown	Enables the WLAN.
Step 9	end	Returns to the privileged EXEC mode.


WPA3-Enterprise 192-bit GUI Configuration (optional)

For endpoints that support SuiteB192-1X encryption, refer to the client interoperability matrix section below, or reach out to the device vendor.

The following steps create a WLAN with 192-bit WPA3-Enterprise security:


1. Choose Configuration > Tags and Profiles > WLANs.
2. Click **Add**.
3. In the **General** tab, enter the **Profile Name** (friendly identifier). Both the SSID and WLAN ID are populated automatically.
4. Enable the **Status** and **Broadcast SSID** toggle buttons to have APs associated with this profile begin broadcasting this configured WLAN.

Figure 6. Radio/Slot Configuration




5. Click the **Security > Layer 2** tab. From the **Layer 2 Security Mode** drop-down list, choose **WPA3**.
6. Confirm that the **PMF** is set to **Required**.
7. Disable Fast Transition.
8. Check the **WPA3 Policy**, **GCMP256**, and **SUITEB192-1X** check boxes, then unselect any other selected parameters.

Figure 7. WLAN Security, Encryption and AKM Configuration



- Click the **Security** tab and click the **AAA** tab and from the **Authentication List** drop-down list, choose the preconfigured RADIUS Server Authentication List.

Figure 8. Security AAA Method List Configuration



10. Click **Apply to Device** to save and finish the WLAN creation process.

Note: SuiteB192-1X is not supported in C9120/C9105/C9115 APs and in FlexConnect Mode.

WPA3-Enterprise 192-bit CLI Configuration (optional)

The following steps create a WLAN with 192-bit WPA3-Enterprise security:

Table 5. WPA3-Enterprise 192-bit encryption CLI configuration

	Command or action	Purpose
Step 1	configure terminal	Enters global configuration mode.
Step 2	wlan <wlan-name> wlan-id <SSID-name> Example: Device(config)# wlan WPA3-Enterprise-192B 8 WPA3-Enterprise-192B	Enters the WLAN configuration sub-mode.
Step 3	no security ft adaptive	Disables Fast Transition Adaptive support.
Step 4	no security wpa wpa2	Disables WPA2 security.
Step 5	no security wpa wpa2 ciphers aes	Disables WPA2/CCMP128 support.

	Command or action	Purpose
Step 6	security wpa wpa2 ciphers gcmp256	Enables GCMP256 support.
Step 7	no security wpa akm dot1x	Disables security AKM 802.1X-SHA1 support.
Step 8	security wpa wpa3	Enables WPA3 support.
Step 9	security dot1x authentication-list list-name Example: Device (config-wlan) # security dot1x authentication-list dot1x	Configures security authentication list for 802.1X security.
Step 10	no shutdown	Enables the WLAN.
Step 11	end	Returns to the privileged EXEC mode.

WPA3-Enterprise Transition Mode

The WPA3-Enterprise Transition Mode, also known as WPA3+WPA2-Enterprise mixed-mode configuration, is used when some clients can support only up to WPA2 and some clients can support up to WPA3. The WPA3-capable clients will use WPA3-Enterprise's 802.1X-SHA256 AKM, while the WPA2-capable clients can use WPA2-Enterprise's 802.1X SHA1 or 802.1X-SHA256. This mode applies to both the bands 2.4 GHz and 5 GHz.

Note: This mode should be used only when necessary. For maximum security, the recommended mode is to use only WPA3 and not a mix of WPA3 and WPA2. Some older devices (like Wi-Fi 5) may not support transition method and may not be able to associate.

Note: Per 6 GHz standard, broadcasting a WLAN in the 6-GHz band is not allowed when configured with WPA2 security (applies to both WPA2 only and WPA2+WPA3 WLAN), so this essentially leads to the behavior that we don't support 6-GHz radio when WLAN is configured with WPA2.

This poses limitations in certain use cases when legacy clients want to support 802.1X-SHA1 along with PMF optional in 5-GHz on the same SSID, whereas 6-GHz clients support 802.1X-SHA256 AKM with PMF mandatory.

To support these deployments, the recommendation in pre-17.12.1 SW versions was to use WPA2+WPA3 transition mode with the same WLAN with different profiles to support both legacy and the latest 6-GHz clients. The challenge with this design is roaming. The roaming between bands in this configuration is not supported, and it is always full roam, which is not preferred.

Starting from 17.12.1, we support transition mode with pure WPA3 for the 6-GHz band, which allows users to enable WPA2+WPA3 in the same WLAN with 6 GHz. This mode eliminates the need to create two different profiles to accommodate legacy and the latest 6-GHz devices. In this mode, the WPA2+WPA3 transition mode can be used in 2.4-GHz/5-GHz, and only WPA3 relevant configurations will be pushed on the 6-GHz band when WLAN has both WPA2 & WPA3 configurations.

WPA3-Enterprise Transition Mode GUI Configuration

The following steps create a WLAN with WPA3+WPA2-Enterprise mixed-mode-level security:

1. Choose Configuration > Tags and Profiles > WLANs.
2. Click **Add**.
3. In the **General** tab, enter the **Profile Name** (friendly identifier). The SSID and WLAN ID are populated automatically.
4. Enable the **Status** and **Broadcast SSID** toggle buttons to have APs associated with this profile begin broadcasting this configured WLAN.
5. Starting 17.12, 6-GHz Radio Policy will be enabled, for a WPA3-Enterprise Transition Mode with only WPA3 broadcasted in the 6 GHz band.

Figure 9. Radio/Slot Policy Configuration

General		Security	Advanced
Profile Name*	wpa3enttrans	Radio Policy ⓘ	
SSID*	wpa3enttrans	Show slot configuration	
WLAN ID*	6	6 GHz	
Status	ENABLED	Status	ENABLED
Broadcast SSID	ENABLED	WPA3 Enabled	
		Dot11ax Enabled	
		5 GHz	
		Status	ENABLED
		2.4 GHz	
		Status	ENABLED
		802.11b/g Policy	802.11b/g ▾

6. Click the **Security > Layer 2** tab. From the **Layer 2 Security Mode** drop-down list, choose **WPA3**.
7. Confirm that the **PMF** is set to **Optional**.

Figure 10. Security, Encryption and AKM Configuration

General
Security
Advanced
Add To Policy Tags

Layer2
Layer3
AAA

⚠ To review the necessary considerations for ensuring WLAN compatibility with Wi-Fi 7 security [click here](#).

WPA + WPA2
 WPA2 + WPA3
 WPA3
 Static WEP
 None

MAC Filtering
Lobby Admin Access

WPA Parameters
Fast Transition

WPA Policy
WPA2 Policy
Status

GTK Randomize
WPA3 Policy
Over the DS

Transition Disable
Beacon Protection
Reassociation Timeout *

WPA2/WPA3 Encryption
Auth Key Mgmt (AKM)

AES(CCMP128)
CCMP256
802.1X
FT + 802.1X

GCMP128
GCMP256
802.1X-SHA256
CCKM ⚠

Protected Management Frame
PSK

PMF
PSK
FT + PSK

Association Comeback Timer*
PSK-SHA256
SAE

SA Query Time*
FT + SAE
SAE-EXT-KEY

FT + SAE-EXT-KEY
FT + 802.1X

8. Scroll down to the WPA Parameters. Check the **WPA2 Policy**, **WPA3 Policy**, and **Encryption AES**, and check the **802.1X** and **802.1X-SHA256** check boxes.
9. Click **Apply to Device** to save and finish the WLAN creation process.

WPA3-Enterprise Transition Mode CLI Configuration

The following steps create a WLAN with WPA3+WPA2-Enterprise mixed-mode-level security:

Table 6. WPA3-Enterprise Transition Mode CLI Configuration

	Command	Purpose
Step 1	configure terminal	Enters global configuration mode.
Step 2	wlan wlan-name wlan-id SSID-name Example: Device (config)# wlan WPA3+WPA2-Enterprise 8 WPA3+WPA2-Enterprise	Enters the WLAN configuration submode.
Step 3	security wpa wpa3	Enables WPA3.
Step 4	Security wpa wpa2	Enables WPA2.
Step 5	security wpa akm dot1x-sha256	Enables the 802.1X SHA2 AKM.
Step 6	radio policy dot11 24ghz	Enables the 2.4-GHz band.
Step 7	radio policy dot11 5ghz	Enables the 5-GHz band.
Step 8	no shutdown	
Step 9	end	

Note: This security combination can be used with FT-enabled mode as well.


WPA3-Personal

WPA3-Personal uses 128-bit (AES) or 256-bit (GCMP256) cryptographic-strength encryption with a password-based authentication method through SAE for user authentication purposes. In addition, unlike WPA2-Personal, WPA3-Personal heightens network security against offline dictionary attacks by limiting password guesses. This requirement makes hacking into a network much more time-consuming and dissuades attempts at a brute force attack.

WPA3-Personal provides the following key advantages:

- Creates a shared secret that is different for each SAE authentication
- Protects against brute force “dictionary” attacks and passive attacks
- Provides forward secrecy

Figure 11. WPA3-Personal Endpoint and Network Handshake Process




WPA3-Personal GUI Configuration

The following steps create a WLAN with WPA3-Personal-level security:


1. Choose **Configuration > Tags and Profiles > WLANs**.
2. Click **Add**.
3. In the **General** tab, enter the **Profile Name** (friendly identifier). The SSID and WLAN ID are populated automatically.
4. Enable the **Status** and **Broadcast SSID** toggle buttons to have APs associated with this profile begin broadcasting this configured WLAN.

Figure 12. WPA3 Personal Radio/Slot Configuration



5. Click the **Security > Layer 2** tab. From the **Layer 2 Security Mode** drop-down list, choose **WPA3**.
6. Confirm that the **PMF** is set to **Required**.
7. Disable Fast Transition.
8. Scroll down to the WPA Parameters. Check the **WPA3 Policy**, **AES**, and **SAE** check boxes.
9. Enter the **Pre-Shared Key** and from the **PSK Format** drop-down list, choose the **PSK format** and from the **PSK Type** drop-down list, choose the **PSK type**.

Figure 13. WPA3 SAE AKM Configuration



10. Click **Apply to Device** to save and finish the WLAN creation process.

Note: If only the 6-GHz band is used, the SAE Password Element supported is Hash to Element (H2E). Hunting and Pecking (HnP) cannot be used in a 6 GHz-only network. If both 5 GHz and 2.4 GHz are used, H2E and HnP can be used as the SAE Password Element. IOS-XE 17.12 version takes care of only using H2E in 6 GHz band.

WPA3-Personal CLI Configuration

The following steps create a WLAN with WPA3-Personal-level security:

Table 7. WPA3-Personal CLI configuration


	Command	Purpose
Step 1	configure terminal	Enters global configuration mode.
Step 2	wlan wlan-name wlan-id SSID-name Example: Device(config)# wlan WPA3-Personal 8 WPA3-Personal	Enters the WLAN configuration sub-mode.
Step 3	no security wpa akm dot1x	Disables security AKM 802.1X.
Step 4	no security ft over-the-ds	Disables Fast Transition over the data source on the WLAN.
Step 5	no security ft	Disables 802.11r Fast Transition on the WLAN.
Step 6	no security wpa wpa2	Disables WPA2 security. PMF is disabled now.
Step 7	security wpa wpa2 ciphers aes	Enables Advanced Encryption Standard (AES)/CCMP128 ciphers.
Step 8	security wpa psk set-key ascii value preshared-key Example: Device(config-wlan)# security wpa psk set-key ascii 0 Cisco123	Specifies a preshared key.
Step 9	security wpa wpa3	Enables WPA3 support. Note: If both WPA2 and WPA3 are supported (SAE and PSK together), it is optional to configure PMF. However, you cannot disable PMF. For WPA3, PMF is mandatory.
Step 10	security wpa akm sae	Enables AKM SAE support.
Step 11	security wpa akm sae pwe h2e/hnp/both	Chooses the Password Element.
Step 12	no shutdown	Enables the WLAN.
Step 13	End	Returns to the privileged EXEC mode.

WPA3-Personal SAE Hash-to-Element Method for Password Element Generation

The following steps will create a WLAN with WPA3-Personal-level security with H2E for password element generation:

1. Choose Configuration > Tags and Profiles > WLANs.
2. Click **Add**.
3. In the **General** tab, enter the **Profile Name** (friendly identifier). The SSID and WLAN ID are populated automatically.
4. Enable the **Status** and **Broadcast SSID** toggle buttons to have APs associated with this profile begin broadcasting this configured WLAN.
5. Click the **Security > Layer 2** tab. From the **Layer 2 Security Mode** drop-down list, choose **WPA3**.

Figure 14. Radio/Slot Policy Configuration



6. Confirm that the **PMF** is set to **Required**.
7. Disable Fast Transition.
8. Scroll down to the **WPA Parameters**. Check the **WPA3 Policy**, **AES**, and **SAE** check boxes.
9. Enter the **Pre-Shared Key** and then from the **PSK Format** drop-down list, choose the PSK format, and from the **PSK Type** drop-down list, choose the PSK type.

10. From the **SAE Password Element** drop-down list, enable **Hash to Element Only**.

Figure 15. Security and AKM Password Element Configuration

Add WLAN

Security

Layer2

WPA + WPA2 WPA2 + WPA3 WPA3 Static WEP None

MAC Filtering

Lobby Admin Access

WPA Parameters

WPA Policy WPA2 Policy
GTK Randomize WPA3 Policy
Transition Disable

Fast Transition

Status

Over the DS

Reassociation Timeout *

WPA2/WPA3 Encryption

AES(CCMP128) CCMP256
GCMP128 GCMP256

Protected Management Frame

PMF

Association Comeback Timer*

SA Query Time*

Auth Key Mgmt

SAE FT + SAE
OWE FT + 802.1x
802.1x-SHA256

Anti Clogging Threshold*

Max Retries*

Retransmit Timeout*

PSK Format

PSK Type

Pre-Shared Key*

SAE Password Element

WPA3-Personal SAE Hash-to-Element Method for Password Element Generation CLI configuration

The following steps create a WLAN with WPA3-Personal-level security with H2E for password element generation:

Table 8. WPA3-Personal SAE hash-to-element CLI configuration

	Command	Purpose
Step 1	configure terminal	Enters global configuration mode.
Step 2	wlan wlan-name wlan-id SSID-name Example: Device(config)# wlan WPA3-Personal-H2E 1 WPA3- Personal-H2E	Enters the WLAN configuration submode.
Step 3	no security wpa akm dot1x	Disables security AKM 802.1X.
Step 4	security wpa wpa3	Enables WPA3.
Step 5	no security ft	Disables 802.11r Fast Transition on the WLAN.
Step 6	no security wpa wpa2	Disables WPA2 security. PMF is disabled now.
Step 7	security wpa wpa2 ciphers aes	Enables AES/CCMP128 ciphers.
Step 8	security wpa psk set-key ascii value preshared-key Example: Device(config-wlan)# security wpa psk set-key ascii 0 Cisco123	Specifies a preshared key.
Step 9	security wpa akm sae	Enables AKM SAE support.
Step 10	security wpa akm sae pwe h2e	Enables H2E for password element generation.
Step 11	no shutdown	Enables the WLAN.
Step 12	End	Returns to the privileged EXEC mode.


WPA3-Personal SAE with Fast Transition Enabled

Starting from Cisco IOS® XE version 17.9.1, WPA3-Personal SAE with Fast Transition (SAE-FT) is supported. Follow the instructions below to configure the WLAN for WPA3 SAE-FT.

The following steps create a WLAN with WPA3-Personal-level SAE security with Fast Transition enabled:

1. Choose Configuration > Tags and Profiles > WLANs.
2. Click **Add**.
3. In the **General** tab, enter the **Profile Name** (friendly identifier). The SSID and WLAN ID are populated automatically.
4. Enable the Status and Broadcast SSID toggle buttons to have APs associated with this profile begin broadcasting this configured WLAN.
5. Click the **Security > Layer 2** tab. From the **Layer 2 Security Mode** drop-down list, choose **WPA3**.
6. Confirm that the **PMF** is set to **Required**.
7. Enable Fast Transition.
8. Scroll down to the **WPA Parameters**. Check the **WPA3 Policy**, **AES**, and **SAE** check boxes.
9. Enter the **Pre-Shared Key** and from the **PSK Format** drop-down list, choose the **PSK format** and from the **PSK Type** drop-down list, choose the **PSK type**.
10. Enable **Hash to Element Only** or **HnP** or **both** from the SAE Password Element drop-down.

Figure 16. WPA3 SAE with FT Enabled



WPA3-Personal SAE with Fast Transition Enabled CLI Configuration

The following steps create a WLAN with WPA3-Personal-level security with Fast Transition enabled:

Table 9. WPA3-Personal SAE FT CLI configuration

	Command	Purpose
Step 1	configure terminal	Enters global configuration mode.

	Command	Purpose
Step 2	wlan wlan-name wlan-id SSID-name Example: Device(config)# wlan WPA3-Personal-H2E 1 WPA3-Personal-H2E	Enters the WLAN configuration sub-mode.
Step 3	no security wpa akm dot1x	Disables security AKM 802.1X.
Step 4	security wpa wpa3	Enables WPA3.
Step 5	security ft	Enables 802.11r Fast Transition on the WLAN.
Step 6	no security wpa wpa2	Disables WPA2 security. PMF is disabled now.
Step 7	security wpa wpa2 ciphers aes	Enables AES/CCMP128 ciphers.
Step 8	security wpa psk set-key ascii value preshared-key Example: Device(config-wlan)# security wpa psk set-key ascii 0 Cisco123	Specifies a preshared key.
Step 9	security wpa akm sae	Enables AKM SAE support.
Step 10	Security wpa akm ft sae	Enables FT SAE.
Step 11	no shutdown	Enables the WLAN.
Step 12	End	Returns to the privileged EXEC mode.

WPA3-Personal Transition Mode

The WPA3-Personal Transition Mode, also known as WPA2+WPA3-Personal mixed-mode configuration, is used when some clients are capable of supporting only WPA2 and some clients are capable of supporting up to WPA3. The WPA3-capable clients will use WPA3-Personal's SAE, while the WPA2-capable clients will use WPA2-Personal's PSK. This mode applies to both the bands of 2.4-GHz and 5-GHz. In IOS-XE 17.12, the same SSID in transition mode for 2.4 and 5 GHz bands and will be WPA3 only in 6 GHz band.

Note: This mode should be used only when necessary. For maximum security, the recommended mode is to use only WPA3 and not a mix of WPA3 and WPA2.

Note: Per 6-GHz standard, broadcasting a WLAN in the 6-GHz band is not allowed when configured with WPA2 security (applies to both WPA2 only and WPA2+WPA3 WLAN), so this essentially leads to behavior that we don't support 6-GHz radio when WLAN is configured with WPA2.

We do have use cases like 2.4-GHz/5-GHz that can be on PSK/SAE AKM with PMF optional and 6-GHz with SAE AKM for WPA3 on the same SSID, which is not a valid configuration pre-17.12.1.


To support these deployments, the recommendation in pre-17.12.1 SW versions were to use WPA2+WPA3 transition mode with the same WLAN with different profiles to support both legacy and the latest 6-GHz clients. The challenge with this design is roaming. The roaming b/w bands in this configuration are not supported and it is always full roam, which is not preferred.

Starting from 17.12.1, we are supporting transition mode with pure WPA3 for 6 GHz band, which allows users to enable WPA2+WPA3 in the same WLAN with 6-GHz. This mode eliminates the need to create two different profiles to accommodate legacy and the latest 6-GHz devices. In this mode, WPA2+WPA3 transition mode can be used in 2.4-GHz/5-GHz and only WPA3 relevant configs will be pushed on the 6-GHz band when WLAN has both WPA2 and WPA3 configurations.

The following steps create a WLAN with WPA3+WPA2-Personal mixed-mode-level security:

1. Choose Configuration > Tags and Profiles > WLANs.
2. Click **Add**.
3. In the **General** tab, enter the **Profile Name** (friendly identifier). The SSID and WLAN ID are populated automatically.
4. Enable the **Status** and **Broadcast SSID** toggle buttons to have APs associated with this profile begin broadcasting this configured WLAN.
5. Disable the **6-GHz** band.

Figure 17. Radio configuration for Transition Mode



6. Click the **Security > Layer 2 tab**. From the **Layer 2 Security Mode** drop-down list, choose **WPA3**.

7. Confirm that the **PMF** is set to **Optional**.

Figure 18. Security, Encryption and AKM Configuration

Add WLAN

General **Security** **Advanced**

Layer2 **Layer3** **AAA**

WPA + WPA2 WPA2 + WPA3 WPA3 Static WEP None

MAC Filtering

Lobby Admin Access

WPA Parameters

WPA Policy <input type="checkbox"/>	WPA2 Policy <input checked="" type="checkbox"/>
GTK Randomize <input type="checkbox"/>	WPA3 Policy <input checked="" type="checkbox"/>
Transition Disable <input type="checkbox"/>	

Fast Transition

Status <input type="button" value="Disabled"/>
Over the DS <input type="checkbox"/>
Reassociation Timeout * 20

WPA2/WPA3 Encryption

AES(CCMP128) <input checked="" type="checkbox"/>	CCMP256 <input type="checkbox"/>
GCMP128 <input type="checkbox"/>	GCMP256 <input type="checkbox"/>

Protected Management Frame

PMF <input type="button" value="Optional"/>
Association Comeback Timer* 1
SA Query Time* 200

Auth Key Mgmt

802.1x <input type="checkbox"/>	PSK <input checked="" type="checkbox"/>
CCKM <input type="checkbox"/>	SAE <input checked="" type="checkbox"/>
FT + SAE <input type="checkbox"/>	OWE <input type="checkbox"/>
FT + 802.1x <input type="checkbox"/>	FT + PSK <input type="checkbox"/>
802.1x-SHA256 <input type="checkbox"/>	

Anti Clogging Threshold* 1500
Max Retries* 5
Retransmit Timeout* 400

PSK Format <input type="button" value="ASCII"/>
PSK Type <input type="button" value="Unencrypted"/>
Pre-Shared Key* <input type="text" value="....."/> <input type="button" value=""/>
SAE Password Element <input type="button" value="Both H2E and HnP"/>

MPSK Configuration

Enable MPSK <input type="checkbox"/>

Cancel **Apply to Device**

8. Scroll down to the WPA Parameters. Check the **WPA2 Policy**, **WPA3 Policy**, **AES**, **PSK**, and **SAE** check boxes.

9. Enter the **Pre-Shared Key** and from the **PSK Format** drop-down list, choose the **PSK format** and from the **PSK Type** drop-down list, choose the **PSK type**.
10. Click **Apply to Device** to save and finish the WLAN creation process.

WPA3 Personal Transition Mode CLI Configuration

The following steps create a WLAN with WPA3+WPA2-Personal mixed-mode-level security:

Table 10. WPA3 Personal transition mode CLI configuration

	Command	Purpose
Step 1	configure terminal	Enters global configuration mode.
Step 2	wlan wlan-name wlan-id SSID-name Example: Device(config)# wlan WPA3+WPA2-Personal 1 WPA3+WPA2-Personal	Enters the WLAN configuration submode.
Step 3	no security wpa akm dot1x	Disables security AKM 802.1X.
Step 4	no security ft	Disables 802.11r Fast Transition on the WLAN.
Step 5	security wpa wpa2 ciphers aes	Configures the WPA2 cipher. Note: You can check whether the cipher is configured by using the no security wpa wpa2 ciphers aes command. If the cipher is not reset, configure the cipher.
Step 6	security wpa psk set-key ascii 0 Cisco123	Specifies a preshared key.
Step 7	security wpa wpa3	Enables WPA3 support. Note: If both WPA2 and WPA3 are supported (SAE and PSK together), it is optional to configure PMF. However, you cannot disable PMF. For WPA3, PMF is mandatory.
Step 8	security wpa akm sae	Enables AKM SAE support.
Step 9	security wpa akm psk	Enables AKM PSK support.
Step 10	radio policy dot11 24ghz	Enables the 2.4-GHz band.
Step 11	radio policy dot11 5ghz	Enables the 5-GHz band.
Step 12	no shutdown	Enables the WLAN.
Step 13	end	Returns to the privileged EXEC mode.

WPA2+WPA3-Personal Transition Mode with 6 GHz

Per 6-GHz standard, broadcasting a WLAN in the 6-GHz band is not allowed when configured with WPA2 security (applies to both WPA2 only and WPA2+WPA3 WLAN), so this essentially leads to behavior that we don't support 6-GHz radio when WLAN is configured with WPA2.

We do have use cases like 2.4-GHz/5-GHz that can be on PSK/SAE AKM with PMF optional and 6-GHz with SAE AKM for WPA3 on the same SSID, which is not a valid configuration pre-17.12.1.


To support these deployments, the recommendation in pre-17.12.1 SW versions were to use WPA2+WPA3 transition mode with the same WLAN with different profiles to support both legacy and the latest 6-GHz clients. The challenge with this design is roaming. The roaming b/w bands in this configuration are not supported and it is always full roam, which is not preferred.

Starting from 17.12.1, we are supporting transition mode with pure WPA3 for 6 GHz band, which allows users to enable WPA2+WPA3 in the same WLAN with 6-GHz. This mode eliminates the need to create two different profiles to accommodate legacy and the latest 6-GHz devices. In this mode, WPA2+WPA3 transition mode can be used in 2.4-GHz/5-GHz and only WPA3 relevant configs will be pushed on the 6-GHz band when WLAN has both WPA2 and WPA3 configurations.

WPA2+WPA3-Personal Transition Mode with 6 GHz GUI Configuration

1. Choose Configuration > Tags and Profiles > WLANs.
2. Click **Add**.
3. In the **General** tab, enter the **Profile Name** (friendly identifier). Both the **SSID** and **WLAN ID** are populated automatically.
4. Enable the **Status** and **Broadcast SSID** toggle buttons to have Access Points (APs) associated with this profile begin broadcasting this configured WLAN.

Figure 19. Radio/Slot Configuration



5. Click the **Security** tab > **Layer 2** tab. From the **Layer 2 Security Mode** drop-down list, choose **WPA3**.

6. Confirm that the PMF is set to Optional.

Note: Though PMF is optional, with WPA3 configuration, it will be considered required for the 6-GHz band.

Figure 20. Configuration

Add WLAN

General **Security** Advanced

Layer2 Layer3 AAA

WPA + WPA2
 WPA2 + WPA3
 WPA3
 Static WEP
 None

MAC Filtering

 Lobby Admin Access

WPA Parameters

WPA Policy <input type="checkbox"/>	WPA2 Policy <input checked="" type="checkbox"/>
GTK Randomize <input type="checkbox"/>	WPA3 Policy <input checked="" type="checkbox"/>
Transition Disable <input type="checkbox"/>	

Fast Transition

Status <input type="button" value="Disabled"/>
Over the DS <input type="checkbox"/>
Reassociation Timeout * <input type="text" value="20"/>

WPA2/WPA3 Encryption

AES(CCMP128) <input checked="" type="checkbox"/>	CCMP256 <input type="checkbox"/>
GCMP128 <input type="checkbox"/>	GCMP256 <input type="checkbox"/>

Protected Management Frame

PMF <input type="button" value="Optional"/>
Association Comeback Timer* <input type="text" value="1"/>
SA Query Time* <input type="text" value="200"/>

Auth Key Mgmt

802.1X <input type="checkbox"/>	PSK <input checked="" type="checkbox"/>
CCKM ⚠ <input type="checkbox"/>	SAE <input checked="" type="checkbox"/>
FT + SAE <input type="checkbox"/>	FT + 802.1X <input type="checkbox"/>
FT + PSK <input type="checkbox"/>	802.1X-SHA256 <input type="checkbox"/>
PSK-SHA256 <input type="checkbox"/>	
Anti Clogging Threshold* <input type="text" value="1500"/>	
Max Retries* <input type="text" value="5"/>	
Retransmit Timeout* <input type="text" value="400"/>	
PSK Format <input type="button" value="ASCII"/>	
PSK Type <input type="button" value="Unencrypted"/>	
Pre-Shared Key* <input type="text" value="....."/> ⚠	
SAE Password Element ⚠ <input type="button" value="Both H2E and..."/>	

MPSK Configuration

Enable MPSK <input type="checkbox"/>

7. Choose the **WPA2 & WPA3 Policy** in **WPA Parameters**, **AES(CCMP128)** in **WPA2/WPA3** encryption, and enable **PSK & SAE** check boxes, then unselect any other selected parameters.
8. Input the Shared key.
9. Click **Apply to Device** to save and finish the WLAN creation process.

WPA2+WPA3-Personal Transition Mode with 6 GHz CLI Configuration

The following steps create a WLAN with WPA3+WPA2-Personal transition mode with 6 GHz enabled:

Table 11. WPA2+WPA3 Transition mode with pure 6 GHz CLI configuration

	Command	Purpose
Step 1	configure terminal	Enters global configuration mode.
Step 2	wlan wlan-name wlan-id SSID-name Example: Device(config)# wlan WPA2+WPA3-PTM 1 WPA2+WPA3- PTM	Enters the WLAN configuration submode.
Step 3	no security wpa akm dot1x	Disables security AKM for 802.1X.
Step 4	no security ft	Disables 802.11r Fast Transition on the WLAN.
Step 5	security wpa wpa2 ciphers aes	Configures the WPA2 cipher. Note: You can check whether the cipher is configured by using the no security wpa wpa2 ciphers aes command. If the cipher is not reset, configure the cipher.
Step 6	security wpa psk set-key ascii 0 Cisco123	Specifies a preshared key.
Step 7	security wpa wpa3	Enables WPA3 support. Note: If both WPA2 and WPA3 are supported (SAE and PSK together), it is optional to configure PMF. However, you cannot disable PMF. For WPA3, PMF is mandatory.
Step 8	security wpa akm sae	Enables AKM SAE support.
Step 9	security wpa akm psk	Enables AKM PSK support.
Step 10	radio policy dot11 6ghz	Enables the 6-GHz band.
Step 11	radio policy dot11 24ghz	Enables the 2.4-GHz band.
Step 12	radio policy dot11 5ghz	Enables the 5-GHz band.
Step 13	no shutdown	Enables the WLAN.

	Command	Purpose
Step 14	end	Returns to the privileged EXEC mode.

WPA2+WPA3-Personal Transition Mode with 6 GHz CLI Output

```
#show wlan summary
Number of WLANs: 1
ID   Profile Name          SSID          Status 2.4GHz/5GHz
Security
6GHz Security
-----
1   WPA2+WPA3-PTM          WPA2+WPA3-PTM    UP      [WPA2 +
WPA3] [PSK] [SAE] [AES]
[WPA3] [SAE] [AES]
```

WPA3 Transition Mode Disable

Transition Disable is an indication from an AP to a STA, that the STA is to disable certain transition modes for subsequent connections to the AP's network.

Ease of network upgrade: WPA2 devices have been there for many years in Wi-Fi networks, so it was important to have a mode of deployment where both WPA2 and WPA3 devices can co-exist. This certainly helps Wi-Fi networks migrate gradually from WPA2 to WPA3-based networks. Wi-Fi Alliance has introduced the WPA3 Transition modes for both personal and enterprise networks. With transition mode enabled on SSID, both WPA2 and WPA3 supporting devices can connect simultaneously, thus paving the path for the gradual migration of the device eco-system from WPA2 to WPA3.

Transition Disable: With the above ease of network upgrade using transition mode comes the security challenge of WPA3 STAs (stations) undergoing downgrade attacks. The attackers can force WPA3 STAs to downgrade to use WPA2 and legacy security-vulnerable technologies. To circumvent this problem, the Wi-Fi alliance has introduced the “Transition Disable” indication, using which APs and network operators can update WPA3 STAs that the network is fully upgraded to support the most secured algorithm defined in a transition mode. The Transition Disable indication is used (in a 4-way handshake during association) to disable transition modes for that network on a STA, and therefore provide protection against downgrade attacks. STAs upon receiving this indication, shall disable certain transition modes for subsequent connections and will disallow association without negotiation of PMF.

An STA implementation might enable certain transition modes (and possibly other legacy security algorithms) in a network profile.

For example, a WPA3-Personal STA might by default enable WPA3-Personal transition mode in a network profile, which enables a pre-shared key (PSK) algorithm. However, when a network (fully) supports the most secure algorithm defined in a transition mode, it can use the Transition Disable indication to disable transition modes for that network on an STA, and therefore protect against downgrade attacks.

On one side, this is good for security, as it will migrate all client devices to WPA3 only as they join the transition mode WLAN, but if the network is composed of multiple physical locations, for example, some are set to WPA2, others to WPA3/WPA2 transition mode, this will cause the migrated clients to fail when moved to a location with WPA2 only.

This is a possible scenario for some large networks, with the same SSID covering different controllers/AP setups and with configurations not matching 100%. The largest example would be “eduroam”, which shares the same SSID name worldwide. Setting this could have serious issues for clients moving across different network providers, so please use this with care, and only if you can ensure the same security setting is set properly across all network locations.

This method is not generally recommended and should be enabled only when it is absolutely necessary.

Note: An AP that uses Transition Disable indication is not required to disable the corresponding transition mode(s) on its own BSS. For example, the APs in a WPA3-Personal network might use Transition Disable indication to ensure that all STAs that support WPA3-Personal are protected against downgrade attacks while still enabling WPA3-Personal transition mode on their BSS so that legacy STAs can connect.

Note: This method is not generally recommended and should be enabled only when it is absolutely necessary.

The below section explains how to enable Transition Disable in the WLAN.

WPA3-Enterprise Transition Mode Disable GUI Configuration

The following steps create a WLAN with WPA3-Enterprise security with Transition Disable:

1. Choose Configuration > Tags and Profiles > WLANs.
2. Click **Add**.
3. In the **General** tab, enter the **Profile Name** (friendly identifier). The SSID and WLAN ID are populated automatically.
4. Enable the **Status** and **Broadcast SSID** toggle buttons to have APs associated with this profile begin broadcasting this configured WLAN.

Figure 21. Radio Policy Configuration

Add WLAN

General Security Advanced

Profile Name* wpa3perstrans

SSID* wpa3perstrans

WLAN ID* 6

Status **ENABLED**

Broadcast SSID **ENABLED**

Radio Policy **i**

Show slot configuration

6 GHz

Status **ENABLED**

WPA3 Enabled
Dot11ax Enabled

5 GHz


Status **ENABLED**

2.4 GHz

Status **ENABLED**


802.11b/g Policy

Cancel Apply to Device



- Starting 17.12, 6-GHz Radio Policy will be enabled, for a WPA3-Enterprise Transition Mode with only WPA3 broadcast in the 6 GHz band. Check the **Security** tab and enable the **WPA2 + WPA3** option.
- Scroll down to the WPA Parameters. Check the **WPA2** and **WPA3 Policy**, **AES**, and **802.1X** and **802.1X-SHA256** check boxes as AKM.
- Confirm that the PMF is set to be **Optional**.
- Enable **Transition Disable** under WPA Parameters.

Figure 22. Security, Encryption and AKM Configurations



WPA3-Enterprise Transition Mode Disable CLI Configuration

Table 12. WPA3-Enterprise Transition Mode Disable CLI Configuration

	Command	Purpose
Step 1	configure terminal	Enters global configuration mode.
Step 2	wlan wlan-name wlan-id SSID-name Example:	Enters the WLAN configuration submode.

	Command	Purpose
	Device(config) # wlan WPA3-Enterprise-TMD 1 WPA3-Enterprise-TMD	
Step 3	security wpa wpa3	Enables WPA3.
Step 4	security wpa wpa2	Enables WPA2 security. PMF is optional now.
Step 5	security wpa wpa2 ciphers aes	Enables Advanced Encryption Standard (AES)/CCMP128 ciphers.
Step 6	security wpa akm dot1x-sha256	Enables AKM 802.1x-SHA256.
Step 7	transition-disable	Enables Transition Disable.
Step 8	radio policy dot11 5ghz	Enables the 5-GHz band.
Step 9	radio policy dot11 24ghz	Enables the 2.4-GHz band.
Step 10	no shutdown	Enables the WLAN.
Step 11	end	Returns to the privileged EXEC mode.


Note: This security combination can be used with FT enabled mode as well.

WPA3-Personal Transition Mode Disable GUI Configuration

The following steps create a WLAN with WPA3-Personal-level security with Transition Disable:

1. Choose Configuration > Tags and Profiles > WLANs.
2. Click **Add**.
3. In the **General** tab, enter the **Profile Name** (friendly identifier). The SSID and WLAN ID are populated automatically.
4. Enable the **Status** and **Broadcast SSID** toggle buttons to have APs associated with this profile begin broadcasting this configured WLAN.

Figure 23. Radio/Slot Configuration for Transition Disable Mode



5. Disable the **6 GHz** band.
6. Under the **Security tab**, enable the **WPA2+WPA3** option.
7. Disable Fast Transition.
8. Scroll down to the **WPA Parameters**. Check the **WPA2** and **WPA3 Policy**, **AES**, and **SAE** and **PSK** check boxes as AKM.
9. Enter the **Pre-Shared Key** and from the **PSK Format** drop-down list, choose the **PSK format** and from the **PSK Type** drop-down list, choose the **PSK type**.
10. Confirm that the **PMF** be **Optional**.
11. Enable the **Transition Disable** option in WPA Parameters.

Figure 10-10 Edit WLAN

⚠ Changing WLAN parameters while it is enabled will result in loss of connectivity for clients connected to it.

General Security Advanced Add To Policy Tags

Layer2 Layer3 AAA

WPA + WPA2 WPA2 + WPA3 WPA3 Static WEP None

MAC Filtering

Lobby Admin Access

WPA Parameters

WPA Policy <input type="checkbox"/>	WPA2 Policy <input checked="" type="checkbox"/>
GTK Randomize <input type="checkbox"/>	WPA3 Policy <input checked="" type="checkbox"/>
Transition Disable <input checked="" type="checkbox"/>	

WPA2/WPA3 Encryption

AES(CCMP128) <input checked="" type="checkbox"/>	CCMP256 <input type="checkbox"/>
GCMP128 <input type="checkbox"/>	GCMP256 <input type="checkbox"/>

Protected Management Frame

PMF	Optional
Association Comeback Timer*	1
SA Query Time*	200

Fast Transition

Status	Disabled
Over the DS	<input type="checkbox"/>
Reassociation Timeout *	20

Auth Key Mgmt

802.1X <input type="checkbox"/>	PSK <input checked="" type="checkbox"/>
CCKM <input type="checkbox"/>	SAE <input checked="" type="checkbox"/>
FT + 802.1X <input type="checkbox"/>	FT + SAE <input type="checkbox"/>
802.1X-SHA256 <input type="checkbox"/>	FT + PSK <input type="checkbox"/>
PSK-SHA256 <input type="checkbox"/>	
Anti Clogging Threshold* 1500	
Max Retries* 5	
Retransmit Timeout* 400	
PSK Format ASCII	
PSK Type Unencrypted	
Pre-Shared Key*	
SAE Password Element Both H2E and...	

MPSK Configuration

Enable MPSK <input type="checkbox"/>

WPA3-Personal Transition Mode Disable CLI Configuration

Table 13. WPA3-Personal transition mode disable CLI configuration


	Command	Purpose
Step 1	configure terminal	Enters global configuration mode.
Step 2	wlan wlan-name wlan-id SSID-name Example: Device (config) # wlan WPA3-Personal-TMD 1 WPA3-Personal-TMD	Enters the WLAN configuration sub-mode.
Step 3	no security wpa akm dot1x	Disables security AKM 802.1X.
Step 4	security wpa wpa3	Enables WPA3.
Step 5	no security ft	Disables 802.11r Fast Transition on the WLAN.
Step 6	security wpa wpa2	Enables WPA2 security. PMF is optional now.
Step 7	security wpa wpa2 ciphers aes	Enables AES/CCMP128 ciphers.
Step 8	security wpa psk set-key ascii value preshared-key Example: Device (config-wlan) # security wpa psk set-key ascii 0 Cisco123	Specifies a preshared key.
Step 9	security wpa akm sae	Enables AKM SAE support.
Step 10	security wpa akm psk	Enables AKM PSK.
Step 11	transition-disable	Enables Transition Disable.
Step 11	radio policy dot11 24ghz	Enables 2.4-GHz.
Step 12	radio policy dot11 5ghz	Enables 5-GHz.
Step 13	no shutdown	Enables the WLAN.
Step 14	End	Returns to the privileged EXEC mode.

OWE

OWE is a security method paired with an open-security wireless network to provide it with encryption to protect the network from eavesdroppers. With OWE, the client and AP perform a Diffie-Hellman key exchange during the endpoint association packet exchange and use the resulting PMK to conduct the 4-way handshake. Being

associated with open-security wireless networks, OWE can be used with regular open networks as well as those associated with captive portals.

Figure 25. OWE Endpoint and Network Handshake Process



Please refer to the following doc, which details the call flows with packet captures of the association process.


<https://www.cisco.com/c/en/us/support/docs/wireless/catalyst-9800-series-wireless-controllers/220712-configure-and-verify-wi-fi-6e-wlan-layer.html>

WPA3 OWE GUI Configuration

The following steps create a WLAN with WPA3 OWE security:


1. Choose Configuration > Tags and Profiles > WLANs.
2. Click **Add**.
3. In the **General** tab, enter the **Profile Name** (friendly identifier). The SSID and the WLAN ID will be populated automatically.
4. Enable the **Status** and **Broadcast SSID** toggle buttons.

Figure 26. WPA3 OWE Radio/Slot Configuration



5. Click the **Security > Layer 2** tab. From the Layer 2 Security Mode drop-down list, choose WPA3.
6. From the **Fast Transition** drop-down list, select **Disabled**.

Figure 27. OWE AKM Configuration



7. Check the **WPA3 Policy**, **AES (CCMP 128)**, and **OWE** check boxes. Uncheck any other selected parameters.
8. Click **Apply to Device** to save and finish the WLAN creation process.

WPA3 OWE CLI Configuration

These steps create a WLAN with WPA3 OWE security:

Table 14. WPA3 OWE CLI configuration

	Command	Purpose
Step 1	configure terminal Example:	Enters global configuration mode.

	Command	Purpose
	Device# configure terminal	
Step 2	wlan wlan-name wlan-id SSID-name Example: Device(config)# wlan WPA3 1 WPA3	Enters the WLAN configuration sub-mode.
Step 3	no security ft	Disables 802.11r Fast Transition on the WLAN.
Step 4	no security wpa akm dot1x	Disables security AKM for 802.1X.
Step 5	no security wpa wpa2	Disables WPA2 security. PMF is disabled now.
Step 6	security wpa wpa2 ciphers aes	Enables WPA2 ciphers for AES. Note: The ciphers for WPA2 and WPA3 are common.
Step 7	security wpa wpa3	Enables WPA3 support.
Step 8	security wpa akm owe	Enables WPA3 OWE support.
Step 9	no shutdown	Enables the WLAN.
Step 10	End	Returns to the privileged EXEC mode.

WPA3 OWE Transition Mode GUI Configuration


The Transition mode was introduced to the public since not all devices support enhanced open capability (refer to the device interoperability matrix). Transition mode is designed to make the enhanced open OWE mode more adaptable. The Wi-Fi Alliance recommends using this strategy to implement an enhanced open wireless network in an environment where not all devices support this mode. The OWE Transition mode requires a separate open SSID configured with properties similar to those of the enhanced open OWE SSID. Both OWE and open WLAN have a corresponding Transition mode WLAN ID, which means that the OWE WLAN has a Transition mode ID set to the open WLAN ID, and the open WLAN has a Transition mode ID set to the OWE WLAN ID.

Note: This is not recommended for Wi-Fi 6E (6 GHz) and Wi-Fi 7 operation as it's not supported and as of Wi-Fi 7.

Part 1: The following steps create a hidden WLAN with WPA3 OWE security:


1. Choose Configuration > Tags and Profiles > WLANs.
2. Click **Add**.
3. In the **General** tab, enter the **Profile Name** (friendly identifier). The SSID and WLAN ID are populated automatically.
4. Disable the **Status** and **Broadcast SSID** toggle buttons.
5. Note the **WLAN ID** of the **WLAN**.

Figure 28. Radio Policy for OWE



6. Click the **Security > Layer 2** tab. From the **Layer 2 Security Mode** drop-down list, choose **WPA3**.
7. Confirm that the **PMF** is set to **Required**.
8. From the **Fast Transition** drop-down list, select **Disabled**.
9. Check the **WPA3 Policy**, **AES (CCMP 128)**, and **OWE** check boxes. Uncheck any other selected parameters.
10. Enter the **Transition mode WLAN ID**, which will be the WLAN ID of the SSID that will be configured next.

Figure 29. OWE with Transition Mode ID Configuration



11. Click **Apply to Device** to save and finish the WLAN creation process.

Part 2: The following steps create a WLAN with open security:

1. Choose Configuration > Tags and Profiles > WLANs.
2. Click **Add**.
3. In the **General** tab, enter the **Profile Name** (friendly identifier).
4. The **SSID** must match the enhanced open SSID. The **WLAN ID** is populated automatically.
5. Enable the **Status** and **Broadcast SSID** toggle buttons.

Figure 30. WLAN Open Security Configuration

Add WLAN


General **Security** **Advanced**

Profile Name*	Open-OWE	Radio Policy i
SSID*	Open-OWE	Show slot configuration
WLAN ID*	2	6 GHz
Status	ENABLED	Status DISABLED
Broadcast SSID	ENABLED	5 GHz
		Status ENABLED
		2.4 GHz
		Status ENABLED
		802.11b/g Policy

Cancel **Apply to Device**

6. Click the **Security > Layer 2** tab. From the **Layer 2 Security Mode** drop-down list, choose **WPA3**.

Figure 31. OWE Transition Mode Configuration



- For the **Transition Mode WLAN ID**, enter the **WLAN ID** that has Layer 2 security set to **Enhanced Open** to be mapped to the open WLAN.
- Click **Apply to Device** to save and finish the WLAN creation process.

WPA3 OWE Transition Mode CLI Configuration

Part1: The following steps create a hidden WLAN with WPA3 OWE security:

Table 15. WPA3 OWE transition mode CLI configuration

	Command	Purpose
Step 1	configure terminal	Enters global configuration mode.
Step 2	wlan wlan-name wlan-id SSID-name Example: Device(config) # wlan WPA3-OWE-Hidden 1 WPA3-OWE-Hidden	Enters the WLAN configuration sub-mode.
Step 3	no broadcast-ssid	Disables SSID broadcast.
Step 4	no security ft	Disables 802.11r Fast Transition on the WLAN.

	Command	Purpose
Step 5	no security wpa akm dot1x	Disables security AKM for 802.1X.
Step 6	no security wpa wpa2	Disables WPA2 security. PMF is disabled now.
Step 7	security wpa akm owe	Enables WPA3 OWE support.
Step 8	security wpa transition-mode-wlan-id 2	Enables Transition mode.
Step 9	security wpa wpa3	Enables WPA3 support.
Step 10	no shutdown	Enables the WLAN.
Step 11	End	Returns to the privileged EXEC mode.

Part 2: The following steps create a WLAN with open OWE security:

	Command	Purpose
Step 1	configure terminal	Enters global configuration mode.
Step 2	wlan wlan-name wlan-id SSID-name Example: Device(config)# wlan Open-OWE 2 Open-OWE	Enters the WLAN configuration sub-mode. Note: The SSID of the hidden WLAN and the open WLAN must be the same.
Step 3	no security ft over-the-ds	Disables Fast Transition over the data source on the WLAN.
Step 4	no security ft	Disables 802.11r Fast Transition on the WLAN.
Step 5	no security wpa akm dot1x	Disables security AKM for 802.1X.
Step 6	no security wpa	Disables security.
Step 7	no security wpa wpa2 ciphers aes	Disables WPA2 ciphers for AES.
Step 8	security wpa transition-mode-wlan-id 1	Enables Transition mode.
Step 9	no shutdown	Enables the WLAN.
Step 10	end	Returns to the privileged EXEC mode.

Useful Catalyst 9800 Controller Commands

To view the system-level statistics for a client that has undergone successful SAE authentication, SAE authentication failures, SAE ongoing sessions, or SAE commits, and to confirm message exchanges, use the following show command:

```
show wireless stats client detail
```

To view the WLAN summary details, use the following command:

- show wlan summary
- show wlan all
- show wlan name <wlan-name>
- show wlan id {Starting 17.12.1, the security section on the WLAN is displayed individually for 2.4GHz/5GHz band and 6GHz band as below}

```
#show wlan id 1

WLAN Profile Name      : WPA2+WPA3-TransitionMode
=====
Identifier             : 1
Description            :
Network Name (SSID)   : WPA2+WPA3-TransitionMode
Status                 : Enabled
...
Security-2.4GHz/5GHz
...
Security-6GHz
...
#
```

To view the correct AKM for a client that has undergone SAE authentication, use the following command:

```
show wireless client mac-address <xxxx.xxxx.xxxx> detail
```

To view a list of the PMK cache stored locally:

```
show wireless pmk-cache
```

Useful Catalyst AP Commands

Configure debugging of WPA3 on a client by entering this command:

```
debug client client-mac-address
```

Configure debugging of SAE events and details by entering this command:

```
debug sae {events | details} {enable | disable}
```

References

- Cisco Catalyst 9800 Series Wireless Controller 17.8.1 Configuration Guide:
https://www.cisco.com/c/en/us/td/docs/wireless/controller/9800/17-8/config-guide/b_wl_17_8_cg.html

- Cisco Catalyst 9100 Access Points documentation:
<https://www.cisco.com/c/en/us/support/wireless/catalyst-9100ax-access-points/series.html>

Legal information

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2025 Cisco Systems, Inc. All rights reserved.