

How To Get Information About Users Connected To The TTY By Using SNMP

Document ID: 45281

Introduction

Prerequisites

- Requirements
- Components Used
- Conventions

Background

- Details of the MIB Variables (Includes OIDs)

Obtain TTY Information with SNMP

- Step-by-Step Instructions

Clear a VTY Session with SNMP

- Step-by-Step Instructions

Related Information

Introduction

This document describes how you can retrieve information about users connected to the TTY lines on a Cisco device with the help of Simple Network Management Protocol (SNMP). This document also explains all possible object identifiers (OIDs) and how to clear a specific TTY line with SNMP.

Prerequisites

Requirements

Before you use the information in this document, make sure that you meet these requirements:

- Understand how to view TTY information on Cisco devices .
- General use of SNMP **walk**, **get**, and **set** commands.
- Understand how to configure SNMP on a Cisco device.

Components Used

This document applies to Cisco routers and switches running a regular Catalyst operating system (OS) or Catalyst IOS that supports the OLD-CISCO-TS-MIB.

Note: The OLD-CISCO-TS-MIB is not loaded by default in NET-SNMP. If the Management Information Base (MIB) is not loaded on your system, you must use the OID instead of the object name.

The information in this document is based on the software and hardware versions listed here:

- Router c3640 running 12.2(13a)
- NET-SNMP version 5.0.6 available at <http://www.net-snmp.org/>

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure that you understand the potential impact of any command.

Conventions

For more information on document conventions, refer to the Cisco Technical Tips Conventions.

Background

Details of the MIB Variables (Includes OIDs)

1.3.6.1.4.1.9.2.9.1 (OLD-CISCO-TS-MIB)

tsLines OBJECT-TYPE

SYNTAX INTEGER

ACCESS read-only

STATUS mandatory

DESCRIPTION "Number of terminal lines on this device. Includes virtual

::= { lts 1 }

1.3.6.1.4.1.9.2.9.2.1.1 (OLD-CISCO-TS-MIB)

tsLineActive OBJECT-TYPE

SYNTAX INTEGER

ACCESS read-only

STATUS mandatory

DESCRIPTION "Boolean whether this line is active or not."

::= { ltsLineEntry 1 }

1.3.6.1.4.1.9.2.9.2.1.2 (OLD-CISCO-TS-MIB)

tsLineType OBJECT-TYPE

SYNTAX INTEGER {

unknown(1),

console(2),

terminal(3),

line-printer(4),

virtual-terminal(5),

auxiliary(6)

}

ACCESS read-only

STATUS mandatory

DESCRIPTION "Type of line."

::= { ltsLineEntry 2 }

1.3.6.1.4.1.9.2.9.2.1.21 (OLD-CISCO-TS-MIB)

tsLineTimeActive OBJECT-TYPE

SYNTAX INTEGER

ACCESS read-only

STATUS mandatory

DESCRIPTION "The time in seconds since line was activated."

::= { ltsLineEntry 21 }

1.3.6.1.4.1.9.2.9.2.1.18 (OLD-CISCO-TS-MIB)

tsLineUser OBJECT-TYPE

SYNTAX DisplayString

ACCESS read-only

STATUS mandatory

DESCRIPTION "TACACS user name,if TACACS is enabled, of user on this line"

::= { ltsLineEntry 18 }

1.3.6.1.4.1.9.2.9.4 (OLD-CISCO-TS-MIB)

tsMsgTtyLine OBJECT-TYPE

```

SYNTAX INTEGER
ACCESS read-write
STATUS mandatory
DESCRIPTION "tty line to send the message to. -1 sends the messages to
::= { lts 4 }

```

1.3.6.1.4.1.9.2.9.10 (OLD-CISCO-TS-MIB)

tsClrTtyLine OBJECT-TYPE

```

SYNTAX INTEGER
ACCESS read-write
STATUS mandatory
DESCRIPTION "tty line to clear. Read returns the last line cleared.
::= { lts 10 }

```

Obtain TTY Information with SNMP

Step-by-Step Instructions

The values in the example are as follows:

- Device hostname = ponch
- Read community = public
- Write community = private

1. Replace the community strings and the hostname in the these commands.

- ◆ To find the available number of TTY lines (that includes the virtual ones), query the object **tsLines**:

```

snmpwalk -c public ponch tsLines
cisco.local.lts.tsLines.0 : INTEGER: 135

```

- ◆ To list active TTY lines query the **tsLineActive** object. The active TTY lines return 1:

```

snmpwalk -c public ponch tsLineActive
cisco.local.lts.ltsLineTable.ltsLineEntry.tsLineActive.0 : INTEGER: 1
cisco.local.lts.ltsLineTable.ltsLineEntry.tsLineActive.129 : INTEGER: 0
cisco.local.lts.ltsLineTable.ltsLineEntry.tsLineActive.130 : INTEGER: 1
&

```

2. Verify this with the **show users** command on the command-line interface (CLI) of the router:

```

ponch#sh users

```

Line	User	Host(s)	Idle	Location
0 con 0		idle	15:32:49	
*130 vty 0		idle	00:00:00	10.61.64.9

Interface	User	Mode	Idle	Peer Address

- ◆ To obtain the type of line, query the **tsLineType** object. This shows how the user is connected:

```

◇ unknown(1)
◇ console(2)
◇ terminal(3)
◇ line-printer(4)
◇ auxiliary(6)
snmpwalk -c public ponch tsLineType

```

```
cisco.local.lts.ltsLineTable.ltsLineEntry.tsLineType.0 : INTEGER: console
cisco.local.lts.ltsLineTable.ltsLineEntry.tsLineType.129 : INTEGER: auxiliary
cisco.local.lts.ltsLineTable.ltsLineEntry.tsLineType.130 : INTEGER: virtual-t
&
```

- ◆ To determine whether the time line is been active,query the **tsLineTimeActive** object. This is the time in seconds since the line was activated:

```
snmpwalk -c public ponch tsLineTimeActive
cisco.local.lts.ltsLineTable.ltsLineEntry.tsLineTimeActive.0 : INTEGER: 17235
cisco.local.lts.ltsLineTable.ltsLineEntry.tsLineTimeActive.129 : INTEGER: 0
cisco.local.lts.ltsLineTable.ltsLineEntry.tsLineTimeActive.130 : INTEGER: 906
&
```

- ◆ To see who is connected to a TTY, you must be connected to the device through TACACS. Query the **tsLineUser** object to find the user name:

Note: If you are NOT connected through TACACS, then **tsLineUser** is empty!

```
snmpwalk -c public ponch tsLineUser
cisco.local.lts.ltsLineTable.ltsLineEntry.tsLineUser.0 : DISPLAY STRING- (asc
cisco.local.lts.ltsLineTable.ltsLineEntry.tsLineUser.129 : DISPLAY STRING- (a
cisco.local.lts.ltsLineTable.ltsLineEntry.tsLineUser.131 : DISPLAY STRING- (a
&
```

3. Compare this sample output to your CLI command **show users** output:

```
ponch#sh users
      Line      User      Host(s)      Idle      Location
    0 con 0      idle      idle      15:32:49
*131 vty 0      cisco     idle      00:00:00 10.61.64.11
```

```
Interface      User      Mode      Idle      Peer Address
```

Clear a VTY Session with SNMP

Step-by-Step Instructions

You can clear a telnet (VTY) session with SNMP. The **SNMP** command is the equivalent of the **clear line vty <number>** command. The object used to clear a line is **tsClrTtyLine**.

1. Use SNMP to clear VTY line 132 with these commands:

```
snmpset -c private ponch tsClrTtyLine.0 integer 132
cisco.local.lts.tcClrTtyLine.0 : INTEGER: 132
```

or

```
snmpset -c private ponch .1.3.6.1.4.1.9.2.9.10.0 integer 132
enterprises.9.2.9.10.0 = 132
```

2. To check this on the router before the line 132 is cleared, issue this command on the CLI:

```
ponch#show users
      Line      User      Host(s)      Idle      Location
    0 con 0      idle      idle      05:23:17
    130 vty 0      idle      idle      1d03h 144.254.7.118
    131 vty 1      idle      idle      1d01h 144.254.7.118
    132 vty 2      idle      idle      00:04:36 144.254.8.54
*133 vty 3      idle      idle      00:00:00 144.254.7.53
```

```
Interface      User      Mode      Idle      Peer Address
```

3. Check the router after you issue this command, to make sure line 132 is cleared:

```
ponch#show users
  Line      User      Host(s)      Idle      Location
  0 con 0
  130 vty 0      idle        05:26:42
  131 vty 1      idle        1d03h 144.254.7.118
  *133 vty 3      idle        1d01h 144.254.7.118
  *133 vty 3      idle        00:00:00 144.254.7.53
```

```
Interface      User      Mode      Idle      Peer Address
4. Line 132 is now cleared.
```

Note: Issue this command carefully because it can disconnect a user from the device without warning!

Related Information

- [Technical Support – Cisco Systems](#)

[Contacts & Feedback](#) | [Help](#) | [Site Map](#)

© 2009 – 2010 Cisco Systems, Inc. All rights reserved. [Terms & Conditions](#) | [Privacy Statement](#) | [Cookie Policy](#) | [Trademarks of Cisco Systems, Inc.](#)

Updated: Oct 26, 2005

Document ID: 45281
