Use EEM Script to Troubleshoot Intermittent RADIUS Server Failures

Contents

Introduction Prerequisites Requirements Components Used Problem Topology Step 1: Configure Packet Capture and Applicable Access-Lists to capture Packets between Servers Step 2: Configure EEM Script EEM Script Explanation Final Steps Real World Example Related Information

Introduction

This document describes how to troubleshoot a RADIUS server marked as failed in ASA and how this can cause outages for the client infrastructure.

Prerequisites

Requirements

Cisco recommends that you have knowledge of these topics:

• Basic awareness or EEM scripting on Cisco ASA

Components Used

This document is not restricted to specific software and hardware versions.

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, ensure that you understand the potential impact of any command.

Problem

RADIUS servers are marked as failed/dead in the Cisco ASA. The problem is intermittent but causes outages for the client infrastructure. TAC must differentiate whether this is an ASA issue, Data Path issue, or Radius Server issue. If a capture is made at the time of failure, it rules out the Cisco ASA as it discerns whether the ASA sends the packets to the RADIUS server, and if they are received in return.

Topology

For this example, this is the topology that is used:



To fix this problem, do these next steps.

Step 1: Configure Packet Capture and Applicable Access-Lists to capture Packets between Servers

The first step is to configure Packet Capture and applicable access-lists to capture packets between the ASA and RADIUS servers.

If you need assistance with Packet Capture, refer to the <u>Packet Capture Config Generator and</u> <u>Analyzer</u>.

access-list TAC extended permit ip host 10.20.20.180 host 10.10.10.150

access-list TAC extended permit ip host 10.10.10.150 host 10.20.20.180

access-list TAC extended permit ip host 10.20.20.180 host 10.10.20.150

access-list TAC extended permit ip host 10.10.20.150host 10.20.20.180

capture RADIUS type raw-data access-list TAC buffer 30000000 interface inside circular-buffer

Note: You need to check the buffer size to ensure that it does not overfill and does the data. A buffer size of 1000000 is sufficient. Notice our example buffer is 3000000.

Step 2: Configure EEM Script

Next, configure the EEM script.

This example uses the Syslog ID of 113022 and you can trigger EEM on many other Syslog messages:

The message types for ASA are found at <u>Cisco Secure Firewall ASA Series Syslog Messages</u>.

The trigger in this scenario is:

Error Message %ASA-113022: AAA Marking RADIUS server servername in aaa-server group AAA-Using-DNS as FAILED

The ASA has tried an authentication, authorization, or accounting request to the AAA server and did not receive a response within the configured timeout window. The AAA server is then marked as failed and removed from service.

event manager applet ISE_Radius_Check

event syslog id 113022

action 0 cli command "show clock"

action 1 cli command "show aaa-server ISE"

action 2 cli command "aaa-server ISE active host 10.10.10.150"

action 3 cli command "aaa-server ISE active host 10.10.20.150"

action 4 cli command "show aaa-server ISE"

action 5 cli command "show capture radius decode dump"

output file append disk0:/ISE_Recover_With_Cap.txt

EEM Script Explanation

event manager applet ISE_Radius_Check. -- You name your eem script.

event syslog id 113022 -- Your trigger: (see prior explanation)

action 0 cli command "show clock" --best practices to capture accurate timestamps while it troubleshoots in order to compare to other logs the client can have.

action 1 cli command "show aaa-server ISE" -- This shows the status of our aaa-server group. In this case that group is called ISE.

action 2 cli command "aaa-server ISE active host 10.10.10.150" -- This command is to "bring back up" the aaa-server with that IP. This enables you to continue to attempt radius packets to determine datapath errors.

action 3 cli command "aaa-server ISE active host 10.10.20.150" -- See Previous command

explanation.

action 4 cli command "show aaa-server ISE". -- This command verifies if the servers came back up.

action 5 cli command "show capture radius decode dump" --you now decode/dump your packet capture.

output file append disk0:/ISE_Recover_With_Cap.txt --this capture is now saved in a text file on the ASA and new results are appended to the end.

Final Steps

Finally, you can then upload this information to a Cisco TAC case or use the information to analyze the latest packets in the flow and figure out why the RADIUS servers are marked as failed.

The text file can be decoded and turned into a pcap at the previously mentioned <u>Packet Capture</u> <u>Config Generator and Analyzer</u>.

Real World Example

In the next example, the capture for RADIUS traffic is filtered out. You see that the ASA is the device that ends in .180 and the RADIUS server ends in .21

In this example, *both* RADIUS servers return a "port unreachable", 3 times in a row for each. This triggers the ASA to mark *both* RADIUS servers as dead within milliseconds of each other.

The Result

Each .21 address in this example was an F5 VIP address. That means that behind the VIPS were clusters of Cisco ISE nodes in the PSN persona.

The F5 returned "port unreachable" due to an F5 defect.

In this example, the Cisco TAC team successfully proved that the ASA worked as expected. That is, it sent radius packets and received 3 ports that were unreachable before, and effected the Radius Server marked failed:

99	329, 426964	10,242,253,180	10,242,230,21	RADIUS	788	Accounting-Request id=233
100	329, 427117	10,242,253,180	10,242,230,21	RADTUS	692	Accounting-Request id+234
101	329,443877	10.242.230.21	10.242.253.180	RADTUS	65	Accounting-Response (d+233
182	129.445899	18.242.238.21	18,242,253,188	RADTUS	66	Accounting-Response ide7M
183	129.588366	18.242.253.188	18,242,238,21	RADTUS	728	Access-Request 1ds215
100	210 558614	14 343 354 31	14 343 343 164	1/100	1.04	Bestingting upreschable (Bort upreschable)
199	243121004	10110401020101	1011006163311000	1070		searcharton aucernance (Lour aucernance)
185	329.511127	10.242.253.180	10.242.230.21	RADIUS	728	Access-Request 1d+236
186	329.513279	18.242.238.21	10.242.253.180	109	- 74	Destination unreachable (Port unreachable)
187	329.513737	10.242.253.100	10.242.230.21	RADIUS	728	Access-Request 1d+237
100	329.515598	10.242.230.21	10.242.253.180	109	- 74	Destination unreachable (Port unreachable)
189	329.516330	10.242.253.180	10.250.230.21	RADIUS	720	Access-Request 1d+238
110	329.521384	10.250.230.21	10.242.253.180	109	- 74	Destination unreachable (Port unreachable)
111	329.526538	10.242.253.180	10.250.230.21	RADIUS	720	Access-Request 1d+239
112	329.531146	10.250.230.21	10.242.253.180	109	- 74	Destination unreachable (Port unreachable)
113	329.536847	10.242.253.180	10.250.230.21	RADIUS	720	Access-Request 1d+240
114	329.541231	10.250.230.21	10.242.253.180	109	- 74	Destination unreachable (Port unreachable)
115	347.373134	10.242.253.180	10.242.230.21	RADIUS	688	Access-Request 1d+242
116	349.486886	10.242.230.21	10.242.253.100	RADIUS	214	Access-Accept id=242
117	349.487538	10.242.253.180	10.242.230.21	RADIUS	614	Access-Request 1d=243
118	349.548174	10.242.230.21	10.242.253.180	RADIUS	218	Access-Accept id=243

Related Information

<u>Cisco Technical Support & Downloads</u>