



Upgrading the Cisco cBR Series Converged Broadband Routers for Cisco IOS XE Bengaluru 17.6

First Published: 2021-08-16 **Last Modified:** 2022-10-25

Americas Headquarters

Cisco Systems, Inc. 170 West Tasman Drive San Jose, CA 95134-1706 USA http://www.cisco.com Tel: 408 526-4000

800 553-NETS (6387) Fax: 408 527-0883 © 2022 Cisco Systems, Inc. All rights reserved.



CONTENTS

CHAPTER 1 Upgrading the Cisco cBR-8 Router System to Cisco IOS XE Bengaluru 17.6.1z1 1

Verify max-carrier value 3

Upgrading from Cisco IOS XE 16.x and later releases to Cisco IOS XE Bengaluru 17.6.1z1 4

Prerequisites 4

Upgrading using reload 6

Upgrading with ISSU for I-CCAP Systems 10

Upgrading Supervisor CPLD Firmware 15

Upgrading cBR CCAP 8x10G Remote PHY Digital Physical Interface Card 19

Upgrading Uboot For CBR-CCAP-LC-40G 22

CHAPTER 2 Upgrading the Cisco cBR-8 Router System to Cisco IOS XE Bengaluru 17.6.1z 25

Verify max-carrier value 27

Upgrading from Cisco IOS XE 16.x and later releases to Cisco IOS XE Bengaluru 17.6.1z 28

Upgrading using reload 30

Upgrading with ISSU for I-CCAP Systems 33

Upgrading Supervisor CPLD Firmware 38

Upgrading cBR CCAP 8x10G Remote PHY Digital Physical Interface Card 43

CHAPTER 3 Upgrading the Cisco cBR-8 Router System to Cisco IOS XE Bengaluru 17.6.1x 47

Verify max-carrier value 49

Upgrading from Cisco IOS XE 16.x and later releases to Cisco IOS XE Bengaluru 17.6.1x **50**

Upgrading using reload 52

Upgrading with ISSU for I-CCAP Systems 55

Upgrading Supervisor CPLD Firmware 60

Upgrading cBR CCAP 8x10G Remote PHY Digital Physical Interface Card 65

CHAPTER 4	Upgrading the Cisco cBR-8 Router System to Cisco IOS XE Bengaluru 17.6.1w 6	39

Verify max-carrier value 71

Upgrading from Cisco IOS XE 16.x and later releases to Cisco IOS XE Bengaluru 17.6.1w 72

Upgrading using reload 74

Upgrading with ISSU for I-CCAP Systems 77

Upgrading Supervisor CPLD Firmware 82

Upgrading cBR CCAP 8x10G Remote PHY Digital Physical Interface Card 87

CHAPTER 5 Upgrading the Cisco cBR-8 Router System to Cisco IOS XE Bengaluru 17.6.1a 91

Verify max-carrier value 93

Upgrading from Cisco IOS XE 16.x and later releases to Cisco IOS XE Bengaluru 17.6.1a 94

Upgrading using reload 96

Upgrading with ISSU for I-CCAP Systems 99

Upgrading Supervisor CPLD Firmware 104

Upgrading cBR CCAP 8x10G Remote PHY Digital Physical Interface Card 109



Upgrading the Cisco cBR-8 Router System to Cisco IOS XE Bengaluru 17.6.1z1



Note

Starting from Cisco IOS XE Bengaluru 17.6.1a, CBR-CCAP-LC-G2-R can only protect CBR-CCAP-LC-G2-R for linecard HA.



Note

If you are using TACACS authentication, the TACACS configuration will be automatically updated to the new version after upgrading to Cisco IOS XE Bengaluru 17.6.1z1. This is a fix to CSCvu62273 and you do not need to take any action regarding the TACACS configuration in the cBR-8 prior to the upgrade.

This section contains the upgrade procedures for the Cisco cBR-8 Router System.

By default, telnet is disabled on Cisco cBR-8. If you are going to use telnet to access the device, make sure the value of line **vty transport** is correct and save the configuration in order to enable telnet.

```
Router# show run | begin line vty
line vty 0 4
exec-timeout 0 0
privilege level 15
password 7 104D081B094410055F
exec prompt timestamp
transport input all
line vty 5 98
exec-timeout 0 0
privilege level 15
password 7 02050D480809
transport input all
line vty 99
transport input all
!
```

The following table encompasses all fiirmware versions that customers are required to update to support Cisco IOS XE Bengaluru 17.6.1z1. All other firmware versions are either not upgradable by the customer, or not required to be upgraded for Cisco IOS XE Bengaluru 17.6.1z1 support. Use the commands in the tables to verify the firmware versions. If you need to upgrade firmware first, refer to the steps in Upgrading the Cisco cBR-8 Router Firmware.



Note

If you want to upgrade Supervisor CPLD firmware, refer to Upgrading Supervisor CPLD Firmware, on page 38.

Table 1: Firmware Versions

Internal Name	Component Name	Required Minimum Version	Command
Supervisor CPLD	CBR-CCAP-SUP-160G CPLD	16052011/19071712	show platform
	CBR-CCAP-SUP-250G CPLD	170724E0/190717E1	show platform
Supervisor ROMMON	CBR-CCAP-SUP-160G ROMMON and CBR-CCAP-SUP-250G ROMMON	16.7(8r)S	show platform
Line Card CPLD	CBR-CCAP-LC-40G CPLD	00000026	show platform diag
Docsis 3.1 downstream module Micro	CBR-CCAP-LC-40G Gemini2 Micro	3.1A	show platform diag
Docsis 3.1 downstream module FPGA	CBR-CCAP-LC-40G Gemini2 Apollo	4.484F	show platform diag
DPIC Uboot and FPGA	CBR-DPIC-8X10G Firmware	00010001	show platform diag
DPIC 100G Uboot and FPGA	CBR-DPIC-2X100G Firmware	00020006	show platform diag



Note

If the user wants to upgrade Supervisor CPLD to version 19071712 and 190717E1, the chassis must be running with Cisco IOS XE Gibraltar 16.12.1w or later releases.



Note

Cisco recommends that operators upgrade their On-Premise SSM Satellite software versions to v7.x or later releases, to ensure the compatibility with cBR-8.

- Verify max-carrier value, on page 3
- Upgrading from Cisco IOS XE 16.x and later releases to Cisco IOS XE Bengaluru 17.6.1z1, on page 4
- Upgrading Supervisor CPLD Firmware, on page 15

- Upgrading cBR CCAP 8x10G Remote PHY Digital Physical Interface Card, on page 19
- Upgrading Uboot For CBR-CCAP-LC-40G, on page 22

Verify max-carrier value

Currently in Remote PHY system, max-carrier value can be configured in the downstream controller profile as well as in RPD configuration for Cisco Remote PHY Shelf 300/600/7200. This may lead to inconsistent max-carrier value configurations.

Starting from Cisco IOS XE Gibraltar 16.10.1f, max-carrier value configured in the **cable rpd** mode is removed and RPD will use the max-carrier value configured in the **controller-profile** mode for the power calculation.

Before upgrading to Cisco IOS XE Gibraltar 16.10.1f or later releases, verify if the max-carrier values configured in the RPD shelf configuration and downstream controller profile(s) associated to RPD downstream port are the same. If they are different, update the cBR-8 configuration prior to upgrade.

Below is an example of correct configuration before upgrade.

```
cable downstream controller-profile 1
max-carrier 128
max-ofdm-spectrum 384000000
rf-chan 0 3
 type DOCSIS
 qam-profile 1
 frequency 381000000
 rf-output NORMAL
 docsis-channel-id 1
cable downstream controller-profile 2
max-carrier 158
max-ofdm-spectrum 384000000
rf-chan 158
 docsis-channel-id 159
 ofdm channel-profile 20 start-frequency 579000000 width 48000000 plc 600000000
cable rpd test
identifier 0001.0001.0001
type shelf
rpd-ds 0 max-carrier 128
rpd-ds 0 base-power 33
rpd-ds 1 max-carrier 158
rpd-ds 1 base-power 25
core-interface Te9/1/0
 rpd-ds 0 downstream-cable 9/0/3 profile 1
 rpd-ds 0 downstream-cable 9/0/4 profile 2
 rpd-us 0 upstream-cable 9/0/3 profile 1
r-dt.i 1
rpd-event profile 0
rpd-55d1-us-event profile 0
```



Note

It is highly recommended to follow this example to check and update configuration if necessary because max-carrier value is used to compute the base power. Otherwise, after upgrade the expected base power value can be different which may affect cable modem coming online.



Note

If you upgrade from a version lower than Cisco IOS XE Fuji 16.9.1, base power range may be changed on the port with OFDM channel configured. So be aware of the potential base power change before and after the upgrade.

Upgrading from Cisco IOS XE 16.x and later releases to Cisco IOS XE Bengaluru 17.6.1z1

Prerequisites

Manual ROMMON Upgrade

If you are upgrading from Cisco IOS XE Everest 16.6.x or Cisco IOS XE Fuji 16.7.x to Cisco IOS XE Bengaluru 17.6.1z1, perform the following steps to upgrade SUP ROMMON manually.

- Download hardware programmable devices upgrade package file cbrsup-programmable_firmware.17.06.01z1.SPA.pkg from the following Cisco.com Software Center URL: https://software.cisco.com/download/home/286283913/type
- **2.** Copy the package file to harddisk:.

```
copy <location>/cbrsup-programmable_firmware.17.06.01z1.SPA.pkg harddisk:
```

3. Verify the hardware programmable devices upgrade package against the md5 hash as provided in the Cisco.com Software center.

verify /md5 harddisk:cbrsup-programmable_firmware.17.06.01z1.SPA.pkg

4. Upgrade SUP ROMMON.

```
Router#Upgrade rom-mon file harddisk:cbrsup-programmable_firmware.17.06.01z1.SPA.pkg r0 Wait for the following output on the console:
ROMMON upgrade complete.
To make the new ROMMON permanent, you must restart the RP
```

Router#Upgrade rom-mon file harddisk:cbrsup-programmable_firmware.17.06.01z1.SPA.pkg r1 Wait for the following output on the console:

ROMMON upgrade complete.

To make the new ROMMON permanent, you must restart the RP



Note

Do not restart the SUPs currently, you can combine reloading the SUP with the IOS upgrade process.

Downstream-Controller Remapping (CBR-CCAP-LC-G2-R with 8x10G DPIC)

If you are using cBR CCAP 8x10G Remote PHY Digital Physical Interface Card (D-PIC) with CBR-CCAP-LC-G2-R linecards, contact your local Cisco representative before upgrading to Cisco IOS XE Cupertino 17.9.1z1.

Starting with in Cisco IOS XE Bengaluru 17.6.1, Cisco introduces a new feature on cBR-8 that provides initial support for 32 Video and 32 DOCSIS service groups per CBR-CCAP-LC-G2-R linecard. The implementation of this feature introduces new 8x10G DPIC port mapping constraints on existing 'Downstream-Cable' controllers. Cisco has prepared a python tool that can be used to determine if a cBR-8 running-configuration includes non-compliant controller mappings, and, to update the running-configuration to be compliant with the latest Cisco IOS XE Cupertino 17.6.1z1. Once you have the python tool, perform the following steps in order to predict and avoid downtime:

Before you begin: Special considerations must be taken when using SmartPHY. Contact your local Cisco representative if your installation includes SmartPHY.

1. Collect the following information from the target cBR-8 to upgrade.

```
Router#show cable rpd sum
Router#show cable modem sum
Router#show cable video session all sum
```

2. Save the running configuration to the harddisk of the cBR-8.

```
Router#copy running-config harddisk:SavedConfig.txt
```

3. Copy the saved running configuration from harddisk: to an offline server for editing using SCP.

```
Router#copy harddisk:SavedConfig.txt scp:<path>
```

- **4.** Run the python tool to modify the controllers in the saved configuration.
 - Option 1 Renumber Downstream-Cable controllers only
 - **a.** Execute python script **kobol_ph2_controller_migration.py**. This script is intended for customers who do not immediately intend to take advantage of the Downstream-Video controllers and expanded SG capacity on CBR-CCAP-LC-G2-R.

```
$ python kobol_ph2_controller_migration.py
Enter the name of the configuration file: SavedConfig.txt
```

b. Output file appends **_remap_controller** to the file name.

```
Output file name: SavedConfig.txt_remap_controller
```

- **c.** Check to ensure that the script completed successfully. If no output file is created or the size of the output file is 0 byte, then check script output for error messages.
- Option 2 Renumber Downstream-Cable and utilize Downstream-Video controllers
- a. Execute python script kobol_ph2_controller_migration_video.py. This script is intended for customers who wish to utilize the new Downstream-Video controllers to free up existing Downstream-Cable controllers for expanded DOCSIS service groups.

```
$ python kobol_ph2_controller_migration_video.py
Enter the name of the configuration file: SavedConfig.txt
```

b. Output file appends **_remap_controller_video** to the file name.

```
Output file name: SavedConfig.txt remap controller video
```

- **c.** Check to ensure that the script completed successfully. If no output file is created or the size of the output file is 0 byte, then check script output for error messages.
- 5. Modify the remapped configuration file to specify the Cisco IOS XE Bengaluru 17.6.1z1 image in the boot parameter.

boot system harddisk:cbrsup-universalk9.17.06.01z1.SPA.bin

6. Copy the final remapped configuration file back to the cBR-8 harddisk.

```
Router#copy scp:<path>/SavedConfig.txt_remap_controller harddisk:
or
Router#copy scp:<path>/SavedConfig.txt remap controller video harddisk:
```

7. Copy remapped configuration file to startup of the cBR-8.

```
Router#copy harddisk:SavedConfig.txt_remap_controller startup-config

Or

Router#copy harddisk:SavedConfig.txt_remap_controller_video startup-config
```

After performing the remapping procedure, monitor the chassis for any of the following errors after reload:

```
Mismatches TE interface. DS controller should be */*/0\sim7, configuration failed. Mismatches TE interface. DS controller should be */*/8\sim15, configuration failed. Mismatches TE interface. DS controller should be */*/16\sim23, configuration failed. Mismatches TE interface. DS controller should be */*/24\sim31, configuration failed.
```

Upgrading using reload

Before you begin



Note

If you are upgrading from Cisco IOS XE Everest 16.6.x or Cisco IOS XE Fuji 16.7.x to Cisco IOS XE Bengaluru 17.6.1z1, perform Manual ROMMON Upgrade to upgrade SUP ROMMON manually before proceeding with IOS upgrading.

Before upgrading the system, make sure the following requirements are met:

- Download two files from the following Cisco.com Software Center URL:
 - https://software.cisco.com/download/home/286283913/type
 - IOS XE Software Version 17.6.1z1: cbrsup-universalk9.17.06.01z1.SPA.bin
 - IOS XE Hardware Programmable Devices Version 17.6.1z1: cbrsup-programmable_firmware.17.06.01z1.SPA.pkg
- **Step 1** Copy Cisco IOS XE Bengaluru 17.6.1z1 package to harddisk: and stby-harddisk:.

```
copy <location>/cbrsup-universalk9.17.06.01z1.SPA.bin harddisk:
copy <location>/cbrsup-universalk9.17.06.01z1.SPA.bin stby-harddisk:
```

Step 2 Verify Cisco IOS XE Bengaluru 17.6.1z1 package against the md5 hash as provided in the Cisco.com Software center.

verify /md5 harddisk:cbrsup-universalk9.17.06.01z1.SPA.bin

verify /md5 stby-harddisk:cbrsup-universalk9.17.06.01z1.SPA.bin

Step 3 Copy the hardware programmable devices upgrade package to harddisk: if the file has not been copied already.

copy <location>/cbrsup-programmable_firmware.17.06.01z1.SPA.pkg harddisk:

Step 4 Verify the hardware programmable devices upgrade package against the md5 hash as provided in the Cisco.com Software center.

verify /md5 harddisk:cbrsup-programmable_firmware.17.06.01z1.SPA.pkg

- **Step 5** Configure the chassis to boot the system with Cisco IOS XE Bengaluru 17.6.1z1 image.
 - **a.** Use the following steps if you do not use cBR CCAP 8x10G Remote PHY Digital Physical Interface Card (D-PIC) with CBR-CCAP-LC-40G-R linecards.

```
configure terminal
no boot system
boot system harddisk:cbrsup-universalk9.17.06.01z1.SPA.bin
config-register 0x2102
end
write mem
```

b. Use the following steps if you use cBR CCAP 8x10G Remote PHY Digital Physical Interface Card (D-PIC) with CBR-CCAP-LC-40G-R linecards.

```
configure terminal
config-register 0x2102
end
```

- **Step 6** Check line card CPLD version via **show platform**. If it is not the minimum version 00000026, upgrade line card CPLD following the sub steps below. Otherwise skip this step.
 - Note To upgrade the line card CPLD to version 00000026, the cBR-8 must be running Cisco IOS XE Gibraltar 16.12.1 or later releases.

This procedure will trigger a reload of the linecard and will cause an outage if the system is not backed up with LCHA.

Do not power cycle the cBR-8 router during the firmware upgrade process. Power cycling the chassis may corrupt the ROMMON/Uboot image.

a) Run the following pre-upgrade commands on the SUP IOS:

upgrade hw-programmable cable active_SUP daggit pre-upgrade slot LC_slot_#
Example:

```
Router# upgrade hw-programmable cable R0 daggit pre-upgrade slot 0 Daggits pre-upgrade successful
```

b) Upgrade the line card CPLD firmware using the SUP IOS command.

Note Do not reboot the line card until the upgrade is complete. Upgrade takes approximately 15 minutes.

upgrade hw-programmable cable LC_slot_# daggit pkg_name firmware_pkg_location_path Example:

```
Router# upgrade hw-programmable cable 0 daggit pkg_name /harddisk/cbrsup-programmable firmware.17.06.01z1.SPA.pkg
```

c) After the upgrade is complete (takes approximately 15 minutes), the line card moves to **unknown** state. Check the status of the line card using the **show platform** command. When the line card is in **unknown** state, run the following command to recover the line card:

```
upgrade hw-programmable cable <code>active_SUP</code> daggit lc-recovery slot <code>LC_slot_#</code> Example:
```

```
Router# upgrade hw-programmable cable R0 daggit lc-recovery slot 0
```

d) The line card moves from **booting** to **active** state. Check the version of the line card using the **show platform** command to make sure version is changed to 00000026.

Example:

```
Router#show platform ......

Slot CPLD Version Rommon Version ......

0 00000026 2011.03.18 ...
```

e) When the line card is in **active** state, run the following command to verify the upgrade.

```
upgrade hw-programmable cable <code>active_SUP</code> daggit post-active slot <code>LC_slot_#</code> Example:
```

```
Router# upgrade hw-programmable cable R0 daggit post-active slot 0 SUCCESS: Daggit_ver-38 : Booted from upgradable Image-1
```

Step 7 Check the firmware version of the Docsis 3.1 downstream modules in all slots, if it is different with the version listed in Table 2: Firmware Versions, on page 26, update the firmware using the following command. Otherwise skip this step.

upgrade hw-programmable cable slot dsphy all pkg_name firmware_pkg_location_path

Example:

```
Router# upgrade hw-programmable cable 0 dsphy all pkg_name /harddisk/cbrsup-programmable firmware.17.06.01z1.SPA.pkg
```

Step 8 Wait for the system log message asking the user to reload the line card that was upgraded.

```
001860: Jun 15 19:05:05.904 PDT: \text{NIOSXE-5-PLATFORM}: CLC0: cdman: Suggest reload the line card for new FW to take effect using CLI: hw slot \text{slot-id} reload
```

Step 9 Reload the system.

Router#reload

During reload, monitor the chassis for any of the following errors, and update the configuration accordingly.

```
Mismatches TE interface. DS controller should be */*/0\sim7, configuration failed. Mismatches TE interface. DS controller should be */*/8\sim15, configuration failed. Mismatches TE interface. DS controller should be */*/16\sim23, configuration failed. Mismatches TE interface. DS controller should be */*/24\sim31, configuration failed.
```

Step 10 If the system is running with SUP250, perform **no shut** on 100G interface after the system comes up for the first time.

What to do next

Perform verification test to determine if the upgrade is successful, include:

- Verify the router is running the new IOS-XE release using **show version** command.
- Check facility alarms using show facility-alarm status command.
- Check the status of the power supplies using **show environment power** command.
- Check PS status using show platform hardware slot P<0-5> mcu status command.
- Complete trace routes to known good off-network IP address using the source address of customer CPE blocks to verify routing is working.
- Check logs for error messages using **show log** command.

These **show** commands may be useful in the verification test:

- · show redundancy
- · show platform
- show platform diag
- show environment
- show redundancy linecard all
- show isis neighbors
- · show ip ospf neighbor
- show ip route rip
- show ip mroute
- show cops servers
- · show cable modem voice
- · show cable calls

- show cable metering verbose
- · show cable licenses all
- show inventory

Upgrading with ISSU for I-CCAP Systems

Before you begin



Note

- ISSU is not supported for Remote PHY systems.
- ISSU to Cisco IOS XE Bengaluru 17.6.1z1 is supported only from Cisco IOS XE Gibraltar 16.10.1g and later releases. If you are upgrading from an earlier release, you must upgrade the cBR-8 system following the steps in Upgrading using reload, on page 6.
- ISSU is not supported from 17.6.1z.

Before upgrading the system, make sure the following requirements are met:

• The cBR-8 has two SUPs installed.

• Standby SUP must be in hot standby state.

• Line card redundancy is in stable state with state Active and Stdby warm.

```
Router# show redundancy linecard all Load for five secs: 14\%/1\%; one minute: 8\%; five minutes: 8\% Time source is NTP, 15:23:26.697 PST Thu Jan 17 2019
```

Slot	Subslot	LC Group	My State	Peer State	Peer Slot	Peer Subslot	Role	Mode
2	- - -	0 0 0	Active Active Active	Stdby Warm Stdby Warm Stdby Warm	0	- -	Active Active Active	Primary Primary Primary

```
6 - 0 Active Stdby Warm 0 - Active Primary 0 - 0 - Multiple None Standby Secondary
```

Auto-boot is enabled.

```
Router# show bootvar
Load for five secs: 14%/0%; one minute: 14%; five minutes: 10%
Time source is NTP, 15:46:59.837 PST Thu Jan 17 2019

BOOT variable = harddisk:IOSXE/packages.conf,12;
CONFIG_FILE variable =
BOOTLDR variable does not exist

Configuration register is 0x2102

Standby BOOT variable = harddisk:IOSXE/packages.conf,12;
Standby CONFIG_FILE variable =
Standby BOOTLDR variable does not exist

Standby Configuration register is 0x2102
```

• Both SUPs are in the sub-package mode, running the same image from the same path.

```
Router# show bootvar
Load for five secs: 14%/0%; one minute: 14%; five minutes: 10%
Time source is NTP, 15:46:59.837 PST Thu Jan 17 2019

BOOT variable = harddisk:IOSXE/packages.conf,12;
CONFIG_FILE variable =
BOOTLDR variable does not exist
Configuration register is 0x2102

Standby BOOT variable = harddisk:IOSXE/packages.conf,12;
Standby CONFIG_FILE variable =
Standby BOOTLDR variable does not exist
Standby Configuration register is 0x2102
```

• The free space on boot device on both SUPs must be greater than 2GB.

```
Router# dir harddisk: | include bytes total 7804653568 bytes total (5691174912 bytes free)
```

• Download two files from the following Cisco.com Software Center URL:

https://software.cisco.com/download/home/286283913/type

- IOS XE Software Version 17.6.1z1: cbrsup-universalk9.17.06.01z1.SPA.bin
- IOS XE Hardware Programmable Devices Version 17.6.1z1: cbrsup-programmable_firmware.17.06.01z1.SPA.pkg
- Copy the target consolidated image **cbrsup-universalk9.17.06.01z1.SPA.bin** to the active SUP in the same directory of the **packages.conf** file that the system is booted up with.
- **Step 1** Copy Cisco IOS XE Bengaluru 17.6.1z1 package to harddisk:.

```
copy <location>/cbrsup-universalk9.17.06.01z1.SPA.bin harddisk:<sub-pkg-dir>/
```

Step 2 Verify Cisco IOS XE Bengaluru 17.6.1z1 package against the md5 hash as provided in the Cisco.com Software center.

verify /md5 harddisk:<sub-pkg-dir>/cbrsup-universalk9.17.06.01z1.SPA.bin

Step 3 Copy the hardware programmable devices upgrade package to harddisk: if the file has not been copied already.

copy <location>/cbrsup-programmable firmware.17.06.01z1.SPA.pkg harddisk:

Step 4 Verify the hardware programmable devices upgrade package against the md5 hash as provided in the Cisco.com Software center.

verify /md5 harddisk:cbrsup-programmable_firmware.17.06.01z1.SPA.pkg

- **Step 5** Check system status prior to upgrade. Save the information to compare against the system status after upgrade. For the commands to use to check the status, see the **show** commands at the end of this section.
- **Step 6** Check line card CPLD version via **show platform**. If it is not the minimum version 00000026, upgrade line card CPLD following the sub steps below. Otherwise skip this step.

Note To upgrade the line card CPLD to version 00000026, the cBR-8 must be running Cisco IOS XE Gibraltar 16.12.1 or later releases.

This procedure will trigger a reload of the linecard and will cause an outage if the system is not backed up with LCHA.

Do not power cycle the cBR-8 router during the firmware upgrade process. Power cycling the chassis may corrupt the ROMMON/Uboot image.

a) Run the following pre-upgrade commands on the SUP IOS:

upgrade hw-programmable cable <code>active_SUP</code> daggit pre-upgrade slot <code>LC_slot_#</code> Example:

Router# upgrade hw-programmable cable R0 daggit pre-upgrade slot 0 Daggits pre-upgrade successful

b) Upgrade the line card CPLD firmware using the SUP IOS command.

Note Do not reboot the line card until the upgrade is complete. Upgrade takes approximately 15 minutes.

upgrade hw-programmable cable LC_slot_# daggit pkg_name firmware_pkg_location_path Example:

```
Router# upgrade hw-programmable cable 0 daggit pkg_name /harddisk/cbrsup-programmable firmware.17.06.01z1.SPA.pkg
```

c) After the upgrade is complete (takes approximately 15 minutes), the line card moves to **unknown** state. Check the status of the line card using the **show platform** command. When the line card is in **unknown** state, run the following command to recover the line card:

upgrade hw-programmable cable active_SUP daggit lc-recovery slot LC_slot_#

Example:

Router# upgrade hw-programmable cable RO daggit lc-recovery slot 0

d) The line card moves from **booting** to **active** state. Check the version of the line card using the **show platform** command to make sure version is changed to 00000026.

Example:

DD0 || 1

cBR8#show	platiorm	
Slot	CPLD Version	Rommon Version
0	00000026	2011.03.18
•••		

e) When the line card is in **active** state, run the following command to verify the upgrade.

upgrade hw-programmable cable <code>active_SUP</code> daggit post-active slot <code>LC_slot_#</code> Example:

```
Router# upgrade hw-programmable cable R0 daggit post-active slot 0 SUCCESS: Daggit ver-38 : Booted from upgradable Image-1
```

Step 7 Check the firmware version of the Docsis 3.1 downstream modules in all slots, if it is different with the version listed in Table 2: Firmware Versions, on page 26, update the firmware using the following command. Otherwise skip this step.

upgrade hw-programmable cable slot dsphy all pkg name firmware pkg location path

Example:

```
Router# upgrade hw-programmable cable 0 dsphy all pkg_name /harddisk/cbrsup-programmable firmware.17.06.01z1.SPA.pkg
```

Step 8 Wait for the system log message asking the user to reload the line card that was upgraded. But do not reload the line card at this time.

001860: Jun 15 19:05:05.904 PDT: \$IOSXE-5-PLATFORM: CLCO: cdman: Suggest reload the line card for new FW to take effect using CLI: hw slot <slot-id> reload

Step 9 Perform ISSU.

request platform software package install node file harddisk:cbrsup-universalk9.17.06.01z1.SPA.bin

Step 10 To monitor the ISSU progress, use the command below.

request platform software package install node attach

Step 11 Use these CLI to check status after ISSU.

```
show version r0 running show version r1 running show version r1 running show version r0 provisioned show version r1 provisioned
```

What to do next

Perform verification test to determine if the upgrade is successful, include:

- Verify the router is running the new IOS-XE release using **show version** command.
- Check facility alarms using show facility-alarm status command.
- Check the status of the power supplies using **show environment power** command.
- Check PS status using **show platform hardware slot P<0-5> mcu status** command.
- Complete trace routes to known good off-network IP address using the source address of customer CPE blocks to verify routing is working.
- Check logs for error messages using show log command.

These **show** commands may be useful in the verification test:

- · show redundancy
- show platform
- · show platform diag
- show environment
- · show redundancy linecard all
- · show isis neighbors
- · show ip ospf neighbor
- show ip route rip
- show ip mroute
- · show cops servers
- show cable modem voice
- · show cable calls
- show cable metering verbose
- · show cable licenses all
- show inventory

Upgrading Supervisor CPLD Firmware

Before you begin



Note

If the supervisor SO CPLD version is lower than 1511_1401 (SUP 160) or 15111401 (SUP 250), or, if the supervisor SIO CPLD version is lower than 1511_1301 (SUP 160) or 15111301 (SUP 250), physically power cycle the chassis when upgrading the supervisor CPLD.

Before upgrading the firmware, make sure the following requirements are met:

- Cisco cBR-8 router is running with Cisco IOS XE Gibraltar 16.12.1w or later releases.
- 2 supervisors are running in the Cisco cBR-8 router and the redundancy is enabled.
- Download the file from the following Cisco.com Software Center URL:

https://software.cisco.com/download/home/286283913/type

- IOS XE Hardware Programmable Devices Version 17.6.1z1: cbrsup-programmable_firmware.17.06.01z1.SPA.pkg
- Console access for both supervisors are required.
- Copy the new firmware package to the cBR-8 using FTP.

```
copy ftp://<location>/cbrsup-programmable_firmware.17.06.01z1.SPA.pkg harddisk:
copy ftp://<location>/cbrsup-programmable_firmware.17.06.01z1.SPA.pkg stby-harddisk:
```



Note

When upgrading SUP0, run the CLI with the R0 setting while controlling SUP0. And when upgrading SUP1, run the CLI with the R1 setting.



Note

This guide assumes SUP0 is in active state and SUP1 is in standby hot state at the beginning.

Perform step 1 to 4 using console connection of active SUP0:

Step 1 Set the config register.

configure terminal config-register 0x2102 end write memory

Step 2 Run the following command to prepare for R0 upgrade.

```
upgrade hw-programmable cable R0 viper pkg_name /harddisk/cbrsup-programmable firmware.17.06.01z1.SPA.pkg
```

On SUP 250, you will see one of the following outputs:

upgrade.
You are upgrading Viper firmware using harddisk/cbrsup-programmable_firmware.17.06.01z1.SPA.pkg image on SUPO, SUPO is active.
Upgrade from assigned pkg file harddisk/cbrsup-programmable_firmware.17.06.01z1.SPA.pkg
Using viper firmware /tmp/viper/mount/supve_viper_fpga_psirt.bin
Size of Viper Upgrade image: 16777216 bytes
No.of parts: 65536
Upgrading golden image...

• It takes 10~20 minutes to upgrade. Console would hung. Please don't do any operation during the

No.of parts: 65536
Upgrading golden image...
65536+0 records in
65536+0 records out
16777216 bytes (17 MB, 16 MiB) copied, 688.873 s, 24.4 kB/s
Upgrading primary image...
65536+0 records in
65536+0 records out
16777216 bytes (17 MB, 16 MiB) copied, 675.19 s, 24.8 kB/s
Viper upgrade clean up 0
Upgrade successfully. Please make sure Rommon version is matched.

Please power cycle the chassis to let the new firmware take effect

 \bullet It takes 10~20 minutes to upgrade. Console would hung. Please don't do any operation during the upgrade.

You are upgrading Viper firmware using harddisk/cbrsup-programmable_firmware.17.06.01z1.SPA.pkg image on SUPO, SUPO is active.

Upgrade from assigned pkg file harddisk/cbrsup-programmable_firmware.17.06.01z1.SPA.pkg
The golden viper is not compatible with assigned firmware
/tmp/viper/mount/supve_viper_fpga_psirt.bin, no upgrade will be performed
Viper upgrade clean up 2

Note This output means the SUP already has the latest version it can support, skip the rest of the steps.

On SUP 160, you will see one of the following outputs:

• It takes about 10 minutes to upgrade. Console would hung. Please don't do any operation during the upgrade.

You are upgrading Viper firmware using harddisk/cbrsup-programmable_firmware.17.06.01z1.SPA.pkg image

Upgrade from assigned pkg file /harddisk/cbrsup-programmable_firmware.17.06.01z1.SPA.pkg Using viper firmware /tmp/viper/mount/viper_fpga.bin Size of Viper Upgrade image: 16777216 bytes

No.of parts: 65536 65536+0 records in

65536+0 records out

Viper upgrade clean up 0

 ${\tt Upgrade \ successfully. \ Please \ make \ sure \ Rommon \ version \ is \ matched.}$

Please power cycle the chassis to let the new firmware take effect

 \bullet It takes 10~20 minutes to upgrade. Console would hung. Please don't do any operation during the upgrade.

You are upgrading Viper firmware using harddisk/cbrsup-programmable_firmware.17.06.01z1.SPA.pkg image on SUPO, SUPO is active.

Upgrade from assigned pkg file harddisk/cbrsup-programmable_firmware.17.06.01z1.SPA.pkg
The golden viper is not compatible with assigned firmware
/tmp/viper/mount/supve_viper_fpga_psirt.bin, no upgrade will be performed
Viper upgrade clean up 2

Note This output means the SUP already has the latest version it can support, skip the rest of the steps.

Note Do not power cycle the chassis in this step.

Step 3 Run the following command to prepare for R1 upgrade.

```
upgrade hw-programmable cable R1 viper pkg_name /harddisk/cbrsup-programmable firmware.17.06.01z1.SPA.pkg
```

You will see the similar output as the one in Step 2.

Note Do not power cycle the chassis in this step.

Step 4 If the supervisor ViperSO CPLD version is 15111401 and the supervisor ViperSIO CPLD version is 15111301 on both supervisors, follow step 5 - 11 to do the upgrade. Otherwise proceed to step 12.

```
Router#show platform diag
Load for five secs: 6%/1%; one minute: 7%; five minutes: 8%
Time source is NTP, 16:05:43.546 PST Thu Feb 8 2018
Chassis type: CBR-8-CCAP-CHASS
<SNTP>
Slot: SUPO, CBR-CCAP-SUP-160G
       Physical insert detect time : 00:01:58 (1d03h ago)
       CPLD version : 16052011
       ViperSO CPLD version
                                : 15111401
       ViperSIO CPLD version
                                : 15111301
       Rommon version
                                 : 16.7(1r)S
                                : 00000112
       Blackbird version
       Raptor ESI version
Raptor MAC version
                                  : 0001003b
                                : 00010031
       SUP-PIC CPLD version : 14071504
                                : 14072207
       SUP-DC CPLD version
       DTI Client FPGA version : 00000005
       DTI Firmware version
                                  : 00000A03
                                 : 201402061607
       Cortina PHY version
       SUP PSOC 0 version
                                : v4.0.9
       SUP PSOC 1 version
                                : v4.0.8
       SUP PSOC 2 version
                                : v4.1.0 IVB
       SUP PSOC 3 version
                                 : v4.0.6
       SUP-DC PSOC 0 version
                                  : v4.0.8
       SUP-DC PSOC 1 version
                                  : v4.0.5
                                 : V2.0.6
       SUP-PIC PSOC 0 version
       SUP-PIC PSOC 1 version
                                 : V2.0.6
<SNIP>
Slot: SUP1, CBR-CCAP-SUP-160G
       Physical insert detect time : 00:02:26 (1d03h ago)
       CPLD version : 16052011

ViperSO CPLD version : 15111401
                               : 15111301
       ViperSIO CPLD version
       Rommon version
                                 : 16.7(1r)S
                                 : 00000112
: 0001003b
       Blackbird version
       Raptor ESI version
Raptor MAC version
                                : 00010031
       SUP-PIC CPLD version
                                : 14071504
       SUP-DC CPLD version
                                : 14072207
       DTI Client FPGA version : 00000005
       DTI Firmware version
                                  : 00000A03
       Cortina PHY version
                                 : 201402061607
       SUP PSOC 0 version
                                 : v4.0.9
       SUP PSOC 1 version
                                : v4.0.8
       SUP PSOC 2 version
                                : v4.1.0_ IVB
       SUP PSOC 3 version
                                  : v4.0.6
```

```
SUP-DC PSOC 0 version : v4.0.9
SUP-DC PSOC 1 version : v4.0.5
SUP-PIC PSOC 0 version : V3.0.0
SUP-PIC PSOC 1 version : V3.0.0
<SNIP>
```

Step 5 Set SUP0 to ROMMON using the following command.

redundancy force-switchover

Perform the following steps 6 to 7 using console connection of current active SUP1.

Step 6 Power cycle the SUP0 to set it to ROMMON.

```
test platform hardware slot RO oir power-cycle
```

This command will reset and re-initialize the ROMMON. The new version of the supervisor CPLD will now take effect. Verify if it matches the following new version.

SUP 160 new version: 0x19071712 SUP 250 new version: 0x190717E1

Step 7 Boot SUP0 into IOS XE using SUP0 console connection.

```
dir harddisk: boot harddisk:cbrsup-universalk9.17.06.01z1.SPA.bin
```

Wait utill SUP0 is in standby hot.

Step 8 Set SUP1 to ROMMON using the following command.

redundancy force-switchover

Perform the following steps 9 to 11 using console connection of current active SUP0.

Step 9 Power cycle the SUP1 to set it to ROMMON.

```
test platform hardware slot R1 oir power-cycle
```

This command will reset and re-initialize the ROMMON. The new version of the supervisor CPLD will now take effect. Verify if it matches the following new version.

SUP 160 new version: 0x19071712 SUP 250 new version: 0x190717E1

Step 10 Boot SUP1 into IOS XE using SUP1 console connection.

```
dir harddisk:
boot harddisk:cbrsup-universalk9.17.06.01z1.SPA.bin
```

Wait utill SUP1 is in standby hot.

Step 11 Wait for the chassis to become SSO and settled down. Then go to step 16. If you skipped step 5 to 10, perform step 12 to 15.

Note You need physical access to the chassis to power cycle the chassis.

Step 12 Reload the system by issuing **reload** command on the active SUP.

Router#reload

Step 13 Power cycle both supervisors.

Step 14 Verify if the new version matches the following on both SUPs.

SUP 160 new version: 0x19071712 SUP 250 new version: 0x190717E1

Step 15 Boot both SUP0 and SUP1 into IOS XE using SUP0 and SUP1 console.

```
dir harddisk: boot harddisk:cbrsup-universalk9.17.06.01z1.SPA.bin
```

Wait till SUP0 become standby hot.

Step 16 Once the system is up and running, perform the following checks.

• Set config register to normal boot.

```
configure terminal
config-register 0x2102
end
write memory
```

- Execute **show redundancy** command to ensure both SUPs are listed, one is active and the other is standby hot.
- Execute show proc CPU sorted | ex 0.00 command.
- Execute show platform diag command.

Upgrading cBR CCAP 8x10G Remote PHY Digital Physical Interface Card

Before you begin

Before upgrading the system, make sure the following requirements are met:

- Make sure the latest available IOS XE version is active in Cisco cBR-8 router.
- There are at lease 20MB free space on the harddisk.



Note

To make use of the new features, it is recommended to upgrade the cBR CCAP 8x10G Remote PHY Digital Physical Interface Card (D-PIC) to the latest version 1.1.

Step 1 Boot up system, wait until IOS is ready.

Step 2 Check current D-PIC version.

show hw-module subslot x/1 fpd

Note x/1 is D-PIC subslot number which needs upgrade.

Example:

Router#show hw-module subslot 9/1 fpd

		=====			
		H/W	Field Programmable	Current	Min. Required
Slot	Card Type	Ver.	Device: "ID-Name"	Version	Version
====					==========
9/1	CBR-DPIC-8X10G	1.0	46-CBR DIGI PIC	1.0	1.0
====					

Step 3 Upgrade D-PIC.

upgrade hw-module subslot x/1 fpd bundled reload

Example:

Router#upgrade hw-module subslot 9/1 fpd bundled reload

% The following FPD will be upgraded for CBR-DPIC-8X10G (H/W ver = 1.0) in subslot 9/1:

Field Programmable	Current	Upgrade	Estimated
Device: "ID-Name"	Version	Version	Upgrade Time
46-CBR DIGI PIC	1.0	1.1	00:05:00

- % NOTES:
 - Use 'show upgrade fpd progress' command to view the progress of the FPD upgrade.
 - The target card will be automatically reloaded after the upgrade operation. This reload will interrupt normal operation of the card. If necessary, ensure that appropriate actions have been taken to redirect card traffic before starting the FPD upgrade.
- \$ Are you sure that you want to perform this operation? [no]: yes \$ Initiating the upgrade operation on the target card ...
- (Use "show upgrade fpd progress" command to see upgrade progress)

Step 4 Check if the upgrade process is finished. Upgrade progress will take about 1 to 2 minutes.

show upgrade fpd progress

Example:

Upgrade still ongoing:

Router#show upgrade fpd progress

FPD Image Upgrade Progress Table:

====					
			Approx.		
		Field Programmable	Time	Elapsed	
Slot	Card Type	Device : "ID-Name"	Needed	Time	State
====					
9/1	CBR-DPIC-8X10G	46-CBR DIGI PIC	00:05:00	00:00:13	Updating
====					

Router# show upgrade fpd progress

FPD Image Upgrade Progress Table:

			Approx.		
		Field Programmable	Time	Elapsed	
Slot	Card Type	Device : "ID-Name"	Needed	Time	State
====					
9/1	CBR-DPIC-8X10G	46-CBR DIGI PIC	00:05:00	00:00:26	Updating

Upgrade finished:

Router#show upgrade fpd progress

% There is no FPD image upgrade in progress.

Step 5 Check if the D-PIC status is ready.

show platform

Example:

Router#show platform

Chassis type: CBR-8-CCAP-CHASS

Slot	Туре	State	Insert time (ago)
8/1 9 9/1	CBR-CCAP-LC-40G	ok ok ok ok ok	00:08:48 00:12:46 00:08:48 00:07:56 00:12:46 00:07:54 00:12:46
4 4/1 SUP1 R1 F1 5	CBR-SUP-8X10G-PIC CBR-CCAP-SUP-160G	ok, active ok	00:07:55 00:12:22 00:07:54
P0 P1 P2 P3 P4 P5 P10 P11 P12	PWR-3KW-AC-V2 PWR-3KW-AC-V2 PWR-3KW-AC-V2 Unknown Unknown PWR-3KW-AC-V2 CBR-FAN-ASSEMBLY CBR-FAN-ASSEMBLY CBR-FAN-ASSEMBLY	ok ps, fail N/A N/A ok ok ok	00:09:49 00:09:49 00:09:49 never never 00:09:49 00:09:39 00:09:39 00:09:39

Step 6 Check if the new version works.

show hw-module subslot x/1 fpd

Example:

Router#show hw-module subslot 9/1 fpd

====		=====			
			Field Programmable		-
Slot	Card Type	Ver.	Device: "ID-Name"	Version	Version
====	=======================================		=======================================		==========
9/1	CBR-DPIC-8X10G	1.0	46-CBR DIGI PIC	1.1	1.0
====					

Upgrading Uboot For CBR-CCAP-LC-40G

Step 1 Copy the package file (cbrsup-programmable firmware.17.06.01z1.SSA.pkg) to the active SUP's harddisk.

copy <location>/cbrsup-programmable firmware.17.06.01z1.SPA.pkg harddisk:

Step 2 Upgrade Uboot using the following CLI command:

upgrade hw-programmable cable <slot#> rommon pkg_name harddisk/cbrsup-programmable firmware.17.06.01z1.SSA.pkg

Example:

Router#upgrade hw-programmable cable <slot#> rommon pkg_name harddisk/cbrsup-programmable_firmware.17.06.01z1.SSA.pkg

UBOOT:

FILE : /tmp/fpd/mount/uboot.bin.SPA

VERSION : U-Boot 2011.03.19

BYTES : 1441792

Upgrade Field Region: SUCCESS! Please reload the card to let the new firmware take effect.

Step 3 Reload Line Card using the following CLI command:

Router#hw-module slot <slot#> reload

Step 4 Check the Uboot version after LC boot up using the following CLI command:

show platform diag

Example:

```
Router# show platform diag
...
Slot: 1, CBR-CCAP-LC-40G
```

```
Running state
               : ok
: online
                          : ok
Internal state
Internal operational state : ok
Physical insert detect time: 00:03:11 (5d11h ago)
Software declared up time : 00:07:46 (5d11h ago)
                         : 00000025
CPLD version
                          : 2011.03.19
Rommon version
Basestar version
                         : 00200057
Raider version
                         : 02010019
dsphy0_fpga version
                         : 4.484B
                         : 3.1A
dsphy0_micro version
dsphy0_psoc version dsphy0_cpld version
                         : 4.4
: 0.7
dsphyl_fpga version
                         : 4.484B
dsphy1 micro version
                         : 3.1A
                         : 4.4
dsphy1_psoc version
                         : 0.7
: 0002000a
dsphy1_cpld version
Caprica version
                         : N/A
HA-PLL version
PSOC 0 version
                         : v4.6
                         : v4.6
PSOC 1 version
```

Upgrading the Cisco cBR Series Converged Broadband Routers for Cisco IOS XE Bengaluru 17.6

Upgrading Uboot For CBR-CCAP-LC-40G



Upgrading the Cisco cBR-8 Router System to Cisco IOS XE Bengaluru 17.6.1z



Note

Starting from Cisco IOS XE Bengaluru 17.6.1a, CBR-CCAP-LC-G2-R can only protect CBR-CCAP-LC-G2-R for linecard HA.



Note

If you are using TACACS authentication, the TACACS configuration will be automatically updated to the new version after upgrading to Cisco IOS XE Bengaluru 17.6.1z. This is a fix to CSCvu62273 and you do not need to take any action regarding the TACACS configuration in the cBR-8 prior to the upgrade.

This section contains the upgrade procedures for the Cisco cBR-8 Router System.

By default, telnet is disabled on Cisco cBR-8. If you are going to use telnet to access the device, make sure the value of line **vty transport** is correct and save the configuration in order to enable telnet.

```
Router# show run | begin line vty
line vty 0 4
exec-timeout 0 0
privilege level 15
password 7 104D081B094410055F
exec prompt timestamp
transport input all
line vty 5 98
exec-timeout 0 0
privilege level 15
password 7 02050D480809
transport input all
line vty 99
transport input all
!
```

The following table encompasses all versions that customers are required to update to support Cisco IOS XE Bengaluru 17.6.1z. All other firmware versions are either not upgradable by the customer, or not required to be upgraded for Cisco IOS XE Bengaluru 17.6.1z support. Use the commands in the tables to verify the firmware versions. If you need to upgrade firmware first, refer to the steps in Upgrading the Cisco cBR-8 Router Firmware.



Note

If you want to upgrade Supervisor CPLD firmware, refer to Upgrading Supervisor CPLD Firmware, on page 38.

Table 2: Firmware Versions

Internal Name	Component Name	Required Minimum Version	Command
Supervisor CPLD	CBR-CCAP-SUP-160G CPLD	16052011/19071712	show platform
	CBR-CCAP-SUP-250G CPLD	170724E0/190717E1	show platform
Supervisor ROMMON	CBR-CCAP-SUP-160G ROMMON and CBR-CCAP-SUP-250G ROMMON	16.7(8r)S	show platform
Line Card CPLD	CBR-CCAP-LC-40G CPLD	00000026	show platform diag
Docsis 3.1 downstream module Micro	CBR-CCAP-LC-40G Gemini2 Micro	3.1A	show platform diag
Docsis 3.1 downstream module FPGA	CBR-CCAP-LC-40G Gemini2 Apollo	4.484F	show platform diag
DPIC Uboot and FPGA	CBR-DPIC-8X10G Firmware	00010001	show platform diag
DPIC 100G Uboot and FPGA	CBR-DPIC-2X100G Firmware	00020006	show platform diag



Note

If the user wants to upgrade Supervisor CPLD to version 19071712 and 190717E1, the chassis must be running with Cisco IOS XE Gibraltar 16.12.1w or later releases.



Note

Cisco recommends that operators upgrade their On-Premise SSM Satellite software versions to v7.x or later releases, to ensure the compatibility with cBR-8.

- Verify max-carrier value, on page 27
- Upgrading from Cisco IOS XE 16.x and later releases to Cisco IOS XE Bengaluru 17.6.1z, on page 28
- Upgrading Supervisor CPLD Firmware, on page 38

• Upgrading cBR CCAP 8x10G Remote PHY Digital Physical Interface Card, on page 43

Verify max-carrier value

Currently in Remote PHY system, max-carrier value can be configured in the downstream controller profile as well as in RPD configuration for Cisco Remote PHY Shelf 300/600/7200. This may lead to inconsistent max-carrier value configurations.

Starting from Cisco IOS XE Gibraltar 16.10.1f, max-carrier value configured in the **cable rpd** mode is removed and RPD will use the max-carrier value configured in the **controller-profile** mode for the power calculation.

Before upgrading to Cisco IOS XE Gibraltar 16.10.1f or later releases, verify if the max-carrier values configured in the RPD shelf configuration and downstream controller profile(s) associated to RPD downstream port are the same. If they are different, update the cBR-8 configuration prior to upgrade.

Below is an example of correct configuration before upgrade.

```
cable downstream controller-profile 1
max-carrier 128
max-ofdm-spectrum 384000000
rf-chan 0 3
 type DOCSIS
 gam-profile 1
 frequency 381000000
 rf-output NORMAL
 docsis-channel-id 1
cable downstream controller-profile 2
max-carrier 158
max-ofdm-spectrum 384000000
rf-chan 158
 docsis-channel-id 159
 ofdm channel-profile 20 start-frequency 579000000 width 48000000 plc 600000000
cable rpd test
identifier 0001.0001.0001
type shelf
rpd-ds 0 max-carrier 128
rpd-ds 0 base-power 33
rpd-ds 1 max-carrier 158
rpd-ds 1 base-power 25
core-interface Te9/1/0
 rpd-ds 0 downstream-cable 9/0/3 profile 1
 rpd-ds 0 downstream-cable 9/0/4 profile 2
 rpd-us 0 upstream-cable 9/0/3 profile 1
r-dti 1
rpd-event profile 0
rpd-55d1-us-event profile 0
```



Note

It is highly recommended to follow this example to check and update configuration if necessary because max-carrier value is used to compute the base power. Otherwise, after upgrade the expected base power value can be different which may affect cable modem coming online.



Note

If you upgrade from a version lower than Cisco IOS XE Fuji 16.9.1, base power range may be changed on the port with OFDM channel configured. So be aware of the potential base power change before and after the upgrade.

Upgrading from Cisco IOS XE 16.x and later releases to Cisco IOS XE Bengaluru 17.6.1z

If you are upgrading from Cisco IOS XE Everest 16.6.x or Cisco IOS XE Fuji 16.7.x to Cisco IOS XE Bengaluru 17.6.1z, perform the following steps to upgrade SUP ROMMON manually. Otherwise proceed with the IOS upgrade.

- Download hardware programmable devices upgrade package file cbrsup-programmable_firmware.17.06.01z.SPA.pkg from the following Cisco.com Software Center URL: https://software.cisco.com/download/home/286283913/type
- **2.** Copy the package file to harddisk:.

```
copy <location>/cbrsup-programmable_firmware.17.06.01z.SPA.pkg harddisk:
```

3. Verify the hardware programmable devices upgrade package against the md5 hash as provided in the Cisco.com Software center.

verify /md5 harddisk:cbrsup-programmable_firmware.17.06.01z.SPA.pkg

4. Upgrade SUP ROMMON.

```
Router#Upgrade rom-mon file harddisk:cbrsup-programmable_firmware.17.06.01z.SPA.pkg r0
Wait for the following output on the console:
ROMMON upgrade complete.
To make the new ROMMON permanent, you must restart the RP

Router#Upgrade rom-mon file harddisk:cbrsup-programmable_firmware.17.06.01z.SPA.pkg r1
Wait for the following output on the console:
ROMMON upgrade complete.
To make the new ROMMON permanent, you must restart the RP
```



Note

Do not restart the SUPs currently, you can combine reloading the SUP with the IOS upgrade process.

If you are using cBR CCAP 8x10G Remote PHY Digital Physical Interface Card (D-PIC) with CBR-CCAP-LC-G2-R linecards, before upgrading to Cisco IOS XE Bengaluru 17.6.1z, contact your local Cisco representative to get the python tool and perform the following steps in order to predict and avoid downtime. This python tool is developed by Cisco, it is used to analyze the cBR-8 configuration file to determine if the configuration file includes non-compliant TenGigabitEthernet interface to downstream controller mappings, and update the configuration file to be compliant with the latest Cisco IOS XE Bengaluru 17.6.1z.

1. Collect the following information from the target cBR-8 to upgrade.

```
Router#show cable rpd sum
Router#show cable modem sum
Router#show cable video session all sum
```

2. Save the running configuration to the harddisk of the cBR-8.

Router#copy running-config harddisk:SavedConfig.txt

3. Copy the saved running configuration from harddisk: to an offline server for editing using SCP.

```
Router#copy harddisk:SavedConfig.txt scp:<path>
```

- **4.** Run the python tool to modify the controllers in the saved configuration.
 - Option 1 Renumber Downstream-Cable controllers only
 - **a.** Execute python script **kobol_ph2_controller_migration.py**. This script is intended for customers who do not immediately intend to take advantage of the Downstream-Video controllers and expanded SG capacity on CBR-CCAP-LC-G2-R.

```
$ python kobol_ph2_controller_migration.py
Enter the name of the configuration file: SavedConfig.txt
```

b. Output file appends **_remap_controller** to the file name.

```
Output file name: SavedConfig.txt remap controller
```

- **c.** Check to ensure that the script completed successfully. If no output file is created or the size of the output file is 0 byte, then check script output for error messages.
- Option 2 Renumber Downstream-Cable and utilize Downstream-Video controllers
- a. Execute python script kobol_ph2_controller_migration_video.py. This script is intended for customers who wish to utilize the new Downstream-Video controllers to free up existing Downstream-Cable controllers for expanded DOCSIS service groups.

```
$ python kobol_ph2_controller_migration_video.py
Enter the name of the configuration file: SavedConfig.txt
```

b. Output file appends **_remap_controller_video** to the file name.

```
Output file name: SavedConfig.txt remap controller video
```

- **c.** Check to ensure that the script completed successfully. If no output file is created or the size of the output file is 0 byte, then check script output for error messages.
- 5. Modify the remapped configuration file to specify the Cisco IOS XE Bengaluru 17.6.1z image in the boot parameter.

```
boot system harddisk:cbrsup-universalk9.17.06.01z.SPA.bin
```

6. Copy the final remapped configuration file back to the cBR-8 harddisk.

```
Router#copy scp:<path>/SavedConfig.txt_remap_controller harddisk:
or
Router#copy scp:<path>/SavedConfig.txt remap controller video harddisk:
```

7. Copy remapped configuration file to startup of the cBR-8.

```
Router#copy harddisk:SavedConfig.txt_remap_controller startup-config or
```

Router#copy harddisk: SavedConfig.txt remap controller video startup-config

Upgrading using reload

Before you begin



Note

If you are upgrading from Cisco IOS XE Everest 16.6.x or Cisco IOS XE Fuji 16.7.x to Cisco IOS XE Bengaluru 17.6.1z, perform pre-upgrade steps 1 to 4 to upgrade SUP ROMMON manually before proceeding with IOS upgrading.

Before upgrading the system, make sure the following requirements are met:

• Download two files from the following Cisco.com Software Center URL:

https://software.cisco.com/download/home/286283913/type

- IOS XE Software Version 17.6.1z: cbrsup-universalk9.17.06.01z.SPA.bin
- IOS XE Hardware Programmable Devices Version 17.6.1z: cbrsup-programmable_firmware.17.06.01z.SPA.pkg
- **Step 1** Copy Cisco IOS XE Bengaluru 17.6.1z package to harddisk: and stby-harddisk:.

```
copy <location>/cbrsup-universalk9.17.06.01z.SPA.bin harddisk:
copy <location>/cbrsup-universalk9.17.06.01z.SPA.bin stby-harddisk:
```

Step 2 Verify Cisco IOS XE Bengaluru 17.6.1z package against the md5 hash as provided in the Cisco.com Software center.

```
verify /md5 harddisk:cbrsup-universalk9.17.06.01z.SPA.bin verify /md5 stby-harddisk:cbrsup-universalk9.17.06.01z.SPA.bin
```

Step 3 Copy the hardware programmable devices upgrade package to harddisk: if the file has not been copied already.

```
copy <location>/cbrsup-programmable firmware.17.06.01z.SPA.pkg harddisk:
```

Step 4 Verify the hardware programmable devices upgrade package against the md5 hash as provided in the Cisco.com Software center.

```
verify /md5 harddisk:cbrsup-programmable firmware.17.06.01z.SPA.pkg
```

- **Step 5** Configure the chassis to boot the system with Cisco IOS XE Bengaluru 17.6.1z image.
 - **a.** Use the following steps if you do not use cBR CCAP 8x10G Remote PHY Digital Physical Interface Card (D-PIC) with CBR-CCAP-LC-40G-R linecards.

```
configure terminal
no boot system
boot system harddisk:cbrsup-universalk9.17.06.01z.SPA.bin
config-register 0x2102
end
write mem
```

b. Use the following steps if you use cBR CCAP 8x10G Remote PHY Digital Physical Interface Card (D-PIC) with CBR-CCAP-LC-40G-R linecards.

```
configure terminal
config-register 0x2102
end
```

Step 6 Check line card CPLD version via **show platform**. If it is not the minimum version 00000026, upgrade line card CPLD following the sub steps below. Otherwise skip this step.

Note To upgrade the line card CPLD to version 00000026, the cBR-8 must be running Cisco IOS XE Gibraltar 16.12.1 or later releases.

This procedure will trigger a reload of the linecard and will cause an outage if the system is not backed up with LCHA.

Do not power cycle the cBR-8 router during the firmware upgrade process. Power cycling the chassis may corrupt the ROMMON/Uboot image.

a) Run the following pre-upgrade commands on the SUP IOS:

```
upgrade hw-programmable cable active_SUP daggit pre-upgrade slot LC_slot_#
Example:
Router# upgrade hw-programmable cable RO daggit pre-upgrade slot 0
```

```
Daggits pre-upgrade successful
```

b) Upgrade the line card CPLD firmware using the SUP IOS command.

Note Do not reboot the line card until the upgrade is complete. Upgrade takes approximately 15 minutes.

upgrade hw-programmable cable LC_slot_# daggit pkg_name firmware_pkg_location_path Example:

```
Router# upgrade hw-programmable cable 0 daggit pkg_name /harddisk/cbrsup-programmable_firmware.17.06.01z.SPA.pkg
```

c) After the upgrade is complete (takes approximately 15 minutes), the line card moves to **unknown** state. Check the status of the line card using the **show platform** command. When the line card is in **unknown** state, run the following command to recover the line card:

```
upgrade hw-programmable cable <code>active_SUP</code> daggit lc-recovery slot <code>LC_slot_#</code> Example:
```

```
\hbox{{\tt Router\#} upgrade $hw$-programmable cable $R0$ daggit $lc$-recovery slot $0$}
```

d) The line card moves from **booting** to **active** state. Check the version of the line card using the **show platform** command to make sure version is changed to 00000026.

Example:

```
Router#show platform ......

Slot CPLD Version Rommon Version .....

0 00000026 2011.03.18 ...
```

e) When the line card is in **active** state, run the following command to verify the upgrade.

```
upgrade hw-programmable cable active\_SUP daggit post-active slot LC\_slot\_\# Example:
```

```
Router# upgrade hw-programmable cable R0 daggit post-active slot 0 SUCCESS: Daggit ver-38 : Booted from upgradable Image-1
```

Step 7 Check the firmware version of the Docsis 3.1 downstream modules in all slots, if it is different with the version listed in Table 2: Firmware Versions, on page 26, update the firmware using the following command. Otherwise skip this step.

upgrade hw-programmable cable slot dsphy all pkg name firmware pkg location path

Example:

```
Router# upgrade hw-programmable cable 0 dsphy all pkg_name /harddisk/cbrsup-programmable_firmware.17.06.01z.SPA.pkg
```

Step 8 Wait for the system log message asking the user to reload the line card that was upgraded.

Step 9 Reload the system.

Router#reload

During reload, monitor the chassis for any of the following errors, and update the configuration accordingly.

```
Mismatches TE interface. DS controller should be */*/0\sim7, configuration failed. Mismatches TE interface. DS controller should be */*/8\sim15, configuration failed. Mismatches TE interface. DS controller should be */*/16\sim23, configuration failed. Mismatches TE interface. DS controller should be */*/24\sim31, configuration failed.
```

Step 10 If the system is running with SUP250, perform **no shut** on 100G interface after the system comes up for the first time.

What to do next

Perform verification test to determine if the upgrade is successful, include:

- Verify the router is running the new IOS-XE release using **show version** command.
- Check facility alarms using show facility-alarm status command.
- Check the status of the power supplies using **show environment power** command.
- Check PS status using **show platform hardware slot P<0-5> mcu status** command.
- Complete trace routes to known good off-network IP address using the source address of customer CPE blocks to verify routing is working.
- Check logs for error messages using show log command.

These **show** commands may be useful in the verification test:

- · show redundancy
- · show platform
- · show platform diag
- show environment
- · show redundancy linecard all
- · show isis neighbors
- · show ip ospf neighbor
- show ip route rip
- show ip mroute
- show cops servers
- show cable modem voice
- · show cable calls
- show cable metering verbose
- · show cable licenses all
- show inventory

Upgrading with ISSU for I-CCAP Systems

Before you begin



Note

ISSU is not supported for Remote PHY systems.



Note

ISSU to Cisco IOS XE Bengaluru 17.6.1z is supported only from Cisco IOS XE Gibraltar 16.10.1g and later releases. If you are upgrading from an earlier release, you must upgrade the cBR-8 system following the steps in Upgrading using reload, on page 30.

Before upgrading the system, make sure the following requirements are met:

• The cBR-8 has two SUPs installed.

• Standby SUP must be in hot standby state.

• Line card redundancy is in stable state with state Active and Stdby warm.

```
Router# show redundancy linecard all
Load for five secs: 14%/1%; one minute: 8%; five minutes: 8%
Time source is NTP, 15:23:26.697 PST Thu Jan 17 2019
```

Slot	Subslot	LC Group	My State	Peer State	Peer Slot	Peer Subslot	Role	Mode
1	_	0	Active	Stdby Warm	0	-	Active	Primary
2	_	0	Active	Stdby Warm	0	_	Active	Primary
3	_	0	Active	Stdby Warm	0	-	Active	Primary
6	_	0	Active	Stdby Warm	0	-	Active	Primary
0	_	0	-	=	Multiple	None	Standby	Secondary

· Auto-boot is enabled.

```
Router# show bootvar
Load for five secs: 14%/0%; one minute: 14%; five minutes: 10%
Time source is NTP, 15:46:59.837 PST Thu Jan 17 2019

BOOT variable = harddisk:IOSXE/packages.conf,12;
CONFIG_FILE variable =
BOOTLDR variable does not exist
Configuration register is 0x2102

Standby BOOT variable = harddisk:IOSXE/packages.conf,12;
Standby CONFIG_FILE variable =
Standby BOOTLDR variable does not exist
Standby Configuration register is 0x2102
```

• Both SUPs are in the sub-package mode, running the same image from the same path.

```
Router# show bootvar
Load for five secs: 14%/0%; one minute: 14%; five minutes: 10%
Time source is NTP, 15:46:59.837 PST Thu Jan 17 2019

BOOT variable = harddisk:IOSXE/packages.conf,12;
CONFIG_FILE variable =
BOOTLDR variable does not exist
Configuration register is 0x2102

Standby BOOT variable = harddisk:IOSXE/packages.conf,12;
Standby CONFIG_FILE variable =
Standby BOOTLDR variable does not exist
Standby Configuration register is 0x2102
```

• The free space on boot device on both SUPs must be greater than 2GB.

```
Router# dir harddisk: | include bytes total 7804653568 bytes total (5691174912 bytes free)
```

• Download two files from the following Cisco.com Software Center URL:

https://software.cisco.com/download/home/286283913/type

- IOS XE Software Version 17.6.1z: cbrsup-universalk9.17.06.01z.SPA.bin
- IOS XE Hardware Programmable Devices Version 17.6.1z: cbrsup-programmable_firmware.17.06.01z.SPA.pkg
- Copy the target consolidated image **cbrsup-universalk9.17.06.01z.SPA.bin** to the active SUP in the same directory of the **packages.conf** file that the system is booted up with.
- **Step 1** Copy Cisco IOS XE Bengaluru 17.6.1z package to harddisk:.

```
copy <location>/cbrsup-universalk9.17.06.01z.SPA.bin harddisk:<sub-pkg-dir>/
```

Step 2 Verify Cisco IOS XE Bengaluru 17.6.1z package against the md5 hash as provided in the Cisco.com Software center.

```
verify /md5 harddisk:<sub-pkg-dir>/cbrsup-universalk9.17.06.01z.SPA.bin
```

Step 3 Copy the hardware programmable devices upgrade package to harddisk: if the file has not been copied already.

```
copy <location>/cbrsup-programmable firmware.17.06.01z.SPA.pkg harddisk:
```

Step 4 Verify the hardware programmable devices upgrade package against the md5 hash as provided in the Cisco.com Software center.

```
verify /md5 harddisk:cbrsup-programmable firmware.17.06.01z.SPA.pkg
```

- **Step 5** Check system status prior to upgrade. Save the information to compare against the system status after upgrade. For the commands to use to check the status, see the **show** commands at the end of this section.
- **Step 6** Check line card CPLD version via **show platform**. If it is not the minimum version 00000026, upgrade line card CPLD following the sub steps below. Otherwise skip this step.

Note To upgrade the line card CPLD to version 00000026, the cBR-8 must be running Cisco IOS XE Gibraltar 16.12.1 or later releases.

This procedure will trigger a reload of the linecard and will cause an outage if the system is not backed up with LCHA.

Do not power cycle the cBR-8 router during the firmware upgrade process. Power cycling the chassis may corrupt the ROMMON/Uboot image.

a) Run the following pre-upgrade commands on the SUP IOS:

upgrade hw-programmable cable active_SUP daggit pre-upgrade slot LC_slot_# Example:

```
Router# upgrade hw-programmable cable R0 daggit pre-upgrade slot 0 Daggits pre-upgrade successful
```

b) Upgrade the line card CPLD firmware using the SUP IOS command.

Note Do not reboot the line card until the upgrade is complete. Upgrade takes approximately 15 minutes.

upgrade hw-programmable cable LC_slot_# daggit pkg_name firmware_pkg_location_path Example:

```
Router# upgrade hw-programmable cable 0 daggit pkg_name /harddisk/cbrsup-programmable_firmware.17.06.01z.SPA.pkg
```

c) After the upgrade is complete (takes approximately 15 minutes), the line card moves to **unknown** state. Check the status of the line card using the **show platform** command. When the line card is in **unknown** state, run the following command to recover the line card:

upgrade hw-programmable cable <code>active_SUP</code> daggit lc-recovery slot <code>LC_slot_#</code> Example:

```
Router# upgrade hw-programmable cable RO daggit lc-recovery slot 0
```

d) The line card moves from **booting** to **active** state. Check the version of the line card using the **show platform** command to make sure version is changed to 00000026.

Example:

CBR8#show platform
.....

Slot CPLD Version Rommon Version

0 00000026 2011.03.18

e) When the line card is in **active** state, run the following command to verify the upgrade.

upgrade hw-programmable cable active_SUP daggit post-active slot LC_slot_#
Example:

```
Router# upgrade hw-programmable cable R0 daggit post-active slot 0 SUCCESS: Daggit ver-38 : Booted from upgradable Image-1
```

Step 7 Check the firmware version of the Docsis 3.1 downstream modules in all slots, if it is different with the version listed in Table 2: Firmware Versions, on page 26, update the firmware using the following command. Otherwise skip this step.

upgrade hw-programmable cable slot dsphy all pkg_name firmware_pkg_location_path

Example:

```
Router# upgrade hw-programmable cable 0 dsphy all pkg_name /harddisk/cbrsup-programmable_firmware.17.06.01z.SPA.pkg
```

Step 8 Wait for the system log message asking the user to reload the line card that was upgraded. But do not reload the line card at this time.

```
001860: Jun 15 19:05:05.904 PDT: \text{NIOSXE-5-PLATFORM}: CLC0: cdman: Suggest reload the line card for new FW to take effect using CLI: hw slot \text{slot-id} reload
```

Step 9 Perform ISSU.

request platform software package install node file harddisk:cbrsup-universalk9.17.06.01z.SPA.bin

Step 10 To monitor the ISSU progress, use the command below.

request platform software package install node attach

Step 11 Use these CLI to check status after ISSU.

```
show version r0 running show version r1 running show version r0 provisioned show version r1 provisioned
```

What to do next

Perform verification test to determine if the upgrade is successful, include:

- Verify the router is running the new IOS-XE release using **show version** command.
- Check facility alarms using **show facility-alarm status** command.
- Check the status of the power supplies using **show environment power** command.

- Check PS status using **show platform hardware slot P<0-5> mcu status** command.
- Complete trace routes to known good off-network IP address using the source address of customer CPE blocks to verify routing is working.
- Check logs for error messages using show log command.

These **show** commands may be useful in the verification test:

- · show redundancy
- show platform
- · show platform diag
- · show environment
- · show redundancy linecard all
- · show isis neighbors
- show ip ospf neighbor
- · show ip route rip
- show ip mroute
- show cops servers
- · show cable modem voice
- show cable calls
- · show cable metering verbose
- · show cable licenses all
- · show inventory

Upgrading Supervisor CPLD Firmware

Before you begin



Note

If the supervisor SO CPLD version is lower than 1511_1401 (SUP 160) or 15111401 (SUP 250), or, if the supervisor SIO CPLD version is lower than 1511_1301 (SUP 160) or 15111301 (SUP 250), physically power cycle the chassis when upgrading the supervisor CPLD.

Before upgrading the firmware, make sure the following requirements are met:

- Cisco cBR-8 router is running with Cisco IOS XE Gibraltar 16.12.1w or later releases.
- 2 supervisors are running in the Cisco cBR-8 router and the redundancy is enabled.
- Download the file from the following Cisco.com Software Center URL:

https://software.cisco.com/download/home/286283913/type

- IOS XE Hardware Programmable Devices Version 17.6.1z: cbrsup-programmable_firmware.17.06.01z.SPA.pkg
- Console access for both supervisors are required.
- Copy the new firmware package to the cBR-8 using FTP.

```
copy ftp://<location>/cbrsup-programmable_firmware.17.06.01z.SPA.pkg harddisk:
copy ftp://<location>/cbrsup-programmable_firmware.17.06.01z.SPA.pkg stby-harddisk:
```



Note

When upgrading SUP0, run the CLI with the R0 setting while controlling SUP0. And when upgrading SUP1, run the CLI with the R1 setting.



Note

This guide assumes SUP0 is in active state and SUP1 is in standby hot state at the beginning.

Perform step 1 to 4 using console connection of active SUP0:

Step 1 Set the config register.

```
configure terminal
config-register 0x2102
end
write memory
```

Step 2 Run the following command to prepare for R0 upgrade.

```
upgrade hw-programmable cable R0 viper pkg_name /harddisk/cbrsup-programmable firmware.17.06.01z.SPA.pkg
```

On SUP 250, you will see one of the following outputs:

 \bullet It takes 10~20 minutes to upgrade. Console would hung. Please don't do any operation during the upgrade.

```
You are upgrading Viper firmware using harddisk/cbrsup-programmable_firmware.17.06.01z.SPA.pkg image on SUPO, SUPO is active.
```

```
Upgrade from assigned pkg file harddisk/cbrsup-programmable_firmware.17.06.01z.SPA.pkg
Using viper firmware /tmp/viper/mount/supve_viper_fpga_psirt.bin
Size of Viper Upgrade image: 16777216 bytes
No.of parts: 65536
Upgrading golden image...
65536+0 records in
65536+0 records out
16777216 bytes (17 MB, 16 MiB) copied, 688.873 s, 24.4 kB/s
Upgrading primary image...
65536+0 records in
65536+0 records out
16777216 bytes (17 MB, 16 MiB) copied, 675.19 s, 24.8 kB/s
```

```
Viper upgrade clean up 0
Upgrade successfully. Please make sure Rommon version is matched.
Please power cycle the chassis to let the new firmware take effect
```

• It takes 10~20 minutes to upgrade. Console would hung. Please don't do any operation during the upgrade.

You are upgrading Viper firmware using harddisk/cbrsup-programmable_firmware.17.06.01z.SPA.pkg image on SUPO, SUPO is active.

Upgrade from assigned pkg file harddisk/cbrsup-programmable_firmware.17.06.01z.SPA.pkg The golden viper is not compatible with assigned firmware

/tmp/viper/mount/supve_viper_fpga_psirt.bin, no upgrade will be performed Viper upgrade clean up 2

Note This output means the SUP already has the latest version it can support, skip the rest of the steps.

On SUP 160, you will see one of the following outputs:

• It takes about 10 minutes to upgrade. Console would hung. Please don't do any operation during the upgrade.

You are upgrading Viper firmware using harddisk/cbrsup-programmable_firmware.17.06.01z.SPA.pkg image

Upgrade from assigned pkg file /harddisk/cbrsup-programmable_firmware.17.06.01z.SPA.pkg Using viper firmware /tmp/viper/mount/viper_fpga.bin

Size of Viper Upgrade image: 16777216 bytes

No.of parts: 65536

65536+0 records in

65536+0 records out

Viper upgrade clean up 0

Upgrade successfully. Please make sure Rommon version is matched.

Please power cycle the chassis to let the new firmware take effect

 \bullet It takes 10~20 minutes to upgrade. Console would hung. Please don't do any operation during the upgrade.

You are upgrading Viper firmware using harddisk/cbrsup-programmable_firmware.17.06.01z.SPA.pkg image on SUPO, SUPO is active.

Upgrade from assigned pkg file harddisk/cbrsup-programmable_firmware.17.06.01z.SPA.pkg
The golden viper is not compatible with assigned firmware

/tmp/viper/mount/supve_viper_fpga_psirt.bin, no upgrade will be performed Viper upgrade clean up 2

Note This output means the SUP already has the latest version it can support, skip the rest of the steps.

Note Do not power cycle the chassis in this step.

Step 3 Run the following command to prepare for R1 upgrade.

```
upgrade hw-programmable cable R1 viper pkg_name /harddisk/cbrsup-programmable_firmware.17.06.01z.SPA.pkg
```

You will see the similar output as the one in Step 2.

Note Do not power cycle the chassis in this step.

Step 4 If the supervisor ViperSO CPLD version is 15111401 and the supervisor ViperSIO CPLD version is 15111301 on both supervisors, follow step 5 - 11 to do the upgrade. Otherwise proceed to step 12.

```
Router#show platform diag
Load for five secs: 6%/1%; one minute: 7%; five minutes: 8%
Time source is NTP, 16:05:43.546 PST Thu Feb 8 2018
```

```
Chassis type: CBR-8-CCAP-CHASS
<SNTP>
Slot: SUPO, CBR-CCAP-SUP-160G
         Physical insert detect time: 00:01:58 (1d03h ago)
        CPLD version : 16052011
         ViperSIO CPLD version : 15111401

Rommon version : 15111301
                                       : 16.7(1r)S
        Rommon version
Blackbird version
                                       : 00000112
        Raptor ESI version
Raptor MAC version
                                      : 0001003b
         SUP-PIC CPLD version : 14071504
SUP-DC CPLD version : 14072207
         DTI Client FPGA version : 00000005
         DTI Firmware version
                                       : 00000A03
                                       : 201402061607
         Cortina PHY version
         SUP PSOC 0 version
                                       : v4.0.9
         SUP PSOC 1 version
SUP PSOC 2 version
SUP PSOC 3 version
                                        : v4.0.8
                                        : v4.1.0 IVB
                                       : v4.0.6
         SUP-DC PSOC 0 version : v4.0.8
         SUP-DC PSOC 1 version
                                       : v4.0.5
                                        : V2.0.6
         SUP-PIC PSOC 0 version
         SUP-PIC PSOC 1 version
                                        : V2.0.6
<SNIP>
Slot: SUP1, CBR-CCAP-SUP-160G
         Physical insert detect time : 00:02:26 (1d03h ago)
         version : 15111401 ViperSIO CPLD version : 15111301 Rommon version
        Rommon version
                                        : 16.7(1r)S
         Blackbird version
                                       : 00000112

      Raptor ESI version
      : 0001003b

      Raptor MAC version
      : 00010031

      SUP-PIC CPLD version
      : 14071504

      SUP-DC CPLD version
      : 14072207

        Raptor ESI version
Raptor MAC version
         DTI Client FPGA version : 00000005
         DTI Firmware version
                                       : 00000A03
         Cortina PHY version
                                       : 201402061607
         SUP PSOC 0 version
                                        : v4.0.9
         SUP PSOC 1 version
                                        : v4.0.8
         SUP PSOC 2 version
SUP PSOC 3 version
                                        : v4.1.0_IVB
                                       : v4.0.6
         SUP-DC PSOC 0 version : v4.0.9
         SUP-DC PSOC 1 version
                                       : v4.0.5
         SUP-PIC PSOC 0 version
                                        : V3.0.0
         SUP-PIC PSOC 1 version
                                        : V3.0.0
<SNIP>
```

Step 5 Set SUP0 to ROMMON using the following command.

redundancy force-switchover

Perform the following steps 6 to 7 using console connection of current active SUP1.

Step 6 Power cycle the SUP0 to set it to ROMMON.

test platform hardware slot RO oir power-cycle

This command will reset and re-initialize the ROMMON. The new version of the supervisor CPLD will now take effect. Verify if it matches the following new version.

SUP 160 new version: 0x19071712

SUP 250 new version: 0x190717E1

Step 7 Boot SUP0 into IOS XE using SUP0 console connection.

dir harddisk:

boot harddisk:cbrsup-universalk9.17.06.01z.SPA.bin

Wait utill SUP0 is in standby hot.

Step 8 Set SUP1 to ROMMON using the following command.

redundancy force-switchover

Perform the following steps 9 to 11 using console connection of current active SUP0.

Step 9 Power cycle the SUP1 to set it to ROMMON.

test platform hardware slot R1 oir power-cycle

This command will reset and re-initialize the ROMMON. The new version of the supervisor CPLD will now take effect. Verify if it matches the following new version.

SUP 160 new version: 0x19071712 SUP 250 new version: 0x190717E1

Step 10 Boot SUP1 into IOS XE using SUP1 console connection.

dir harddisk:
boot harddisk:cbrsup-universalk9.17.06.01z.SPA.bin

Wait utill SUP1 is in standby hot.

Step 11 Wait for the chassis to become SSO and settled down. Then go to step 16. If you skipped step 5 to 10, perform step 12 to 15.

Note You need physical access to the chassis to power cycle the chassis.

Step 12 Reload the system by issuing **reload** command on the active SUP.

Router#reload

Step 13 Power cycle both supervisors.

Step 14 Verify if the new version matches the following on both SUPs.

SUP 160 new version: 0x19071712 SUP 250 new version: 0x190717E1

Step 15 Boot both SUP0 and SUP1 into IOS XE using SUP0 and SUP1 console.

dir harddisk: boot harddisk:cbrsup-universalk9.17.06.01z.SPA.bin

Wait till SUP0 become standby hot.

Step 16 Once the system is up and running, perform the following checks.

Set config register to normal boot.

```
configure terminal
config-register 0x2102
end
write memory
```

- Execute **show redundancy** command to ensure both SUPs are listed, one is active and the other is standby hot.
- Execute show proc CPU sorted | ex 0.00 command.
- Execute show platform diag command.

Upgrading cBR CCAP 8x10G Remote PHY Digital Physical Interface Card

Before you begin

Before upgrading the system, make sure the following requirements are met:

- Make sure the latest available IOS XE version is active in Cisco cBR-8 router.
- There are at lease 20MB free space on the harddisk.



Note

To make use of the new features, it is recommended to upgrade the cBR CCAP 8x10G Remote PHY Digital Physical Interface Card (D-PIC) to the latest version 1.1.

- **Step 1** Boot up system, wait until IOS is ready.
- **Step 2** Check current D-PIC version.

```
show hw-module subslot x/1 fpd
```

Note x/1 is D-PIC subslot number which needs upgrade.

Example:

9/1	CBR-DPIC-8X10G	1.0	46-CBR DIGI PIC	1.0	1.0
====	=======================================	======	================		=========

Step 3 Upgrade D-PIC.

upgrade hw-module subslot x/1 fpd bundled reload

Example:

Router#upgrade hw-module subslot 9/1 fpd bundled reload

% The following FPD will be upgraded for CBR-DPIC-8X10G (H/W ver = 1.0) in subslot 9/1:

Field Programmable	Current	Upgrade	Estimated
Device: "ID-Name"	Version	Version	Upgrade Time
=======================================			========
46-CBR DIGI PIC	1.0	1.1	00:05:00
			========

- % NOTES:
 - Use 'show upgrade fpd progress' command to view the progress of the FPD upgrade.
 - The target card will be automatically reloaded after the upgrade operation. This reload will interrupt normal operation of the card. If necessary, ensure that appropriate actions have been taken to redirect card traffic before starting the FPD upgrade.
- % Are you sure that you want to perform this operation? [no]: yes
- % Initiating the upgrade operation on the target card ...
 (Use "show upgrade fpd progress" command to see upgrade progress)

Step 4 Check if the upgrade process is finished. Upgrade progress will take about 1 to 2 minutes.

show upgrade fpd progress

Example:

Upgrade still ongoing:

Router#show upgrade fpd progress

FPD Image Upgrade Progress Table:

			Approx.		
		Field Programmable	Time	Elapsed	
Slot	Card Type	Device : "ID-Name"	Needed	Time	State
9/1	CBR-DPIC-8X10G	46-CBR DIGI PIC	00:05:00	00:00:13	Updating

Router# show upgrade fpd progress

FPD Image Upgrade Progress Table:

====						
			Approx.			
		Field Programmable	Time	Elapsed		
Slot	Card Type	Device : "ID-Name"	Needed	Time	State	

9/1 CBR-DPIC-8X10G 46-CBR DIGI PIC 00:05:00 00:00:26 Updating...

Upgrade finished:

Router#show upgrade fpd progress

% There is no FPD image upgrade in progress.

Step 5 Check if the D-PIC status is ready.

show platform

Example:

Router#show platform

Chassis type: CBR-8-CCAP-CHASS

Slot	Туре	State	Insert time (ago)
2/1	CBR-RF-PROT-PIC	ok	00:08:48
	CBR-CCAP-LC-40G		00:12:46
3/1	CBR-RF-PIC	ok	00:08:48
8/1	CBR-DPIC-8X10G	ok	00:07:56
9	CBR-CCAP-LC-40G	ok	00:12:46
9/1	CBR-DPIC-8X10G	ok	00:07:54
SUP0	CBR-CCAP-SUP-160G	inserted	00:12:46
R0		ok, active	
FO		ok, active	
4		ok, active	
4/1	CBR-SUP-8X10G-PIC	ok	00:07:55
SUP1	CBR-CCAP-SUP-160G	inserted	00:12:22
R1		ok, standby	
F1		ok, standby	
5		ok, standby	
5/1	CBR-SUP-8X10G-PIC	ok	00:07:54
P0	PWR-3KW-AC-V2	ok	00:09:49
P1	PWR-3KW-AC-V2	ok	00:09:49
P2	PWR-3KW-AC-V2	ps, fail	00:09:49
P3	Unknown	N/A	never
P4	Unknown	N/A	never
P5	PWR-3KW-AC-V2	ok	00:09:49
P10	CBR-FAN-ASSEMBLY	ok	00:09:39
P11	CBR-FAN-ASSEMBLY	ok	00:09:39
P12	CBR-FAN-ASSEMBLY	ok	00:09:39
P13	CBR-FAN-ASSEMBLY	ok	00:09:39
P14	CBR-FAN-ASSEMBLY	ok	00:09:39
Slot	CPLD Version	Rommon Version	
9 SUPO	00000025 16052011	2011.03.18 2011.03.18 16.7(3r)S	
SUP1	16052011	16.7(3r)S	

Step 6 Check if the new version works.

show hw-module subslot x/1 fpd

Example:

Router#show hw-module subslot 9/1 fpd

====		=====			
		H/W	Field Programmable	Current	Min. Required
Slot	Card Type	Ver.	Device: "ID-Name"	Version	Version

====		=====			
9/1	CBR-DPIC-8X10G	1.0	46-CBR DIGI PIC	1.1	1.0
====					



Upgrading the Cisco cBR-8 Router System to Cisco IOS XE Bengaluru 17.6.1x



Note

Starting from Cisco IOS XE Bengaluru 17.6.1a, CBR-CCAP-LC-G2-R can only protect CBR-CCAP-LC-G2-R for linecard HA.



Note

If you are using TACACS authentication, the TACACS configuration will be automatically updated to the new version after upgrading to Cisco IOS XE Bengaluru 17.6.1x. This is a fix to CSCvu62273 and you do not need to take any action regarding the TACACS configuration in the cBR-8 prior to the upgrade.

This section contains the upgrade procedures for the Cisco cBR-8 Router System.

By default, telnet is disabled on Cisco cBR-8. If you are going to use telnet to access the device, make sure the value of line **vty transport** is correct and save the configuration in order to enable telnet.

```
Router# show run | begin line vty
line vty 0 4
exec-timeout 0 0
privilege level 15
password 7 104D081B094410055F
exec prompt timestamp
transport input all
line vty 5 98
exec-timeout 0 0
privilege level 15
password 7 02050D480809
transport input all
line vty 99
transport input all
```

The following table encompasses all versions that customers are required to update to support Cisco IOS XE Bengaluru 17.6.1x. All other firmware versions are either not upgradable by the customer, or not required to be upgraded for Cisco IOS XE Bengaluru 17.6.1x support. Use the commands in the tables to verify the firmware versions. If you need to upgrade firmware first, refer to the steps in Upgrading the Cisco cBR-8 Router Firmware.



Note

If you want to upgrade Supervisor CPLD firmware, refer to Upgrading Supervisor CPLD Firmware, on page 60.

Table 3: Firmware Versions

Internal Name	Component Name	Required Minimum Version	Command
Supervisor CPLD	CBR-CCAP-SUP-160G CPLD	16052011/19071712	show platform
	CBR-CCAP-SUP-250G CPLD	170724E0/190717E1	show platform
Supervisor ROMMON	CBR-CCAP-SUP-160G ROMMON and CBR-CCAP-SUP-250G ROMMON	16.7(8r)S	show platform
Line Card CPLD	CBR-CCAP-LC-40G CPLD	00000026	show platform diag
Docsis 3.1 downstream module Micro	CBR-CCAP-LC-40G Gemini2 Micro	3.1A	show platform diag
Docsis 3.1 downstream module FPGA	CBR-CCAP-LC-40G Gemini2 Apollo	4.484F	show platform diag
DPIC Uboot and FPGA	CBR-DPIC-8X10G Firmware	00010001	show platform diag
DPIC 100G Uboot and FPGA	CBR-DPIC-2X100G Firmware	00020006	show platform diag



Note

If the user wants to upgrade Supervisor CPLD to version 19071712 and 190717E1, the chassis must be running with Cisco IOS XE Gibraltar 16.12.1w or later releases.



Note

Cisco recommends that operators upgrade their On-Premise SSM Satellite software versions to v7.x or later releases, to ensure the compatibility with cBR-8.

- Verify max-carrier value, on page 49
- Upgrading from Cisco IOS XE 16.x and later releases to Cisco IOS XE Bengaluru 17.6.1x, on page 50
- Upgrading Supervisor CPLD Firmware, on page 60

• Upgrading cBR CCAP 8x10G Remote PHY Digital Physical Interface Card, on page 65

Verify max-carrier value

Currently in Remote PHY system, max-carrier value can be configured in the downstream controller profile as well as in RPD configuration for Cisco Remote PHY Shelf 300/600/7200. This may lead to inconsistent max-carrier value configurations.

Starting from Cisco IOS XE Gibraltar 16.10.1f, max-carrier value configured in the **cable rpd** mode is removed and RPD will use the max-carrier value configured in the **controller-profile** mode for the power calculation.

Before upgrading to Cisco IOS XE Gibraltar 16.10.1f or later releases, verify if the max-carrier values configured in the RPD shelf configuration and downstream controller profile(s) associated to RPD downstream port are the same. If they are different, update the cBR-8 configuration prior to upgrade.

Below is an example of correct configuration before upgrade.

```
cable downstream controller-profile 1
max-carrier 128
max-ofdm-spectrum 384000000
rf-chan 0 3
 type DOCSIS
 gam-profile 1
 frequency 381000000
 rf-output NORMAL
 docsis-channel-id 1
cable downstream controller-profile 2
max-carrier 158
max-ofdm-spectrum 384000000
rf-chan 158
 docsis-channel-id 159
 ofdm channel-profile 20 start-frequency 579000000 width 48000000 plc 600000000
cable rpd test
identifier 0001.0001.0001
type shelf
rpd-ds 0 max-carrier 128
rpd-ds 0 base-power 33
rpd-ds 1 max-carrier 158
rpd-ds 1 base-power 25
core-interface Te9/1/0
 rpd-ds 0 downstream-cable 9/0/3 profile 1
 rpd-ds 0 downstream-cable 9/0/4 profile 2
 rpd-us 0 upstream-cable 9/0/3 profile 1
r-dti 1
rpd-event profile 0
rpd-55d1-us-event profile 0
```



Note

It is highly recommended to follow this example to check and update configuration if necessary because max-carrier value is used to compute the base power. Otherwise, after upgrade the expected base power value can be different which may affect cable modem coming online.



Note

If you upgrade from a version lower than Cisco IOS XE Fuji 16.9.1, base power range may be changed on the port with OFDM channel configured. So be aware of the potential base power change before and after the upgrade.

Upgrading from Cisco IOS XE 16.x and later releases to Cisco IOS XE Bengaluru 17.6.1x

If you are upgrading from Cisco IOS XE Everest 16.6.x or Cisco IOS XE Fuji 16.7.x to Cisco IOS XE Bengaluru 17.6.1x, perform the following steps to upgrade SUP ROMMON manually. Otherwise proceed with the IOS upgrade.

- Download hardware programmable devices upgrade package file cbrsup-programmable_firmware.17.06.01x.SPA.pkg from the following Cisco.com Software Center URL: https://software.cisco.com/download/home/286283913/type
- **2.** Copy the package file to harddisk:.

```
copy <location>/cbrsup-programmable_firmware.17.06.01x.SPA.pkg harddisk:
```

3. Verify the hardware programmable devices upgrade package against the md5 hash as provided in the Cisco.com Software center.

```
verify /md5 harddisk:cbrsup-programmable_firmware.17.06.01x.SPA.pkg
```

4. Upgrade SUP ROMMON.

```
Router#Upgrade rom-mon file harddisk:cbrsup-programmable_firmware.17.06.01x.SPA.pkg r0
Wait for the following output on the console:
ROMMON upgrade complete.
To make the new ROMMON permanent, you must restart the RP

Router#Upgrade rom-mon file harddisk:cbrsup-programmable_firmware.17.06.01x.SPA.pkg r1
Wait for the following output on the console:
ROMMON upgrade complete.
To make the new ROMMON permanent, you must restart the RP
```



Note

Do not restart the SUPs currently, you can combine reloading the SUP with the IOS upgrade process.

If you are using cBR CCAP 8x10G Remote PHY Digital Physical Interface Card (D-PIC) with CBR-CCAP-LC-G2-R linecards, before upgrading to Cisco IOS XE Bengaluru 17.6.1x, contact your local Cisco representative to get the python tool and perform the following steps in order to predict and avoid downtime. This python tool is developed by Cisco, it is used to analyze the cBR-8 configuration file to determine if the configuration file includes non-compliant TenGigabitEthernet interface to downstream controller mappings, and update the configuration file to be compliant with the latest Cisco IOS XE Bengaluru 17.6.1x.

1. Collect the following information from the target cBR-8 to upgrade.

```
Router#show cable rpd sum
Router#show cable modem sum
Router#show cable video session all sum
```

2. Save the running configuration to the harddisk of the cBR-8.

Router#copy running-config harddisk:SavedConfig.txt

3. Copy the saved running configuration from harddisk: to an offline server for editing using SCP.

```
Router#copy harddisk:SavedConfig.txt scp:<path>
```

- **4.** Run the python tool to modify the controllers in the saved configuration.
 - Option 1 Renumber Downstream-Cable controllers only
 - **a.** Execute python script **kobol_ph2_controller_migration.py**. This script is intended for customers who do not immediately intend to take advantage of the Downstream-Video controllers and expanded SG capacity on CBR-CCAP-LC-G2-R.

```
$ python kobol_ph2_controller_migration.py
Enter the name of the configuration file: SavedConfig.txt
```

b. Output file appends **_remap_controller** to the file name.

```
Output file name: SavedConfig.txt remap controller
```

- **c.** Check to ensure that the script completed successfully. If no output file is created or the size of the output file is 0 byte, then check script output for error messages.
- Option 2 Renumber Downstream-Cable and utilize Downstream-Video controllers
- a. Execute python script kobol_ph2_controller_migration_video.py. This script is intended for customers who wish to utilize the new Downstream-Video controllers to free up existing Downstream-Cable controllers for expanded DOCSIS service groups.

```
$ python kobol_ph2_controller_migration_video.py
Enter the name of the configuration file: SavedConfig.txt
```

b. Output file appends **_remap_controller_video** to the file name.

```
Output file name: SavedConfig.txt remap controller video
```

- **c.** Check to ensure that the script completed successfully. If no output file is created or the size of the output file is 0 byte, then check script output for error messages.
- 5. Modify the remapped configuration file to specify the Cisco IOS XE Bengaluru 17.6.1x image in the boot parameter.

```
boot system harddisk:cbrsup-universalk9.17.06.01x.SPA.bin
```

6. Copy the final remapped configuration file back to the cBR-8 harddisk.

```
Router#copy scp:<path>/SavedConfig.txt_remap_controller harddisk:
or
Router#copy scp:<path>/SavedConfig.txt remap controller video harddisk:
```

7. Copy remapped configuration file to startup of the cBR-8.

```
Router#copy harddisk:SavedConfig.txt_remap_controller startup-config  or \\
```

Router#copy harddisk: SavedConfig.txt remap controller video startup-config

Upgrading using reload

Before you begin



Note

If you are upgrading from Cisco IOS XE Everest 16.6.x or Cisco IOS XE Fuji 16.7.x to Cisco IOS XE Bengaluru 17.6.1x, perform pre-upgrade steps 1 to 4 to upgrade SUP ROMMON manually before proceeding with IOS upgrading.

Before upgrading the system, make sure the following requirements are met:

• Download two files from the following Cisco.com Software Center URL:

https://software.cisco.com/download/home/286283913/type

- IOS XE Software Version 17.6.1x: cbrsup-universalk9.17.06.01x.SPA.bin
- IOS XE Hardware Programmable Devices Version 17.6.1x: cbrsup-programmable_firmware.17.06.01x.SPA.pkg
- **Step 1** Copy Cisco IOS XE Bengaluru 17.6.1x package to harddisk: and stby-harddisk:.

```
copy <location>/cbrsup-universalk9.17.06.01x.SPA.bin harddisk:
copy <location>/cbrsup-universalk9.17.06.01x.SPA.bin stby-harddisk:
```

Step 2 Verify Cisco IOS XE Bengaluru 17.6.1x package against the md5 hash as provided in the Cisco.com Software center.

```
verify /md5 harddisk:cbrsup-universalk9.17.06.01x.SPA.bin
verify /md5 stby-harddisk:cbrsup-universalk9.17.06.01x.SPA.bin
```

Step 3 Copy the hardware programmable devices upgrade package to harddisk: if the file has not been copied already.

```
copy <location>/cbrsup-programmable firmware.17.06.01x.SPA.pkg harddisk:
```

Step 4 Verify the hardware programmable devices upgrade package against the md5 hash as provided in the Cisco.com Software center.

```
verify /md5 harddisk:cbrsup-programmable firmware.17.06.01x.SPA.pkg
```

- **Step 5** Configure the chassis to boot the system with Cisco IOS XE Bengaluru 17.6.1x image.
 - **a.** Use the following steps if you do not use cBR CCAP 8x10G Remote PHY Digital Physical Interface Card (D-PIC) with CBR-CCAP-LC-40G-R linecards.

```
configure terminal
no boot system
boot system harddisk:cbrsup-universalk9.17.06.01x.SPA.bin
config-register 0x2102
end
write mem
```

b. Use the following steps if you use cBR CCAP 8x10G Remote PHY Digital Physical Interface Card (D-PIC) with CBR-CCAP-LC-40G-R linecards.

```
configure terminal
config-register 0x2102
end
```

Step 6 Check line card CPLD version via **show platform**. If it is not the minimum version 00000026, upgrade line card CPLD following the sub steps below. Otherwise skip this step.

Note To upgrade the line card CPLD to version 00000026, the cBR-8 must be running Cisco IOS XE Gibraltar 16.12.1 or later releases.

This procedure will trigger a reload of the linecard and will cause an outage if the system is not backed up with LCHA.

Do not power cycle the cBR-8 router during the firmware upgrade process. Power cycling the chassis may corrupt the ROMMON/Uboot image.

a) Run the following pre-upgrade commands on the SUP IOS:

```
upgrade hw-programmable cable active_SUP daggit pre-upgrade slot LC_slot_# Example:
```

```
Router# upgrade hw-programmable cable R0 daggit pre-upgrade slot 0 Daggits pre-upgrade successful
```

b) Upgrade the line card CPLD firmware using the SUP IOS command.

Note Do not reboot the line card until the upgrade is complete. Upgrade takes approximately 15 minutes.

upgrade hw-programmable cable LC_slot_# daggit pkg_name firmware_pkg_location_path Example:

```
Router# upgrade hw-programmable cable 0 daggit pkg_name /harddisk/cbrsup-programmable_firmware.17.06.01x.SPA.pkg
```

c) After the upgrade is complete (takes approximately 15 minutes), the line card moves to **unknown** state. Check the status of the line card using the **show platform** command. When the line card is in **unknown** state, run the following command to recover the line card:

```
upgrade hw-programmable cable active_SUP daggit lc-recovery slot LC_slot_# Example:
```

```
Router# upgrade hw-programmable cable RO daggit lc-recovery slot 0
```

d) The line card moves from **booting** to **active** state. Check the version of the line card using the **show platform** command to make sure version is changed to 00000026.

Example:

```
Router#show platform ......

Slot CPLD Version Rommon Version

0 00000026 2011.03.18 ...
```

e) When the line card is in **active** state, run the following command to verify the upgrade.

```
upgrade hw-programmable cable active_SUP daggit post-active slot LC_slot_#
Example:
Router# upgrade hw-programmable cable RO daggit post-active slot 0
SUCCESS: Daggit ver-38 : Booted from upgradable Image-1
```

Step 7 Check the firmware version of the Docsis 3.1 downstream modules in all slots, if it is different with the version listed in Table 3: Firmware Versions, on page 48, update the firmware using the following command. Otherwise skip this step.

upgrade hw-programmable cable slot dsphy all pkg name firmware pkg location path

Example:

```
Router# upgrade hw-programmable cable 0 dsphy all pkg_name /harddisk/cbrsup-programmable_firmware.17.06.01x.SPA.pkg
```

Wait for the system log message asking the user to reload the line card that was upgraded.

```
001860: Jun 15 19:05:05.904 PDT: %IOSXE-5-PLATFORM: CLCO: cdman: Suggest reload the line card for new FW to take effect using CLI: hw slot <slot-id> reload
```

Step 8 Reload the system.

Router#reload

During reload, monitor the chassis for any of the following errors, and update the configuration accordingly.

```
Mismatches TE interface. DS controller should be */*/0\sim7, configuration failed. Mismatches TE interface. DS controller should be */*/8\sim15, configuration failed. Mismatches TE interface. DS controller should be */*/16\sim23, configuration failed. Mismatches TE interface. DS controller should be */*/24\sim31, configuration failed.
```

Step 9 If the system is running with SUP250, perform **no shut** on 100G interface after the system comes up for the first time.

What to do next

Perform verification test to determine if the upgrade is successful, include:

- Verify the router is running the new IOS-XE release using **show version** command.
- Check facility alarms using show facility-alarm status command.
- Check the status of the power supplies using show environment power command.
- Check PS status using **show platform hardware slot P<0-5> mcu status** command.
- Complete trace routes to known good off-network IP address using the source address of customer CPE blocks to verify routing is working.
- Check logs for error messages using show log command.

These **show** commands may be useful in the verification test:

- · show redundancy
- show platform
- · show platform diag
- show environment
- · show redundancy linecard all
- · show isis neighbors
- · show ip ospf neighbor
- show ip route rip
- show ip mroute
- show cops servers
- show cable modem voice
- · show cable calls
- show cable metering verbose
- · show cable licenses all
- show inventory

Upgrading with ISSU for I-CCAP Systems

Before you begin



Note

ISSU is not supported for Remote PHY systems.



Note

ISSU to Cisco IOS XE Bengaluru 17.6.1x is supported only from Cisco IOS XE Gibraltar 16.10.1g and later releases. If you are upgrading from an earlier release, you must upgrade the cBR-8 system following the steps in Upgrading using reload, on page 52.

Before upgrading the system, make sure the following requirements are met:

The cBR-8 has two SUPs installed.

• Standby SUP must be in hot standby state.

• Line card redundancy is in stable state with state Active and Stdby warm.

```
Router# show redundancy linecard all
Load for five secs: 14%/1%; one minute: 8%; five minutes: 8%
Time source is NTP, 15:23:26.697 PST Thu Jan 17 2019
```

Slot	Subslot	LC Group	My State	Peer State	Peer Slot	Peer Subslot	Role	Mode
1	_	0	Active	Stdby Warm	0	-	Active	Primary
2	_	0	Active	Stdby Warm	0	_	Active	Primary
3	_	0	Active	Stdby Warm	0	-	Active	Primary
6	_	0	Active	Stdby Warm	0	-	Active	Primary
0	_	0	-	=	Multiple	None	Standby	Secondary

· Auto-boot is enabled.

```
Router# show bootvar
Load for five secs: 14%/0%; one minute: 14%; five minutes: 10%
Time source is NTP, 15:46:59.837 PST Thu Jan 17 2019

BOOT variable = harddisk:IOSXE/packages.conf,12;
CONFIG_FILE variable =
BOOTLDR variable does not exist
Configuration register is 0x2102

Standby BOOT variable = harddisk:IOSXE/packages.conf,12;
Standby CONFIG_FILE variable =
Standby BOOTLDR variable does not exist
Standby Configuration register is 0x2102
```

• Both SUPs are in the sub-package mode, running the same image from the same path.

```
Router# show bootvar
Load for five secs: 14%/0%; one minute: 14%; five minutes: 10%
Time source is NTP, 15:46:59.837 PST Thu Jan 17 2019

BOOT variable = harddisk:IOSXE/packages.conf,12;
CONFIG_FILE variable =
BOOTLDR variable does not exist
Configuration register is 0x2102

Standby BOOT variable = harddisk:IOSXE/packages.conf,12;
Standby CONFIG_FILE variable =
Standby BOOTLDR variable does not exist
Standby Configuration register is 0x2102
```

• The free space on boot device on both SUPs must be greater than 2GB.

```
Router# dir harddisk: | include bytes total 7804653568 bytes total (5691174912 bytes free)
```

• Download two files from the following Cisco.com Software Center URL:

https://software.cisco.com/download/home/286283913/type

- IOS XE Software Version 17.6.1x: cbrsup-universalk9.17.06.01x.SPA.bin
- IOS XE Hardware Programmable Devices Version 17.6.1x: cbrsup-programmable_firmware.17.06.01x.SPA.pkg
- Copy the target consolidated image **cbrsup-universalk9.17.06.01x.SPA.bin** to the active SUP in the same directory of the **packages.conf** file that the system is booted up with.
- **Step 1** Copy Cisco IOS XE Bengaluru 17.6.1x package to harddisk:.

```
copy <location>/cbrsup-universalk9.17.06.01x.SPA.bin harddisk:<sub-pkg-dir>/
```

Step 2 Verify Cisco IOS XE Bengaluru 17.6.1x package against the md5 hash as provided in the Cisco.com Software center.

```
verify /md5 harddisk:<sub-pkg-dir>/cbrsup-universalk9.17.06.01x.SPA.bin
```

Step 3 Copy the hardware programmable devices upgrade package to harddisk: if the file has not been copied already.

```
copy <location>/cbrsup-programmable firmware.17.06.01x.SPA.pkg harddisk:
```

Step 4 Verify the hardware programmable devices upgrade package against the md5 hash as provided in the Cisco.com Software center.

```
verify /md5 harddisk:cbrsup-programmable firmware.17.06.01x.SPA.pkg
```

- **Step 5** Check system status prior to upgrade. Save the information to compare against the system status after upgrade. For the commands to use to check the status, see the **show** commands at the end of this section.
- **Step 6** Check line card CPLD version via **show platform**. If it is not the minimum version 00000026, upgrade line card CPLD following the sub steps below. Otherwise skip this step.

Note To upgrade the line card CPLD to version 00000026, the cBR-8 must be running Cisco IOS XE Gibraltar 16.12.1 or later releases.

This procedure will trigger a reload of the linecard and will cause an outage if the system is not backed up with LCHA.

Do not power cycle the cBR-8 router during the firmware upgrade process. Power cycling the chassis may corrupt the ROMMON/Uboot image.

a) Run the following pre-upgrade commands on the SUP IOS:

```
upgrade hw-programmable cable <code>active_SUP</code> daggit pre-upgrade slot <code>LC_slot_#</code> Example:
```

```
Router# upgrade hw-programmable cable R0 daggit pre-upgrade slot 0 Daggits pre-upgrade successful
```

b) Upgrade the line card CPLD firmware using the SUP IOS command.

Note Do not reboot the line card until the upgrade is complete. Upgrade takes approximately 15 minutes.

```
upgrade hw-programmable cable LC_slot_# daggit pkg_name firmware_pkg_location_path Example:
```

```
Router# upgrade hw-programmable cable 0 daggit pkg_name /harddisk/cbrsup-programmable_firmware.17.06.01x.SPA.pkg
```

c) After the upgrade is complete (takes approximately 15 minutes), the line card moves to **unknown** state. Check the status of the line card using the **show platform** command. When the line card is in **unknown** state, run the following command to recover the line card:

```
upgrade hw-programmable cable <code>active_SUP</code> daggit lc-recovery slot <code>LC_slot_#</code> Example:
```

```
Router# upgrade hw-programmable cable RO daggit lc-recovery slot 0
```

d) The line card moves from **booting** to **active** state. Check the version of the line card using the **show platform** command to make sure version is changed to 00000026.

Example:

cBR8#show	platform	
•••••		
Slot	CPLD Version	Rommon Version
0	00000026	2011.03.18

e) When the line card is in **active** state, run the following command to verify the upgrade.

upgrade hw-programmable cable <code>active_SUP</code> daggit post-active slot <code>LC_slot_#</code> Example:

```
Router# upgrade hw-programmable cable R0 daggit post-active slot 0 SUCCESS: Daggit ver-38 : Booted from upgradable Image-1
```

Step 7 Check the firmware version of the Docsis 3.1 downstream modules in all slots, if it is different with the version listed in Table 3: Firmware Versions, on page 48, update the firmware using the following command. Otherwise skip this step.

upgrade hw-programmable cable slot dsphy all pkg_name firmware_pkg_location_path

Example:

```
Router# upgrade hw-programmable cable 0 dsphy all pkg_name /harddisk/cbrsup-programmable_firmware.17.06.01x.SPA.pkg
```

Wait for the system log message asking the user to reload the line card that was upgraded. But do not reload the line card at this time.

001860: Jun 15 19:05:05.904 PDT: NIOSXE-5-PLATFORM: CLCO: cdman: Suggest reload the line card for new FW to take effect using CLI: hw slot slot-id reload

Step 8 Perform ISSU.

request platform software package install node file harddisk:cbrsup-universalk9.17.06.01x.SPA.bin

Step 9 To monitor the ISSU progress, use the command below.

request platform software package install node attach

Step 10 Use these CLI to check status after ISSU.

```
show version r0 running show version r1 running show version r0 provisioned show version r1 provisioned
```

What to do next

Perform verification test to determine if the upgrade is successful, include:

- Verify the router is running the new IOS-XE release using **show version** command.
- Check facility alarms using **show facility-alarm status** command.
- Check the status of the power supplies using **show environment power** command.
- Check PS status using show platform hardware slot P<0-5> mcu status command.

- Complete trace routes to known good off-network IP address using the source address of customer CPE blocks to verify routing is working.
- Check logs for error messages using **show log** command.

These **show** commands may be useful in the verification test:

- · show redundancy
- show platform
- · show platform diag
- show environment
- · show redundancy linecard all
- · show isis neighbors
- · show ip ospf neighbor
- show ip route rip
- show ip mroute
- show cops servers
- · show cable modem voice
- · show cable calls
- show cable metering verbose
- · show cable licenses all
- show inventory

Upgrading Supervisor CPLD Firmware

Before you begin



Note

If the supervisor SO CPLD version is lower than 1511_1401 (SUP 160) or 15111401 (SUP 250), or, if the supervisor SIO CPLD version is lower than 1511_1301 (SUP 160) or 15111301 (SUP 250), physically power cycle the chassis when upgrading the supervisor CPLD.

Before upgrading the firmware, make sure the following requirements are met:

- Cisco cBR-8 router is running with Cisco IOS XE Gibraltar 16.12.1w or later releases.
- 2 supervisors are running in the Cisco cBR-8 router and the redundancy is enabled.
- Download the file from the following Cisco.com Software Center URL:

https://software.cisco.com/download/home/286283913/type

- IOS XE Hardware Programmable Devices Version 17.6.1x: cbrsup-programmable_firmware.17.06.01x.SPA.pkg
- Console access for both supervisors are required.
- Copy the new firmware package to the cBR-8 using FTP.

```
copy ftp://<location>/cbrsup-programmable_firmware.17.06.01x.SPA.pkg harddisk:
copy ftp://<location>/cbrsup-programmable_firmware.17.06.01x.SPA.pkg stby-harddisk:
```



Note

When upgrading SUP0, run the CLI with the R0 setting while controlling SUP0. And when upgrading SUP1, run the CLI with the R1 setting.



Note

This guide assumes SUP0 is in active state and SUP1 is in standby hot state at the beginning.

Perform step 1 to 4 using console connection of active SUP0:

Step 1 Set the config register.

```
configure terminal
config-register 0x2102
end
write memory
```

Step 2 Run the following command to prepare for R0 upgrade.

```
upgrade hw-programmable cable R0 viper pkg_name /harddisk/cbrsup-programmable_firmware.17.06.01x.SPA.pkg
```

On SUP 250, you will see one of the following outputs:

 \bullet It takes 10~20 minutes to upgrade. Console would hung. Please don't do any operation during the upgrade.

```
You are upgrading Viper firmware using harddisk/cbrsup-programmable_firmware.17.06.01x.SPA.pkg image on SUPO, SUPO is active.
```

```
Upgrade from assigned pkg file harddisk/cbrsup-programmable_firmware.17.06.01x.SPA.pkg Using viper firmware /tmp/viper/mount/supve_viper_fpga_psirt.bin Size of Viper Upgrade image: 16777216 bytes
```

No.of parts: 65536

Upgrading golden image...

65536+0 records in

65536+0 records out

16777216 bytes (17 MB, 16 MiB) copied, 688.873 s, 24.4 kB/s

Upgrading primary image...

65536+0 records in

65536+0 records out

16777216 bytes (17 MB, 16 MiB) copied, 675.19 s, 24.8 kB/s

Viper upgrade clean up 0

```
Upgrade successfully. Please make sure Rommon version is matched. Please power cycle the chassis to let the new firmware take effect
```

• It takes 10~20 minutes to upgrade. Console would hung. Please don't do any operation during the upgrade.

You are upgrading Viper firmware using harddisk/cbrsup-programmable_firmware.17.06.01x.SPA.pkg image on SUPO, SUPO is active.

Upgrade from assigned pkg file harddisk/cbrsup-programmable_firmware.17.06.01x.SPA.pkg The golden viper is not compatible with assigned firmware

/tmp/viper/mount/supve_viper_fpga_psirt.bin, no upgrade will be performed Viper upgrade clean up 2

Note This output means the SUP already has the latest version it can support, skip the rest of the steps.

On SUP 160, you will see one of the following outputs:

• It takes about 10 minutes to upgrade. Console would hung. Please don't do any operation during the upgrade.

You are upgrading Viper firmware using harddisk/cbrsup-programmable_firmware.17.06.01x.SPA.pkg image

Upgrade from assigned pkg file /harddisk/cbrsup-programmable_firmware.17.06.01x.SPA.pkg Using viper firmware /tmp/viper/mount/viper fpga.bin

Size of Viper Upgrade image: 16777216 bytes

No.of parts: 65536

65536+0 records in

65536+0 records out

Viper upgrade clean up 0

Upgrade successfully. Please make sure Rommon version is matched.

Please power cycle the chassis to let the new firmware take effect

 \bullet It takes 10~20 minutes to upgrade. Console would hung. Please don't do any operation during the upgrade.

You are upgrading Viper firmware using harddisk/cbrsup-programmable_firmware.17.06.01x.SPA.pkg image on SUPO, SUPO is active.

Upgrade from assigned pkg file harddisk/cbrsup-programmable_firmware.17.06.01x.SPA.pkg The golden viper is not compatible with assigned firmware

/tmp/viper/mount/supve_viper_fpga_psirt.bin, no upgrade will be performed Viper upgrade clean up 2

Note This output means the SUP already has the latest version it can support, skip the rest of the steps.

Note Do not power cycle the chassis in this step.

Step 3 Run the following command to prepare for R1 upgrade.

```
upgrade hw-programmable cable R1 viper pkg_name /harddisk/cbrsup-programmable_firmware.17.06.01x.SPA.pkg
```

You will see the similar output as the one in Step 2.

Note Do not power cycle the chassis in this step.

Step 4 If the supervisor ViperSO CPLD version is 15111401 and the supervisor ViperSIO CPLD version is 15111301 on both supervisors, follow step 5 - 11 to do the upgrade. Otherwise proceed to step 12.

```
Router#show platform diag
Load for five secs: 6%/1%; one minute: 7%; five minutes: 8%
Time source is NTP, 16:05:43.546 PST Thu Feb 8 2018
Chassis type: CBR-8-CCAP-CHASS
```

```
<SNIP>
Slot: SUPO, CBR-CCAP-SUP-160G
           Physical insert detect time: 00:01:58 (1d03h ago)

      CPLD version
      : 16052011

      ViperSO CPLD version
      : 15111401

      ViperSIO CPLD version
      : 15111301

                                                  : 15111301
           ViperSIO CPLD version
           Rommon version
Blackbird version
                                                     : 16.7(1r)S
           Blackbird version
Raptor ESI version : 0001003b
Raptor MAC version : 00010031
SUP-PIC CPLD version : 14071504
:- DG CDID version : 14072207
           SUP-DC CPLD version : 14072207
DTI Client FPGA version : 00000005
DTI Firmware version : 00000A03
           DTI Client rrow. ...

DTI Firmware version : 0000UAU3
: 201402061607
           SUP PSOC 0 version
                                                  : v4.0.9
           SUP PSOC 1 version
                                                   : v4.0.8
                                                    : v4.1.0_IVB
           SUP PSOC 2 version
SUP PSOC 3 version
           SUP-PIC PSOC 0 version
                                                   : V2.0.6
           SUP-PIC PSOC 1 version
                                                    : V2.0.6
<SNIP>
Slot: SUP1, CBR-CCAP-SUP-160G
           Physical insert detect time : 00:02:26 (1d03h ago)
           CPLD version : 16052011
ViperSO CPLD version : 15111401
           ViperSIO CPLD version : 15111401
ViperSIO CPLD version : 15111301
Rommon version : 16 7/1 17
                                                     : 16.7(1r)S
           Blackbird version
                                                    : 00000112
           Raptor ESI version
Raptor MAC version

      Raptor ESI version
      : 0001003b

      Raptor MAC version
      : 00010031

      SUP-PIC CPLD version
      : 14071504

      SUP-DC CPLD version
      : 14072207

                                                  : 0001003b
           SUP-DC CPLD version
                                                    : 14072207
           DTI Client FPGA version
           DTI Client From vor.

DTI Firmware version : 00000A05
: 201402061607
                                                    : 00000005
           SUP PSOC 0 version
                                                  : v4.0.9
           SUP PSOC 1 version
SUP PSOC 2 version
SUP PSOC 3 version
                                                   : v4.0.8
                                                     : v4.1.0 IVB
                                                    : v4.0.6
           SUP-DC PSOC 0 version
                                                   : v4.0.9
           SUP-DC PSOC 1 version
                                                   : v4.0.5
                                                   : V3.0.0
           SUP-PIC PSOC 0 version
            SUP-PIC PSOC 1 version
                                                     : V3.0.0
<SNTP>
```

Step 5 Set SUP0 to ROMMON using the following command.

redundancy force-switchover

Perform the following steps 6 to 7 using console connection of current active SUP1.

Step 6 Power cycle the SUP0 to set it to ROMMON.

test platform hardware slot R0 oir power-cycle

This command will reset and re-initialize the ROMMON. The new version of the supervisor CPLD will now take effect. Verify if it matches the following new version.

SUP 160 new version: 0x19071712 SUP 250 new version: 0x190717E1 **Step 7** Boot SUP0 into IOS XE using SUP0 console connection.

dir harddisk:
boot harddisk:cbrsup-universalk9.17.06.01x.SPA.bin

Wait utill SUP0 is in standby hot.

Step 8 Set SUP1 to ROMMON using the following command.

redundancy force-switchover

Perform the following steps 9 to 11 using console connection of current active SUP0.

Step 9 Power cycle the SUP1 to set it to ROMMON.

test platform hardware slot R1 oir power-cycle

This command will reset and re-initialize the ROMMON. The new version of the supervisor CPLD will now take effect. Verify if it matches the following new version.

SUP 160 new version: 0x19071712 SUP 250 new version: 0x190717E1

Step 10 Boot SUP1 into IOS XE using SUP1 console connection.

dir harddisk: boot harddisk:cbrsup-universalk9.17.06.01x.SPA.bin

Wait utill SUP1 is in standby hot.

Step 11 Wait for the chassis to become SSO and settled down. Then go to step 16. If you skipped step 5 to 10, perform step 12 to 15.

Note You need physical access to the chassis to power cycle the chassis.

Step 12 Reload the system by issuing **reload** command on the active SUP.

Router#reload

Step 13 Power cycle both supervisors.

Step 14 Verify if the new version matches the following on both SUPs.

SUP 160 new version: 0x19071712 SUP 250 new version: 0x190717E1

Step 15 Boot both SUP0 and SUP1 into IOS XE using SUP0 and SUP1 console.

dir harddisk: boot harddisk:cbrsup-universalk9.17.06.01x.SPA.bin

Wait till SUP0 become standby hot.

Step 16 Once the system is up and running, perform the following checks.

• Set config register to normal boot.

```
configure terminal
config-register 0x2102
end
write memory
```

- Execute **show redundancy** command to ensure both SUPs are listed, one is active and the other is standby hot.
- Execute show proc CPU sorted | ex 0.00 command.
- Execute show platform diag command.

Upgrading cBR CCAP 8x10G Remote PHY Digital Physical Interface Card

Before you begin

Before upgrading the system, make sure the following requirements are met:

- Make sure the latest available IOS XE version is active in Cisco cBR-8 router.
- There are at lease 20MB free space on the harddisk.



Note

To make use of the new features, it is recommended to upgrade the cBR CCAP 8x10G Remote PHY Digital Physical Interface Card (D-PIC) to the latest version 1.1.

- **Step 1** Boot up system, wait until IOS is ready.
- **Step 2** Check current D-PIC version.

show hw-module subslot x/1 fpd

Note x/1 is D-PIC subslot number which needs upgrade.

Example:

Router#show hw-module subslot 9/1 fpd

====					
		H/W	Field Programmable	Current	Min. Required
Slot	Card Type	Ver.	Device: "ID-Name"	Version	Version
====		=====		========	
9/1	CBR-DPIC-8X10G	1.0	46-CBR DIGI PIC	1.0	1.0
====					

Step 3 Upgrade D-PIC.

upgrade hw-module subslot x/1 fpd bundled reload

Example:

Router#upgrade hw-module subslot 9/1 fpd bundled reload

% = 1.0 The following FPD will be upgraded for CBR-DPIC-8X10G (H/W ver = 1.0) in subslot 9/1:

Field Programmable	Current	Upgrade	Estimated
Device: "ID-Name"	Version	Version	Upgrade Time
46-CBR DIGI PIC	1.0	1.1	00:05:00

- % NOTES:
 - Use 'show upgrade fpd progress' command to view the progress of the FPD upgrade.
 - The target card will be automatically reloaded after the upgrade operation. This reload will interrupt normal operation of the card. If necessary, ensure that appropriate actions have been taken to redirect card traffic before starting the FPD upgrade.
- % Are you sure that you want to perform this operation? [no]: yes
- % Initiating the upgrade operation on the target card ...
 (Use "show upgrade fpd progress" command to see upgrade progress)

Step 4 Check if the upgrade process is finished. Upgrade progress will take about 1 to 2 minutes.

show upgrade fpd progress

Example:

Upgrade still ongoing:

Router#show upgrade fpd progress

FPD Image Upgrade Progress Table:

====	==========	===========				
		Approx.				
		Field Programmable	Time	Elapsed		
Slot	Card Type	Device : "ID-Name"	Needed	Time	State	
9/1	CBR-DPIC-8X10G	46-CBR DIGI PIC	00:05:00	00:00:13	Updating	
====						

sj-104-cbr-13#show upgrade fpd progress

FPD Image Upgrade Progress Table:

			Approx.		
		Field Programmable	Time	Elapsed	
Slot	Card Type	Device : "ID-Name"	Needed	Time	State
====					
9/1	CBR-DPIC-8X10G	46-CBR DIGI PIC	00:05:00	00:00:26	Updating

Upgrade finished:

Router#show upgrade fpd progress

% There is no FPD image upgrade in progress.

Step 5 Check if the D-PIC status is ready.

show platform

Example:

Router#show platform

Chassis type: CBR-8-CCAP-CHASS

Slot	Type	State	Insert time (ago)
2/1	CBR-RF-PROT-PIC	ok	00:08:48
	CBR-CCAP-LC-40G		00:12:46
3/1	CBR-RF-PIC	ok	00:08:48
8/1	CBR-DPIC-8X10G	ok	00:07:56
9	CBR-CCAP-LC-40G	ok	00:12:46
9/1	CBR-DPIC-8X10G	ok	00:07:54
SUP0	CBR-CCAP-SUP-160G	inserted	00:12:46
R0		ok, active	
F0		ok, active	
4		ok, active	
4/1	CBR-SUP-8X10G-PIC	ok	00:07:55
SUP1	CBR-CCAP-SUP-160G	inserted	00:12:22
R1		ok, standby	
F1		ok, standby	
5		ok, standby	
	CBR-SUP-8X10G-PIC		00:07:54
P0	PWR-3KW-AC-V2		00:09:49
P1	PWR-3KW-AC-V2	ok	00:09:49
P2	PWR-3KW-AC-V2	ps, fail	00:09:49
	Unknown	N/A	never
P4	Unknown	N/A	never
		ok	00:09:49
P10	CBR-FAN-ASSEMBLY	ok	00:09:39
	CBR-FAN-ASSEMBLY		00:09:39
P12	CBR-FAN-ASSEMBLY	ok	00:09:39
P13	CBR-FAN-ASSEMBLY	ok	00:09:39
P14	CBR-FAN-ASSEMBLY	ok	00:09:39
Slot	CPLD Version	Rommon Version	
3	00000025	2011.03.18	
		2011.03.18	
		16.7(3r)S	
	16052011	16.7(3r)S	

Step 6 Check if the new version works.

show hw-module subslot x/1 fpd

Example:

Router#show hw-module subslot 9/1 fpd

====					
		H/W	Field Programmable	Current	Min. Required
Slot	Card Type	Ver.	Device: "ID-Name"	Version	Version

9/1 CBR-DPIC-8X10G 1.0 46-CBR DIGI PIC 1.1 1.0



Upgrading the Cisco cBR-8 Router System to Cisco IOS XE Bengaluru 17.6.1w



Note

Starting from Cisco IOS XE Bengaluru 17.6.1a, CBR-CCAP-LC-G2-R can only protect CBR-CCAP-LC-G2-R for linecard HA.



Note

If you are using TACACS authentication, the TACACS configuration will be automatically updated to the new version after upgrading to Cisco IOS XE Bengaluru 17.6.1w. This is a fix to CSCvu62273 and you do not need to take any action regarding the TACACS configuration in the cBR-8 prior to the upgrade.

This section contains the upgrade procedures for the Cisco cBR-8 Router System.

By default, telnet is disabled on Cisco cBR-8. If you are going to use telnet to access the device, make sure the value of line **vty transport** is correct and save the configuration in order to enable telnet.

```
Router# show run | begin line vty
line vty 0 4
exec-timeout 0 0
privilege level 15
password 7 104D081B094410055F
exec prompt timestamp
transport input all
line vty 5 98
exec-timeout 0 0
privilege level 15
password 7 02050D480809
transport input all
line vty 99
transport input all
```

The following table encompasses all versions that customers are required to update to support Cisco IOS XE Bengaluru 17.6.1w. All other firmware versions are either not upgradable by the customer, or not required to be upgraded for Cisco IOS XE Bengaluru 17.6.1w support. Use the commands in the tables to verify the firmware versions. If you need to upgrade firmware first, refer to the steps in Upgrading the Cisco cBR-8 Router Firmware.



Note

If you want to upgrade Supervisor CPLD firmware, refer to Upgrading Supervisor CPLD Firmware, on page 82.

Table 4: Firmware Versions

Internal Name	Component Name	Required Minimum Version	Command
Supervisor CPLD	CBR-CCAP-SUP-160G CPLD	16052011/19071712	show platform
	CBR-CCAP-SUP-250G CPLD	170724E0/190717E1	show platform
Supervisor ROMMON	CBR-CCAP-SUP-160G ROMMON and CBR-CCAP-SUP-250G ROMMON	16.7(8r)S	show platform
Line Card CPLD	CBR-CCAP-LC-40G CPLD	00000026	show platform diag
Docsis 3.1 downstream module Micro	CBR-CCAP-LC-40G Gemini2 Micro	3.1A	show platform diag
Docsis 3.1 downstream module FPGA	CBR-CCAP-LC-40G Gemini2 Apollo	4.484F	show platform diag
DPIC Uboot and FPGA	CBR-DPIC-8X10G Firmware	00010001	show platform diag
DPIC 100G Uboot and FPGA	CBR-DPIC-2X100G Firmware	00020006	show platform diag



Note

If the user wants to upgrade Supervisor CPLD to version 19071712 and 190717E1, the chassis must be running with Cisco IOS XE Gibraltar 16.12.1w or later releases.



Note

Cisco recommends that operators upgrade their On-Premise SSM Satellite software versions to v7.x or later releases, to ensure the compatibility with cBR-8.

- Verify max-carrier value, on page 71
- Upgrading from Cisco IOS XE 16.x and later releases to Cisco IOS XE Bengaluru 17.6.1w, on page 72
- Upgrading Supervisor CPLD Firmware, on page 82

• Upgrading cBR CCAP 8x10G Remote PHY Digital Physical Interface Card, on page 87

Verify max-carrier value

Currently in Remote PHY system, max-carrier value can be configured in the downstream controller profile as well as in RPD configuration for Cisco Remote PHY Shelf 300/600/7200. This may lead to inconsistent max-carrier value configurations.

Starting from Cisco IOS XE Gibraltar 16.10.1f, max-carrier value configured in the **cable rpd** mode is removed and RPD will use the max-carrier value configured in the **controller-profile** mode for the power calculation.

Before upgrading to Cisco IOS XE Gibraltar 16.10.1f or later releases, verify if the max-carrier values configured in the RPD shelf configuration and downstream controller profile(s) associated to RPD downstream port are the same. If they are different, update the cBR-8 configuration prior to upgrade.

Below is an example of correct configuration before upgrade.

```
cable downstream controller-profile 1
max-carrier 128
max-ofdm-spectrum 384000000
rf-chan 0 3
 type DOCSIS
 gam-profile 1
 frequency 381000000
 rf-output NORMAL
 docsis-channel-id 1
cable downstream controller-profile 2
max-carrier 158
max-ofdm-spectrum 384000000
rf-chan 158
 docsis-channel-id 159
 ofdm channel-profile 20 start-frequency 579000000 width 48000000 plc 600000000
cable rpd test
identifier 0001.0001.0001
type shelf
rpd-ds 0 max-carrier 128
rpd-ds 0 base-power 33
rpd-ds 1 max-carrier 158
rpd-ds 1 base-power 25
core-interface Te9/1/0
 rpd-ds 0 downstream-cable 9/0/3 profile 1
 rpd-ds 0 downstream-cable 9/0/4 profile 2
 rpd-us 0 upstream-cable 9/0/3 profile 1
r-dti 1
rpd-event profile 0
rpd-55d1-us-event profile 0
```



Note

It is highly recommended to follow this example to check and update configuration if necessary because max-carrier value is used to compute the base power. Otherwise, after upgrade the expected base power value can be different which may affect cable modem coming online.



Note

If you upgrade from a version lower than Cisco IOS XE Fuji 16.9.1, base power range may be changed on the port with OFDM channel configured. So be aware of the potential base power change before and after the upgrade.

Upgrading from Cisco IOS XE 16.x and later releases to Cisco IOS XE Bengaluru 17.6.1w

If you are upgrading from Cisco IOS XE Everest 16.6.x or Cisco IOS XE Fuji 16.7.x to Cisco IOS XE Bengaluru 17.6.1w, perform the following steps to upgrade SUP ROMMON manually. Otherwise proceed with the IOS upgrade.

- Download hardware programmable devices upgrade package file cbrsup-programmable_firmware.17.06.01w.SPA.pkg from the following Cisco.com Software Center URL: https://software.cisco.com/download/home/286283913/type
- **2.** Copy the package file to harddisk:.

```
copy <location>/cbrsup-programmable_firmware.17.06.01w.SPA.pkg harddisk:
```

3. Verify the hardware programmable devices upgrade package against the md5 hash as provided in the Cisco.com Software center.

verify /md5 harddisk:cbrsup-programmable_firmware.17.06.01w.SPA.pkg

4. Upgrade SUP ROMMON.

```
Router#Upgrade rom-mon file harddisk:cbrsup-programmable_firmware.17.06.01w.SPA.pkg r0
Wait for the following output on the console:
ROMMON upgrade complete.
To make the new ROMMON permanent, you must restart the RP

Router#Upgrade rom-mon file harddisk:cbrsup-programmable_firmware.17.06.01w.SPA.pkg r1
Wait for the following output on the console:
ROMMON upgrade complete.
To make the new ROMMON permanent, you must restart the RP
```



Note

Do not restart the SUPs currently, you can combine reloading the SUP with the IOS upgrade process.

If you are using cBR CCAP 8x10G Remote PHY Digital Physical Interface Card (D-PIC) with CBR-CCAP-LC-G2-R linecards, before upgrading to Cisco IOS XE Bengaluru 17.6.1w, contact your local Cisco representative to get the python tool and perform the following steps in order to predict and avoid downtime. This python tool is developed by Cisco, it is used to analyze the cBR-8 configuration file to determine if the configuration file includes non-compliant TenGigabitEthernet interface to downstream controller mappings, and update the configuration file to be compliant with the latest Cisco IOS XE Bengaluru 17.6.1w.

1. Collect the following information from the target cBR-8 to upgrade.

```
Router#show cable rpd sum
Router#show cable modem sum
Router#show cable video session all sum
```

2. Save the running configuration to the harddisk of the cBR-8.

```
Router#copy running-config harddisk:SavedConfig.txt
```

3. Copy the saved running configuration from harddisk: to an offline server for editing using SCP.

```
Router#copy harddisk:SavedConfig.txt scp:<path>
```

- **4.** Run the python tool to modify the controllers in the saved configuration.
 - Option 1 Renumber Downstream-Cable controllers only
 - **a.** Execute python script **kobol_ph2_controller_migration.py**. This script is intended for customers who do not immediately intend to take advantage of the Downstream-Video controllers and expanded SG capacity on CBR-CCAP-LC-G2-R.

```
$ python kobol_ph2_controller_migration.py
Enter the name of the configuration file: SavedConfig.txt
```

b. Output file appends **_remap_controller** to the file name.

```
Output file name: SavedConfig.txt remap controller
```

- **c.** Check to ensure that the script completed successfully. If no output file is created or the size of the output file is 0 byte, then check script output for error messages.
- Option 2 Renumber Downstream-Cable and utilize Downstream-Video controllers
- a. Execute python script kobol_ph2_controller_migration_video.py. This script is intended for customers who wish to utilize the new Downstream-Video controllers to free up existing Downstream-Cable controllers for expanded DOCSIS service groups.

```
$ python kobol_ph2_controller_migration_video.py
Enter the name of the configuration file: SavedConfig.txt
```

b. Output file appends **_remap_controller_video** to the file name.

```
Output file name: SavedConfig.txt remap controller video
```

- **c.** Check to ensure that the script completed successfully. If no output file is created or the size of the output file is 0 byte, then check script output for error messages.
- 5. Modify the remapped configuration file to specify the Cisco IOS XE Bengaluru 17.6.1w image in the boot parameter.

```
boot system harddisk:cbrsup-universalk9.17.06.01w.SPA.bin
```

6. Copy the final remapped configuration file back to the cBR-8 harddisk.

```
Router#copy scp:<path>/SavedConfig.txt_remap_controller harddisk:
or
Router#copy scp:<path>/SavedConfig.txt remap controller video harddisk:
```

7. Copy remapped configuration file to startup of the cBR-8.

```
\label{lem:controller} \mbox{Router\#copy harddisk:SavedConfig.txt\_remap\_controller startup-config} \\ \mbox{or}
```

Router#copy harddisk: SavedConfig.txt remap controller video startup-config

Upgrading using reload

Before you begin



Note

If you are upgrading from Cisco IOS XE Everest 16.6.x or Cisco IOS XE Fuji 16.7.x to Cisco IOS XE Bengaluru 17.6.1w, perform pre-upgrade steps 1 to 4 to upgrade SUP ROMMON manually before proceeding with IOS upgrading.

Before upgrading the system, make sure the following requirements are met:

• Download two files from the following Cisco.com Software Center URL:

https://software.cisco.com/download/home/286283913/type

- IOS XE Software Version 17.6.1w: cbrsup-universalk9.17.06.01w.SPA.bin
- IOS XE Hardware Programmable Devices Version 17.6.1w: cbrsup-programmable_firmware.17.06.01w.SPA.pkg
- **Step 1** Copy Cisco IOS XE Bengaluru 17.6.1w package to harddisk: and stby-harddisk:.

```
copy <location>/cbrsup-universalk9.17.06.01w.SPA.bin harddisk:
copy <location>/cbrsup-universalk9.17.06.01w.SPA.bin stby-harddisk:
```

Step 2 Verify Cisco IOS XE Bengaluru 17.6.1w package against the md5 hash as provided in the Cisco.com Software center.

```
verify /md5 harddisk:cbrsup-universalk9.17.06.01w.SPA.bin verify /md5 stby-harddisk:cbrsup-universalk9.17.06.01w.SPA.bin
```

Step 3 Copy the hardware programmable devices upgrade package to harddisk: if the file has not been copied already.

```
copy <location>/cbrsup-programmable firmware.17.06.01w.SPA.pkg harddisk:
```

Step 4 Verify the hardware programmable devices upgrade package against the md5 hash as provided in the Cisco.com Software center.

```
verify /md5 harddisk:cbrsup-programmable firmware.17.06.01w.SPA.pkg
```

- **Step 5** Configure the chassis to boot the system with Cisco IOS XE Bengaluru 17.6.1w image.
 - **a.** Use the following steps if you do not use cBR CCAP 8x10G Remote PHY Digital Physical Interface Card (D-PIC) with CBR-CCAP-LC-40G-R linecards.

```
configure terminal no boot system boot system harddisk:cbrsup-universalk9.17.06.01w.SPA.bin config-register 0x2102 end write mem
```

b. Use the following steps if you use cBR CCAP 8x10G Remote PHY Digital Physical Interface Card (D-PIC) with CBR-CCAP-LC-40G-R linecards.

```
configure terminal
config-register 0x2102
end
```

Step 6 Check line card CPLD version via **show platform**. If it is not the minimum version 00000026, upgrade line card CPLD following the sub steps below. Otherwise skip this step.

Note To upgrade the line card CPLD to version 00000026, the cBR-8 must be running Cisco IOS XE Gibraltar 16.12.1 or later releases.

This procedure will trigger a reload of the linecard and will cause an outage if the system is not backed up with LCHA.

Do not power cycle the cBR-8 router during the firmware upgrade process. Power cycling the chassis may corrupt the ROMMON/Uboot image.

a) Run the following pre-upgrade commands on the SUP IOS:

```
upgrade hw-programmable cable active_SUP daggit pre-upgrade slot LC_slot_#
Example:
Router# upgrade hw-programmable cable RO daggit pre-upgrade slot 0
```

```
Daggits pre-upgrade successful
```

b) Upgrade the line card CPLD firmware using the SUP IOS command.

Note Do not reboot the line card until the upgrade is complete. Upgrade takes approximately 15 minutes.

upgrade hw-programmable cable LC_slot_# daggit pkg_name firmware_pkg_location_path Example:

```
Router# upgrade hw-programmable cable 0 daggit pkg_name /harddisk/cbrsup-programmable_firmware.17.06.01w.SPA.pkg
```

c) After the upgrade is complete (takes approximately 15 minutes), the line card moves to **unknown** state. Check the status of the line card using the **show platform** command. When the line card is in **unknown** state, run the following command to recover the line card:

```
upgrade hw-programmable cable <code>active_SUP</code> daggit lc-recovery slot <code>LC_slot_#</code> Example:
```

```
\label{eq:continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous
```

d) The line card moves from **booting** to **active** state. Check the version of the line card using the **show platform** command to make sure version is changed to 00000026.

Example:

```
Router#show platform ......

Slot CPLD Version Rommon Version

0 00000026 2011.03.18 ...
```

e) When the line card is in **active** state, run the following command to verify the upgrade.

```
upgrade hw-programmable cable active\_SUP daggit post-active slot LC\_slot\_\# Example:
```

```
Router# upgrade hw-programmable cable R0 daggit post-active slot 0 SUCCESS: Daggit ver-38 : Booted from upgradable Image-1
```

Step 7 Check the firmware version of the Docsis 3.1 downstream modules in all slots, if it is different with the version listed in Table 4: Firmware Versions, on page 70, update the firmware using the following command. Otherwise skip this step.

upgrade hw-programmable cable slot dsphy all pkg name firmware pkg location path

Example:

```
Router# upgrade hw-programmable cable 0 dsphy all pkg_name /harddisk/cbrsup-programmable_firmware.17.06.01w.SPA.pkg
```

Step 8 Wait for the system log message asking the user to reload the line card that was upgraded.

Step 9 Reload the system.

Router#reload

During reload, monitor the chassis for any of the following errors, and update the configuration accordingly.

```
Mismatches TE interface. DS controller should be */*/0\sim7, configuration failed. Mismatches TE interface. DS controller should be */*/8\sim15, configuration failed. Mismatches TE interface. DS controller should be */*/16\sim23, configuration failed. Mismatches TE interface. DS controller should be */*/24\sim31, configuration failed.
```

Step 10 If the system is running with SUP250, perform **no shut** on 100G interface after the system comes up for the first time.

What to do next

Perform verification test to determine if the upgrade is successful, include:

- Verify the router is running the new IOS-XE release using **show version** command.
- Check facility alarms using show facility-alarm status command.
- Check the status of the power supplies using show environment power command.
- Check PS status using **show platform hardware slot P<0-5> mcu status** command.
- Complete trace routes to known good off-network IP address using the source address of customer CPE blocks to verify routing is working.
- Check logs for error messages using show log command.

These **show** commands may be useful in the verification test:

- · show redundancy
- show platform
- · show platform diag
- show environment
- · show redundancy linecard all
- · show isis neighbors
- · show ip ospf neighbor
- show ip route rip
- show ip mroute
- show cops servers
- show cable modem voice
- · show cable calls
- show cable metering verbose
- · show cable licenses all
- show inventory

Upgrading with ISSU for I-CCAP Systems

Before you begin



Note

ISSU is not supported for Remote PHY systems.



Note

ISSU to Cisco IOS XE Bengaluru 17.6.1w is supported only from Cisco IOS XE Gibraltar 16.10.1g and later releases. If you are upgrading from an earlier release, you must upgrade the cBR-8 system following the steps in Upgrading using reload, on page 74.

Before upgrading the system, make sure the following requirements are met:

The cBR-8 has two SUPs installed.

• Standby SUP must be in hot standby state.

• Line card redundancy is in stable state with state Active and Stdby warm.

```
Router# show redundancy linecard all
Load for five secs: 14%/1%; one minute: 8%; five minutes: 8%
Time source is NTP, 15:23:26.697 PST Thu Jan 17 2019
```

Slot	Subslot	LC Group	My State	Peer State	Peer Slot	Peer Subslot	Role	Mode
1	_	0	Active	Stdby Warm	0	-	Active	Primary
2	_	0	Active	Stdby Warm	0	_	Active	Primary
3	_	0	Active	Stdby Warm	0	-	Active	Primary
6	_	0	Active	Stdby Warm	0	-	Active	Primary
0	_	0	_	=	Multiple	None	Standby	Secondary

· Auto-boot is enabled.

```
Router# show bootvar
Load for five secs: 14%/0%; one minute: 14%; five minutes: 10%
Time source is NTP, 15:46:59.837 PST Thu Jan 17 2019

BOOT variable = harddisk:IOSXE/packages.conf,12;
CONFIG_FILE variable =
BOOTLDR variable does not exist
Configuration register is 0x2102

Standby BOOT variable = harddisk:IOSXE/packages.conf,12;
Standby CONFIG_FILE variable =
Standby BOOTLDR variable does not exist
Standby Configuration register is 0x2102
```

• Both SUPs are in the sub-package mode, running the same image from the same path.

```
Router# show bootvar
Load for five secs: 14%/0%; one minute: 14%; five minutes: 10%
Time source is NTP, 15:46:59.837 PST Thu Jan 17 2019

BOOT variable = harddisk:TOSXE/packages.conf,12;
CONFIG_FILE variable =
BOOTLDR variable does not exist
Configuration register is 0x2102

Standby BOOT variable = harddisk:TOSXE/packages.conf,12;
Standby CONFIG_FILE variable =
Standby BOOTLDR variable does not exist
Standby Configuration register is 0x2102
```

• The free space on boot device on both SUPs must be greater than 2GB.

```
Router# dir harddisk: | include bytes total 7804653568 bytes total (5691174912 bytes free)
```

• Download two files from the following Cisco.com Software Center URL:

https://software.cisco.com/download/home/286283913/type

- IOS XE Software Version 17.6.1w: cbrsup-universalk9.17.06.01w.SPA.bin
- IOS XE Hardware Programmable Devices Version 17.6.1w: cbrsup-programmable_firmware.17.06.01w.SPA.pkg
- Copy the target consolidated image **cbrsup-universalk9.17.06.01w.SPA.bin** to the active SUP in the same directory of the **packages.conf** file that the system is booted up with.
- **Step 1** Copy Cisco IOS XE Bengaluru 17.6.1w package to harddisk:.

```
copy <location>/cbrsup-universalk9.17.06.01w.SPA.bin harddisk:<sub-pkg-dir>/
```

Step 2 Verify Cisco IOS XE Bengaluru 17.6.1w package against the md5 hash as provided in the Cisco.com Software center.

```
verify /md5 harddisk:<sub-pkg-dir>/cbrsup-universalk9.17.06.01w.SPA.bin
```

Step 3 Copy the hardware programmable devices upgrade package to harddisk: if the file has not been copied already.

```
copy <location>/cbrsup-programmable firmware.17.06.01w.SPA.pkg harddisk:
```

Step 4 Verify the hardware programmable devices upgrade package against the md5 hash as provided in the Cisco.com Software center.

```
verify /md5 harddisk:cbrsup-programmable firmware.17.06.01w.SPA.pkg
```

- **Step 5** Check system status prior to upgrade. Save the information to compare against the system status after upgrade. For the commands to use to check the status, see the **show** commands at the end of this section.
- **Step 6** Check line card CPLD version via **show platform**. If it is not the minimum version 00000026, upgrade line card CPLD following the sub steps below. Otherwise skip this step.

Note To upgrade the line card CPLD to version 00000026, the cBR-8 must be running Cisco IOS XE Gibraltar 16.12.1 or later releases.

This procedure will trigger a reload of the linecard and will cause an outage if the system is not backed up with LCHA.

Do not power cycle the cBR-8 router during the firmware upgrade process. Power cycling the chassis may corrupt the ROMMON/Uboot image.

a) Run the following pre-upgrade commands on the SUP IOS:

upgrade hw-programmable cable active_SUP daggit pre-upgrade slot LC_slot_# Example:

```
Router# upgrade hw-programmable cable R0 daggit pre-upgrade slot 0 Daggits pre-upgrade successful
```

b) Upgrade the line card CPLD firmware using the SUP IOS command.

Note Do not reboot the line card until the upgrade is complete. Upgrade takes approximately 15 minutes.

upgrade hw-programmable cable LC_slot_# daggit pkg_name firmware_pkg_location_path Example:

```
Router# upgrade hw-programmable cable 0 daggit pkg_name /harddisk/cbrsup-programmable_firmware.17.06.01w.SPA.pkg
```

c) After the upgrade is complete (takes approximately 15 minutes), the line card moves to **unknown** state. Check the status of the line card using the **show platform** command. When the line card is in **unknown** state, run the following command to recover the line card:

upgrade hw-programmable cable <code>active_SUP</code> daggit lc-recovery slot <code>LC_slot_#</code> Example:

```
Router# upgrade hw-programmable cable RO daggit lc-recovery slot 0
```

d) The line card moves from **booting** to **active** state. Check the version of the line card using the **show platform** command to make sure version is changed to 00000026.

Example:

CBR8#show platform
.....
Slot CPLD Version Rommon Version
-----0 00000026 2011.03.18
...

e) When the line card is in **active** state, run the following command to verify the upgrade.

upgrade hw-programmable cable active_SUP daggit post-active slot LC_slot_#
Example:

```
Router# upgrade hw-programmable cable R0 daggit post-active slot 0 SUCCESS: Daggit ver-38 : Booted from upgradable Image-1
```

Step 7 Check the firmware version of the Docsis 3.1 downstream modules in all slots, if it is different with the version listed in Table 4: Firmware Versions, on page 70, update the firmware using the following command. Otherwise skip this step.

upgrade hw-programmable cable slot dsphy all pkg_name firmware_pkg_location_path

Example:

```
Router# upgrade hw-programmable cable 0 dsphy all pkg_name /harddisk/cbrsup-programmable_firmware.17.06.01w.SPA.pkg
```

Step 8 Wait for the system log message asking the user to reload the line card that was upgraded. But do not reload the line card at this time.

```
001860: Jun 15 19:05:05.904 PDT: \text{NIOSXE-5-PLATFORM}: CLC0: cdman: Suggest reload the line card for new FW to take effect using CLI: hw slot \text{slot-id} reload
```

Step 9 Perform ISSU.

request platform software package install node file harddisk:cbrsup-universalk9.17.06.01w.SPA.bin

Step 10 To monitor the ISSU progress, use the command below.

request platform software package install node attach

Step 11 Use these CLI to check status after ISSU.

```
show version r0 running show version r1 running show version r0 provisioned show version r1 provisioned
```

What to do next

Perform verification test to determine if the upgrade is successful, include:

- Verify the router is running the new IOS-XE release using **show version** command.
- Check facility alarms using **show facility-alarm status** command.
- Check the status of the power supplies using **show environment power** command.

- Check PS status using **show platform hardware slot P<0-5> mcu status** command.
- Complete trace routes to known good off-network IP address using the source address of customer CPE blocks to verify routing is working.
- Check logs for error messages using show log command.

These **show** commands may be useful in the verification test:

- · show redundancy
- show platform
- · show platform diag
- · show environment
- · show redundancy linecard all
- · show isis neighbors
- show ip ospf neighbor
- · show ip route rip
- show ip mroute
- · show cops servers
- · show cable modem voice
- show cable calls
- · show cable metering verbose
- · show cable licenses all
- show inventory

Upgrading Supervisor CPLD Firmware

Before you begin



Note

If the supervisor SO CPLD version is lower than 1511_1401 (SUP 160) or 15111401 (SUP 250), or, if the supervisor SIO CPLD version is lower than 1511_1301 (SUP 160) or 15111301 (SUP 250), physically power cycle the chassis when upgrading the supervisor CPLD.

Before upgrading the firmware, make sure the following requirements are met:

- Cisco cBR-8 router is running with Cisco IOS XE Gibraltar 16.12.1w or later releases.
- 2 supervisors are running in the Cisco cBR-8 router and the redundancy is enabled.
- Download the file from the following Cisco.com Software Center URL:

https://software.cisco.com/download/home/286283913/type

- IOS XE Hardware Programmable Devices Version 17.6.1w: cbrsup-programmable_firmware.17.06.01w.SPA.pkg
- Console access for both supervisors are required.
- Copy the new firmware package to the cBR-8 using FTP.

```
copy ftp://<location>/cbrsup-programmable_firmware.17.06.01w.SPA.pkg harddisk:
copy ftp://<location>/cbrsup-programmable_firmware.17.06.01w.SPA.pkg stby-harddisk:
```



Note

When upgrading SUP0, run the CLI with the R0 setting while controlling SUP0. And when upgrading SUP1, run the CLI with the R1 setting.



Note

This guide assumes SUP0 is in active state and SUP1 is in standby hot state at the beginning.

Perform step 1 to 4 using console connection of active SUP0:

Step 1 Set the config register.

```
configure terminal
config-register 0x2102
end
write memory
```

Step 2 Run the following command to prepare for R0 upgrade.

```
upgrade hw-programmable cable R0 viper pkg_name /harddisk/cbrsup-programmable firmware.17.06.01w.SPA.pkg
```

On SUP 250, you will see one of the following outputs:

 \bullet It takes 10~20 minutes to upgrade. Console would hung. Please don't do any operation during the upgrade.

```
You are upgrading Viper firmware using harddisk/cbrsup-programmable_firmware.17.06.01w.SPA.pkg image on SUPO, SUPO is active.
```

```
Upgrade from assigned pkg file harddisk/cbrsup-programmable_firmware.17.06.01w.SPA.pkg
Using viper firmware /tmp/viper/mount/supve_viper_fpga_psirt.bin
Size of Viper Upgrade image: 16777216 bytes
No.of parts: 65536
Upgrading golden image...
65536+0 records in
65536+0 records out
16777216 bytes (17 MB, 16 MiB) copied, 688.873 s, 24.4 kB/s
Upgrading primary image...
65536+0 records in
65536+0 records out
16777216 bytes (17 MB, 16 MiB) copied, 675.19 s, 24.8 kB/s
```

```
Viper upgrade clean up 0
Upgrade successfully. Please make sure Rommon version is matched.
Please power cycle the chassis to let the new firmware take effect
```

• It takes 10~20 minutes to upgrade. Console would hung. Please don't do any operation during the upgrade.

You are upgrading Viper firmware using harddisk/cbrsup-programmable_firmware.17.06.01w.SPA.pkg image on SUPO, SUPO is active.

Upgrade from assigned pkg file harddisk/cbrsup-programmable_firmware.17.06.01w.SPA.pkg The golden viper is not compatible with assigned firmware

/tmp/viper/mount/supve_viper_fpga_psirt.bin, no upgrade will be performed Viper upgrade clean up 2

Note This output means the SUP already has the latest version it can support, skip the rest of the steps.

On SUP 160, you will see one of the following outputs:

• It takes about 10 minutes to upgrade. Console would hung. Please don't do any operation during the upgrade.

You are upgrading Viper firmware using harddisk/cbrsup-programmable_firmware.17.06.01w.SPA.pkg image

Upgrade from assigned pkg file /harddisk/cbrsup-programmable_firmware.17.06.01w.SPA.pkg Using viper firmware /tmp/viper/mount/viper fpga.bin

Size of Viper Upgrade image: 16777216 bytes

No.of parts: 65536

65536+0 records in

65536+0 records out

Viper upgrade clean up 0

Upgrade successfully. Please make sure Rommon version is matched.

Please power cycle the chassis to let the new firmware take effect

• It takes 10~20 minutes to upgrade. Console would hung. Please don't do any operation during the upgrade.

You are upgrading Viper firmware using harddisk/cbrsup-programmable_firmware.17.06.01w.SPA.pkg image on SUPO, SUPO is active.

Upgrade from assigned pkg file harddisk/cbrsup-programmable_firmware.17.06.01w.SPA.pkg The golden viper is not compatible with assigned firmware /tmp/viper/mount/supve viper fpga psirt.bin, no upgrade will be performed

Note This output means the SUP already has the latest version it can support, skip the rest of the steps.

Note Do not power cycle the chassis in this step.

Step 3 Run the following command to prepare for R1 upgrade.

Viper upgrade clean up 2

```
upgrade hw-programmable cable R1 viper pkg_name
/harddisk/cbrsup-programmable_firmware.17.06.01w.SPA.pkg
```

You will see the similar output as the one in Step 2.

Note Do not power cycle the chassis in this step.

Step 4 If the supervisor ViperSO CPLD version is 15111401 and the supervisor ViperSIO CPLD version is 15111301 on both supervisors, follow step 5 - 11 to do the upgrade. Otherwise proceed to step 12.

```
Router#show platform diag
Load for five secs: 6%/1%; one minute: 7%; five minutes: 8%
Time source is NTP, 16:05:43.546 PST Thu Feb 8 2018
```

```
Chassis type: CBR-8-CCAP-CHASS
<SNTP>
Slot: SUPO, CBR-CCAP-SUP-160G
        Physical insert detect time: 00:01:58 (1d03h ago)
        CPLD version : 16052011
        ViperSO CPLD version : 15111401
ViperSIO CPLD version : 15111301
Rommon version : 16.7(1r)S
        Rommon version
Blackbird version
                                     : 00000112
        Raptor ESI version
Raptor MAC version
                                     : 0001003b
        SUP-PIC CPLD version : 14071504
SUP-DC CPLD version : 14072207
        DTI Client FPGA version : 00000005
        DTI Firmware version
                                     : 00000A03
                                     : 201402061607
        Cortina PHY version
        SUP PSOC 0 version
                                     : v4.0.9
        SUP PSOC 1 version
SUP PSOC 2 version
SUP PSOC 3 version
                                      : v4.0.8
                                      : v4.1.0 IVB
                                      : v4.0.6
        SUP-DC PSOC 0 version : v4.0.8
        SUP-DC PSOC 1 version
                                     : v4.0.5
                                      : V2.0.6
         SUP-PIC PSOC 0 version
        SUP-PIC PSOC 1 version
                                       : V2.0.6
<SNIP>
Slot: SUP1, CBR-CCAP-SUP-160G
        Physical insert detect time : 00:02:26 (1d03h ago)
        version : 15111401

ViperSIO CPLD version : 15111301

Rommon version
        Rommon version
                                      : 16.7(1r)S
        Blackbird version
                                     : 00000112
        Raptor ESI version : 0001003b
Raptor MAC version : 00010031
SUP-PIC CPLD version : 14071504
SUP-DC CPLD version : 14072207
        Raptor ESI version
Raptor MAC version
        DTI Client FPGA version : 00000005
        DTI Firmware version
                                     : 00000A03
        Cortina PHY version
                                     : 201402061607
        SUP PSOC 0 version
                                      : v4.0.9
        SUP PSOC 1 version
                                       : v4.0.8
        SUP PSOC 2 version
SUP PSOC 3 version
                                      : v4.1.0_IVB
                                      : v4.0.6
        SUP-DC PSOC 0 version : v4.0.9
        SUP-DC PSOC 1 version
                                     : v4.0.5
         SUP-PIC PSOC 0 version
                                      : V3.0.0
        SUP-PIC PSOC 1 version
                                      : V3.0.0
<SNIP>
```

Step 5 Set SUP0 to ROMMON using the following command.

redundancy force-switchover

Perform the following steps 6 to 7 using console connection of current active SUP1.

Step 6 Power cycle the SUP0 to set it to ROMMON.

```
test platform hardware slot RO oir power-cycle
```

This command will reset and re-initialize the ROMMON. The new version of the supervisor CPLD will now take effect. Verify if it matches the following new version.

SUP 160 new version: 0x19071712

SUP 250 new version: 0x190717E1

Step 7 Boot SUP0 into IOS XE using SUP0 console connection.

dir harddisk:

boot harddisk:cbrsup-universalk9.17.06.01w.SPA.bin

Wait utill SUP0 is in standby hot.

Step 8 Set SUP1 to ROMMON using the following command.

redundancy force-switchover

Perform the following steps 9 to 11 using console connection of current active SUP0.

Step 9 Power cycle the SUP1 to set it to ROMMON.

test platform hardware slot R1 oir power-cycle

This command will reset and re-initialize the ROMMON. The new version of the supervisor CPLD will now take effect. Verify if it matches the following new version.

SUP 160 new version: 0x19071712 SUP 250 new version: 0x190717E1

Step 10 Boot SUP1 into IOS XE using SUP1 console connection.

dir harddisk:
boot harddisk:cbrsup-universalk9.17.06.01w.SPA.bin

Wait utill SUP1 is in standby hot.

Step 11 Wait for the chassis to become SSO and settled down. Then go to step 16. If you skipped step 5 to 10, perform step 12 to 15.

Note You need physical access to the chassis to power cycle the chassis.

Step 12 Reload the system by issuing **reload** command on the active SUP.

Router#reload

Step 13 Power cycle both supervisors.

Step 14 Verify if the new version matches the following on both SUPs.

SUP 160 new version: 0x19071712 SUP 250 new version: 0x190717E1

Step 15 Boot both SUP0 and SUP1 into IOS XE using SUP0 and SUP1 console.

dir harddisk: boot harddisk:cbrsup-universalk9.17.06.01w.SPA.bin

Wait till SUP0 become standby hot.

Step 16 Once the system is up and running, perform the following checks.

Set config register to normal boot.

```
configure terminal
config-register 0x2102
end
write memory
```

- Execute **show redundancy** command to ensure both SUPs are listed, one is active and the other is standby hot.
- Execute show proc CPU sorted | ex 0.00 command.
- Execute show platform diag command.

Upgrading cBR CCAP 8x10G Remote PHY Digital Physical Interface Card

Before you begin

Before upgrading the system, make sure the following requirements are met:

- Make sure the latest available IOS XE version is active in Cisco cBR-8 router.
- There are at lease 20MB free space on the harddisk.



Note

To make use of the new features, it is recommended to upgrade the cBR CCAP 8x10G Remote PHY Digital Physical Interface Card (D-PIC) to the latest version 1.1.

- **Step 1** Boot up system, wait until IOS is ready.
- **Step 2** Check current D-PIC version.

```
show hw-module subslot x/1 fpd
```

Note x/1 is D-PIC subslot number which needs upgrade.

Example:

9/1	CBR-DPIC-8X10G	1.0	46-CBR DIGI PIC	1.0	1.0
====	=======================================	======	================		=========

Step 3 Upgrade D-PIC.

upgrade hw-module subslot x/1 fpd bundled reload

Example:

Router#upgrade hw-module subslot 9/1 fpd bundled reload

% The following FPD will be upgraded for CBR-DPIC-8X10G (H/W ver = 1.0) in subslot 9/1:

Field Programmable	Current	Upgrade	Estimated
Device: "ID-Name"	Version	Version	Upgrade Time
46-CBR DIGI PIC	1.0	1.1	00:05:00
			========

- % NOTES:
 - Use 'show upgrade fpd progress' command to view the progress of the FPD upgrade.
 - The target card will be automatically reloaded after the upgrade operation. This reload will interrupt normal operation of the card. If necessary, ensure that appropriate actions have been taken to redirect card traffic before starting the FPD upgrade.
- % Are you sure that you want to perform this operation? [no]: yes
- % Initiating the upgrade operation on the target card ...
 (Use "show upgrade fpd progress" command to see upgrade progress)

Step 4 Check if the upgrade process is finished. Upgrade progress will take about 1 to 2 minutes.

show upgrade fpd progress

Example:

Upgrade still ongoing:

Router#show upgrade fpd progress

FPD Image Upgrade Progress Table:

====							
Slot	Card Type	Field Programmable Device : "ID-Name"	Approx. Time Needed	Elapsed Time	State		
9/1	CBR-DPIC-8X10G	46-CBR DIGI PIC	00:05:00	00:00:13	Updating		
sj-104-cbr-13#show upgrade fpd progress FPD Image Upgrade Progress Table:							
====			Approx		=======		

====							
		Approx.					
		Field Programmable	Time	Elapsed			
Slot	Card Type	Device : "ID-Name"	Needed	Time	State		

9/1 CBR-DPIC-8X10G 46-CBR DIGI PIC 00:05:00 00:00:26 Updating...

Upgrade finished:

Router#show upgrade fpd progress

% There is no FPD image upgrade in progress.

Step 5 Check if the D-PIC status is ready.

show platform

Example:

Router#show platform

Chassis type: CBR-8-CCAP-CHASS

Slot	Туре	State	Insert time (ago)
2/1	CBR-RF-PROT-PIC	ok	00:08:48
3	CBR-CCAP-LC-40G		00:12:46
3/1	CBR-RF-PIC	ok	00:08:48
8/1	CBR-DPIC-8X10G	ok	00:07:56
9	CBR-CCAP-LC-40G	ok	00:12:46
9/1	CBR-DPIC-8X10G	ok	00:07:54
SUP0	CBR-CCAP-SUP-160G	inserted	00:12:46
R0		ok, active	
F0		ok, active	
4		ok, active	
4/1	CBR-SUP-8X10G-PIC	ok	00:07:55
SUP1	CBR-CCAP-SUP-160G	inserted	00:12:22
R1		ok, standby	
F1		ok, standby	
5		ok, standby	
5/1	CBR-SUP-8X10G-PIC	ok	00:07:54
P0	PWR-3KW-AC-V2	ok	00:09:49
P1	PWR-3KW-AC-V2	ok	00:09:49
P2	PWR-3KW-AC-V2	ps, fail	00:09:49
P3	Unknown	N/A	never
P4		N/A	never
P5	PWR-3KW-AC-V2	ok	00:09:49
P10	CBR-FAN-ASSEMBLY	ok	00:09:39
	CBR-FAN-ASSEMBLY		00:09:39
P12	CBR-FAN-ASSEMBLY	ok	00:09:39
	CBR-FAN-ASSEMBLY		00:09:39
P14	CBR-FAN-ASSEMBLY	ok	00:09:39
Slot	CPLD Version	Rommon Version	
3	00000025	2011.03.18	
9	00000025	2011.03.18	
SUP0	16052011	16.7(3r)S	
SUP1	16052011	16.7(3r)S	

Step 6 Check if the new version works.

show hw-module subslot x/1 fpd

Example:

Router#show hw-module subslot 9/1 fpd

====		=====			
		H/W	Field Programmable	Current	Min. Required
Slot.	Card Type	Ver.	Device: "ID-Name"	Version	Version

====					=========
9/1	CBR-DPIC-8X10G	1.0	46-CBR DIGI PIC	1.1	1.0
====		=====			



Upgrading the Cisco cBR-8 Router System to Cisco IOS XE Bengaluru 17.6.1a



Note

Starting from Cisco IOS XE Bengaluru 17.6.1a, CBR-CCAP-LC-G2-R can only protect CBR-CCAP-LC-G2-R for linecard HA.



Note

If you are using TACACS authentication, the TACACS configuration will be automatically updated to the new version after upgrading to Cisco IOS XE Bengaluru 17.6.1a. This is a fix to CSCvu62273 and you do not need to take any action regarding the TACACS configuration in the cBR-8 prior to the upgrade.

This section contains the upgrade procedures for the Cisco cBR-8 Router System.

By default, telnet is disabled on Cisco cBR-8. If you are going to use telnet to access the device, make sure the value of line **vty transport** is correct and save the configuration in order to enable telnet.

```
Router# show run | begin line vty
line vty 0 4
exec-timeout 0 0
privilege level 15
password 7 104D081B094410055F
exec prompt timestamp
transport input all
line vty 5 98
exec-timeout 0 0
privilege level 15
password 7 02050D480809
transport input all
line vty 99
transport input all
!
```

The following table encompasses all versions that customers are required to update to support Cisco IOS XE Bengaluru 17.6.1a. All other firmware versions are either not upgradable by the customer, or not required to be upgraded for Cisco IOS XE Bengaluru 17.6.1a support. Use the commands in the tables to verify the firmware versions. If you need to upgrade firmware first, refer to the steps in Upgrading the Cisco cBR-8 Router Firmware.



Note

If you want to upgrade Supervisor CPLD firmware, refer to Upgrading Supervisor CPLD Firmware, on page 104.

Table 5: Firmware Versions

Internal Name	Component Name	Required Minimum Version	Command
Supervisor CPLD	CBR-CCAP-SUP-160G CPLD	16052011/19071712	show platform
	CBR-CCAP-SUP-250G CPLD	170724E0/190717E1	show platform
Supervisor ROMMON	CBR-CCAP-SUP-160G ROMMON and CBR-CCAP-SUP-250G ROMMON	16.7(2r)S	show platform
Line Card CPLD	CBR-CCAP-LC-40G CPLD	00000026	show platform diag
Docsis 3.1 downstream module Micro	CBR-CCAP-LC-40G Gemini2 Micro	3.1A	show platform diag
Docsis 3.1 downstream module FPGA	CBR-CCAP-LC-40G Gemini2 Apollo	4.484F	show platform diag
DPIC Uboot and FPGA	CBR-DPIC-8X10G Firmware	00010001	show platform diag
DPIC 100G Uboot and FPGA	CBR-DPIC-2X100G Firmware	00020005	show platform diag



Note

If the user wants to upgrade Supervisor CPLD to version 19071712 and 190717E1, the chassis must be running with Cisco IOS XE Gibraltar 16.12.1w or later releases.



Note

Cisco recommends that operators upgrade their On-Premise SSM Satellite software versions to v7.x or later releases, to ensure the compatibility with cBR-8.

- Verify max-carrier value, on page 93
- Upgrading from Cisco IOS XE 16.x and later releases to Cisco IOS XE Bengaluru 17.6.1a, on page 94
- Upgrading Supervisor CPLD Firmware, on page 104

• Upgrading cBR CCAP 8x10G Remote PHY Digital Physical Interface Card, on page 109

Verify max-carrier value

Currently in Remote PHY system, max-carrier value can be configured in the downstream controller profile as well as in RPD configuration for Cisco Remote PHY Shelf 300/600/7200. This may lead to inconsistent max-carrier value configurations.

Starting from Cisco IOS XE Gibraltar 16.10.1f, max-carrier value configured in the **cable rpd** mode is removed and RPD will use the max-carrier value configured in the **controller-profile** mode for the power calculation.

Before upgrading to Cisco IOS XE Gibraltar 16.10.1f or later releases, verify if the max-carrier values configured in the RPD shelf configuration and downstream controller profile(s) associated to RPD downstream port are the same. If they are different, update the cBR-8 configuration prior to upgrade.

Below is an example of correct configuration before upgrade.

```
cable downstream controller-profile 1
max-carrier 128
max-ofdm-spectrum 384000000
rf-chan 0 3
 type DOCSIS
 gam-profile 1
 frequency 381000000
 rf-output NORMAL
 docsis-channel-id 1
cable downstream controller-profile 2
max-carrier 158
max-ofdm-spectrum 384000000
rf-chan 158
 docsis-channel-id 159
 ofdm channel-profile 20 start-frequency 579000000 width 48000000 plc 600000000
cable rpd test
identifier 0001.0001.0001
type shelf
rpd-ds 0 max-carrier 128
rpd-ds 0 base-power 33
rpd-ds 1 max-carrier 158
rpd-ds 1 base-power 25
core-interface Te9/1/0
 rpd-ds 0 downstream-cable 9/0/3 profile 1
 rpd-ds 0 downstream-cable 9/0/4 profile 2
 rpd-us 0 upstream-cable 9/0/3 profile 1
r-dti 1
rpd-event profile 0
rpd-55d1-us-event profile 0
```



Note

It is highly recommended to follow this example to check and update configuration if necessary because max-carrier value is used to compute the base power. Otherwise, after upgrade the expected base power value can be different which may affect cable modem coming online.



Note

If you upgrade from a version lower than Cisco IOS XE Fuji 16.9.1, base power range may be changed on the port with OFDM channel configured. So be aware of the potential base power change before and after the upgrade.

Upgrading from Cisco IOS XE 16.x and later releases to Cisco IOS XE Bengaluru 17.6.1a

If you are upgrading from Cisco IOS XE Everest 16.6.x or Cisco IOS XE Fuji 16.7.x to Cisco IOS XE Bengaluru 17.6.1a, perform the following steps to upgrade SUP ROMMON manually. Otherwise proceed with the IOS upgrade.

- Download hardware programmable devices upgrade package file cbrsup-programmable_firmware.17.06.01a.SPA.pkg from the following Cisco.com Software Center URL: https://software.cisco.com/download/home/286283913/type
- **2.** Copy the package file to harddisk:.

```
copy <location>/cbrsup-programmable_firmware.17.06.01a.SPA.pkg harddisk:
```

3. Verify the hardware programmable devices upgrade package against the md5 hash as provided in the Cisco.com Software center.

verify /md5 harddisk:cbrsup-programmable_firmware.17.06.01a.SPA.pkg

4. Upgrade SUP ROMMON.

```
Router#Upgrade rom-mon file harddisk:cbrsup-programmable_firmware.17.06.01a.SPA.pkg r0
Wait for the following output on the console:
ROMMON upgrade complete.
To make the new ROMMON permanent, you must restart the RP

Router#Upgrade rom-mon file harddisk:cbrsup-programmable_firmware.17.06.01a.SPA.pkg r1
Wait for the following output on the console:
ROMMON upgrade complete.
To make the new ROMMON permanent, you must restart the RP
```



Note

Do not restart the SUPs currently, you can combine reloading the SUP with the IOS upgrade process.

If you are using cBR CCAP 8x10G Remote PHY Digital Physical Interface Card (D-PIC) with CBR-CCAP-LC-G2-R linecards, before upgrading to Cisco IOS XE Bengaluru 17.6.1a, contact your local Cisco representative to get the python tool and perform the following steps in order to predict and avoid downtime. This python tool is developed by Cisco, it is used to analyze the cBR-8 configuration file to determine if the configuration file includes non-compliant TenGigabitEthernet interface to downstream controller mappings, and update the configuration file to be compliant with the latest Cisco IOS XE Bengaluru 17.6.1a.

1. Collect the following information from the target cBR-8 to upgrade.

```
Router#show cable rpd sum
Router#show cable modem sum
Router#show cable video session all sum
```

2. Save the running configuration to the harddisk of the cBR-8.

Router#copy running-config harddisk:SavedConfig.txt

3. Copy the saved running configuration from harddisk: to an offline server for editing using SCP.

```
Router#copy harddisk:SavedConfig.txt scp:<path>
```

- **4.** Run the python tool to modify the controllers in the saved configuration.
 - Option 1 Renumber Downstream-Cable controllers only
 - **a.** Execute python script **kobol_ph2_controller_migration.py**. This script is intended for customers who do not immediately intend to take advantage of the Downstream-Video controllers and expanded SG capacity on CBR-CCAP-LC-G2-R.

```
$ python kobol_ph2_controller_migration.py
Enter the name of the configuration file: SavedConfig.txt
```

b. Output file appends **_remap_controller** to the file name.

```
Output file name: SavedConfig.txt remap controller
```

- **c.** Check to ensure that the script completed successfully. If no output file is created or the size of the output file is 0 byte, then check script output for error messages.
- Option 2 Renumber Downstream-Cable and utilize Downstream-Video controllers
- a. Execute python script kobol_ph2_controller_migration_video.py. This script is intended for customers who wish to utilize the new Downstream-Video controllers to free up existing Downstream-Cable controllers for expanded DOCSIS service groups.

```
$ python kobol_ph2_controller_migration_video.py
Enter the name of the configuration file: SavedConfig.txt
```

b. Output file appends **_remap_controller_video** to the file name.

```
Output file name: SavedConfig.txt remap controller video
```

- **c.** Check to ensure that the script completed successfully. If no output file is created or the size of the output file is 0 byte, then check script output for error messages.
- 5. Modify the remapped configuration file to specify the Cisco IOS XE Bengaluru 17.6.1a image in the boot parameter.

```
boot system harddisk:cbrsup-universalk9.17.06.01a.SPA.bin
```

6. Copy the final remapped configuration file back to the cBR-8 harddisk.

```
Router#copy scp:<path>/SavedConfig.txt_remap_controller harddisk:
or
Router#copy scp:<path>/SavedConfig.txt remap controller video harddisk:
```

7. Copy remapped configuration file to startup of the cBR-8.

```
Router#copy harddisk:SavedConfig.txt_remap_controller startup-config or
```

Router#copy harddisk: SavedConfig.txt remap controller video startup-config

Upgrading using reload

Before you begin



Note

If you are upgrading from Cisco IOS XE Everest 16.6.x or Cisco IOS XE Fuji 16.7.x to Cisco IOS XE Bengaluru 17.6.1a, perform pre-upgrade steps 1 to 4 to upgrade SUP ROMMON manually before proceeding with IOS upgrading.

Before upgrading the system, make sure the following requirements are met:

• Download two files from the following Cisco.com Software Center URL:

https://software.cisco.com/download/home/286283913/type

- IOS XE Software Version 17.6.1a: cbrsup-universalk9.17.06.01a.SPA.bin
- IOS XE Hardware Programmable Devices Version 17.6.1a: cbrsup-programmable_firmware.17.06.01a.SPA.pkg
- **Step 1** Copy Cisco IOS XE Bengaluru 17.6.1a package to harddisk: and stby-harddisk:.

```
copy <location>/cbrsup-universalk9.17.06.01a.SPA.bin harddisk:
copy <location>/cbrsup-universalk9.17.06.01a.SPA.bin stby-harddisk:
```

Step 2 Verify Cisco IOS XE Bengaluru 17.6.1a package against the md5 hash as provided in the Cisco.com Software center.

```
verify /md5 harddisk:cbrsup-universalk9.17.06.01a.SPA.bin verify /md5 stby-harddisk:cbrsup-universalk9.17.06.01a.SPA.bin
```

Step 3 Copy the hardware programmable devices upgrade package to harddisk: if the file has not been copied already.

```
copy <location>/cbrsup-programmable firmware.17.06.01a.SPA.pkg harddisk:
```

Step 4 Verify the hardware programmable devices upgrade package against the md5 hash as provided in the Cisco.com Software center.

```
verify /md5 harddisk:cbrsup-programmable firmware.17.06.01a.SPA.pkg
```

- **Step 5** Configure the chassis to boot the system with Cisco IOS XE Bengaluru 17.6.1a image.
 - **a.** Use the following steps if you do not use cBR CCAP 8x10G Remote PHY Digital Physical Interface Card (D-PIC) with CBR-CCAP-LC-40G-R linecards.

```
configure terminal no boot system boot system harddisk:cbrsup-universalk9.17.06.01a.SPA.bin config-register 0x2102 end write mem
```

b. Use the following steps if you use cBR CCAP 8x10G Remote PHY Digital Physical Interface Card (D-PIC) with CBR-CCAP-LC-40G-R linecards.

```
configure terminal
config-register 0x2102
end
```

Step 6 Check line card CPLD version via **show platform**. If it is not the minimum version 00000026, upgrade line card CPLD following the sub steps below. Otherwise skip this step.

Note To upgrade the line card CPLD to version 00000026, the cBR-8 must be running Cisco IOS XE Gibraltar 16.12.1 or later releases.

This procedure will trigger a reload of the linecard and will cause an outage if the system is not backed up with LCHA.

Do not power cycle the cBR-8 router during the firmware upgrade process. Power cycling the chassis may corrupt the ROMMON/Uboot image.

a) Run the following pre-upgrade commands on the SUP IOS:

```
upgrade hw-programmable cable active_SUP daggit pre-upgrade slot LC_slot_#
Example:
Router# upgrade hw-programmable cable RO daggit pre-upgrade slot 0
```

Daggits pre-upgrade successful

b) Upgrade the line card CPLD firmware using the SUP IOS command.

Note Do not reboot the line card until the upgrade is complete. Upgrade takes approximately 15 minutes.

upgrade hw-programmable cable LC_slot_# daggit pkg_name firmware_pkg_location_path Example:

```
Router# upgrade hw-programmable cable 0 daggit pkg_name /harddisk/cbrsup-programmable_firmware.17.06.01a.SPA.pkg
```

c) After the upgrade is complete (takes approximately 15 minutes), the line card moves to **unknown** state. Check the status of the line card using the **show platform** command. When the line card is in **unknown** state, run the following command to recover the line card:

```
upgrade hw-programmable cable <code>active_SUP</code> daggit lc-recovery slot <code>LC_slot_#</code> Example:
```

```
\label{eq:continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous_continuous
```

d) The line card moves from **booting** to **active** state. Check the version of the line card using the **show platform** command to make sure version is changed to 00000026.

Example:

```
Router#show platform
.....

Slot CPLD Version Rommon Version
------

0 00000026 2011.03.18
...
```

e) When the line card is in **active** state, run the following command to verify the upgrade.

```
upgrade hw-programmable cable active_SUP daggit post-active slot LC_slot_#
Example:
```

```
Router# upgrade hw-programmable cable R0 daggit post-active slot 0 SUCCESS: Daggit ver-38 : Booted from upgradable Image-1
```

Step 7 Check the firmware version of the Docsis 3.1 downstream modules in all slots, if it is different with the version listed in Table 5: Firmware Versions, on page 92, update the firmware using the following command. Otherwise skip this step.

upgrade hw-programmable cable slot dsphy all pkg name firmware pkg location path

Example:

```
Router# upgrade hw-programmable cable 0 dsphy all pkg_name /harddisk/cbrsup-programmable_firmware.17.06.01a.SPA.pkg
```

Step 8 Wait for the system log message asking the user to reload the line card that was upgraded.

Step 9 Reload the system.

Router#reload

During reload, monitor the chassis for any of the following errors, and update the configuration accordingly.

```
Mismatches TE interface. DS controller should be */*/0\sim7, configuration failed. Mismatches TE interface. DS controller should be */*/8\sim15, configuration failed. Mismatches TE interface. DS controller should be */*/16\sim23, configuration failed. Mismatches TE interface. DS controller should be */*/24\sim31, configuration failed.
```

Step 10 If the system is running with SUP250, perform **no shut** on 100G interface after the system comes up for the first time.

What to do next

Perform verification test to determine if the upgrade is successful, include:

- Verify the router is running the new IOS-XE release using **show version** command.
- Check facility alarms using show facility-alarm status command.
- Check the status of the power supplies using show environment power command.
- Check PS status using **show platform hardware slot P<0-5> mcu status** command.
- Complete trace routes to known good off-network IP address using the source address of customer CPE blocks to verify routing is working.
- Check logs for error messages using show log command.

These **show** commands may be useful in the verification test:

- · show redundancy
- · show platform
- · show platform diag
- show environment
- · show redundancy linecard all
- · show isis neighbors
- · show ip ospf neighbor
- show ip route rip
- show ip mroute
- show cops servers
- show cable modem voice
- · show cable calls
- show cable metering verbose
- · show cable licenses all
- show inventory

Upgrading with ISSU for I-CCAP Systems

Before you begin



Note

ISSU is not supported for Remote PHY systems.



Note

ISSU to Cisco IOS XE Bengaluru 17.6.1a is supported only from Cisco IOS XE Gibraltar 16.10.1g and later releases. If you are upgrading from an earlier release, you must upgrade the cBR-8 system following the steps in Upgrading using reload, on page 96.

Before upgrading the system, make sure the following requirements are met:

The cBR-8 has two SUPs installed.

• Standby SUP must be in hot standby state.

• Line card redundancy is in stable state with state Active and Stdby warm.

```
Router# show redundancy linecard all
Load for five secs: 14%/1%; one minute: 8%; five minutes: 8%
Time source is NTP, 15:23:26.697 PST Thu Jan 17 2019
```

Slot	Subslot	LC Group	My State	Peer State	Peer Slot	Peer Subslot	Role	Mode
1	_	0	Active	Stdby Warm	0	-	Active	Primary
2	_	0	Active	Stdby Warm	0	_	Active	Primary
3	_	0	Active	Stdby Warm	0	-	Active	Primary
6	_	0	Active	Stdby Warm	0	-	Active	Primary
0	_	0	_	=	Multiple	None	Standby	Secondary

· Auto-boot is enabled.

```
Router# show bootvar
Load for five secs: 14%/0%; one minute: 14%; five minutes: 10%
Time source is NTP, 15:46:59.837 PST Thu Jan 17 2019

BOOT variable = harddisk:IOSXE/packages.conf,12;
CONFIG_FILE variable =
BOOTLDR variable does not exist
Configuration register is 0x2102

Standby BOOT variable = harddisk:IOSXE/packages.conf,12;
Standby CONFIG_FILE variable =
Standby BOOTLDR variable does not exist
Standby Configuration register is 0x2102
```

• Both SUPs are in the sub-package mode, running the same image from the same path.

```
Router# show bootvar
Load for five secs: 14%/0%; one minute: 14%; five minutes: 10%
Time source is NTP, 15:46:59.837 PST Thu Jan 17 2019

BOOT variable = harddisk:IOSXE/packages.conf,12;
CONFIG_FILE variable =
BOOTLDR variable does not exist
Configuration register is 0x2102

Standby BOOT variable = harddisk:IOSXE/packages.conf,12;
Standby CONFIG_FILE variable =
Standby BOOTLDR variable does not exist
Standby Configuration register is 0x2102
```

• The free space on boot device on both SUPs must be greater than 2GB.

```
Router# dir harddisk: | include bytes total 7804653568 bytes total (5691174912 bytes free)
```

• Download two files from the following Cisco.com Software Center URL:

https://software.cisco.com/download/home/286283913/type

- IOS XE Software Version 17.6.1a: cbrsup-universalk9.17.06.01a.SPA.bin
- IOS XE Hardware Programmable Devices Version 17.6.1a: cbrsup-programmable_firmware.17.06.01a.SPA.pkg
- Copy the target consolidated image **cbrsup-universalk9.17.06.01a.SPA.bin** to the active SUP in the same directory of the **packages.conf** file that the system is booted up with.
- **Step 1** Copy Cisco IOS XE Bengaluru 17.6.1a package to harddisk:.

```
copy <location>/cbrsup-universalk9.17.06.01a.SPA.bin harddisk:<sub-pkg-dir>/
```

Step 2 Verify Cisco IOS XE Bengaluru 17.6.1a package against the md5 hash as provided in the Cisco.com Software center.

```
verify /md5 harddisk:<sub-pkg-dir>/cbrsup-universalk9.17.06.01a.SPA.bin
```

Step 3 Copy the hardware programmable devices upgrade package to harddisk: if the file has not been copied already.

```
copy <location>/cbrsup-programmable firmware.17.06.01a.SPA.pkg harddisk:
```

Step 4 Verify the hardware programmable devices upgrade package against the md5 hash as provided in the Cisco.com Software center.

```
verify /md5 harddisk:cbrsup-programmable firmware.17.06.01a.SPA.pkg
```

- **Step 5** Check system status prior to upgrade. Save the information to compare against the system status after upgrade. For the commands to use to check the status, see the **show** commands at the end of this section.
- **Step 6** Check line card CPLD version via **show platform**. If it is not the minimum version 00000026, upgrade line card CPLD following the sub steps below. Otherwise skip this step.

Note To upgrade the line card CPLD to version 00000026, the cBR-8 must be running Cisco IOS XE Gibraltar 16.12.1 or later releases.

This procedure will trigger a reload of the linecard and will cause an outage if the system is not backed up with LCHA.

Do not power cycle the cBR-8 router during the firmware upgrade process. Power cycling the chassis may corrupt the ROMMON/Uboot image.

a) Run the following pre-upgrade commands on the SUP IOS:

upgrade hw-programmable cable active_SUP daggit pre-upgrade slot LC_slot_# Example:

```
Router# upgrade hw-programmable cable R0 daggit pre-upgrade slot 0 Daggits pre-upgrade successful
```

b) Upgrade the line card CPLD firmware using the SUP IOS command.

Note Do not reboot the line card until the upgrade is complete. Upgrade takes approximately 15 minutes.

upgrade hw-programmable cable LC_slot_# daggit pkg_name firmware_pkg_location_path Example:

```
Router# upgrade hw-programmable cable 0 daggit pkg_name /harddisk/cbrsup-programmable_firmware.17.06.01a.SPA.pkg
```

c) After the upgrade is complete (takes approximately 15 minutes), the line card moves to **unknown** state. Check the status of the line card using the **show platform** command. When the line card is in **unknown** state, run the following command to recover the line card:

upgrade hw-programmable cable <code>active_SUP</code> daggit lc-recovery slot <code>LC_slot_#</code> Example:

```
Router# upgrade hw-programmable cable RO daggit lc-recovery slot 0
```

d) The line card moves from **booting** to **active** state. Check the version of the line card using the **show platform** command to make sure version is changed to 00000026.

Example:

e) When the line card is in **active** state, run the following command to verify the upgrade.

upgrade hw-programmable cable active_SUP daggit post-active slot LC_slot_#
Example:

```
Router# upgrade hw-programmable cable R0 daggit post-active slot 0 SUCCESS: Daggit ver-38 : Booted from upgradable Image-1
```

Step 7 Check the firmware version of the Docsis 3.1 downstream modules in all slots, if it is different with the version listed in Table 5: Firmware Versions, on page 92, update the firmware using the following command. Otherwise skip this step.

upgrade hw-programmable cable slot dsphy all pkg_name firmware_pkg_location_path

Example:

Router# upgrade hw-programmable cable 0 dsphy all pkg_name /harddisk/cbrsup-programmable_firmware.17.06.01a.SPA.pkg

Step 8 Wait for the system log message asking the user to reload the line card that was upgraded. But do not reload the line card at this time.

001860: Jun 15 19:05:05.904 PDT: NIOSXE-5-PLATFORM: CLCO: cdman: Suggest reload the line card for new FW to take effect using CLI: hw slot slot-id reload

Step 9 Perform ISSU.

request platform software package install node file harddisk:cbrsup-universalk9.17.06.01a.SPA.bin

Step 10 To monitor the ISSU progress, use the command below.

request platform software package install node attach

Step 11 Use these CLI to check status after ISSU.

```
show version r0 running show version r1 running show version r0 provisioned show version r1 provisioned
```

What to do next

Perform verification test to determine if the upgrade is successful, include:

- Verify the router is running the new IOS-XE release using **show version** command.
- Check facility alarms using **show facility-alarm status** command.
- Check the status of the power supplies using **show environment power** command.

- Check PS status using **show platform hardware slot P<0-5> mcu status** command.
- Complete trace routes to known good off-network IP address using the source address of customer CPE blocks to verify routing is working.
- Check logs for error messages using show log command.

These **show** commands may be useful in the verification test:

- · show redundancy
- show platform
- · show platform diag
- · show environment
- · show redundancy linecard all
- · show isis neighbors
- show ip ospf neighbor
- · show ip route rip
- show ip mroute
- show cops servers
- · show cable modem voice
- show cable calls
- · show cable metering verbose
- · show cable licenses all
- show inventory

Upgrading Supervisor CPLD Firmware

Before you begin



Note

If the supervisor SO CPLD version is lower than 1511_1401 (SUP 160) or 15111401 (SUP 250), or, if the supervisor SIO CPLD version is lower than 1511_1301 (SUP 160) or 15111301 (SUP 250), physically power cycle the chassis when upgrading the supervisor CPLD.

Before upgrading the firmware, make sure the following requirements are met:

- Cisco cBR-8 router is running with Cisco IOS XE Gibraltar 16.12.1w or later releases.
- 2 supervisors are running in the Cisco cBR-8 router and the redundancy is enabled.
- Download the file from the following Cisco.com Software Center URL:

https://software.cisco.com/download/home/286283913/type

- IOS XE Hardware Programmable Devices Version 17.6.1a: cbrsup-programmable_firmware.17.06.01a.SPA.pkg
- Console access for both supervisors are required.
- Copy the new firmware package to the cBR-8 using FTP.

```
copy ftp://<location>/cbrsup-programmable_firmware.17.06.01a.SPA.pkg harddisk:
copy ftp://<location>/cbrsup-programmable firmware.17.06.01a.SPA.pkg stby-harddisk:
```



Note

When upgrading SUP0, run the CLI with the R0 setting while controlling SUP0. And when upgrading SUP1, run the CLI with the R1 setting.



Note

This guide assumes SUP0 is in active state and SUP1 is in standby hot state at the beginning.

Perform step 1 to 4 using console connection of active SUP0:

Step 1 Set the config register.

```
configure terminal
config-register 0x2102
end
write memory
```

Step 2 Run the following command to prepare for R0 upgrade.

```
upgrade hw-programmable cable R0 viper pkg_name /harddisk/cbrsup-programmable firmware.17.06.01a.SPA.pkg
```

On SUP 250, you will see one of the following outputs:

 \bullet It takes 10~20 minutes to upgrade. Console would hung. Please don't do any operation during the upgrade.

```
You are upgrading Viper firmware using harddisk/cbrsup-programmable_firmware.17.06.01a.SPA.pkg image on SUPO, SUPO is active.
```

```
Upgrade from assigned pkg file harddisk/cbrsup-programmable_firmware.17.06.01a.SPA.pkg
Using viper firmware /tmp/viper/mount/supve_viper_fpga_psirt.bin
Size of Viper Upgrade image: 16777216 bytes
No.of parts: 65536
Upgrading golden image...
65536+0 records in
65536+0 records out
16777216 bytes (17 MB, 16 MiB) copied, 688.873 s, 24.4 kB/s
Upgrading primary image...
65536+0 records in
65536+0 records out
16777216 bytes (17 MB, 16 MiB) copied, 675.19 s, 24.8 kB/s
```

```
Viper upgrade clean up 0
Upgrade successfully. Please make sure Rommon version is matched.
Please power cycle the chassis to let the new firmware take effect
```

• It takes 10~20 minutes to upgrade. Console would hung. Please don't do any operation during the upgrade.

You are upgrading Viper firmware using harddisk/cbrsup-programmable_firmware.17.06.01a.SPA.pkg image on SUPO, SUPO is active.

Upgrade from assigned pkg file harddisk/cbrsup-programmable_firmware.17.06.01a.SPA.pkg The golden viper is not compatible with assigned firmware

/tmp/viper/mount/supve_viper_fpga_psirt.bin, no upgrade will be performed Viper upgrade clean up 2

Note This output means the SUP already has the latest version it can support, skip the rest of the steps.

On SUP 160, you will see one of the following outputs:

• It takes about 10 minutes to upgrade. Console would hung. Please don't do any operation during the upgrade.

You are upgrading Viper firmware using harddisk/cbrsup-programmable_firmware.17.06.01a.SPA.pkg image

Upgrade from assigned pkg file /harddisk/cbrsup-programmable_firmware.17.06.01a.SPA.pkg Using viper firmware /tmp/viper/mount/viper fpga.bin

Size of Viper Upgrade image: 16777216 bytes

No.of parts: 65536

65536+0 records in

65536+0 records out

Viper upgrade clean up 0

Upgrade successfully. Please make sure Rommon version is matched.

Please power cycle the chassis to let the new firmware take effect

 \bullet It takes 10~20 minutes to upgrade. Console would hung. Please don't do any operation during the upgrade.

You are upgrading Viper firmware using harddisk/cbrsup-programmable_firmware.17.06.01a.SPA.pkg image on SUPO, SUPO is active.

Upgrade from assigned pkg file harddisk/cbrsup-programmable_firmware.17.06.01a.SPA.pkg The golden viper is not compatible with assigned firmware /tmp/viper/mount/supve_viper_fpga_psirt.bin, no upgrade will be performed

Note This output means the SUP already has the latest version it can support, skip the rest of the steps.

Note Do not power cycle the chassis in this step.

Step 3 Run the following command to prepare for R1 upgrade.

Viper upgrade clean up 2

```
upgrade hw-programmable cable R1 viper pkg_name /harddisk/cbrsup-programmable_firmware.17.06.01a.SPA.pkg
```

You will see the similar output as the one in Step 2.

Note Do not power cycle the chassis in this step.

Step 4 If the supervisor ViperSO CPLD version is 15111401 and the supervisor ViperSIO CPLD version is 15111301 on both supervisors, follow step 5 - 11 to do the upgrade. Otherwise proceed to step 12.

```
Router#show platform diag
Load for five secs: 6%/1%; one minute: 7%; five minutes: 8%
Time source is NTP, 16:05:43.546 PST Thu Feb 8 2018
```

```
Chassis type: CBR-8-CCAP-CHASS
<SNTP>
Slot: SUPO, CBR-CCAP-SUP-160G
        Physical insert detect time: 00:01:58 (1d03h ago)
                                : 15111401
: 15111<sup>-</sup>
        CPLD version : 16052011
        ViperSO CPLD version
        ViperSIO CPLD version
                                     : 16.7(1r)S
        Rommon version
Blackbird version
                                    : 00000112
        Raptor ESI version
Raptor MAC version
                                   : 0001003b
        SUP-PIC CPLD version : 14071504
SUP-DC CPLD version : 14072207
        DTI Client FPGA version : 00000005
        DTI Firmware version
                                    : 00000A03
                                    : 201402061607
        Cortina PHY version
        SUP PSOC 0 version
                                    : v4.0.9
        SUP PSOC 1 version
SUP PSOC 2 version
SUP PSOC 3 version
                                     : v4.0.8
                                     : v4.1.0 IVB
                                     : v4.0.6
        SUP-DC PSOC 0 version : v4.0.8
        SUP-DC PSOC 1 version
                                    : v4.0.5
                                     : V2.0.6
        SUP-PIC PSOC 0 version
        SUP-PIC PSOC 1 version
                                     : V2.0.6
<SNIP>
Slot: SUP1, CBR-CCAP-SUP-160G
        Physical insert detect time : 00:02:26 (1d03h ago)
        version : 15111401 ViperSIO CPLD version : 15111301 Rommon version
        Rommon version
                                     : 16.7(1r)S
        Blackbird version
                                    : 00000112
        Raptor ESI version : 0001003b
Raptor MAC version : 00010031
SUP-PIC CPLD version : 14071504
SUP-DC CPLD version : 14072207
        Raptor ESI version
Raptor MAC version
        DTI Client FPGA version : 00000005
        DTI Firmware version
                                    : 00000A03
        Cortina PHY version
                                    : 201402061607
        SUP PSOC 0 version
                                     : v4.0.9
        SUP PSOC 1 version
                                     : v4.0.8
        SUP PSOC 2 version
SUP PSOC 3 version
                                     : v4.1.0_IVB
                                     : v4.0.6
        SUP-DC PSOC 0 version : v4.0.9
        SUP-DC PSOC 1 version
                                    : v4.0.5
        SUP-PIC PSOC 0 version
                                     : V3.0.0
        SUP-PIC PSOC 1 version
                                     : V3.0.0
<SNIP>
```

Step 5 Set SUP0 to ROMMON using the following command.

redundancy force-switchover

Perform the following steps 6 to 7 using console connection of current active SUP1.

Step 6 Power cycle the SUP0 to set it to ROMMON.

test platform hardware slot RO oir power-cycle

This command will reset and re-initialize the ROMMON. The new version of the supervisor CPLD will now take effect. Verify if it matches the following new version.

SUP 160 new version: 0x19071712

SUP 250 new version: 0x190717E1

Step 7 Boot SUP0 into IOS XE using SUP0 console connection.

dir harddisk:

boot harddisk:cbrsup-universalk9.17.06.01a.SPA.bin

Wait utill SUP0 is in standby hot.

Step 8 Set SUP1 to ROMMON using the following command.

redundancy force-switchover

Perform the following steps 9 to 11 using console connection of current active SUP0.

Step 9 Power cycle the SUP1 to set it to ROMMON.

test platform hardware slot R1 oir power-cycle

This command will reset and re-initialize the ROMMON. The new version of the supervisor CPLD will now take effect. Verify if it matches the following new version.

SUP 160 new version: 0x19071712 SUP 250 new version: 0x190717E1

Step 10 Boot SUP1 into IOS XE using SUP1 console connection.

dir harddisk: boot harddisk:cbrsup-universalk9.17.06.01a.SPA.bin

Wait utill SUP1 is in standby hot.

Step 11 Wait for the chassis to become SSO and settled down. Then go to step 16. If you skipped step 5 to 10, perform step 12 to 15.

Note You need physical access to the chassis to power cycle the chassis.

Step 12 Reload the system by issuing **reload** command on the active SUP.

Router#reload

Step 13 Power cycle both supervisors.

Step 14 Verify if the new version matches the following on both SUPs.

SUP 160 new version: 0x19071712 SUP 250 new version: 0x190717E1

Step 15 Boot both SUP0 and SUP1 into IOS XE using SUP0 and SUP1 console.

dir harddisk: boot harddisk:cbrsup-universalk9.17.06.01a.SPA.bin

Wait till SUP0 become standby hot.

Step 16 Once the system is up and running, perform the following checks.

Set config register to normal boot.

```
configure terminal
config-register 0x2102
end
write memory
```

- Execute **show redundancy** command to ensure both SUPs are listed, one is active and the other is standby hot.
- Execute show proc CPU sorted | ex 0.00 command.
- Execute show platform diag command.

Upgrading cBR CCAP 8x10G Remote PHY Digital Physical Interface Card

Before you begin

Before upgrading the system, make sure the following requirements are met:

- Make sure the latest available IOS XE version is active in Cisco cBR-8 router.
- There are at lease 20MB free space on the harddisk.



Note

To make use of the new features, it is recommended to upgrade the cBR CCAP 8x10G Remote PHY Digital Physical Interface Card (D-PIC) to the latest version 1.1.

- **Step 1** Boot up system, wait until IOS is ready.
- **Step 2** Check current D-PIC version.

```
show hw-module subslot x/1 fpd
```

Note x/1 is D-PIC subslot number which needs upgrade.

Example:

Router#show hw-module subslot 9/1 fpd

H/W Field Programmable Current Min. Required
Slot Card Type Ver. Device: "ID-Name" Version Version

9/1	CBR-DPIC-8X10G	1.0	46-CBR DIGI PIC	1.0	1.0
====		======			

Step 3 Upgrade D-PIC.

upgrade hw-module subslot x/1 fpd bundled reload

Example:

Router#upgrade hw-module subslot 9/1 fpd bundled reload

% The following FPD will be upgraded for CBR-DPIC-8X10G (H/W ver = 1.0) in subslot 9/1:

Field Programmable	Current	Upgrade	Estimated	
Device: "ID-Name"	Version	Version	Upgrade Time	
=======================================				
46-CBR DIGI PIC	1.0	1.1	00:05:00	

- % NOTES:
 - Use 'show upgrade fpd progress' command to view the progress of the FPD upgrade.
 - The target card will be automatically reloaded after the upgrade operation. This reload will interrupt normal operation of the card. If necessary, ensure that appropriate actions have been taken to redirect card traffic before starting the FPD upgrade.
- % Are you sure that you want to perform this operation? [no]: yes
- % Initiating the upgrade operation on the target card ...
 (Use "show upgrade fpd progress" command to see upgrade progress)

Step 4 Check if the upgrade process is finished. Upgrade progress will take about 1 to 2 minutes.

show upgrade fpd progress

Example:

Upgrade still ongoing:

Router#show upgrade fpd progress

FPD Image Upgrade Progress Table:

==== ===========	==========					
Slot Card Type	Field Programmable Device : "ID-Name"	Approx. Time Needed	Elapsed Time	State		
9/1 CBR-DPIC-8X10G	46-CBR DIGI PIC	00:05:00	00:00:13	Updating		
sj-104-cbr-13#show upgrade fpd progress FPD Image Upgrade Progress Table:						
Slot Card Type	Field Programmable Device: "ID-Name"	Approx. Time Needed	Elapsed Time	State		

9/1 CBR-DPIC-8X10G 46-CBR DIGI PIC 00:05:00 00:00:26 Updating...

Upgrade finished:

Router#show upgrade fpd progress

% There is no FPD image upgrade in progress.

Step 5 Check if the D-PIC status is ready.

show platform

Example:

Router#show platform

Chassis type: CBR-8-CCAP-CHASS

Slot	Туре	State	Insert time (ago)
2/1	CBR-RF-PROT-PIC	ok	00:08:48
3	CBR-CCAP-LC-40G		00:12:46
3/1	CBR-RF-PIC	ok	00:08:48
8/1	CBR-DPIC-8X10G	ok	00:07:56
9	CBR-CCAP-LC-40G	ok	00:12:46
9/1	CBR-DPIC-8X10G	ok	00:07:54
SUP0	CBR-CCAP-SUP-160G	inserted	00:12:46
R0		ok, active	
F0		ok, active	
4		ok, active	
4/1	CBR-SUP-8X10G-PIC	ok	00:07:55
SUP1	CBR-CCAP-SUP-160G	inserted	00:12:22
R1		ok, standby	
F1		ok, standby	
5		ok, standby	
5/1	CBR-SUP-8X10G-PIC	ok	00:07:54
P0	PWR-3KW-AC-V2	ok	00:09:49
P1	PWR-3KW-AC-V2	ok	00:09:49
P2	PWR-3KW-AC-V2	ps, fail	00:09:49
P3	Unknown	N/A	never
P4		N/A	never
P5	PWR-3KW-AC-V2	ok	00:09:49
P10	CBR-FAN-ASSEMBLY	ok	00:09:39
	CBR-FAN-ASSEMBLY		00:09:39
P12	CBR-FAN-ASSEMBLY	ok	00:09:39
	CBR-FAN-ASSEMBLY		00:09:39
P14	CBR-FAN-ASSEMBLY	ok	00:09:39
Slot	CPLD Version	Rommon Version	
3	00000025	2011.03.18	
9	00000025	2011.03.18	
SUP0	16052011	16.7(3r)S	
SUP1	16052011	16.7(3r)S	

Step 6 Check if the new version works.

show hw-module subslot x/1 fpd

Example:

Router#show hw-module subslot 9/1 fpd

====					
		H/W	Field Programmable	Current	Min. Required
Slot	Card Type	Ver.	Device: "ID-Name"	Version	Version

====					=========
9/1	CBR-DPIC-8X10G	1.0	46-CBR DIGI PIC	1.1	1.0
====		=====			