

## DHCP—DHCPv6 Guard

This module describes the Dynamic Host Configuration Protocol version 6 (DHCPv6) Guard feature. This feature blocks DHCP reply and advertisement messages that originate from unauthorized DHCP servers and relay agents that forward DHCP packets from servers to clients. Client messages or messages sent by relay agents from clients to servers are not blocked. The filtering decision is determined by the device role assigned to the receiving switch port, trunk, or VLAN. In addition, to provide a finer level of filter granularity, messages can be filtered based on the address of the sending server or relay agent, or by the prefixes and addresses ranges listed in the reply message. This functionality helps to prevent traffic redirection or denial of service (DoS).

- Finding Feature Information, page 1
- Restrictions for DHCPv6 Guard, page 1
- Information About DHCPv6 Guard, page 2
- How to Configure DHCPv6 Guard, page 3
- Configuration Examples for DHCPv6 Guard, page 6
- Additional References, page 7
- Feature Information for DHCP—DHCPv6 Guard, page 8

## **Finding Feature Information**

Your software release may not support all the features documented in this module. For the latest caveats and feature information, see Bug Search Tool and the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the feature information table at the end of this module.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to <a href="https://www.cisco.com/go/cfn">www.cisco.com/go/cfn</a>. An account on Cisco.com is not required.

### **Restrictions for DHCPv6 Guard**

• The DHCPv6 guard feature is not supported on Etherchannel ports.

## **Information About DHCPv6 Guard**

### **DHCPv6 Guard Overview**

The DHCPv6 Guard feature blocks reply and advertisement messages that come from unauthorized DHCP servers and relay agents.

Packets are classified into one of the three DHCP type messages. All client messages are always switched regardless of device role. DHCP server messages are only processed further if the device role is set to server. Further processing of server messages includes DHCP server advertisements (for source validation and server preference) and DHCP server replies (for permitted prefixes).

If the device is configured as a DHCP server, all the messages need to be switched, regardless of the device role configuration.

## **How to Configure DHCPv6 Guard**

## Configuring DHCP—DHCPv6 Guard

### **SUMMARY STEPS**

- 1. enable
- 2. configure terminal
- 3. ipv6 access-list access-list-name
- 4. permit host address any
- 5. exit
- 6. ipv6 prefix-list list-name permit ipv6-prefix 128
- 7. ipv6 dhcp guard policy policy-name
- 8. device-role {client | server}
- 9. match server access-list ipv6-access-list-name
- 10. match reply prefix-list ipv6-prefix-list-name
- **11. preference min** *limit*
- 12. preference max limit
- 13. trusted-port
- **14.** exit
- **15**. **interface** *type number*
- 16. switchport
- 17. ipv6 dhcp guard [attach-policy policy-name] [vlan {add | all | all | except | none | remove} vlan-id][ ... vlan-id]]
- **18.** exit
- 19. vlan vlan-id
- 20. ipv6 dhcp guard [attach-policy policy-name]
- **21**. exit
- **22**. exit
- 23. show ipv6 dhcp guard policy [policy-name]

### **DETAILED STEPS**

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Device> enable	

	Command or Action	Purpose	
Step 2	configure terminal	Enters global configuration mode.	
	Example:		
	Device# configure terminal		
Step 3	ipv6 access-list access-list-name	Defines the IPv6 access list and enters IPv6 access list configuration mode.	
	Example:	_	
	Device(config)# ipv6 access-list acl1		
Step 4	permit host address any	Sets the conditions in the named IP access list.	
	Example:		
	Device(config-ipv6-acl)# permit host FE80::A8BB:CCFF:FE01:F700 any		
Step 5	exit	Exits IPv6 access list configuration mode and returns to global configuration mode.	
	Example:		
	Device(config-ipv6-acl)# exit		
Step 6	ipv6 prefix-list list-name permit ipv6-prefix 128	Creates an entry in an IPv6 prefix list.	
	Example:		
	Device(config)# ipv6 prefix-list abc permit 2001:0DB8::/64 le 128		
Step 7	ipv6 dhcp guard policy policy-name	Defines the DHCPv6 guard policy name and enters DHCP guard configuration mode.	
	Example:	guard configuration mode.	
	Device(config)# ipv6 dhcp guard policy pol1		
Step 8	device-role {client   server}	Specifies the device role of the device attached to the target (interface or VLAN).	
	Example:		
	Device(config-dhcp-guard)# device-role server		
Step 9	match server access-list ipv6-access-list-name	(Optional) Enables verification of the advertised DHCP servand relay address in inspected messages from the configure	
	Example:	authorized server access list. If not configured, this check be bypassed. An empty access list is treated as a permit.	
	Device(config-dhcp-guard)# match server access-list acl1	oc bypassed. An empty access list is treated as a permit.	

	Command or Action	Purpose
Step 10	match reply prefix-list ipv6-prefix-list-name	(Optional) Enables verification of the advertised prefixes in DHCP reply messages from the configured authorized prefix
	Example:	list. If not configured, this check will be bypassed. An empty prefix list is treated as a permit.
	<pre>Device(config-dhcp-guard)# match reply prefix-list abc</pre>	
Step 11	preference min limit	(Optional) Enables verification that the advertised preference (in preference option) is greater than the specified limit. If no
	Example:	specified, this check will be bypassed.
	Device(config-dhcp-guard)# preference min 0	
Step 12	preference max limit	(Optional) Enables verification that the advertised preference (in preference option) is less than the specified limit. If not
	Example:	specified, this check will be bypassed.
	Device(config-dhcp-guard)# preference max 255	
Step 13	trusted-port	(Optional) Specifies that this policy is being applied to trusted ports. All DHCP guard policing will be disabled.
	Example:	potential state game perions will be uncured.
	Device(config-dhcp-guard)# trusted-port	
Step 14	exit	Exits DHCP guard configuration mode and returns to global configuration mode.
	Example:	
	Device(config-dhcp-guard)# exit	
Step 15	interface type number	Specifies an interface and enters interface configuration mode.
	Example:	
	Device(config)# interface GigabitEthernet 0/2/0	
Step 16	switchport	Puts an interface that is in Layer 3 mode into Layer 2 mode for Layer 2 configuration.
	Example:	
	Device(config-if)# switchport	
Step 17	ipv6 dhcp guard [attach-policy policy-name] [vlan {add   all   all   except   none   remove} vlan-id][ vlan-id]]	Attaches a DHCPv6 guard policy to an interface. The attach-policy and vlan keywords are optional in the interface command. If no VLAN number is specified, traffic from all VLANs on the port will be checked.
	Example:	
	Device(config-if)# ipv6 dhcp guard attach-policy pol1 vlan add vlan1	

	Command or Action	Purpose
Step 18	exit	Exits interface configuration mode and returns to global configuration mode.
	Example:	
	Device(config-if)# exit	
Step 19	vlan vlan-id	Specifies a VLAN and enters VLAN configuration mode.
	Example:	
	Device(config)# vlan 1	
Step 20	ipv6 dhcp guard [attach-policy policy-name]	Attaches a DHCPv6 guard policy to a VLAN.
	Example:	
	Device(config-vlan)# ipv6 dhcp guard attach-policy pol1	
Step 21	exit	Exits interface configuration mode and returns to global configuration mode.
	Example:	
	Device(config-vlan)# exit	
Step 22	exit	Exits global configuration mode and returns to privileged EXEC mode.
	Example:	
	Device(config)# exit	
Step 23	show ipv6 dhcp guard policy [policy-name]	(Optional) Displays the policy configuration as well as all the interfaces where the policy is applied.
	Example:	
	Device# show ipv6 dhcp policy guard pol1	

# **Configuration Examples for DHCPv6 Guard**

## **Example: Configuring DHCP—DHCPv6 Guard**

The following example displays a sample configuration for DHCPv6 Guard:

enable
configure terminal
ipv6 access-list acl1
 permit host FE80::A8BB:CCFF:FE01:F700 any

```
ipv6 prefix-list abc permit 2001:0DB8::/64 le 128
ipv6 dhcp guard policy pol1
device-role server
match server access-list acl1
match reply prefix-list abc
preference min 0
preference max 255
trusted-port
interface GigabitEthernet 0/2/0
switchport
ipv6 dhcp guard attach-policy pol1 vlan add 1
vlan 1
ipv6 dhcp guard attach-policy pol1
show ipv6 dhcp guard policy pol1
```

## **Additional References**

#### **Related Documents**

Related Topic	Document Title	
Cisco IOS commands	Cisco IOS Master Commands List, All Releases	
DHCP commands: complete command syntax, command modes, command history, defaults, usage guidelines, and examples	Cisco IOS IP Addressing Services Command Reference	
DHCP conceptual and configuration information	Cisco IOS IP Addressing Services Configuration Guide	

### Standards/RFCs

Standard	Title
No new or modified standards/RFCs are supported by this feature.	_

### **MIBs**

MIB	MIBs Link
No new or modified MIBs are supported by this feature.	To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL:  http://www.cisco.com/go/mibs

#### **Technical Assistance**

Description	Link
The Cisco Support and Documentation website provides online resources to download documentation, software, and tools. Use these resources to install and configure the software and to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password.	

## Feature Information for DHCP—DHCPv6 Guard

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to <a href="https://www.cisco.com/go/cfn">www.cisco.com/go/cfn</a>. An account on Cisco.com is not required.

Table 1: Feature Information for DHCP—DHCPv6 Guard

Feature Name	Releases	Feature Information
DHCP—DHCPv6 Guard	15.2(4)S 15.0(2)SE 15.1(2)SG Cisco IOS XE Release 3.8S Cisco IOS XE Release 3.2SE	The DHCP—DHCPv6 Guard feature blocks DHCP reply and advertisement messages that originate from unauthorized DHCP servers and relay agents that forward DHCP packets from servers to clients. Client messages or messages sent by relay agents from clients to servers are not blocked.  The following commands were introduced or modified:  device-role, ipv6 dhcp guard attach-policy (DHCPv6 Guard),
		ipv6 dhcp guard policy, match reply prefix-list, match server access-list, preference (DHCPv6 Guard), show ipv6 dhcp guard policy, trusted-port (DHCPv6 Guard).