

Configuring the Cisco Discovery Protocol

Cisco Discovery Protocol is a Layer 2, media-independent, and network-independent protocol that runs on Cisco devices and enables networking applications to learn about directly connected devices nearby. This protocol facilitates the management of Cisco devices by discovering these devices, determining how they are configured, and allowing systems using different network-layer protocols to learn about each other.

This module describes Cisco Discovery Protocol Version 2 and how it functions with SNMP.

- Finding Feature Information, on page 1
- Information About CDP, on page 1
- How to Configure CDP, on page 2
- Monitoring and Maintaining Cisco Discovery Protocol, on page 10
- Additional References, on page 11
- Feature History and Information for Cisco Discovery Protocol, on page 12

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest caveats and feature information, see Bug Search Tool and the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the feature information table at the end of this module.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to https://cfnng.cisco.com/. An account on Cisco.com is not required.

Information About CDP

Cisco Discovery Protocol Overview

Cisco Discovery Protocol is a device discovery protocol that runs over Layer 2 (the data-link layer) on all Cisco-manufactured devices (routers, bridges, access servers, controllers, and switches) and allows network management applications to discover Cisco devices that are neighbors of already known devices. With Cisco Discovery Protocol, network management applications can learn the device type and the SNMP agent address of neighboring devices running lower-layer, transparent protocols. This feature enables applications to send SNMP queries to neighboring devices.

Cisco Discovery Protocol runs on all media that support Subnetwork Access Protocol (SNAP). Because Cisco Discovery Protocol runs over the data-link layer only, two systems that support different network-layer protocols can learn about each other.

Each Cisco Discovery Protocol-configured device sends periodic messages to a multicast address, advertising at least one address at which it can receive SNMP messages. The advertisements also contain time-to-live, or holdtime information, which is the length of time a receiving device holds Cisco Discovery Protocol information before discarding it. Each device also listens to the messages sent by other devices to learn about neighboring devices.

On the device, Cisco Discovery Protocol enables Network Assistant to display a graphical view of the network. The device uses Cisco Discovery Protocol to find cluster candidates and maintain information about cluster members and other devices up to three cluster-enabled devices away from the command device by default.

- Cisco Discovery Protocol identifies connected endpoints that communicate directly with the device.
- To prevent duplicate reports of neighboring devices, only one wired device reports the location information.
- The wired device and the endpoints both send and receive location information.

Related Topics

Configuring Cisco Discovery Protocol Characteristics, on page 2 Monitoring and Maintaining Cisco Discovery Protocol, on page 10

Default Cisco Discovery Protocol Configuration

This table shows the default Cisco Discovery Protocol configuration.

Feature	Default Setting
Cisco Discovery Protocol global state	Enabled
Cisco Discovery Protocol interface state	Enabled
Cisco Discovery Protocol timer (packet update frequency)	60 seconds
Cisco Discovery Protocol holdtime (before discarding)	180 seconds
Cisco Discovery Protocol Version-2 advertisements	Enabled

Related Topics

Enabling Cisco Discovery Protocol, on page 6

Disabling Cisco Discovery Protocol, on page 4

Enabling Cisco Discovery Protocol on an Interface, on page 9

Disabling Cisco Discovery Protocol on an Interface, on page 7

How to Configure CDP

Configuring Cisco Discovery Protocol Characteristics

You can configure these Cisco Discovery Protocol characteristics:

- Frequency of Cisco Discovery Protocol updates
- Amount of time to hold the information before discarding it
- Whether or not to send Version 2 advertisements



Note

Steps 3 through 5 are all optional and can be performed in any order.

Follow these steps to configure the Cisco Discovery Protocol characteristics.

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- 3. cdp timer seconds
- 4. cdp holdtime seconds
- 5. cdp advertise-v2
- 6. end
- 7. show running-config
- 8. copy running-config startup-config

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Device> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 3	cdp timer seconds	(Optional) Sets the transmission frequency of Cisco
	Example:	Discovery Protocol updates in seconds.
	·	The range is 5 to 254; the default is 60 seconds.
	Device(config)# cdp timer 20	
Step 4	cdp holdtime seconds	(Optional) Specifies the amount of time a receiving device
	Example:	should hold the information sent by your device before discarding it.
	Device(config)# cdp holdtime 60	The range is 10 to 255 seconds; the default is 180 seconds.

	Command or Action	Purpose
Step 5	cdp advertise-v2	(Optional) Configures Cisco Discovery Protocol to send
	Example:	Version 2 advertisements.
		This is the default state.
	Device(config)# cdp advertise-v2	
Step 6	end	Returns to privileged EXEC mode.
	Example:	
	Device(config)# end	
Step 7	show running-config	Verifies your entries.
	Example:	
	Device# show running-config	
Step 8	copy running-config startup-config	(Optional) Saves your entries in the configuration file.
	Example:	
	Device# copy running-config startup-config	

What to do next

Use the **no** form of the Cisco Discovery Protocol commands to return to the default settings.

Related Topics

Cisco Discovery Protocol Overview, on page 1 Monitoring and Maintaining Cisco Discovery Protocol, on page 10

Disabling Cisco Discovery Protocol

Cisco Discovery Protocol is enabled by default.



Note

Device clusters and other Cisco devices (such as Cisco IP Phones) regularly exchange Cisco Discovery Protocol messages. Disabling Cisco Discovery Protocol can interrupt cluster discovery and device connectivity.

Follow these steps to disable the Cisco Discovery Protocol device discovery capability.

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- 3. no cdp run
- 4. end

- 5. show running-config
- 6. copy running-config startup-config

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Device> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 3	no cdp run	Disables Cisco Discovery Protocol.
	Example:	
	Device(config)# no cdp run	
Step 4	end	Returns to privileged EXEC mode.
	Example:	
	Device(config)# end	
Step 5	show running-config	Verifies your entries.
	Example:	
	Device# show running-config	
Step 6	copy running-config startup-config	(Optional) Saves your entries in the configuration file.
	Example:	
	Device# copy running-config startup-config	

What to do next

You must reenable Cisco Discovery Protocol to use it.

Related Topics

Enabling Cisco Discovery Protocol, on page 6 Default Cisco Discovery Protocol Configuration, on page 2

Enabling Cisco Discovery Protocol

Cisco Discovery Protocol is enabled by default.



Note

Device clusters and other Cisco devices (such as Cisco IP Phones) regularly exchange Cisco Discovery Protocol messages. Disabling Cisco Discovery Protocol can interrupt cluster discovery and device connectivity.

Follow these steps to enable Cisco Discovery Protocol when it has been disabled.

Before you begin

Cisco Discovery Protocol must be disabled, or it cannot be enabled.

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- 3. cdp run
- 4. end
- 5. show running-config
- 6. copy running-config startup-config

DETAILED STEPS

1.1-	
enable	Enables privileged EXEC mode.
Example:	• Enter your password if prompted.
Device> enable	
configure terminal	Enters global configuration mode.
Example:	
Device# configure terminal	
cdp run	Enables Cisco Discovery Protocol if it has been disabled.
Example:	
Device(config)# cdp run	
end	Returns to privileged EXEC mode.
Example:	
Device(config)# end	
	configure terminal Example: Device# configure terminal cdp run Example: Device(config)# cdp run end Example:

	Command or Action	Purpose
Step 5	show running-config	Verifies your entries.
	Example:	
	Device# show running-config	
Step 6	copy running-config startup-config	(Optional) Saves your entries in the configuration file.
	Example:	
	Device# copy running-config startup-config	

What to do next

Use the **show run all** command to show that Cisco Discovery Protocol has been enabled. If you enter only **show run**, the enabling of Cisco Discovery Protocol may not be displayed.

Related Topics

Default Cisco Discovery Protocol Configuration, on page 2 Disabling Cisco Discovery Protocol, on page 4

Disabling Cisco Discovery Protocol on an Interface

Cisco Discovery Protocol is enabled by default on all supported interfaces to send and to receive Cisco Discovery Protocol information.



Note

Device clusters and other Cisco devices (such as Cisco IP Phones) regularly exchange Cisco Discovery Protocol messages. Disabling Cisco Discovery Protocol can interrupt cluster discovery and device connectivity.



Note

Cisco Discovery Protocol bypass is not supported and may cause a port go into err-disabled state.

Follow these steps to disable Cisco Discovery Protocol on a port.

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- 3. interface interface-id
- 4. no cdp enable
- **5**. end
- 6. show running-config
- 7. copy running-config startup-config

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Device> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 3	interface interface-id	Specifies the interface on which you are disabling Cisco
	Example:	Discovery Protocol, and enters interface configuration mode.
	Device(config)# interface gigabitethernet 0/1	
Step 4	no cdp enable	Disables Cisco Discovery Protocol on the interface specified
	Example:	in Step 3.
	Device(config-if)# no cdp enable	
Step 5	end	Returns to privileged EXEC mode.
	Example:	
	Device(config)# end	
Step 6	show running-config	Verifies your entries.
	Example:	
	Device# show running-config	
Step 7	copy running-config startup-config	(Optional) Saves your entries in the configuration file.
	Example:	
	Device# copy running-config startup-config	

Related Topics

Enabling Cisco Discovery Protocol on an Interface, on page 9 Default Cisco Discovery Protocol Configuration, on page 2

Enabling Cisco Discovery Protocol on an Interface

Cisco Discovery Protocol is enabled by default on all supported interfaces to send and to receive Cisco Discovery Protocol information.



Note

Device clusters and other Cisco devices (such as Cisco IP Phones) regularly exchange Cisco Discovery Protocol messages. Disabling Cisco Discovery Protocol can interrupt cluster discovery and device connectivity.



Note

Cisco Discovery Protocol bypass is not supported and may cause a port go into err-disabled state.

Follow these steps to enable Cisco Discovery Protocol on a port on which it has been disabled.

Before you begin

Cisco Discovery Protocol must be disabled on the port that you are trying to Cisco Discovery Protocol enable on, or it cannot be enabled.

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- 3. interface interface-id
- 4. cdp enable
- **5**. end
- 6. show running-config
- 7. copy running-config startup-config

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Device> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 3	interface interface-id	Specifies the interface on which you are enabling Cisco Discovery Protocol, and enters interface configuration mode
	Example: Device(config)# interface gigabitethernet0/1	2 second 1 received, and emote interface configuration mode

	Command or Action	Purpose
Step 4	cdp enable	Enables Cisco Discovery Protocol on a disabled interface.
	Example:	
	Device(config-if)# cdp enable	
Step 5	end	Returns to privileged EXEC mode.
	Example:	
	Device(config)# end	
Step 6	show running-config	Verifies your entries.
	Example:	
	Device# show running-config	
Step 7	copy running-config startup-config	(Optional) Saves your entries in the configuration file.
	Example:	
	Device# copy running-config startup-config	

Related Topics

Default Cisco Discovery Protocol Configuration, on page 2 Disabling Cisco Discovery Protocol on an Interface, on page 7

Monitoring and Maintaining Cisco Discovery Protocol

Table 1: Commands for Displaying Cisco Discovery Protocol Information

Command	Description
clear cdp counters	Resets the traffic counters to zero.
clear cdp table	Deletes the Cisco Discovery Protocol table of information about nei
show cdp	Displays global information, such as frequency of transmissions and th for packets being sent.
show cdp entry entry-name [version] [protocol]	Displays information about a specific neighbor. You can enter an asterisk (*) to display all Cisco Discovery Protocol or you can enter the name of the neighbor about which you want information also limit the display to information about the protocols enable specified neighbor or information about the version of software runn device.

Command	Description
show cdp interface [interface-id]	Displays information about interfaces where Cisco Discovery Proto
	You can limit the display to the interface about which you want i
show cdp neighbors [interface-id] [detail]	Displays information about neighbors, including device type, inte number, holdtime settings, capabilities, platform, and port ID.
	You can limit the display to neighbors of a specific interface or edisplay to provide more detailed information.
show cdp traffic	Displays Cisco Discovery Protocol counters, including the numb sent and received and checksum errors.

Related Topics

Configuring Cisco Discovery Protocol Characteristics, on page 2 Cisco Discovery Protocol Overview, on page 1

Additional References

Related Documents

Related Topic	Document Title
System Management Commands	Network Management Command Reference, Cisco IOS Release 15.2(2)E

Error Message Decoder

Description	Link
To help you research and resolve system error messages in this release, use the Error Message Decoder tool.	https://www.cisco.com/cgi-bin/Support/Errordecoder/index.cgi

Standards and RFCs

Standard/RFC	Title
None	-

MIBs

MIB	MIBs Link	
All supported MIBs for this release.	To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL:	
	http://www.cisco.com/go/mibs	

Technical Assistance

Description	Link
The Cisco Support website provides extensive online resources, including documentation and tools for troubleshooting and resolving technical issues with Cisco products and technologies.	http://www.cisco.com/support
To receive security and technical information about your products, you can subscribe to various services, such as the Product Alert Tool (accessed from Field Notices), the Cisco Technical Services Newsletter, and Really Simple Syndication (RSS) Feeds.	
Access to most tools on the Cisco Support website requires a Cisco.com user ID and password.	

Feature History and Information for Cisco Discovery Protocol

Release	Modification
Cisco IOS 15.0(2)EX	This feature was introduced.