



Cisco IOS Firewall—SIP Enhancements: ALG and AIC

First Published: April 14, 2008
Last Updated: March 31, 2010

Enhanced Session Initiation Protocol (SIP) inspection in the Cisco IOS firewall provides basic SIP inspect functionality (SIP packet inspection and pinholes opening) as well as protocol conformance and application security. These enhancements give you more control than in previous releases on what policies and security checks to apply to SIP traffic and the capability to filter out unwanted messages or users.

The development of additional SIP functionality in Cisco IOS software provides increased support for Cisco Call Manager (CCM), Cisco Call Manager Express (CCME), and Cisco IP-IP Gateway based voice/video systems. Application Layer Gateway (ALG), and Application Inspection and Control (AIC) SIP enhancements also support RFC 3261 and its extensions.

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest feature information and caveats, see the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the [“Feature Information for Cisco IOS Firewall—SIP Enhancements: ALG and AIC” section on page 21](#).

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to <http://www.cisco.com/go/cfn>. An account on Cisco.com is not required.

Contents

- [Prerequisites for Cisco IOS Firewall—SIP Enhancements: ALG and AIC, page 2](#)
- [Restrictions for Cisco IOS Firewall—SIP Enhancements: ALG and AIC, page 2](#)
- [Information About Cisco IOS Firewall—SIP Enhancements: ALG and AIC, page 3](#)



Americas Headquarters:
Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

- [How to Configure Cisco IOS Firewall—SIP Enhancements: ALG and AIC, page 4](#)
- [Configuration Examples for Cisco IOS Firewall—SIP Enhancements: ALG and AIC, page 18](#)
- [Additional References, page 19](#)
- [Feature Information for Cisco IOS Firewall—SIP Enhancements: ALG and AIC, page 21](#)

Prerequisites for Cisco IOS Firewall—SIP Enhancements: ALG and AIC

The following prerequisites apply to the configuration of Cisco IOS Firewall—SIP Enhancements: ALG and AIC.

Hardware Requirements

- One of the following router platforms:
 - Cisco 861, Cisco 881, or Cisco 881G routers
 - Cisco 1700 routers
 - Cisco 1800 routers
 - Cisco 2600 routers
 - Cisco 2800 routers
 - Cisco 3700 routers
 - Cisco 3800 routers
 - Cisco 7200 routers
 - Cisco 7300 routers

Software Requirements

- Cisco IOS Release 12.4(15)XZ or a later release.

Restrictions for Cisco IOS Firewall—SIP Enhancements: ALG and AIC

DNS Name Resolution

Although SIP methods can have Domain Name System (DNS) names instead of raw IP addresses, this feature currently does not support DNS names.

Earlier Releases of Cisco IOS Software

Some Cisco IOS releases earlier than Release 12.4(15)XZ may accept the configuration commands for SIP that are shown in this document; however, those earlier versions will not function properly.

Information About Cisco IOS Firewall—SIP Enhancements: ALG and AIC

- [Firewall and SIP Overviews, page 3](#)
- [Firewall for SIP Functionality Description, page 3](#)
- [SIP Inspection, page 4](#)

Firewall and SIP Overviews

This section provides an overview of the Cisco IOS firewall and SIP.

Cisco IOS Firewall

The Cisco IOS firewall extends the concept of static access control lists (ACLs) by introducing dynamic ACL entries that open on the basis of the necessary application ports on a specific application and close these ports at the end of the application session. The Cisco IOS firewall achieves this functionality by inspecting the application data, checking for conformance of the application protocol, extracting the relevant port information to create the dynamic ACL entries, and closing these ports at the end of the session. The Cisco IOS firewall is designed to easily allow a new application inspection whenever support is needed.

Session Initiation Protocol

SIP is an application-layer control (signaling) protocol for creating, modifying, and terminating sessions with one or more participants. These sessions could include Internet telephone calls, multimedia distribution, and multimedia conferences. SIP is based on an HTTP-like request/response transaction model. Each transaction consists of a request that invokes a particular method or function on the server and at least one response.

SIP invitations used to create sessions carry session descriptions that allow participants to agree on a set of compatible media types. SIP makes use of elements called proxy servers to help route requests to the user's current location, authenticate and authorize users for services, implement provider call-routing policies, and provide features to users. SIP also provides a registration function that allows users to upload their current locations for use by proxy servers. SIP runs on top of several different transport protocols.

Firewall for SIP Functionality Description

The Firewall for SIP Support feature allows SIP signaling requests to traverse directly between gateways or through a series of proxies to the destination gateway or phone. After the initial request, if the Record-Route header field is not used, subsequent requests can traverse directly to the destination gateway address as specified in the Contact header field. Thus, the Cisco IOS firewall is aware of all surrounding proxies and gateways and allows the following functionality:

- SIP signaling responses can travel the same path as SIP signaling requests.
- Subsequent signaling requests can travel directly to the endpoint (destination gateway).
- Media endpoints can exchange data between each other.

SIP UDP and TCP Support

RFC 3261 is the current RFC for SIP, which replaces RFC 2543. This feature supports the SIP User Datagram Protocol (UDP) and the TCP format for signaling.

SIP Inspection

This section describes the deployment scenarios supported by the Cisco IOS Firewall—SIP, ALG, and AIC Enhancements feature.

Cisco IOS Firewall Between SIP Phones and CCM

The Cisco IOS firewall is located between CCM or CCME and SIP phones. SIP phones are registered to CCM or CCME through the firewall, and any SIP calls from or to the SIP phones pass through the firewall.

Cisco IOS Firewall Between SIP Gateways

The Cisco IOS firewall is located between two SIP gateways, which can be CCM, CCME, or a SIP proxy. Phones are registered with SIP gateways directly. The firewall sees the SIP session or traffic only when there is a SIP call between phones registered to different SIP gateways. In some scenarios an IP-IP gateway can also be configured on the same device as the firewall. With this scenario all the calls between the SIP gateways are terminated in the IP-IP gateway.

Cisco IOS Firewall with Local CCME and Remote CCME/CCCM

The Cisco IOS firewall is located between two SIP gateways, which can be CCM, CCME, or a SIP proxy. One of the gateways is configured on the same device as the firewall. All the phones registered to this gateway are locally inspected by the firewall. The firewall also inspects SIP sessions between the two gateways when there is a SIP call between them. With this scenario the firewall locally inspects SIP phones on one side and SIP gateways on the other side.

Cisco IOS Firewall with Local CCME

The Cisco IOS firewall and CCME is configured on the same device. All the phones registered to the CCME are locally inspected by the firewall. Any SIP call between any of the phones registered will also be inspected by the Cisco IOS firewall.

How to Configure Cisco IOS Firewall—SIP Enhancements: ALG and AIC

- [Configuring a Policy to Allow RFC 3261 Methods, page 4](#)
- [Configuring a Policy to Block Messages, page 7](#)
- [Configuring a 403 Response Alarm, page 9](#)
- [Limiting Application Messages, page 11](#)
- [Limiting Application Messages for a Particular Proxy, page 14](#)

Configuring a Policy to Allow RFC 3261 Methods

Perform this task to configure a policy to allow basic RFC 3261 methods and block extension methods.

**Note**

The Cisco IOS Firewall—SIP Enhancements: ALG and AIC feature provides essential support for the new SIP methods such as UPDATE and PRACK, as CCM 5.x and CCME 4.x also use these methods.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **class-map type inspect** *protocol-name* **match-any** *class-map-name*
4. **match request method** *method-name*
5. **exit**
6. **class-map type inspect** *protocol-name* **match-any** *class-map-name*
7. **match request method** *method-name*
8. **exit**
9. **policy-map type inspect** *protocol-name* *policy-map-name*
10. **class type inspect** *protocol-name* *class-map-name*
11. **allow**
12. **exit**
13. **class type inspect** *protocol-name* *class-map-name*
14. **reset**
15. **exit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	class-map type inspect <i>protocol-name</i> match-any <i>class-map-name</i> Example: Router(config)# class-map type inspect sip match-any sip-class1	Creates an inspect type class map and enters class-map configuration mode.
Step 4	match request method <i>method-name</i> Example: Router(config-cmap)# match request method invite	Matches RFC 3261 methods. Methods include the following: <ul style="list-style-type: none"> • ack, bye, cancel, info, invite, message, notify, options, prack, refer, register, subscribe, update.

	Command or Action	Purpose
Step 5	exit Example: Router(config-cmap)# exit	Exits class-map configuration mode.
Step 6	class-map type inspect protocol-name match-any class-map-name Example: Router(config)# class-map type inspect sip match-any sip-class2	Creates an inspect type class map and enters class-map configuration mode.
Step 7	match request method method-name Example: Router(config-cmap)# match request method message	Matches RFC 3261 methods, which include the following: <ul style="list-style-type: none"> ack, bye, cancel, info, invite, message, notify, options, prack, refer, register, subscribe, update.
Step 8	exit Example: Router(config-cmap)# exit	Exits class-map configuration mode.
Step 9	policy-map type inspect protocol-name policy-map-name Example: Router(config)# policy-map type inspect sip sip-policy	Creates an inspect type policy map and enters policy-map configuration mode.
Step 10	class type inspect protocol-name class-map-name Example: Router(config-pmap)# class type inspect sip sip_class1	Specifies the class on which the action is performed and enters policy-map class configuration mode.
Step 11	allow Example: Router(config-pmap-c)# allow	Allows SIP inspection.
Step 12	exit Example: Router(config-pmap-c)# exit	Exits policy-map class configuration mode.
Step 13	class type inspect protocol-name class-map-name Example: Router(config-pmap)# class type inspect sip sip-class2	Specifies the class on which the action is performed and enters policy-map class configuration mode.

	Command or Action	Purpose
Step 14	reset Example: Router(config-pmap-c)# reset	Resets the class map.
Step 15	exit Example: Router(config-pmap-c)# exit	Exits policy-map class configuration mode.

Configuring a Policy to Block Messages

Perform this task to configure a policy to block SIP messages coming from a particular proxy device.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **parameter-map type regex** *parameter-map-name*
4. **pattern** *url-pattern*
5. **exit**
6. **class-map type inspect** *protocol-name class-map-name*
7. **match request header** *field* **regex** *regex-parameter-map*
8. **exit**
9. **policy-map type inspect** *protocol-name policy-map-name*
10. **class type inspect** *protocol-name class-map-name*
11. **reset**
12. **exit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.

	Command or Action	Purpose
Step 3	parameter-map type regex <i>parameter-map-name</i> Example: Router(config)# parameter-map type regex unsecure-proxy	Configures a parameter-map type to match a specific traffic pattern and enters profile configuration mode.
Step 4	pattern <i>url-pattern</i> Example: Router(config-profile)# pattern "compromised.server.com"	Matches a call based on the SIP uniform resource identifier (URI).
Step 5	exit Example: Router(config-profile)# exit	Exits profile configuration mode.
Step 6	class-map type inspect <i>protocol-name</i> <i>class-map-name</i> Example: Router(config)# class-map type inspect sip sip-class	Creates an inspect type class map and enters class-map configuration mode.
Step 7	match request header field regex <i>regex-param-map</i> Example: Router(config-cmap)# match request header Via regex unsecure-proxy	Configures a class-map type to match a specific request header pattern.
Step 8	exit Example: Router(config-cmap)# exit	Exits class-map configuration mode.
Step 9	policy-map type inspect <i>protocol-name</i> <i>policy-map-name</i> Example: Router(config)# policy-map type inspect sip sip-policy	Creates an inspect type policy map and enters policy-map configuration mode.
Step 10	class type inspect <i>protocol-name</i> <i>class-map-name</i> Example: Router(config-pmap)# class type inspect sip sip-class	Specifies the class on which the action is performed and enters policy-map class configuration mode.

	Command or Action	Purpose
Step 11	reset Example: Router(config-pmap-c)# reset	Resets the class map.
Step 12	exit Example: Router(config-pmap-c)# exit	Exits policy-map class configuration mode.

Configuring a 403 Response Alarm

Perform this task to configure a policy to generate an alarm whenever a 403 response is returned.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **parameter-map type regex** *parameter-map-name*
4. **pattern** *url-pattern*
5. **exit**
6. **class-map type inspect** *protocol-name class-map-name*
7. **match response status regex** *regex-parameter-map*
8. **exit**
9. **policy-map type inspect** *protocol-name policy-map-name*
10. **class type inspect** *protocol-name class-map-name*
11. **log**
12. **exit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.

	Command or Action	Purpose
Step 3	parameter-map type regex <i>parameter-map-name</i> Example: Router(config)# parameter-map type regex allowed-im-users	Configures a parameter-map type to match a specific traffic pattern and enters profile configuration mode.
Step 4	pattern <i>url-pattern</i> Example: Router(config-profile)# pattern "403"	Matches a call based on the SIP URI.
Step 5	exit Example: Router(config-profile)# exit	Exits profile configuration mode.
Step 6	class-map type inspect <i>protocol-name</i> <i>class-map-name</i> Example: Router(config)# class-map type inspect sip sip-class	Creates an inspect type class map and enters class-map configuration mode.
Step 7	match response status regex <i>regex-parameter-map</i> Example: Router(config-cmap)# match response status regex allowed-im-users	Configures a class-map type to match a specific response pattern.
Step 8	exit Example: Router(config-cmap)# exit	Exits class-map configuration mode.
Step 9	policy-map type inspect <i>protocol-name</i> <i>policy-map-name</i> Example: Router(config)# policy-map type inspect sip sip-policy	Creates an inspect type policy map and enters policy-map configuration mode.
Step 10	class type inspect <i>protocol-name</i> <i>class-map-name</i> Example: Router(config-pmap)# class type inspect sip sip-class	Specifies the class on which the action is performed and enters policy-map class configuration mode.

	Command or Action	Purpose
Step 11	<code>log</code> Example: <code>Router(config-pmap-c)# log</code>	Generates a log of messages.
Step 12	<code>exit</code> Example: <code>Router(config)# exit</code>	Exits policy-map class configuration mode.

Limiting Application Messages

Perform this task to configure a policy to rate-limit INVITE messages.



Note

While configuring the **rate-limit** command, do not configure the **allow** or **reset** commands. An error message is displayed if you try to configure the **allow** or **reset** commands while configuring the **rate-limit** command and vice versa.

SUMMARY STEPS

1. `enable`
2. `configure terminal`
3. `class-map type inspect protocol-name match-any class-map-name`
4. `match request method method-name`
5. `exit`
6. `policy-map type inspect protocol-name policy-map-name`
7. `class type inspect protocol-name class-map-name`
8. `rate-limit limit-number`
9. `exit`
10. `exit`
11. `class-map type inspect match-any class-map-name`
12. `match protocol protocol-name`
13. `exit`
14. `policy-map type inspect policy-map-name`
15. `class type inspect class-map-name`
16. `inspect`
17. `service-policy protocol-name policy-map-name`
18. `exit`

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none">Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	class-map type inspect protocol-name match-any class-map-name Example: Router(config)# class-map type inspect sip match-any class-2	Creates an inspect type class map and enters class-map configuration mode.
Step 4	match request method method-name Example: Router(config-cmap)# match request method invite	Matches RFC 3261 methods. Methods include the following: <ul style="list-style-type: none">ack, bye, cancel, info, invite, message, notify, options, prack, refer, register, subscribe, update.
Step 5	exit Example: Router(config-cmap)# exit	Exits class-map configuration mode.
Step 6	policy-map type inspect protocol-name policy-map-name Example: Router(config)# policy-map type inspect sip policy-2	Creates an inspect type policy map and enters policy-map configuration mode.
Step 7	class type inspect protocol-name class-map-name Example: Router(config-pmap)# class type inspect sip class-2	Specifies the class on which the action is performed and enters policy-map class configuration mode.
Step 8	rate-limit limit-number Example: Router(config-pmap-c)# rate-limit 16	Limits the number of SIP messages that strike the Cisco IOS firewall every second.
Step 9	exit Example: Router(config-pmap-c)# exit	Exits policy-map class configuration mode.

	Command or Action	Purpose
Step 10	exit Example: Router(config-pmap)# exit	Exits policy-map configuration mode and enters global configuration mode.
Step 11	class-map type inspect match-any <i>class-map-name</i> Example: Router(config)# class-map type inspect match-any class-1	Creates an inspect type class map and enters class-map configuration mode.
Step 12	match protocol <i>protocol-name</i> Example: Router(config-cmap)# match protocol sip	Configures the match criterion for a class map on the basis of the specified protocol.
Step 13	exit Example: Router(config-cmap)# exit	Exits class-map configuration mode.
Step 14	policy-map type inspect <i>policy-map-name</i> Example: Router(config)# policy-map type inspect policy-1	Creates an inspect type policy map and enters policy-map configuration mode.
Step 15	class type inspect <i>class-map-name</i> Example: Router(config-pmap)# class type inspect class-1	Specifies the class on which the action is performed and enters policy-map class configuration mode.
Step 16	inspect Example: Router(config-pmap-c)# inspect	Enables stateful packet inspection.
Step 17	service-policy <i>protocol-name</i> <i>policy-map-name</i> Example: Router(config-pmap-c)# service-policy sip policy_2	Attaches the policy map to the service policy for the interface or virtual circuit.
Step 18	exit Example: Router(config-pmap-c)# exit	Exits policy-map class configuration mode.

Limiting Application Messages for a Particular Proxy

Perform this task to configure a policy to rate-limit INVITE messages coming for a particular proxy.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **parameter-map type regex** *parameter-map-name*
4. **pattern** *url-pattern*
5. **exit**
6. **class-map type inspect match-any** *class-map-name*
7. **match request method** *method-name*
8. **match request header field regex** *regex-parameter-map*
9. **exit**
10. **policy-map type inspect** *protocol-name policy-map-name*
11. **class type inspect** *protocol-name class-map-name*
12. **rate-limit** *limit-number*
13. **exit**
14. **exit**
15. **class-map type inspect match-any** *class-map-name*
16. **match protocol** *protocol-name*
17. **exit**
18. **policy-map type inspect** *policy-map-name*
19. **class type inspect** *class-map-name*
20. **inspect**
21. **service-policy** *protocol-name policy-map-name*
22. **exit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.

	Command or Action	Purpose
Step 3	<p>parameter-map type regex <i>parameter-map-name</i></p> <p>Example: Router(config)# parameter-map type regex rate-limited-proxy</p>	Configures a parameter-map type to match a specific traffic pattern and enters profile configuration mode.
Step 4	<p>pattern <i>url-pattern</i></p> <p>Example: Router(config-profile)# pattern "compromised.server.com"</p>	Matches a call based on the SIP URI.
Step 5	<p>exit</p> <p>Example: Router(config-cmap)# exit</p>	Exits profile configuration mode.
Step 6	<p>class-map type inspect <i>protocol-name</i> match-any <i>class-map-name</i></p> <p>Example: Router(config)# class-map type inspect sip match-any class_2</p>	Creates an inspect type class map and enters class-map configuration mode.
Step 7	<p>match request method <i>method-name</i></p> <p>Example: Router(config-cmap)# match request method invite</p>	Matches RFC 3261 methods. Methods include the following: <ul style="list-style-type: none"> ack, bye, cancel, info, invite, message, notify, options, prack, refer, register, subscribe, update.
Step 8	<p>match request header <i>field</i> regex <i>regex-param-map</i></p> <p>Example: Router(config-cmap)# match request header Via regex rate-limited-proxy</p>	Configures a class-map type to match a specific request header pattern.
Step 9	<p>exit</p> <p>Example: Router(config-cmap)# exit</p>	Exits class-map configuration mode.
Step 10	<p>policy-map type inspect <i>protocol-name</i> <i>policy-map-name</i></p> <p>Example: Router(config)# policy-map type inspect sip policy-2</p>	Creates an inspect type policy map and enters policy-map configuration mode.
Step 11	<p>class type inspect <i>protocol-name</i> <i>class-map-name</i></p> <p>Example: Router(config-pmap)# class type inspect sip class-2</p>	Specifies the class on which the action is performed and enters policy-map class configuration mode.

	Command or Action	Purpose
Step 12	rate-limit <i>limit-number</i> Example: Router(config-pmap-c)# rate-limit 16	Limits the number of SIP messages that strike the Cisco IOS firewall every second.
Step 13	exit Example: Router(config-pmap-c)# exit	Exits policy-map class configuration mode.
Step 14	exit Example: Router(config-pmap)# exit	Exits policy-map configuration mode and enters global configuration mode.
Step 15	class-map type inspect match-any <i>class-map-name</i> Example: Router(config)# class-map type inspect match-any class-1	Creates an inspect type class map and enters class-map configuration mode.
Step 16	match protocol <i>protocol-name</i> Example: Router(config-cmap)# match protocol sip	Configures the match criterion for a class map on the basis of the specified protocol.
Step 17	exit Example: Router(config-cmap)# exit	Exits class-map configuration mode.
Step 18	policy-map type inspect <i>policy-map-name</i> Example: Router(config)# policy-map type inspect policy-1	Creates an inspect type policy map and enters policy-map configuration mode.
Step 19	class type inspect <i>class-map-name</i> Example: Router(config-pmap)# class type inspect class-1	Specifies the class on which the action is performed and enters policy-map class configuration mode.
Step 20	inspect Example: Router(config-pmap-c)# inspect	Enables stateful packet inspection.

	Command or Action	Purpose
Step 21	service-policy <i>protocol-name policy-map-name</i> Example: Router(config-pmap-c)# service-policy sip policy-2	Attaches the policy map to the service policy for the interface or virtual circuit.
Step 22	exit Example: Router(config-pmap-c)# exit	Exits policy-map class configuration mode.

Verifying and Troubleshooting Cisco IOS Firewall—SIP Enhancements: ALG and AIC

The following commands can be used to troubleshoot the Cisco IOS Firewall—SIP Enhancements: ALG and AIC feature:

1. **clear zone-pair**
2. **debug cce**
3. **debug ip inspect**
4. **debug policy-map type inspect**
5. **show policy-map type inspect zone-pair**
6. **show zone-pair security**



Note

Effective with Cisco IOS Release 12.4(20)T, the **debug ip inspect** command is replaced by the **debug policy-firewall** command. See the *Cisco IOS Debug Command Reference* for more information.

Examples

Step 1 show policy-map type inspect zone-pair

The following is sample output of the **show policy-map type inspect zone-pair** command when the **session** keyword is used.

```
Router# show policy-map type inspect zone-pair session
```

```
policy exists on zp zp_test_out_self
Zone-pair: zp_test_out_self
Service-policy inspect : test
Class-map: c_sip (match-any)
...
Number of Established Sessions = 2
Established Sessions
Session 6717A7A0 (192.168.105.118:62265)=>(192.168.105.2:5060) sip:udp SIS_OPEN
Created 00:10:27, Last heard 00:00:03
Bytes sent (initiator:responder) [35579:14964]
Session 67179EA0 (192.168.105.119:62266)=>(192.168.105.2:5060) sip:udp SIS_OPEN
Created 00:10:27, Last heard 00:03:17
Bytes sent (initiator:responder) [10689:4093]
```

```

Number of Pre-generated Sessions = 7
Pre-generated Sessions
Pre-gen session 6717A560 192.168.105.2[1024:65535]=>192.168.105.118[62265:62265]
sip:udp
Created never, Last heard never
Bytes sent (initiator:responder) [0:0]
Pre-gen session 67179C60 192.168.105.2[1024:65535]=>192.168.105.119[62266:62266]
sip:udp
Created never, Last heard never
Bytes sent (initiator:responder) [0:0]
Pre-gen session 67176F60 192.168.105.118[1024:65535]=>192.168.105.2[5060:5060]
sip:udp
Created never, Last heard never
Bytes sent (initiator:responder) [0:0]
Pre-gen session 67176AE0 192.168.105.118[1024:65535]=>192.168.105.2[18318:18318]
sip-RTP-data:udp
Created never, Last heard never
Bytes sent (initiator:responder) [0:0]
Pre-gen session 671768A0 192.168.105.2[1024:65535]=>192.168.105.118[62495:62495]
sip-RTP-data:udp
Created never, Last heard never
Bytes sent (initiator:responder) [0:0]
Pre-gen session 671783A0 192.168.105.118[1024:65535]=>192.168.105.2[18319:18319]
sip-RTCP-data:udp
Created never, Last heard never
Bytes sent (initiator:responder) [0:0]
Pre-gen session 67176420 192.168.105.2[1024:65535]=>192.168.105.118[62496:62496]
sip-RTCP-data:udp
Created never, Last heard never
Bytes sent (initiator:responder) [0:0]

```

Step 2 show zone-pair security

The following is sample output of the **show zone-pair security** command.

```

Router# show zone-pair security

Zone-pair name zp_in_out
Source-Zone inside Destination-Zone outside
service-policy test
Zone-pair name zp_in_self
Source-Zone inside Destination-Zone self
service-policy test
Zone-pair name zp_self_out
Source-Zone self Destination-Zone outside
service-policy test

```

Configuration Examples for Cisco IOS Firewall—SIP Enhancements: ALG and AIC

- [Example: Firewall and SIP Configuration, page 18](#)

Example: Firewall and SIP Configuration

The following example shows how to configure the Cisco IOS Firewall—SIP Enhancements: ALG and AIC feature when the Cisco IOS firewall is located between two SIP gateways (CCM or CCME), as described in the [Cisco IOS Firewall Between SIP Gateways, page 4](#). Some phones are registered to the

CCME inside the firewall (inside zone). Other phones are registered to another CCME / CCM outside the firewall (outside zone). Cisco IOS firewall is configured for SIP inspection when there is no IP-IP gateway configured on the firewall device.

```
class-map type inspect sip match-any sip-aic-class
match request method invite
policy-map type inspect sip sip-aic-policy
class type inspect sip sip-aic-class
rate-limit 15
!
policy-map type inspect sip-policy
class type inspect sip-traffic-class
service-policy sip sip-aic-policy
!
class-map type inspect match-any sip-traffic-class
match protocol sip
!
policy-map type inspect sip-policy
class type inspect sip-traffic-class
inspect my-parameters
!
zone security inside
zone security outside
!
interface fastethernet 0
zone-member security inside
interface fastethernet 1
zone-member security outside
!
zone-pair security in-out source inside destination outside
service-policy type inspect sip-policy
!
zone-pair security in-self source inside destination self
service-policy type inspect sip-policy
```

Additional References

Related Documents

Related Topic	Document Title
Cisco IOS commands	Cisco IOS Master Commands List, All Releases
Cisco IOS firewall commands	Cisco IOS Security Command Reference
SIP information and configuration tasks	Configuring Session Initiation Protocol for Voice over IP” module in the Cisco IOS Voice, Video, and Fax Configuration Guide
Additional SIP Information	Guide to Cisco Systems VoIP Infrastructure Solution for SIP

MIBs

MIB	MIBs Link
None	To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL: http://www.cisco.com/go/mibs

RFCs

RFC	Title
RFC 3261	<i>SIP: Session Initiation Protocol</i>

Technical Assistance

Description	Link
The Cisco Support and Documentation website provides online resources to download documentation, software, and tools. Use these resources to install and configure the software and to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password.	http://www.cisco.com/cisco/web/support/index.html

Feature Information for Cisco IOS Firewall—SIP Enhancements: ALG and AIC

Table 1 lists the features in this module and provides links to specific configuration information.

Use Cisco Feature Navigator to find information about platform support and software image support. Cisco Feature Navigator enables you to determine which software images support a specific software release, feature set, or platform. To access Cisco Feature Navigator, go to <http://www.cisco.com/go/cfn>. An account on Cisco.com is not required.



Note

Table 1 lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Table 1 Feature Information for Cisco IOS Firewall—SIP Enhancements: ALG and AIC

Feature Name	Releases	Feature Information
Cisco IOS Firewall—SIP Enhancements: ALG and AIC	12.4(15)XZ 12.4(20)T	<p>This feature provides voice security enhancements within the firewall feature set in Cisco IOS software for Release 12.4(15)XZ and later releases.</p> <p>In Release 12.4(15)XZ, this feature was introduced on the Cisco 861, Cisco 881, and Cisco 881G routers.</p> <p>In Release 12.4(20)T, this feature was implemented on the Cisco 1700, Cisco 1800, Cisco 2600, Cisco 2800, Cisco 3700, Cisco 3800, Cisco 7200, and Cisco 7300 routers.</p> <p>The following commands were introduced or modified: class-map type inspect, match protocol, match protocol-violation, match req-resp, match request, match response, policy-map type inspect, rate-limit (firewall).</p>

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at www.cisco.com/go/trademarks. Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1005R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2008–2010 Cisco Systems, Inc. All rights reserved.

