



Send documentation comments to mdsfeedback-doc@cisco.com.

CHAPTER 13

Q Commands

The commands in this chapter apply to the Cisco MDS 9000 Family of multilayer directors and fabric switches. All commands are shown here in alphabetical order regardless of command mode. Please see the Command Mode section to determine the appropriate mode for each command. For more information, see the *Cisco MDS 9000 Family Configuration Guide*.

- qos control priority

Send documentation comments to mdsfeedback-doc@cisco.com.

qos control priority

To disable support for the QoS priority assignment for control traffic feature on the MDS 9000 family of switches, use the **qos control** command.

qos control priority *value*

no qos control *value*

Syntax	Description
qos control	Controls QoS traffic from one fabric controller to another
priority	Sets priority: 0=lowest, 7=highest (default).
<i>value</i>	Priority values range from 0=lowest, 7=highest (default).
no	Disables the control traffic QoS feature.

Defaults Enabled, priority value=7 (highest).

Command Modes Configuration mode

Usage Guidelines None.

Examples

```
switch# config t
switch(config)# no qos control priority
0 0=lowest, 7=highest (default, use no as prefix)
switch(config)# qos control priority 0
0 0=lowest, 7=highest (default, use no as prefix)
switch(config)#
```

Related Commands	Command	Description
	show qos internal	Shows internal debug information
	show qos statistics	Shows QoS related statistics