



# Cisco Business 150AX Access Point




Thank you for choosing the Cisco Business 150AX Access Point.

This access point can be used to create a new Wi-Fi 6 wireless network, or expand coverage of your existing Cisco Business Wireless (CBW) Wi-Fi 6 Network.

This Quick Start Guide will get you up and running in no time.

## What's in the Box

- Cisco Business 150AX Access Point
- Mounting Kit
- Ethernet Cable
- Quick Start Guide
- Technical Support Contact List
- Pointer Card China RoHS
- Compliance Information (for EU SKU only)
- PoE Injector



## Product Features

- ① Status LED
- ② PoE (Power over Ethernet)-In Port (Ethernet Uplink Port)
- ③ Kensington Lock
- ④ Disabled
- ⑤ Mode Button
- ⑥ Security Screw Hole
- ⑦ Mounting Bracket

**START  
HERE**


## First, You'll Need...

- An active Internet connection.
- A mobile device with Wi-Fi capability (not connected to an active wireless network).
- A PoE (Power over Ethernet) switch, router, or the included PoE injector to supply power to the access point.
- A router or switch (to act as your DHCP Server).

## Get Connected

1

Connect your access point via ethernet cable (provided) to a PoE LAN port on your switch or router. If you do not have a PoE switch or router you will need to use a PoE injector (included).



### Setting up a new network or adding to an existing network?

#### Set up a new network

If setting up a new network the device will begin initial boot up. The LED will cycle through patterns of green, red and off. This is normal and can take up to 6 minutes or longer. The device is not ready until the LED is solid green. Once this occurs you can proceed to “[Get Configured](#)”.

2

#### Add to an existing CBW Wi-Fi 6 wireless network

Allow the access point to boot up and automatically update its firmware and configuration to match the existing network. This can take 10 minutes or more, and the LED will cycle through green, red and off. This is normal. Once the LED is solid green the setup is complete and ready to be connected to the network. Once you are connected the LED turns blue.



## Get Configured

### Download the Cisco Business Mobile app



No computer is needed for setup, just use the app on your mobile phone.

Scan the QR code here to download the app or go to [cisco.com/go/cbapp](https://cisco.com/go/cbapp) and follow the installation instructions.



### Alternative: Web UI (Internet Browser) Setup

If you do not wish to use the Cisco Business Mobile app you can use the Web UI for setup. These instructions can be found online in the Web UI Setup Document.

To download the instructions see the “[Get Support](#)” section below.

### Mounting and Grounding

Cisco Business Wireless access points can be mounted in several configurations—on a suspended ceiling, on a hard ceiling or wall, or in the plenum air space above a suspended ceiling.

Mounting instructions are located in the Administration Guide, see the “[Get Support](#)” section below.

**Note:** Cisco Business Wireless (CBW) access points are not compatible with the Cisco Wireless LAN Controllers (WLCs) or other Cisco wireless access point series, such as Mobility Express. The CBW devices cannot coexist on the same network as WLCs. Additionally, the CBW Wi-Fi 5 product line (14x and 240 series) is incompatible with the CBW Wi-Fi 6 product line (15x series). If a CBW access point is placed on the same network as any of the incompatible products mentioned, it may enter a boot loop. In rare cases, it might even attempt to install a firmware update from the incompatible product, leading to bootloader corruption and product failure.

## Get Support



For Cisco support and additional product documentation, including the Web UI Setup Document and Administration Guide, visit:

<https://cisco.com/go/cbw150ax>