Troubleshoot Nexus 9000 Interface CRC Error with Script

Contents

Introduction Background Information Prerequisites Requirements Steps to install requirements.txt Components Used Background Information Script execution Steps Poller Script (Script-1) Execution Parser Script (Script-2) Execution Parser Script (Script-2) Output Review Related Information

Introduction

This document describes steps to execute Nexus 9000 CRC(Cyclic Redundancy Check) Script which identifies ports with CRC errors and provides remediation steps.

Background Information

Cisco Nexus 9000 series switches use cut-through switching by default. Cut-through switching is where a switch makes a forwarding decision on a frame and begins forwarding the frame out of an egress interface as soon as the switch has processed enough of the frame header to make a valid forwarding decision. This differs from store-and-forward switching, where a switch buffers the entire frame prior to forwarding the frame out of an egress interface.

To troubleshoot Interface CRC errors, CRC and FCS(Frame Check Sequence)) counter incremental values need to be reviewed to troubleshoot interface counter errors in these switches.

This script automates identification of CRC /FCS errors in 9200 & 9300 cloud scale ASIC(Application Specific Integrated Circuit) switches. It collects interface CRC and FCS counter values at periodic interval to see if errors are historic or live and provides remediation steps.

Script execution is divided in two parts where,

- 1. Poller Script (Script-1) collects Interface error data in files every 10-30 for maximum up to seven days of duration.
- 2. Parser Script (Script-2) analyses these outputs and gives tabular output with interfaces which are source of Error, as well interfaces which are just forwarding the stomped packets.

Run script-2 atleast after 30mins of script-1 execution, that is atleast when two or more files are collected as a part of script-1 execution.

Script collects output of these set of commands and analyses same to identify the source of CRC. Refer to link in the "Related Information" section.

switch# show interface

switch# show interface counters errors non-zero

switch# show interface hardware-mappings

switch# slot {x} show hardware internal tah counters asic {y}

Prerequisites

The script is available on Git.

It needs to downloaded and executed from client machine (jump server) with network access to Nexus switches, where CRC error analysis is needed.

Click <u>here</u> to download the script.

Requirements

Ensure that these pre-requisites are installed in client machine (jump server):

- 1. Python3
- 2. Client machine (jump server) to have network access to Nexus Switches
- Nexus_CRC_requirements.txt available in git to be installed in client machine. (This is a one time setup in client jump host. This step installs required python libraries to jump-host)

Steps to install requirements.txt

- Step-1: Download NEXUS_CRC_requirements.txt
- Step-2: Open terminal window /command prompt
- Step-3: Navigate to folder where NEXUS_CRC_requirements.txt is located and run command:

#pip install -r Nexus_CRC_requirements.txt

```
[rgajjar@RGAJJAR-M-925B NEXUS_CRC_Latest % pip3 install -r NEXUS_CRC_Requirements.txt
Defaulting to user installation because normal site-packages is not writeable
Collecting DateTime==4.3
  Using cached DateTime-4.3-py2.py3-none-any.whl (60 kB)
Collecting numpy==1.21.2
 Using cached numpy-1.21.2-cp38-cp38-macosx_10_9_x86_64.whl (16.9 MB)
Collecting pandas==1.3.2
 Using cached pandas-1.3.2-cp38-cp38-macosx_10_9_x86_64.whl (11.4 MB)
Collecting paramiko==2.7.2
  Using cached paramiko-2.7.2-py2.py3-none-any.whl (206 kB)
Collecting python-dateutil==2.8.2
 Using cached python_dateutil-2.8.2-py2.py3-none-any.whl (247 kB)
Collecting stdiomask==0.0.5
 Using cached stdiomask-0.0.5-py3-none-any.whl
Collecting tabulate==0.8.9
 Using cached tabulate-0.8.9-py3-none-any.whl (25 kB)
```

Upon successful installation, it shows message as below:

Successfully installed DateTime-4.3 numpy-1.21.2 pandas-1.3.2 paramiko-2.7.2 pythondateutil-2.8.2 stdiomask-0.0.5 tabulate-0.8.9 termcolor-1.1.0

Components Used

The script is tested on these jump servers:

- Windows-10 64 bit
- MAC Monterey

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, ensure that you understand the potential impact of any command.

Related Products

This script is intended to analyse CRC errors for Nexus 9200 & 9300 Cloud Scale ASIC switches:

Applicable Platforms: Nexus 9200/9300 Fixed Switches

- N9K-C92160YC-X
- N9K-C92300YC
- N9K-C92304QC
- N9K-C92348GC-X
- N9K-C9236C
- N9K-C9272Q
- N9K-C9332C
- N9K-C9364C
- N9K-C93108TC-EX
- N9K-C93108TC-EX-24
- N9K-C93180LC-EX
- N9K-C93180YC-EX
- N9K-C93180YC-EX-24
- N9K-C93108TC-FX
- N9K-C93108TC-FX-24
- N9K-C93180YC-FX
- N9K-C93180YC-FX-24

- N9K-C9348GC-FXP
- N9K-C93240YC-FX2
- N9K-C93216TC-FX2
- N9K-C9336C-FX2
- N9K-C9336C-FX2-E
- N9K-C93360YC-FX2
- N9K-C93180YC-FX3
- N9K-C93108TC-FX3P
- N9K-C93180YC-FX3S
- N9K-C9316D-GX
- N9K-C93600CD-GX
- N9K-C9364C-GX
- N9K-C9364D-GX2A
- N9K-C9332D-GX2B

Background Information

Cisco Nexus 9000 series switches use cut-through switching by default.

CRC and FCS counter incremental values need to be reviewed to troubleshoot interface counter errors in these switches.

This script automates identification of CRC /FCS errors in 9200 & 9300 cloud scale ASIC switches. It collects interface CRC and FCS counter values at periodic interval to see if errors are historic or live and provides remediation steps.

Script execution is divided in two parts where,

- 1. Poller Script (Script-1) collects Interface error data in files every 10-30 for maximum up to seven days of duration.
- 2. Parser Script (Script-2) analyses these outputs and gives tabular output with interfaces which are source of Error, as well interfaces which are just forwarding the stomped packets.

Run script-2 atleast after 30mins of script-1 execution, that is atleast when two or more files are collected as a part of script-1 execution.

Script execution Steps

Poller Script (Script-1) Execution

These steps are to execute Poller script, which collects CRC /FCS error counters in files at periodic interval.

Step-1: Open the terminal /command prompt and execute "NEXUS_CRC_POLLER.py" :

#python3 NEXUS_CRC_POLLER.py

Inputs:

Enter Nexus Switch IP /FQDN, Username and password:

```
rgajjar@RGAJJAR-M-925B NEXUS_CRC_Latest % python3 NEXUS_CRC_POLLER.py
Enter the IP address of Switch: 10.78.51.89
Enter the username: admin
Enter the password: ********
Trying to connect to Nexus...
Connection established to the Nexus
```

Step-2: Enter path to folder (location on your jump host), where you want to save the files:

VALID folder format:

EXAMPLE:

Windows-> C:\Users\Admin\Desktop\Nexus\

MAC -> /Users/admin/Desktop/Nexus/

PLEASE NOTE that data collection and script execution gets impacted if folder format is not as above. Also make sure that folder where you want to save files already exists



Step-3: Enter Duration for which you want to run the script:

Maximum - Seven days

Minimum - Run for atleast 30 mins to collect CRC counters multiple times and identify increments

Script collects Interface errors every 10 to 30 minutes and saves data to files at the path specified in earlier input. Data collection script end time based on End Time provided in input



Step-4: If there are no errors in the domain, it asks if user still wants to continue and collect data once more:

Parser Script (Script-2) Execution

These steps are to execute Parser script, which analyses CRC /FCS error files collected by Poller Script and provides remediation steps.

Start Parser script (Script-2) execution, once there are at-least have two files generated as a part of Poller Script (Script-1) execution to compare data (that is after approximately 30 minutes of Poller script execution).

Keep your terminal session font resolution to 100% for proper tabular output view.

Step-1: Open the terminal /command prompt and execute "NEXUS_CRC_PARSER.py":

Enter the same file location, where you have collected data from Script-1.

Example:

Enter the absolute path of the folder where the files are stored: <u>/Users/rgajjar/Desktop/CRC_NEXUS/</u>

Parser Script (Script-2) Output Review

Sample Execution and Output table for switch version >=10.2:

lease make	JJAR-M-925B NE r the folder w sure we have	KUS_CRC_Late here files a at least two	st % python3 NE re stored files exists in	XUS_CRC_PARS	ER.py ory where you have	saved data
ALID folde: XAMPLE: /indows-> C MAC -> /Use:	r format: :\Users\Admin\ rs/admin/Deskt	Desktop\CRC\ op/CRC/				
LEASE NOTE	that data col	lection and	script execution	n might get	impacted if folder	format is not as above
nter the al	bsolute path o	f the folder	where the file	s are stored	:/Users/rgajjar/Des	top/CRC_NEXUS/
.2022-08-10 etching fin RC_20220810	8 rst and last f: 8_1615.txt	ile of the s	ame date 202208	18		
RC_2022081 he script ersion: 10 ostname: F	8_1630.txt is executing .2(3) .cisco.cm					
RC_2022081/ he script : ersion: 10 ostname: F	8_1630.txt is executing .2(3) .cisco.cm Align-Err	FCS-Err	StompedCRC	eth_crc	eth_stomped_crc	Remediation
RC_2022081 he script ersion: 10 ostname: F	8_1630.txt is executing .2(3) .cisco.cm Align-Err 0	FCS-Err 0	StompedCRC 0	eth_crc 345	eth_stomped_crc 673	Remediation Please ignore. These are Stomped errors received from Remote end.
RC_2022081 he script ersion: 10 ostname: F Eth1/14 Eth1/18	8_1630.txt is executing .2(3) .cisco.cm Align-Err 0 0	FCS-Err 0 0	StompedCRC 0 0	eth_crc 345 653	eth_stomped_crc 673 236	Remediation Please ignore. These are Stomped errors received from Remote end. It is physical layer problem. Please Check for SFP and cabling.

Sample Execution and Output table for switch version < 10.2:

rgajjar@RG Please ent Please mai	AJJAR-M-9258 NEXU er the folder whe ce sure we have at	S_CRC_Lat re files least to	test % python3 are stored wo files exists	NEXUS_CRC_P	ARSER.py ectory where you have saved	data	
VALID fold EXAMPLE: Windows-> MAC -> /U:	der format: C:\Users\Admin\De ers/admin/Desktop	sktop\CR /CRC/	c\				
PLEASE NOT	E that data colle	ction and	d script execut	ion might g	et impacted if folder forma	t is not as above	
Enter the	absolute path of	the fold	er where the fi	les are sto	red:/Users/rgajjar/Desktop/	CRC_NEXUS/	
1.2022-09- Fetching f CRC_202209 CRC_202209 The script Version: 9 Hostname:	-11 first and last fil P11_1115.txt P11_1132.txt : is executing P.2(3) switch	e of the	same date 2022				
	input_errors	crc	Align-Err	FCS-Err	02-RX Frm with FCS Err	16-RX Frm CRC Err(Stomp)	Remediation
Eth1/5	252	0	0	3534	8635 	6455	- It is a physical layer problem. Please Check for SFP and cabling
Eth1/7	234	275	273	9	0	5344	Please ignore.

Related Information

To further understand the identification of N9K CRC errors, refer: <u>https://www.cisco.com/c/en/us/support/docs/switches/nexus-9000-series-switches/216239-nexus-9000-cloud-scale-asic-crc-identifi.html#anc12</u>