# **BE7000 Migration from Single RAID5 Volume to Dual RAID5 Arrays without VM Rebuild**



Document ID: 118847

Contributed by Ryan Ratliff, Cisco TAC Engineer. Mar 19, 2015

# Contents

Introduction Problem Solution Detailed Instructions Take Application–Level Backups of VMs Back Up ESXi Configuration and License Move VMs Off the Local Datastore Reconfigure the Array Re–install and Reconfigure ESXi Move VMs Back Onto the Local Datastore

## Introduction

This document describes the process for how to convert a Business Edition 7000 server that is configured with a single, 12–disk Redundant Array of Independent Disks (RAID) 5 volume to two, 6–disk RAID 5 volumes.

# Problem

Some Cisco Business Edition 7000 (BE7K) servers manufacturered prior to August of 2014 shipped from the factory with a single, 12–disk RAID 5 virtual drive. The Unified Communications (UC) on Unified Computing System (UCS) documentation specifies that this server and its equivalent Tested Reference Configuration (TRC) (C240 M3 SFF TRC2) use two RAID 5 virtual drives of 6 disks each.

If you change the array configuration on the UCS C240M3, it erases all data on the disks that are reconfigured. This means that ESXi must be re–installed and that you must re–apply ESXi licenses, reconfigure ESXi, and restore the Virtual Machines (VMs) in order to complete this migration.

It is easy to identify when the BE7K has an incorrect virtual disk configuration. In the vSphere client, navigate to *Home > Inventory > Inventory*. Select the *BE7K server* on the left, and then the *Configuration tab*. Finally, select *Storage* and ensure *Datastores* is selected.

This is what the datstore looks like for a BE7K with a single, 12–disk RAID5 virtual disk from the vSphere client.

rdware	View: Datastores Devices							
Health Status	Datastores					Refresh I	Delete Add Storage.	Rescan /
Processors	Identification 🗠 De	vice	Drive Type	Capacity	Free 1	ype La	st Update	Hardware A
Memory	CALO (read only) cal	lo-edisto:/nfs/voice/	Unknown	4.75 TB	3.07 GB	FS 8/	18/2014 7:21:06 AM	Not support
Storage	🖬 calo-edisto (read cal	o-edisto: Infs/voice	Unknown	4.75 TB	3.07 GB	FS 8/	18/2014 7:21:07 AM	Not support
Networking	Di konstitti MES/re 17	2 18 120 88 ironno	Linknown	48.69.CB	8 57 (8 8	<b>F</b> 5 8/	18/2014 7:21:07 AM	Not support
Storage Adapters	itp-be7k-1-datast Lo	cal LSJ Disk (naa.600	Non-SSD	2.99 TB	1.76 TB \	MPS5 8/	18/2014 7:21:07 AM	Not support
Network Adapters	ta section-hast in	BEST BUSI DER (CIU	NUTROU	339.75 58		MP35 8/	18/2014 7:21:06 AM	supporced
Advanced Settings								
Power Management								
Licensed Features Time Configuration	Datastore Details			2 00 TP /	math	-		Properti
DNS and Routing Authentication Services Virtual Machine Saratop/Shutdown Virtual Machine Swapfile Location Security Profile Host Octos Configuration	Location: Vinis Vi	2d515c9-37cf8b36-38e1- ot supported	78dade90fc78	1.22 TB	Lused Free			
System Resource Allocation Agent VM Settings	Path Selection Pixed (VHware) Vo	perties June Label: rtp-be7i	Extents	isk (naa.600605.	. 2.9	9 TB		

*Note*: The local disk datastore has a capacity of 2.99TB.

This is what a BE7K should look like when correctly configured with two 6-disk RAID 5 virtual disks.

🖸 🔯 🧑 Hane 🕽 🚮 ärverb	tory 🕨 🎁 Inventory								
8 e									
L1.46.42.38	ocalhost.localdomain YMMare ESXI, S.1.4 Getting Started Surmary Witaia Nacha Hardware Health Status	.0, 1665491   Evaluation (44 days remaining) and Denours Alexator Performance Configuration Local Uners's Source Events (Permissions) Yese Detailores Devices Datasteres Refresh Debte Add Storage Reson 41							
	Processors Memory 5 Storage Nativorking Storage Adopters Nativork Adopters Advanced Sattings Power Management	identification i defactorel i defactore2 i defactore2	Device     Local LST Disk (m.,,     Local LST Disk (m.,,	Drive Type Non-SSD Non-SSD	Capacity 1.35 TB 1.36 TB	Free Type 1.35 T8 VHP55 1.36 T8 VHP55 1.36 T8 VHP55	Last Update 8(15/2014 3:06-47 AM 8(15/2014 3:06-47 AM	Hardware Acceleration Not supported Not supported	
	Software Licensed Testures The Configuration DHS and Routing Authenkiscon Services Witual Machine Startup/Studiown Witual Machine Songfile Location Security Intellie Host: Cache Configuration	RAID-2 Location (vm/s/v Hardware Acceleration	kunes/153edaec2-966aea n: Not supported	s1-c2b1-76da6e90	1.36 T 1784 978,30 H 1.36 T	B Capacity B E Used B Free	•	Properties	
	System Resource Allocation Agent VM Settings Advanced Settings	Path Selection Fixed (Wiware)	Properties Volume Label:	S-DIA	Extents Local LSI Disk (naa.60	0605 1.36	570	×	

*Note*: The two local disk datastores each have 1.35TB of space.

### Solution

In order to make this process as easy as possible, complete these steps:

- 1. Take application–level backups of all VMs that run on the BE7K.
- 2. Back up the ESXi configuration and license(s). (Refer to the Backing up and restoring ESXi configuration using the vSphere Command–Line Interface and vSphere PowerCLI (2042141) article for more information.)

- 3. Move all VMs off of the local datastore. There are two ways to achieve this:
  - vMotion the VMs to another host and datastore.
  - Gracefully shutdown the VMs and copy everything on the local datastore to an external storage location.
- 4. Reboot the BE7K and reconfigure the RAID array with two 6-disk RAID 5 logical disks.
- 5. Re–install ESXi:
  - ♦ Apply ESXi Licenses.
  - Restore ESXi configuration. (Refer to the Backing up and restoring ESXi configuration using the vSphere Command–Line Interface and vSphere PowerCLI (2042141) article for more information.)
- 6. Move all VMs back onto the BE7K and start them back up.

### **Detailed Instructions**

#### Take Application–Level Backups of VMs

Follow the instructions in the Cisco.com documentation for the UC application in order to take a backup and save it to a safe location. For applications that use Disaster Recovery System (DRS), the Secure Shell FTP (SFTP) server should not be hosted on the BE7K for obvious reasons.

#### **Back Up ESXi Configuration and License**

Reference these two VMware KB articles in order to gain access to the vSphere CLI and perform a backup.

- Using ESXi Shell in ESXi 5.x (2004746)
- Backing up and restoring ESXi configuration using the vSphere Command–Line Interface and vSphere PowerCLI (2042141)

Here is an example of how to use the ESXi shell in order to back up the configuration.

```
~ # vim-cmd hostsvc/firmware/sync_config
~ # vim-cmd hostsvc/firmware/backup_config
Bundle can be downloaded at : http://*/downloads/
configBundle-RTP-CUCM-BE7K-1.cisco.com.tgz
```

For this example, you can download the backup archive from *https://rtp-cucm-be7k-1.cisco.com/downloads/configBundle-RTP-CUCM-BE7K-1.cisco.com.tgz*.

The contents of this bundle include the *license.cfg* file. This confirms that the ESXi backup and restore operation includes licenses.

#### Move VMs Off the Local Datastore

If the BE7K is part of a VCenter deployment, then the VMs should be migrated to shared storage so they can be run on an alternate host while the BE7K is under maintenance. If there is no shared storage available, then the process is as described here:

- 1. Gracefully shut down and power off all VMs on the BE7K.
- 2. Use the vSphere client in order to copy all files on the BE7K datastore to an alternate location.

If no alternate storage location is available to store the VMs and other content on the BE7K datastore, then open a Cisco Technical Assistance Center (TAC) Service Request (SR) so that other options can be explored. Be sure to cite this docuement when you open a TAC SR for this issue.

### **Reconfigure the Array**

Follow the steps in Cisco Collaboration on Virtual Servers in order to reconfigure the array for two 6–disk RAID5 logical disks. If you use extra Hard Disk Drives (HDDs) in the BE7K for backup purposes, be careful to not to delete the RAID 0 drive group or select *New Configuration* in the preboot GUI's configuration wizard.

### **Re-install and Reconfigure ESXi**

- 1. Follow the steps in About vSphere Installation and Setup if you are not familiar with how to install ESXi.
- 2. If you backed up the ESXi configuration, follow the instructions in Backing up and restoring ESXi configuration using the vSphere Command–Line Interface and vSphere PowerCLI (2042141) in order to restore the backup.
- 3. Because the ESXi installer does not create any additional datastores, you must use the vSphere client in order to add the second, 1.35TB virtual disk to ESXi as a Virtual Machine File System (VMFS) volume.
  - a. Go to the Storage Configuration and click the link for Add Storage.

naroware	View: Da	stastores Devic	tes					
Health Status	Datastores	5					Refresh Delete A	dd Stor
Processors	Identificati	on 🗠	Device	Drive Type	Capacity	Free Type	Last Update	
Memory	🗐 datas	store1	Local LSI Disk (n	Non-SSD	1.35 TB	1.35 TB VMP55	8/18/2014 8:03:14 4	-
Storage	× ×							
Networking								
Storage Adapters								
Network Adapters			Pa .					
Advanced Settings			·				1. Click "	Add
Power Management								
oftware								
Ucensed Features								
Ucensed Peatures Time Configuration	Datastore	Details						
Ucensed Features Time Configuration DNS and Routing	Datastore	Details 1			1.35	i TB Capacity	_	_
Ucensed Peatures Time Configuration DNS and Routing Authentication Services	Datastore datastore Location:	Details :1 /vmfs/volum	es/53db80dd-370027	45-2b2e-78dade9	1.35 357a4 972 aa	TB Capacity		
Utensed Features Time Configuration DNS and Routing Authentication Services Virtual Machine Startup(Shutdown	Datastore datastore Location: Hardware	Details 1 /vmfs/volum Acceleration:	es/53db80dd-370027 Not supported	945-2b2e-70de6e99	1.35 3 <b>17a4</b> 977.00 1.35	i TB Capacity	0	
Licensed Features Time Configuration DNS and Routing Authentication Services Virtual Machine Starbup(Shutdown Virtual Machine Starbup(Shutdown	Datastore datastore Location: Hardware	Details 1 Jvmfs/volum Acceleration:	es(53db80dd-370027 Not supported	45-2b2e-76de6e94	1.39 97 <b>84</b> 977.00 1.30	iTB Capacity IMB I Used ITB I Free	•	
Ucensed Features Time Configuration DNS and Routing Authentication Services Virtual Machine Starbup/Shutdown Virtual Machine Swapfile Location Security Profile	Datastore datastore Location: Hardware	Details 1 Jonfs/volum Acceleration:	es(53db00dd-370027 Not supported	45-2620-70do6e99	1.39 3F7a4 977.00 1.38	5TB Capacity MB Used 5TB Free	•	
Ucensed Features Time Configuration DNS and Routing Authenticistion Services Virtual Machine Startup/Shutdown Virtual Machine Swepfile Location Security Profile Host Cache Configuration	Datastore datastore Location: Hardware	Details 1 Jvmfs/volum Acceleration:	es/53db00dd-370027 Not supported	45-2620-78do6e94	1.38 977a4 977.00 1.38	iTB Capacity MB ■ Used iTB ■ Free	•	
Usersed Features Time Configuration DNS and Routing Authentication Services Virtual Machine Startup/Shutdown Virtual Machine Swepfle Location Security Profile Host Cache Configuration System Resource Alectation	Datastore datastore Location: Hardware Path Selec	Details Jumfs(volum Acceleration: ction	es/53db00dd-370027 Not supported	45-2620-78do6e94	1.38 97 <b>84</b> 977.00 1.38	STB Capacity IMB II Used STB II Free	•	
Licensed Features Time Configuration DNS and Routing Authentication Services Virtual Machine Startup/Shukdown Virtual Machine Swepfie Location Security Profile Host Cache Configuration System Resource Allocation Agent: Witsethos	Datastore datastore Location: Hardware Path Selec Fixed (WM	Details I /vmfs/volum Acceleration: ction I ware) I	es/53db00dd-370027 Not supported Properties	45-2520-7845699	1.38 9734 977.00 1.38 Extents	STB Capacity IMB Used STB Free	•	

b. In the Add Storage Wizard, make these selections:

- 1. Select *Disk/Lun* for the Storage Type.
- 2. If multiple options are available, select the disk with a capacity of 1.36TB.
- 3. Select the defaults for the rest of the wizard until you are prompted to provide a name for the datastore.

When completed, you should see two 1.3TB datastores available to use.

### Move VMs Back Onto the Local Datastore

This step is simply the reverse of whatever method you used to copy the VMs off of the old datastore.

If you use vCenter in order to migrate the VMs from shared storage back to the BE7K, then the VMs can be powered on immediately after they are migrated. If you manually copy the files back to the datastore, then you must use the vSphere client in order to import the VMs back into ESXi before they can be powered on.

If you used the vSphere datastore browser in order to move files, then it is likely you will see a message like the one here when you import the VMs back into ESXi. Select whether the VM was moved or copied (as appropriate) and click *OK* in order to proceed.

?	Virtual Machine Message This virtual machine might have been moved or copied. In order to configure certain management and networking features, VMware ESX needs to know if this virtual machine was moved or copied. If you don't know, answer "I copied Cancel I moved it I copied it
	ОК

*Note*: Because this process reduced the size of the previous datastore from 2.99TB to two separate 1.39TB volumes, it is possible the files that were copied off of the BE7K will not fit onto a single datastore. If this is the case, you should distribute the VMs among the two datastores, and make sure to leave plenty of free space on both.

Updated: Mar 19, 2015

Document ID: 118847