

BGP Graceful Shutdown

The BGP Graceful Shutdown feature reduces or eliminates the loss of traffic along a link being shut down for maintenance. Routers always have a valid route available during the convergence process. This feature is used primarily for maintenance on a link between a Provider Edge (PE), PE-PE, PE- Route Reflector (RR), PE-Customer Edge (CE) and CE.

- Finding Feature Information, on page 1
- Information About BGP Graceful Shutdown, on page 1
- How to Configure BGP Graceful Shutdown, on page 2
- Configuration Examples for BGP Graceful Shutdown, on page 6
- Additional References, on page 7

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest caveats and feature information, see Bug Search Tool and the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the feature information table at the end of this module.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Information About BGP Graceful Shutdown

Purpose and Benefits of BGP Graceful Shutdown

There are times when planned maintenance operations cause routing changes in BGP. After the shutdown of eBGP and iBGP peering sessions between autonomous system border routers (ASBRs), BGP devices are temporarily unreachable during BGP convergence. The goal of gracefully shutting down one or more BGP sessions is to minimize traffic loss during the planned shutdown and subsequent reestablishment of the sessions.

The BGP Graceful Shutdown feature reduces or eliminates the loss of inbound or outbound traffic flows that were initially forwarded along the peering link that is being shut down for maintenance. This feature is primarily for PE-CE, PE-RR and PE-PE links. Lowering the local preference for paths received over the session being shutdown renders the affected paths less preferred by the BGP decision process, but still allows the paths to

be used during the convergence while alternative paths are propagated to the affected devices. Therefore, devices always have a valid route available during the convergence process.

The feature also allows vendors to provide a graceful shutdown mechanism that does not require any router reconfiguration at maintenance time. The benefits of the BGP Graceful Shutdown feature are fewer lost packets and less time spent reconfiguring devices.

GSHUT Community

The GSHUT community is a well-known community used in conjunction with the BGP Graceful Shutdown feature. The GSHUT community attribute is applied to a neighbor specified by the **neighbor shutdown graceful** command, thereby gracefully shutting down the link in an expected number of seconds. The GSHUT community is always sent by the GSHUT initiator.

The GSHUT community is specified in a community list, which is referenced by a route map and then used to make policy routing decisions.

The GSHUT community can also be used in the **show ip bgp community** command to limit output to GSHUT routes.

How to Configure BGP Graceful Shutdown

Shutting Down a BGP Link Gracefully

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- **3.** router bgp autonomous-system-number
- **4. neighbor** {*ipv4-address* | *ipv6-address*} **remote-as** *number*
- **5. neighbor** {*ipv4-address* | *ipv6-address* | *peer-group-name*} **shutdown graceful** *seconds* {**community** *value* [**local-preference** *value*] | **local-preference** *value*}
- 6. end
- 7. show ip bgp community gshut

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Device> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	

	Command or Action	Purpose
Step 3	router bgp autonomous-system-number	Configures a BGP routing process.
	Example:	
	Device(config)# router bgp 5000	
Step 4	neighbor {ipv4-address ipv6-address} remote-as number	
	Example:	neighbor belongs.
	Device(config-router)# neighbor 2001:db8:3::1 remote-as 5500	
Step 5	neighbor {ipv4-address ipv6-address peer-group-name}	Configures the device to gracefully shut down the link
	shutdown graceful seconds {community value [local-preference value] local-preference value}	the specified peer in the specified number of seconds; advertises the route with the GSHUT (Graceful Shutdown)
	Example:	community; and advertises the route with another community or specifies a local preference value for the route, or both.
	Device(config-router)# neighbor 2001:db8:3::1 shutdown graceful 600 community 1200 local-preference 300	Make sure to specify an adequate amount of time for
		iBGP peers to converge and to choose an alternate path as the best path.
		• If the graceful keyword is used in the neighbor
		shutdown command, at least one of the two attributes (a community or local preference) must be configured. You may configure both attributes.
		• If the graceful keyword is used in the neighbor shutdown command, the route is advertised with the GSHUT community by default. You may also set one
		other community for policy routing purposes.
		 In this particular example, the route to the neighbor is configured to shut down in 600 seconds, is advertised with the GSHUT community and community 1200, and is configured with a local preference of 300.
		The device receiving the advertisement looks at the community value(s) of the route and optionally uses the community value to apply routing policy. Filtering routes based on a community is done with the ip community-list command and a route map.
		During the graceful shutdown, the neighbor shutdown command is not nvgened. After the timer expires, SHUTDOWN is nvgened.
Step 6	end	Returns to EXEC mode.
	Example:	
	Device(config-router)# end	

	Command or Action	Purpose
Step 7	show ip bgp community gshut	(Optional) Displays information about the routes that are
	Example:	advertised with the well-known GSHUT community.
	Device# show ip bgp community gshut	

Filtering BGP Routes Based on the GSHUT Community

Perform this task on a BGP peer to the device where you enabled the BGP Graceful Shutdown feature.

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- **3. router bgp** *autonomous-system-number*
- **4. neighbor** {*ipv4-address* | *ipv6-address*} **remote-as** *number*
- **5. neighbor** {*ipv4-address* | *ipv6-address*} **activate**
- **6. neighbor** {*ipv4-address* | *ipv6-address*} **send-community**
- 7. exit
- **8. route-map** *map-tag* [**permit** | **deny**] [*sequence-number*]
- **9. match community** {standard-list-number | expanded-list-number | community-list-name [exact]}
- **10**. exit
- 11. ip community-list {standard | standard list-name} {deny | permit} gshut
- **12. router bgp** *autonomous-system-number*
- 13. neighbor address route-map map-name in

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Device> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 3	router bgp autonomous-system-number	Configures a BGP routing process.
	Example:	
	Device(config)# router bgp 2000	

	Command or Action	Purpose
Step 4	neighbor {ipv4-address ipv6-address} remote-as number	Configures the autonomous system (AS) to which the neighbor belongs.
	Example:	
	Device(config-router)# neighbor 2001:db8:4::1 remote-as 1000	
Step 5	neighbor {ipv4-address ipv6-address} activate	Activates the neighbor.
	Example:	
	Device(config-router)# neighbor 2001:db8:4::1 activate	
Step 6	neighbor {ipv4-address ipv6-address} send-community	Enables BGP community exchange with the neighbor.
	Example:	
	Device(config-router) # neighbor 2001:db8:4::1 send-community	
Step 7	exit	Exits router configuration mode.
	Example:	
	Device(config-router)# exit	
Step 8	route-map map-tag [permit deny] [sequence-number]	Configures a route map to permit or deny routes for policy
	Example:	routing.
	Device(config)# route-map RM_GSHUT deny 10	
Step 9	match community {standard-list-number expanded-list-number community-list-name [exact]}	Configures that the routes that match ip community-list GSHUT will be policy routed.
	Example:	
	Device(config-route-map)# match community GSHUT	
Step 10	exit	Exits route-map configuration mode.
	Example:	
	Device(config-route-map)# exit	
Step 11	ip community-list {standard standard list-name} {deny permit} gshut	Configures a community list and permits or denies routes that have the GSHUT community to the community list.
	Example:	• If you specify other communities in the same
	Device(config)# ip community-list standard GSHUT permit gshut	statement, there is a logical AND operation and all communities in the statement must match the communities for the route in order for the statement to be processed.

	Command or Action	Purpose
Step 12	router bgp autonomous-system-number	Configures a BGP routing process.
	Example:	
	Device(config)# router bgp 2000	
•	neighbor address route-map map-name in	Applies the route map to incoming routes from the
	specified neighbor.	
	Device(config) # neighbor 2001:db8:4::1 route-map RM_GSHUT in	• In this example, the route map named RM_GSHUT denies routes from the specified neighbor that have the GSHUT community.

Configuration Examples for BGP Graceful Shutdown

Example: Shutting Down a BGP Link Gracefully

Graceful Shutdown While Setting a Local-Preference

This example gracefully shuts down the link to the specified neighbor in 600 seconds, adds the GSHUT community to the route, and sets a local preference of 500 for the route.

```
router bgp 1000
neighbor 2001:db8:5::1 remote-as 2000
neighbor 2001:db8:5::1 shutdown graceful 600 local-preference 500
neighbor 2001:db8:5::1 send-community
```

Graceful Shutdown While Setting an Additional Community

This example gracefully shuts down the link to the specified neighbor in 600 seconds, and adds the GSHUT community and numbered community to the route.

```
router bgp 1000
neighbor 2001:db8:5::1 remote-as 2000
neighbor 2001:db8:5::1 shutdown graceful 600 community 1400
neighbor 2001:db8:5::1 send-community
exit
```

Graceful Shutdown while Setting an Additional Community and Local-Preference

This example gracefully shuts down the link to the specified neighbor in 600 seconds, adds the GSHUT community and the numbered community to the route, and sets a local preference of 500 to the route.

```
router bgp 1000
neighbor 2001:db8:5::1 remote-as 2000
neighbor 2001:db8:5::1 shutdown graceful 600 community 1400 local-preference 500
neighbor 2001:db8:5::1 send-community
exit
```

Example: Filtering BGP Routes Based on the GSHUT Community

In additional to being able to gracefully shut down a BGP route, another use of the GSHUT community is to configure a community list to filter routes with this community from getting into the BGP routing table.

This example illustrates how to use a community list to filter incoming BGP routes based on the GSHUT community. In this example, a route map named RM_GSHUT denies routes based on a standard community list named GSHUT. The community list contains routes with the GSHUT community. The route map is then applied to incoming routes from the neighbor at 2001:db8:4::1.

```
router bgp 2000
neighbor 2001:db8:4::1 remote-as 1000
neighbor 2001:db8:4::1 activate
neighbor 2001:db8:4::1 send-community
exit
route-map RM_GSHUT deny 10
match community GSHUT
exit
ip community-list standard GSHUT permit gshut
router bgp 2000
neighbor 2001:db8:4::1 route-map RM GSHUT in
```

Additional References

Related Documents

Related Topic	Document Title
Cisco IOS commands	Cisco IOS Master Commands List, All Releases
BGP commands	Cisco IOS IP Routing: BGP Command Reference

Standards and RFCs

Standard/RFC	Title
RFC 6198	Requirements for the Graceful Shutdown of BGP Sessions

Technical Assistance

Description	Link
The Cisco Support and Documentation website provides online resources to download documentation, software, and tools. Use these resources to install and configure the software and to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password.	