

MPLS LDP Session Protection

Last Updated: November 28, 2011

The MPLS LDP Session Protection feature provides faster label distribution protocol convergence when a link recovers following an outage. MPLS LDP Session Protection protects a label distribution protocol (LDP) session between directly connected neighbors or an LDP session established for a traffic engineering (TE) tunnel.

- Finding Feature Information, page 1
- Restrictions for MPLS LDP Session Protection, page 1
- Information About MPLS LDP Session Protection, page 2
- How to Configure MPLS LDP Session Protection, page 3
- Configuration Examples for MPLS LDP Session Protection, page 6
- Additional References, page 9
- Command Reference, page 10

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest feature information and caveats, see the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the Feature Information Table at the end of this document.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Restrictions for MPLS LDP Session Protection

This feature is not supported under the following circumstances:

- With TDP sessions
- · With extended access lists
- With LC-ATM routers



Information About MPLS LDP Session Protection

MPLS LDP Session Protection maintains LDP bindings when a link fails. MPLS LDP sessions are protected through the use of LDP Hello messages. When you enable MPLS LDP, the label switched routers (LSRs) send messages to find other LSRs with which they can create LDP sessions.

- If the LSR is one hop from its neighbor, it is directly connected to its neighbor. The LSR sends out LDP Hello messages as User Datagram Protocol (UDP) packets to all the routers on the subnet. The hello message is called an LDP Link Hello. A neighboring LSR responds to the hello message and the two routers begin to establish an LDP session.
- If the LSR is more than one hop from its neighbor, it is not directly connected to its neighbor. The LSR sends out a directed hello message as a UDP packet, but as a unicast message specifically addressed to that LSR. The hello message is called an LDP Targeted Hello. The nondirectly connected LSR responds to the Hello message and the two routers establish an LDP session. (If the path between two LSRs has been traffic engineered and has LDP enabled, the LDP session between them is called a targeted session.)

MPLS LDP Session Protection uses LDP Targeted Hellos to protect LDP sessions. Take, for example, two directly connected routers that have LDP enabled and can reach each other through alternate IP routes in the network. An LDP session that exists between two routers is called an LDP Link Hello Adjacency. When MPLS LDP Session Protection is enabled, an LDP Targeted Hello Adjacency is also established for the LDP session. If the link between the two routers fails, the LDP Link Adjacency also fails. However, if the LDP peer is still reachable through IP, the LDP session stays up, because the LDP Targeted Hello Adjacency still exists between the routers. When the directly connected link recovers, the session does not need to be reestablished, and LDP bindings for prefixes do not need to be relearned.

MPLS LDP Session Protection Customizations, page 2

MPLS LDP Session Protection Customizations

You can modify MPLS LDP Session Protection by using the keywords in the mpls ldp session protection command.

Specifying How Long an LDP Targeted Hello Adjacency Should Be Retained

The default behavior of the mpls ldp session protection command allows an LDP Targeted Hello Adjacency to exist indefinitely following the loss of an LDP Link Hello Adjacency. You can issue the **duration** keyword to specify the number of seconds (from 30 to 2,147,483) that the LDP Targeted Hello Adjacency is retained after the loss of the LDP Link Hello Adjacency. When the link is lost, a timer starts. If the timer expires, the LDP Targeted Hello Adjacency is removed.

Specifying Which Routers Should Have MPLS LDP Session Protection

The default behavior of the mpls ldp session protection command allows MPLS LDP Session Protection for all neighbor sessions. You can issue either the **vrf**or **for** keyword to limit the number of neighbor sessions that are protected.

Enabling MPLS LDP Session Protection on Specified VPN Routing and Forwarding Instances

If the router is configured with at least one VPN routing and forwarding (VRF) instance, you can use the **vrf** keyword to select which VRF is to be protected. You cannot specify more than one VRF with the mpls ldp session protection command. To specify multiple VRFs, issue the command multiple times.

Enabling MPLS LDP Session Protection on Specified Peer Routers

You can create an access list that includes several peer routers. You can specify that access list with the **for** keyword to enable LDP Session Protection for the peer routers in the access control list.

How to Configure MPLS LDP Session Protection

- Enabling MPLS LDP Session Protection, page 3
- Verifying MPLS LDP Session Protection, page 5
- Troubleshooting Tips, page 6

Enabling MPLS LDP Session Protection

You use the mpls ldp session protection command to enable MPLS LDP Session Protection. This command enables LDP sessions to be protected during a link failure. By default, the command protects all LDP sessions. The command has several options that enable you to specify which LDP sessions to protect. The **vrf**keyword lets you protect LDP sessions for a specified VRF. The **for** keyword lets you specify a standard IP access control list (ACL) of prefixes that should be protected. The **duration** keyword enables you to specify how long the router should retain the LDP Targeted Hello Adjacency following the loss of the LDP Link Hello Adjacency.

LSRs must be able to respond to LDP targeted hellos. Otherwise, the LSRs cannot establish a targeted adjacency. All routers that participate in MPLS LDP Session Protection must be enabled to respond to targeted hellos. Both neighbor routers must be configured for session protection or one router must be configured for session protection and the other router must be configured to respond to targeted hellos.

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- 3. ip cef [distributed]
- 4. interface loopback number
- **5. ip address** {*prefix mask*}
- 6. interface interface
- 7. mpls ip
- 8. mpls label protocol {ldp | tdp | both}
- 9. exit
- **10.** mpls ldp session protection [vrf vpn-name] [for acl] [duration seconds]

DETAILED STEPS

Command or Action	Purpose
enable	Enables privileged EXEC mode.
	Enter your password if prompted.
Example:	
Router> enable	
configure terminal	Enters global configuration mode.
Example:	
Router# configure terminal	
ip cef [distributed]	Configures Cisco Express Forwarding.
Router(config)# ip cef	
interface loopback number	Configures a loopback interface and enters interface configuration mode.
Example:	
Router(config)# interface Loopback0	
ip address {prefix mask}	Assigns an IP address to the loopback interface.
Example:	
Router(config-if)# ip address 10.25.0.11 255.255.255	
interface interface	Specifies the interface to configure.
-	
Router(config-if)# interface POS3/0	
mpls ip	Configures MPLS hop-by-hop forwarding for a specified interface.
Example:	
Router(config-if)# mpls ip	
	Example: Router> enable Configure terminal Example: Router# configure terminal Ip cef [distributed] Example: Router(config)# ip cef Interface loopback number Example: Router(config)# interface Loopback0 Ip address {prefix mask} Example: Router(config-if)# ip address 10.25.0.11 255.255.255.255 Interface interface Example: Router(config-if)# interface POS3/0 Impls ip Example: Router(config-if)# interface POS3/0 Impls ip

	Command or Action	Purpose
Step 8	mpls label protocol {ldp tdp both}	Configures the use of LDP on a specific interface or on all interfaces.
	<pre>Example: Router(config-if)# mpls label protocol ldp</pre>	In interface configuration mode, the command sets the default label distribution protocol for the interface to be LDP, overriding any default set by the global mpls label protocol command.
		In global configuration mode, the command sets all the interfaces to LDP.
Step 9	exit	Exits from interface configuration mode.
	Example:	
	Router(config-if)# exit	
Step 10	mpls ldp session protection [vrf vpn-name] [for acl] [duration seconds]	Enables MPLS LDP Session Protection.
	Example:	
	Router(config)# mpls ldp session protection	

Verifying MPLS LDP Session Protection

SUMMARY STEPS

- 1. show mpls ldp discovery
- 2. show mpls ldp neighbor
- 3. show mpls ldp neighbor detail

DETAILED STEPS

Step 1 show mpls ldp discovery

Issue this command and check that the output contains xmit/recv to the peer router.

Example:

Router# show mpls ldp discovery
Local LDP Identifier:
10.0.0.5:0
Discovery Sources:
Interfaces:
ATM5/1/0.5 (ldp): xmit/recv
LDP Id: 10.0.0.1:0
Targeted Hellos:

```
10.0.0.5 -> 10.0.0.3 (ldp): active, xmit/recv LDP Id: 10.0.0.3:0
```

Step 2 show mpls ldp neighbor

Issue this command to check that the targeted hellos are active.

Example:

```
Router# show mpls ldp neighbor

Peer LDP Ident: 10.0.0.3:0; Local LDP Ident 10.0.0.5:0

TCP connection: 10.0.0.3.646 - 10.0.0.5.11005

State: Oper; Msgs sent/rcvd: 1453/1464; Downstream

Up time: 21:09:56

LDP discovery sources:

Targeted Hello 10.0.0.5 -> 10.0.0.3, active

Addresses bound to peer LDP Ident:

10.3.104.3 10.0.0.2 10.0.0.3
```

Step 3 show mpls ldp neighbor detail

Issue this command to check that the MPLS LDP Session Protection state is Ready or Protecting. If the second last line of the output shows Incomplete, the Targeted Hello Adjacency is not up yet.

Example:

```
Router# show mpls ldp neighbor detail
   Peer LDP Ident: 10.16.16.16:0; Local LDP Ident 10.15.15.15:0
        TCP connection: 10.16.16.16.11013 - 10.15.15.15.646
        State: Oper; Msgs sent/rcvd: 53/51; Downstream; Last TIB rev sent 74
        Up time: 00:11:32; UID: 1; Peer Id 0;
        LDP discovery sources:
          Targeted Hello 10.15.15.15 -> 10.16.16.16, active, passive;
            holdtime: infinite, hello interval: 10000 ms
        Addresses bound to peer LDP Ident:
                                          10.101.101.101 11.0.0.1
          10.0.0.2
                          10.16.16.16
        Peer holdtime: 180000 ms; KA interval: 60000 ms; Peer state: estab
        Clients: Dir Adj Client
        LDP Session Protection enabled, state: Protecting
            duration: infinite
```

Troubleshooting Tips


Use the **clear mpls ldp neighbor** command if you need to terminate an LDP session after a link goes down. This is useful for situations where the link needs to be taken out of service or needs to be connected to a different neighbor.

To enable the display of events related to MPLS LDP Session Protection, use the **debug mpls ldp session protection**command.

Configuration Examples for MPLS LDP Session Protection

The figure below shows a sample configuration for MPLS LDP Session Protection.

Figure 1 MPLS LDP Session Protection Example



R1

```
redundancy
no keepalive-enable
mode hsa
ip cef distributed
no ip domain-lookup
multilink bundle-name both
mpls label protocol ldp
mpls ldp session protection
no mpls traffic-eng auto-bw timers frequency 0
tag-switching tdp router-id Loopback0 force
interface Loopback0
ip address 10.0.0.1 255.255.255.255
 no ip directed-broadcast
no ip mroute-cache
interface Multilink4
no ip address
no ip directed-broadcast
 no ip mroute-cache
 load-interval 30
ppp multilink
multilink-group 4
interface Ethernet1/0/0
ip address 10.3.123.1 255.255.0.0
no ip directed-broadcast
interface Ethernet4/0/0
no ip address
no ip directed-broadcast
 shutdown
interface Ethernet4/0/1
description -- ip address 10.0.0.2 255.255.255.0
no ip address
no ip directed-broadcast
 shutdown
interface Ethernet4/0/4
 ip address 10.0.0.1 255.0.0.0
no ip directed-broadcast
 mpls label protocol ldp
 tag-switching ip
interface Ethernet4/0/6
 ip address 10.0.0.1 255.0.0.0
 no ip directed-broadcast
mpls label protocol ldp
 tag-switching ip
interface Ethernet4/0/7
ip address 10.0.0.1 255.0.0.0
no ip directed-broadcast
```

```
mpls label protocol ldp
tag-switching ip
!
router ospf 100
log-adjacency-changes
redistribute connected
network 10.0.0.1 0.0.0.0 area 100
network 10.0.0.0 0.255.255.255 area 100
!
ip classless

R2

redundancy
no keepalive-enable
mode hsa
!
```

ip subnet-zero ip cef distributed mpls label protocol ldp mpls ldp session protection no mpls traffic-eng auto-bw timers frequency 0 tag-switching tdp router-id Loopback0 force interface Loopback0 ip address 10.0.0.3 255.255.255.255 no ip directed-broadcast interface Ethernet5/0/0 no ip address no ip directed-broadcast shutdown full-duplex interface Ethernet5/0/2 ip address 10.0.0.1 255.0.0.0 no ip directed-broadcast full-duplex mpls label protocol ldp tag-switching ip interface Ethernet5/0/6 ip address 10.0.0.2 255.0.0.0 no ip directed-broadcast ip load-sharing per-packet full-duplex mpls label protocol ldp tag-switching ip interface FastEthernet5/1/0 ip address 10.3.123.112 255.255.0.0 no ip directed-broadcast router ospf 100 log-adjacency-changes redistribute connected network $10.0.0.3 \ 0.0.0.0$ area 100network 10.0.0.0 0.255.255.255 area 100 network 10.0.0.0 0.255.255.255 area 100 ip classless

R3

```
ip cef
no ip domain-lookup
mpls label range 200 100000 static 16 199
```

8

```
mpls label protocol ldp
no mpls traffic-eng auto-bw timers frequency 0
tag-switching tdp router-id Loopback0 force
interface Loopback0
 ip address 10.0.0.5 255.255.255
no ip directed-broadcast
interface Ethernet1/0
no ip address
no ip directed-broadcast
shutdown
half-duplex
interface Ethernet1/2
ip address 10.0.0.2 255.0.0.0
no ip directed-broadcast
full-duplex
mpls label protocol ldp
 tag-switching ip
interface Ethernet1/4
ip address 10.0.0.2 255.0.0.0
no ip directed-broadcast
 full-duplex
mpls label protocol ldp
tag-switching ip
1
router ospf 100
log-adjacency-changes
redistribute connected
network 10.0.0.5 0.0.0.0 area 100
network 10.0.0.0 0.255.255.255 area 100
network 10.0.0.0 0.255.255.255 area 100
ip classless
```

Additional References

Related Documents

Related Topic	Document Title
MPLS LDP	MPLS Label Distribution Protocol
MPLS LDP-IGP synchronization	MPLS LDP-IGP Synchronization
LDP autoconfiguration	LDP Autoconfiguration

Standards

Standards	Title
None	

MIBs

MIBs	MIBs Link		
MPLS LDP MIB	To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL:		
	http://www.cisco.com/go/mibs		
RFCs			
RFCs	Title		
RFC 3036	LDP Specification		
RFC 3037	LDP Applicability		
Technical Assistance			
Description	Link		
The Cisco Support website provides extensive online resources, including documentation and tools for troubleshooting and resolving technical issues with Cisco products and technologies. Access to most tools on the Cisco Support website requires a Cisco.com user ID and password. If you have a valid service contract but do not have a user ID or password, you can register on Cisco.com.	http://www.cisco.com/techsupport		

Command Reference

The following commands are introduced or modified in the feature or features documented in this module. For information about these commands, see the *Cisco IOS Multiprotocol Label Switching Command Reference* at http://www.cisco.com/en/US/docs/ios/mpls/command/reference/mp_book.html . For information about all Cisco IOS commands, go to the Command Lookup Tool at http://tools.cisco.com/Support/CLILookup or to the *Cisco IOS Master Commands List*.

- · debug mpls ldp session protection
- · mpls ldp session protection
- · show mpls ldp neighbor

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams,

and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2011 Cisco Systems, Inc. All rights reserved.