



Low Latency Queueing for IPsec Encryption Engines

This feature module describes the LLQ for IPsec encryption engines feature and includes the following sections:

- [Finding Feature Information, on page 1](#)
- [Feature Overview, on page 1](#)
- [Supported Standards MIBs and RFCs, on page 2](#)
- [Prerequisites, on page 3](#)
- [Configuration Tasks, on page 3](#)
- [Monitoring and Maintaining LLQ for IPsec Encryption Engines, on page 7](#)
- [Configuration Examples, on page 7](#)

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest caveats and feature information, see [Bug Search Tool](#) and the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the feature information table.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Feature Overview

Low Latency Queueing (LLQ) for IPsec encryption engines helps reduce packet latency by introducing the concept of queueing before crypto engines. Prior to this, the crypto processing engine gave data traffic and voice traffic equal status. Administrators now designate voice traffic as priority. Data packets arriving at a router interface are directed into a data packet inbound queue for crypto engine processing. This queue is called the best effort queue. Voice packets arriving on a router interface are directed into a priority packet inbound queue for crypto engine processing. This queue is called the priority queue. The crypto engine undertakes packet processing in a favorable ratio for voice packets. Voice packets are guaranteed a minimum processing bandwidth on the crypto engine.

Benefits of the LLQ for IPsec Encryption Engines

The LLQ for IPsec encryption engines feature guarantees a certain level of crypto engine processing time for priority designated traffic.

Better Voice Performance

Voice packets can be identified as priority, allowing the crypto engine to guarantee a certain percentage of processing bandwidth. This feature impacts the end user experience by assuring voice quality if voice traffic is directed onto a congested network.

Improved Latency and Jitters

Predictability is a critical component of network performance. The LLQ for IPsec encryption engines feature delivers network traffic predictability relating to VPN. With this feature disabled, an end user employing an IP phone over VPN might experience jitter or latency, both symptoms of overall network latency and congestion. With this feature enabled, these undesirable characteristics are dissipated.

Restrictions

- No per-tunnel QoS policy. An interface QoS policy represents all tunnels.
- Assume the same IP precedence/DSCP marking for inbound and outbound voice packets.
- Assume the IP precedence/DSCP marking for voice packets are done at the source.
- Limited match criteria for voice traffic in the interface QoS policy.
- Assume call admission control is enforced within the enterprise.
- No strict error checking when aggregate policy's bandwidth exceeds crypto engine bandwidth. Only a warning is displayed but configuration is allowed.
- Assume voice packets are either all encrypted or unencrypted.

Related Documents

- Cisco IOS Quality of Service Solutions Command Reference
- "Applying QoS Features Using the MQC" module

Supported Standards MIBs and RFCs

Standards

No new or modified standards are supported by this feature.

MIBs

No new or modified standards are supported by this feature.

To locate and download MIBs for selected platforms, Cisco IOS XE Software releases, and feature sets, use Cisco MIB Locator found at the following URL:

<http://www.cisco.com/go/mibs>

RFCs

No new or modified RFCs are supported by this feature.

Prerequisites

To use this feature, you should be familiar with the following:

- Access control lists
- Bandwidth management
- CBWFQ

Configuration Tasks

Defining Class Maps

SUMMARY STEPS

1. Router(config)# **class-map**class-map-name
2. Do one of the following:
 - Router(config-cmap)# **match access-group** {*access-group* | *name access-group-name*}

DETAILED STEPS

	Command or Action	Purpose
Step 1	Router(config)# class-map class-map-name	Specifies the name of the class map to be created.
Step 2	Do one of the following: <ul style="list-style-type: none"> • Router(config-cmap)# match access-group {<i>access-group</i> <i>name access-group-name</i>} Example: <pre>Router(config-cmap)# match input-interface interface-name</pre> Example: or Example:	Specifies the name of the access control list (ACL) against whose contents packets are checked to determine if they belong to the class. Specifies the name of the input interface used as a match criterion against which packets are checked to determine if they belong to the class. Specifies the name of the protocol used as a match criterion against which packets are checked to determine if they belong to the class.

	Command or Action	Purpose
	Router(config-cmap) # match protocol <i>protocol</i>	

Configuring Class Policy in the Policy Map

To configure a policy map and create class policies that make up the service policy, begin with the **policy-map** command to specify the policy map name. Then use one or more of the following commands to configure the policy for a standard class or the default class:

- **priority**
- **bandwidth**
- **queue-limit** or **random-detect**
- **fair-queue** (for class-default class only)

For each class that you define, you can use one or more of the commands listed to configure the class policy. For example, you might specify bandwidth for one class and both bandwidth and queue limit for another class.

The default class of the policy map (commonly known as the class-default class) is the class to which traffic is directed if that traffic does not satisfy the match criteria of the other classes defined in the policy map.

You can configure class policies for as many classes as are defined on the router, up to the maximum of 64. However, the total amount of bandwidth allocated for all classes in a policy map must not exceed the minimum committed information rate (CIR) configured for the virtual circuit (VC) minus any bandwidth reserved by the **frame-relay voice bandwidth** and **frame-relay ip rtp priority** commands. If the minimum CIR is not configured, the bandwidth defaults to one half of the CIR. If all of the bandwidth is not allocated, the remaining bandwidth is allocated proportionally among the classes on the basis of their configured bandwidth.

To configure class policies in a policy map, perform the tasks described in the following sections. The task in the first section is required; the tasks in the remaining sections are optional.

Configuring Class Policy for a Priority Queue

SUMMARY STEPS

1. Router(config)# **policy-map** policy-map
2. Router(config-cmap)# **class** class-name
3. Router(config-pmap-c)# **priority** bandwidth-kbps

DETAILED STEPS

	Command or Action	Purpose
Step 1	Router(config)# policy-map policy-map	Specifies the name of the policy map to be created or modified.
Step 2	Router(config-cmap)# class class-name	Specifies the name of a class to be created and included in the service policy.

	Command or Action	Purpose
Step 3	Router(config-pmap-c)# priority bandwidth-kbps	Creates a strict priority class and specifies the amount of bandwidth, in kbps, to be assigned to the class.

Configuring Class Policy Using a Specified Bandwidth

SUMMARY STEPS

1. Router(config)# **policy-map** policy-map
2. Router(config-cmap)# **class** class-name
3. Router(config-pmap-c)# **bandwidth** bandwidth-kbps

DETAILED STEPS

	Command or Action	Purpose
Step 1	Router(config)# policy-map policy-map	Specifies the name of the policy map to be created or modified.
Step 2	Router(config-cmap)# class class-name	Specifies the name of a class to be created and included in the service policy.
Step 3	Router(config-pmap-c)# bandwidth bandwidth-kbps	Specifies the amount of bandwidth to be assigned to the class, in kbps, or as a percentage of the available bandwidth. Bandwidth must be specified in kbps or as a percentage consistently across classes. (Bandwidth of the priority queue must be specified in kbps.)

Configuring the Class-Default Class Policy

SUMMARY STEPS

1. Router(config)# **policy-map** policy-map
2. Router(config-cmap)# **class class-default** *default-class-name*
3. Router(config-pmap-c)# **bandwidth** bandwidth-kbps

DETAILED STEPS

	Command or Action	Purpose
Step 1	Router(config)# policy-map policy-map	Specifies the name of the policy map to be created or modified.
Step 2	Router(config-cmap)# class class-default <i>default-class-name</i>	Specifies the default class so that you can configure or modify its policy.

	Command or Action	Purpose
		<p>Note The class-default class is used to classify traffic that does not fall into one of the defined classes. Even though the class-default class is predefined when you create the policy map, you still have to configure it. If a default class is not configured, then traffic that does not match any of the configured classes is given best-effort treatment, which means that the network will deliver the traffic if it can, without any assurance of reliability, delay prevention, or throughput.</p>
Step 3	<p>Router(config-pmap-c)# bandwidth bandwidth-kbps</p> <p>Example:</p> <p>Example:</p> <p>or</p> <p>Example:</p> <p>Example:</p> <pre>Router (config-pmap-c) # fair-queue [number-of-dynamic-queues]</pre>	<p>Specifies the amount of bandwidth, in kbps, to be assigned to the class. Specifies the number of dynamic queues to be reserved for use by flow-based WFQ running on the default class. The number of dynamic queues is derived from the bandwidth of the interface.</p>

Attaching the Service Policy

SUMMARY STEPS

1. Router(config)# **interfacetype** number
2. Router(config-if)# **service-policy output**policy-map

DETAILED STEPS

	Command or Action	Purpose
Step 1	Router(config)# interfacetype number	Specifies the interface using the LLQ for IPsec encryption engines.
Step 2	Router(config-if)# service-policy output policy-map	Attaches the specified service policy map to the output interface and enables LLQ for IPsec encryption engines.

Verifying Configuration of Policy Maps and Their Classes

SUMMARY STEPS

1. Router# `show frame-relay pvc dlc`
2. Router# `show policy-map interface interface-name`
3. Router# `show policy-map interface interface-name dlc dlc`

DETAILED STEPS

	Command or Action	Purpose
Step 1	Router# <code>show frame-relay pvc dlc</code>	Displays statistics about the PVC and the configuration of classes for the policy map on the specified data-link connection identifier (DLCI).
Step 2	Router# <code>show policy-map interface interface-name</code>	When LLQ is configured, displays the configuration of classes for all policy maps.
Step 3	Router# <code>show policy-map interface interface-name dlc dlc</code>	When LLQ is configured, displays the configuration of classes for the policy map on the specified DLCI.

Monitoring and Maintaining LLQ for IPsec Encryption Engines

SUMMARY STEPS

1. Router# `show crypto eng qos`

DETAILED STEPS

	Command or Action	Purpose
Step 1	Router# <code>show crypto eng qos</code>	Displays quality of service queueing statistics for LLQ for IPsec encryption engines.

Configuration Examples

LLQ for IPsec Encryption Engines Example

In the following example, a strict priority queue with a guaranteed allowed bandwidth of 50 kbps is reserved for traffic that is sent from the source address 10.10.10.10 to the destination address 10.10.10.20, in the range of ports 16384 through 20000 and 53000 through 56000.

First, the following commands configure access list 102 to match the desired voice traffic:

```
Router(config)# access-list 102 permit udp host 10.10.10.10 host 10.10.10.20 range 16384 20000
```

```
Router(config)# access-list 102 permit udp host 10.10.10.10 host 10.10.10.20 range 53000 56000
```

Next, the class map voice is defined, and the policy map called policy1 is created; a strict priority queue for the class voice is reserved, a bandwidth of 20 kbps is configured for the class bar, and the default class is configured for WFQ. The service-policy command then attaches the policy map to the fas0/0.

```
Router(config)# class-map voice
Router(config-cmap)# match access-group 102
Router(config-cmap)# exit
Router(config)# policy-map policy1
Router(config-pmap)# class voice
Router(config-pmap-c)# priority 50
Router (config-cmap-c)# exit
Router(config-pmap)# class bar
Router(config-pmap-c)# bandwidth 20
Router(config-cmap-c)# exit
Router(config-pmap)# class class-default
Router(config-pmap-c)# fair-queue
Router(config-cmap-c)# exit
Router(config-cmap)# exit
Router(config)# interface fastethernet0/0/0
Router(config-if)# service-policy output policy1
```