



Multi-Level Priority Queues

The Multi-Level Priority Queues (MPQ) feature allows you to configure multiple priority queues for multiple traffic classes by specifying a different priority level for each of the traffic classes in a single service policy map. You can configure multiple service policy maps per device. Having multiple priority queues enables the device to place delay-sensitive traffic (for example, voice) on the outbound link before delay-insensitive traffic. As a result, high-priority traffic receives the lowest latency possible on the device.

- [Finding Feature Information, on page 1](#)
- [Prerequisites for Multi-Level Priority Queues, on page 1](#)
- [Restrictions for Multi-Level Priority Queues, on page 1](#)
- [Information About Multi-Level Priority Queues, on page 2](#)
- [How to Configure Multi-Level Priority Queues, on page 4](#)
- [Configuration Examples for Multi-Level Priority Queues, on page 6](#)
- [Additional References for Multi-Level Priority Queues, on page 7](#)
- [Feature Information for Multi-Level Priority Queues, on page 8](#)

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest caveats and feature information, see [Bug Search Tool](#) and the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the feature information table.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Prerequisites for Multi-Level Priority Queues

You must configure traffic classes using the **class-map** command.

Restrictions for Multi-Level Priority Queues

- You cannot configure both the **priority** command and the **priority level** command for two different classes in the same policy map. For example, the device does not accept the following configuration:

```

Device> enable
Device# configure terminal
Device(config)# policy-map Map1
Device(config-pmap)# class Bronze
Device(config-pmap-c)# priority level 1
Device(config-pmap-c)# exit
Device(config-pmap)# class Gold
Device(config-pmap-c)# priority 1000
Device(config-pmap-c)# end

```



Note The **priority rate** command is not supported, instead you can use *priority cir* command on the Cisco RSP3 Module.

- You cannot specify the same priority level for two different classes in the same policy map. For example, the device does not accept the following configuration:
- You cannot configure the default queue as a priority queue at any level.
- You cannot configure the **bandwidth** command and multi-level priority queues on the same class. For example, the device rejects the following configuration:

```

policy-map P1
class C1
  priority level 1
  bandwidth 200

```

- You cannot configure the **shape** command and multi-level priority queues on the same class. For example, the device rejects the following configuration:

```

policy-map P1
class C1
  priority level 1
  shape average 56000

```

- To convert a one-level (flat) service policy with multiple priority queues configured to a hierarchical multi-level priority queues service policy, you must first detach the flat service policy from the interface using the **no service-policy** command and then add a child policy map to it.
- We recommend not to use MPQ at the logical level, that is, under the class-map containing match for the VLANs .

Information About Multi-Level Priority Queues

Benefits of Multi-Level Priority Queues

The MPQ feature allows you to configure multiple priority queues for multiple traffic classes by specifying a different priority level for each of the traffic classes in a single service policy map. You can configure multiple service policy maps per device.

Previously, devices could have only one strict priority queue per policy map for all delay-sensitive traffic—the device associated all priority traffic with this one single priority queue. However, having only one priority

queue can cause significant delay in delivering traffic, especially if the device sends high-priority traffic (for example, voice) behind low-priority traffic (for example, video). Using class-based weighted fair queueing (CBWFQ) to reduce delay by heavily weighting one queue can affect the granularity of bandwidth allocations to the other queues. The MPQ feature addresses these issues and improves latency.

Functionality of Multi-Level Priority Queues

The **priority** command is used to specify that a class of traffic has latency requirements with respect to other classes. For multiple priority queues, you can use the **priority level** command to configure a level of priority service on a class in a policy map. The device places traffic with a high-priority level on the outbound link ahead of traffic with a low-priority level. High-priority packets, therefore, are not delayed behind low-priority packets.

The device services the high-level priority queues until empty before servicing the next-level priority queues and non-priority queues. While the device services a queue, the service rate is as fast as possible and is constrained only by the rate of the underlying link or parent node in a hierarchy. If a rate is configured and the device determines that a traffic stream has exceeded the configured rate, the device drops the exceeding packets during periods of congestion. If the link is currently not congested, the device places the exceeding packets onto the outbound link.

When configuring MPQ on different traffic classes in a policy map, you must specify different priority levels for the traffic classes. For example, configure one traffic class to have priority level 2 and another class to have priority level 1.



Note In a hierarchical MPQ configuration in which *all* traffic is sent through the level-2 priority queue only, the traffic sent through the level-2 priority queue receives the same treatment as the traffic sent through the level-1 priority queue.

You cannot configure the **priority** command and the **priority level** command on different classes in the same policy map.

Traffic Policing and Multi-Level Priority Queues

Bandwidth guarantees can be given to other classes only if traffic policing is enabled on the priority queue.

Using the **priority** and **police** commands, multi-level priority queues can be configured to police traffic in one of the following ways:

- Conditional traffic policing, for example:

```
policy-map my_policy
  class voice
    priority 400000 <<< Priority queue conditionally policed to 400M
  class gold
    bandwidth 400000 <<< 400M minimum guaranteed to class gold
```

With conditional traffic policing on the queue, you run the risk of sudden degradation in priority service when an interface becomes congested. You can go from an instance of a priority class using the entire link to suddenly traffic being policed to the configured value. You need to know the available bandwidth and use some form of admission control to ensure that your offered loads do not exceed the available bandwidth.



Note With the conditional policing, traffic policing does not engage unless the interface is congested.

- Unconditional traffic policing, for example:

```
policy-map my_policy
  class voice
    priority <<< Indicates priority scheduling
    police 40000000 <<< Traffic policed to 400M
  class gold
    bandwidth 400000 <<<400M minimum guaranteed to class gold
```

The priority class is configured with an “always on” (unconditional) policer. The priority class is always policed to the configured value regardless of whether the interface is congested. The advantage of an unconditional policer is that you always know how much priority traffic will be offered to the downstream devices, thus making your bandwidth planning much simpler. This is the recommended choice.

- Absolute priority queue (no traffic policing)

If traffic policing is not configured, the priority traffic may consume the entire interface bandwidth.

How to Configure Multi-Level Priority Queues

Configuring Multi-Level Priority Queues in a Policy Map

Before you begin

The traffic classes, class maps, and policy maps must exist.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **policy-map** *policy-name*
4. **class** *class-name*
5. **priority level** *level*
6. **police cir** *bps*
7. **police cir percent** *percent*
8. **end**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example:	Enables privileged EXEC mode. • Enter your password if prompted.

	Command or Action	Purpose
	Device> enable	
Step 2	configure terminal Example: Device# configure terminal	Enters global configuration mode.
Step 3	policy-map <i>policy-name</i> Example: Device(config)# policy-map Premium	Creates or modifies a policy map and enters policy-map configuration mode. <ul style="list-style-type: none"> • Enter the name of the policy map.
Step 4	class <i>class-name</i> Example: Device(config-pmap)# class business	Specifies a traffic class and enters policy-map class configuration mode. <ul style="list-style-type: none"> • Enter the name of a previously configured traffic class.
Step 5	priority level <i>level</i> Example: Device(config-pmap-c)# priority level 2	Assigns priority to a traffic class at the priority level specified. <ul style="list-style-type: none"> • Enter the level of priority assigned to the priority class. Valid values are 1 (high priority) and 2 (low priority). The default is 1. <p>Note Do not specify the same priority level for two different classes in the same policy map.</p>
Step 6	police cir <i>bps</i> Example: Device(config-pmap-c)# police cir 8000	(Optional) Configures traffic policing based on a bits per second (bps) rate. <ul style="list-style-type: none"> • cir is the committed information rate and is based on the interface shape rate. This keyword indicates an average rate at which the policer meters traffic. • bps specifies the average rate in bits per second (bps). Valid values are from 8000 to 2488320000 bps.
Step 7	police cir percent <i>percent</i> Example: Device(config-pmap-c)# police cir percent 20	(Optional) Configures traffic policing based on a percentage of bandwidth available on the interface. <ul style="list-style-type: none"> • cir is the committed information rate and is based on the interface shape rate. This keyword indicates an average rate at which the policer meters traffic. • percent <i>percent</i> indicates to use the percentage of available bandwidth specified in percent to calculate the CIR. Valid values are from 1 to 100.

	Command or Action	Purpose
Step 8	end Example: Device(config-pmap-c)# end	(Optional) Exits policy-map class mode.

Verifying Multi-Level Priority Queues

Step 1

enable

Example:

```
Device> enable
```

Enables privileged EXEC mode.

- Enter your password if prompted.

Step 2

show policy-map interface *type number*

Example:

Displays the packet statistics of all classes that are configured for all service policies either on the specified interface or subinterface or on a specific PVC on the interface.

- Enter the interface type and number.

Step 3

exit

Example:

```
Device# exit
```

(Optional) Exits privileged EXEC mode.

Configuration Examples for Multi-Level Priority Queues

Example: Configuring Multi-Level Priority Queues

The following example shows how to configure multiple priority queues with 2 level priority. The policy map named Business has two traffic classes: Bronze and Gold. Bronze traffic has a level 2 (low) priority, whereas Gold traffic has a level 1 (high) priority. To prevent bandwidth starvation of Bronze traffic, the Gold traffic is policed at 30 percent of the interface bandwidth.



Note Although a policer is not required, configure policing for priority traffic to prevent bandwidth starvation of low-priority traffic. When policing is configured, the traffic rate is policed at the police rate for each of the priority queues.

The following example shows how to configure multiple priority queues with 7 level priority. The policy map named Business has seven traffic classes: Platinum, Gold, Silver, Bronze, Iron, Aluminium, and Steel. Steel traffic has a level 7 (lowest) priority, whereas Platinum traffic has a level 1 (highest) priority. To prevent bandwidth starvation, the Platinum and Gold traffic is policed at 30 percent and 20 percent respectively, of the interface bandwidth.

Example: Verifying Multi-Level Priority Queues

The following is partial sample output from the `show policy-map interface` command.

```
Device# show policy-map interface serial2/1/0

Serial2/1/0
Service-policy output: P1
Queue statistics for all priority classes:
.
.
.
Class-map: Gold (match-all)
 0 packets, 0 bytes    /*Updated for each priority level configured.*/
 5 minute offered rate 0 bps, drop rate 0 bps
Match: ip precedence 2
Priority: 0 kbps, burst bytes 1500, b/w exceed drops: 0
Priority Level 2:
 0 packets, 0 bytes
```

Additional References for Multi-Level Priority Queues

Related Documents

Related Topic	Document Title
QoS commands: complete command syntax, command modes, command history, defaults, usage guidelines, and examples	<i>Cisco IOS Quality of Service Solutions Command Reference</i>
Priority queues, creating classes, class maps, and policy maps	“Applying QoS Features Using the MQC” module

Technical Assistance

Description	Link
The Cisco Support and Documentation website provides online resources to download documentation, software, and tools. Use these resources to install and configure the software and to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password.	http://www.cisco.com/cisco/web/support/index.html

Feature Information for Multi-Level Priority Queues

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Table 1: Feature Information for Multi-Level Priority Queues

Feature Name	Releases	Feature Information
Multi-Level Priority Queues	Cisco IOS XE Fuji 16.8.x	You can now configure MPQ till priority level 7.

Feature Name	Releases	Feature Information
Multi-Level Priority Queues	Cisco IOS Release XE 2.1 Cisco IOS Release XE 3.7S Cisco IOS Release XE 3.16	<p>The MPQ feature allows you to configure multiple priority queues for multiple traffic classes by specifying a different priority level for each of the traffic classes in a single service policy map. You can configure multiple service policy maps per device. Having multiple priority queues enables the device to place delay-sensitive traffic (for example, voice) on the outbound link before delay-insensitive traffic. As a result, high-priority traffic receives the lowest latency possible on the device.</p> <p>In Cisco IOS XE Release 2.1, this feature was implemented on the Cisco ASR 1000 Series Routers.</p> <p>In Cisco IOS XE Release 3.7S, support was added for the Cisco ASR 903 Router.</p> <p>In Cisco IOS XE Release 3.16, support was added for the Cisco ASR 900 RSP3 Module.</p> <p>The following commands were introduced or modified: priority level, show policy-map interface.</p>

