

AVC Configuration

Revised: July 2014

This chapter addresses Cisco AVC configuration and includes the following topics:

- Recent Configuration Enhancements and Limitations, page 4-2
- Unified Policy CLI, page 4-2
- Metric Producer Parameters, page 4-3
- Reacts, page 4-4
- NetFlow/IPFIX Flow Monitor, page 4-4
- NetFlow/IPFIX Flow Record, page 4-5
- QoS Metrics: Cisco IOS Platforms, page 4-13
- QoS Metrics: Cisco IOS XE Platforms, page 4-18
- Connection/Transaction Metrics, page 4-24
- Easy Performance Monitor, page 4-27
- CLI Field Aliases, page 4-36
- Identifying the Monitored Interface, page 4-37
- Configuration Examples, page 4-37

Recent Configuration Enhancements and Limitations

Table 4-1 describes configuration features added in recent releases, and limitations.

Table 4-1 Configuration Features and Enhancements

Feature	IOS Platforms	IOS XE Platforms	Information/Limitations
Export Spreading	Added in IOS 15.4(1)T	Added in IOS XE 3.11S	For information, see NetFlow/IPFIX Flow Monitor, page 4-4
Easy Performance Monitor "express" method of provisioning monitors	Added in IOS 15.4(1)T	Added in IOS XE 3.10S	For information, see Easy Performance Monitor, page 4-27
Support for configuring 40 fields for each FNF record	Not applicable	Added in IOS XE 3.10S	For limitations, see: Downgrading to an IOS XE Version that Does Not Support More than 32 Fields, page 6-4
CLI field aliases	Added in IOS 15.4(1)T	Added in IOS XE 3.10S	For limitations, see: Removing Aliases before Downgrading from Cisco IOS 15.4(1)T / Cisco IOS XE 3.10 or Later, page 6-4

Unified Policy CLI

Cisco IOS Platforms	Cisco IOS XE Platforms
Added in release 15.4(1)T	Added in release 3.8S

Monitoring a configuration is done using performance-monitor unified monitor and policy.

Configuration Format

```
policy-map type performance-monitor <policy-name>
  [no] parameter default account-on-resolution
  class <class-map name>
    flow monitor <monitor-name> [sampler <sampler name>]
    [sampler <sampler name>]
    monitor metric rtp
```

Usage Guidelines

- Supports:
 - Multiple flow monitors under a class-map
 - Up to 5 monitors per attached class-map
 - Up to 256 classes per performance-monitor policy
- No support for:
 - Hierarchical policy
 - Inline policy
- Metric producer parameters are optional.

• Account-on-resolution (AOR) configuration causes all classes in the policy-map to work in AOR mode, which delays the action until the class-map results are finalized (the application is determined by NBAR2).

Attaching a Policy

Attach a policy to the interface using following command:

```
interface <interface-name>
    service-policy type performance-monitor <policy-name> {input|output}
```

Displaying Policy Map Performance Monitor Data

Display policy map performance monitor data using the command below. Example output is shown here.

- On Cisco IOS platforms, the data is reported once per flow, either for the first packet of the flow or for the packet of resolution if AOR is enabled.
- On Cisco IOS XE platforms, the data is reported for all packets that match the policy map.

```
Router# show policy-map type performance-monitor interface
Ethernet1/0
```

Service-policy performance-monitor input: policy

Class-map: classmap (match-all) 20 packets, 1280 bytes 5 minute offered rate 0000 bps, drop rate 0000 bps Match: access-group name seawolf_acl_ipv4_tcp

```
Class-map: class-default (match-any)
0 packets, 0 bytes
5 minute offered rate 0000 bps, drop rate 0000 bps
Match: any
```

Service-policy performance-monitor output: policy

```
Class-map: classmap (match-all)
20 packets, 1160 bytes
5 minute offered rate 0000 bps, drop rate 0000 bps
Match: access-group name seawolf_acl_ipv4_tcp
```

```
Class-map: class-default (match-any)
0 packets, 0 bytes
5 minute offered rate 0000 bps, drop rate 0000 bps
Match: any
```

Metric Producer Parameters

Metric producer-specific parameters are optional and can be defined for each metric producer for each class-map.

Configuration Format

```
monitor metric rtp
  clock-rate {type-number| type-name | default} rate
  max-dropout number
  max-reorder number
  min-sequential number
  ssrc maximum number
```

Reacts

The **react** CLI defines the alerts applied to a flow monitor. The **react** CLI has a performance impact on the router. When possible, send the monitor records directly to the Management and Reporting system and apply the network alerts in the Management and Reporting system.

```
<u>Note</u>
```

Cisco IOS XE Platforms: Applying reacts on the device requires punting the monitor records to the route processor (RP) for alert processing. To avoid the performance reduction of punting the monitor records to the RP, send the monitor records directly to the Management and Reporting system, as described above.

Configuration Format

```
react <id> [media-stop|mrv|rtp-jitter-average|transport-packets-lost-rate]
```

NetFlow/IPFIX Flow Monitor

Cisco IOS Platforms	Cisco IOS XE Platforms
export-spread feature added in IOS 15.4(1)T	export-spread feature added in IOS XE 3.11S

Flow monitor defines monitor parameters, such as record, exporter, and other cache parameters.

Configuration Format: Cisco IOS Platforms

```
flow monitor type performance-monitor <monitor-name>
  record <name | default-rtp | default-tcp>
  exporter <exporter-name>
  history size <size> [timeout <interval>]
  cache entries <num>
  cache timeout {{active | inactive} <value> | synchronized <value> {export-spread
  <interval>}}
  cache type {permanent | normal | immediate}
  react-map <react-map-name>
```

Configuration Format: Cisco IOS XE Platforms

```
flow monitor type performance-monitor <monitor-name>
  record <name | default-rtp | default-tcp>
  exporter <exporter-name>
  history size <size> [timeout <interval>]
  cache entries <num>
  cache timeout {{active | inactive} <value> | synchronized <value>
  {export-spread <interval>} event transaction end}
  cache type {permanent | normal | immediate}
  react-map <react-map-name>
```

Usage Guidelines

- The **react-map** CLI is allowed under the class in the policy-map. In this case, the monitor must include the exporting of the class-id in the flow record. The route processor (RP) correlates the class-id in the monitor with the class-id where the react is configured.
- Applying history or a react requires punting the record to the RP.

- Export on the "event transaction end" is used to export the records when the connection or transaction is terminated. In this case, the records are not exported based on timeout. Exporting on the event transaction end should be used when detailed connection/transaction granularity is required, and has the following advantages:
 - Sends the record close to the time that it has ended.
 - Exports only one record on true termination.
 - Conserves memory in the cache and reduces the load on the Management and Reporting system.
 - Enables exporting multiple transactions of the same flow. (This requires a protocol pack that supports multi-transaction.)
- Export spreading—In a case of synchronized cache, all network devices export records from the
 monitor cache at the same time. If multiple network devices are configured with the same monitor
 interval and synchronized cache, the collector may receive all records from all devices at the same
 time, which can impact the collector performance. The export-spreading feature spreads out the
 export over a time interval, which is automatically set by MMA or specified by the user.

NetFlow/IPFIX Flow Record

The flow record defines the record fields. With each Cisco IOS release, the Cisco AVC solution supports a more extensive set of metrics.

The sections that follow list commonly used AVC-specific fields organized by functional groups. These sections do not provide detailed command reference information, but highlight important usage guidelines.

In addition to the fields described below, a record can include any NetFlow field supported by the platform.

A detailed description of NetFlow fields appears in the *Cisco IOS Flexible NetFlow Command Reference*.

Note

On Cisco IOS XE platforms, the record size is limited to 40 fields (key and non-key fields or match and collect fields).

L3/L4 Fields

The following are L3/L4 fields commonly used by the Cisco AVC solution.

[collect	match]	connection [client server] [ipv4 ipv6] address
[collect	match]	connection [client server] transport port
[collect	match]	[ipv4 ipv6] [source destination] address
[collect	match]	transport [source-port destination-port]
[collect	match]	[ipv4 ipv6] version
[collect	match]	[ipv4 ipv6] protocol
[collect	match]	routing vrf [input output]
[collect	match]	[ipv4 ipv6] dscp
[collect	match]	ipv4 ttl
[collect	match]	ipv6 hop-limit
collect		transport tcp option map
collect		<pre>transport tcp window-size [minimum maximum sum]</pre>
collect		transport tcp maximum-segment-size

Usage Guidelines

The client is determined according to the initiator of the connection.

The client and server fields are bi-directional. The source and destination fields are uni-directional.

L7 Fields

The following are L7 fields commonly used by the Cisco AVC solution.

```
[collect | match] application name [account-on-resolution]
collect application http url
collect application http uri statistics
collect application http host
collect application http user-agent
collect application http referer
collect application rtsp host-name
collect application smtp server
collect application smtp sender
collect application pop3 server
collect application nntp group-name
collect application sip source
collect application sip destination
```

Usage Guidelines

- The application ID is exported according to RFC-6759.
- Account-On-Resolution configures FNF to collect data in a temporary memory location until the record key fields are resolved. After resolution of the record key fields, FNF combines the temporary data collected with the standard FNF records. Use the **account-on-resolution** option when the field used as a key is not available at the time that FNF receives the first packet.

The following limitations apply when using Account-On-Resolution:

- Flows ended before resolution are not reported.
- On Cisco IOS XE platforms, FNF packet/octet counters, timestamp, and TCP performance metrics are collected until resolution. All other field values are taken from the packet that provides resolution or the following packets.
- For information about extracted fields, including the formats in which they are exported, see: *Cisco Application Visibility and Control Field Definition Guide for Third-Party Customers*

Interfaces and Directions

The following are interface and direction fields commonly used by the Cisco AVC solution:

```
[collect | match] interface [input|output]
[collect | match] flow direction
collect connection initiator
```

Counters and Timers

The following are counter and timer fields commonly used by the Cisco AVC solution.



Two aliases provide backward compatibility for configurations created on earlier releases:

- connection client bytes transport long is an alias for connection client bytes long.
- connection server bytes transport long is an alias for connection server bytes long.

```
collect connection server counter bytes network long
collect connection server counter bytes transport long
collect connection server counter bytes long
collect connection server counter packets long
collect connection client counter bytes network long
collect connection client counter bytes transport long
collect connection client counter bytes long
collect connection client counter packets long
collect counter bytes rate
collect connection server counter responses
collect connection client counter packets retransmitted
collect connection transaction duration {sum, min, max}
collect connection transaction counter complete
collect connection new-connections
collect connection sum-duration
collect timestamp sys-uptime first
collect timestamp sys-uptime last
```

On Cisco IOS platforms:

collect counter packets long collect counter bytes long

On Cisco IOS XE platforms:

collect counter packets [long]
collect counter bytes [long]

TCP Performance Metrics

The following are fields commonly used for TCP performance metrics by the Cisco AVC solution:

connection	delay	network	to-server	{sum,	min,	max}
connection	delay	network	to-client	{sum,	min,	max}
connection	delay	network	client-to-server	{sum,	min,	max}
connection	delay	response	e to-server	{sum,	min,	max}
connection	delay	response	e to-server histogr	ram		
			[bucket1	bucket	:7 :	late]
connection	delay	response	e client-to-server	{sum,	min,	max}
$\operatorname{connection}$	delay	applicat	ion	{sum,	min,	max}
	connection connection connection connection connection	connection delay connection delay connection delay connection delay connection delay connection delay	connection delay network connection delay network connection delay network connection delay response connection delay response connection delay applicat	connection delay network to-server connection delay network to-client connection delay network client-to-server connection delay response to-server connection delay response to-server histogr [bucket1 connection delay response client-to-server connection delay application	connection delay network to-server {sum, connection delay network to-client {sum, connection delay network client-to-server {sum, connection delay response to-server histogram [bucket1 bucket connection delay response client-to-server {sum, connection delay application {sum,	connection delay network to-server{sum, min,connection delay network to-client{sum, min,connection delay network client-to-server{sum, min,connection delay response to-server{sum, min,connection delay response to-server histogram[bucket1 bucket7 1connection delay response client-to-server{sum, min,connection delay response client-to-server {sum, min,connection delay response client-to-server {sum, min,connection delay application

Usage Guidelines

The following limitations apply to TCP performance metrics:

- All TCP performance metrics must observe bi-directional traffic.
- The policy-map must be applied in both directions.

Figure 4-1 provides an overview of network response time metrics.

Figure 4-1 Network Response Times



Figure 4-2 provides details of network response time metrics.





Media Performance Metrics

The following are fields commonly used for media performance metrics by the Cisco AVC solution:

[collect	match] match transport rtp ssrc
collect	transport rtp payload-type
collect	transport rtp jitter mean sum
collect	<pre>transport rtp jitter [minimum maximum]</pre>
collect	transport packets lost counter
collect	transport packets expected counter
collect	transport packets lost counter
collect	transport packets lost rate
collect	transport event packet-loss counter
collect	counter packets dropped
collect	application media bytes counter
collect	application media bytes rate
collect	application media packets counter
collect	application media packets rate
collect	application media event
collect	monitor event

Usage Guidelines

Some of the media performance fields require punt to the route processor (RP). For more information, see *Cisco Application Visibility and Control Field Definition Guide for Third-Party Customers*.

L2 Information

The following are L2 fields commonly used by the Cisco AVC solution:

[collect | match] datalink [source-vlan-id | destination-vlan-id] [collect | match] datalink mac [source | destination] address [input | output]

WAAS Interoperability

Cisco IOS Platforms	Cisco IOS XE Platforms
Not available	Available

The following are WAAS fields commonly used by the Cisco AVC solution:

[collect | match] services waas segment [account-on-resolution] collect services waas passthrough-reason

Usage Guidelines

Account-On-Resolution configures FNF to collect data in a temporary memory location until the record key fields are resolved. After resolution of the record key fields, FNF combines the temporary data collected with the standard FNF records. Use this option (**account-on-resolution**) when the field used as a key is not available at the time that FNF receives the first packet.

The following limitations apply when using Account-On-Resolution:

- Flows ended before resolution are not reported.
- FNF packet/octet counters, timestamp and TCP performance metrics are collected until resolution. All other field values are taken from the packet that provides resolution or the following packets.

Classification

The following are classification fields commonly used by the Cisco AVC solution:

[collect | match] policy performance-monitor classification hierarchy

Usage Guidelines

Use this field to report the matched class for the performance-monitor policy-map.

NetFlow/IPFIX Option Templates

NetFlow option templates map IDs to string names and descriptions:

```
flow exporter my-exporter
  export-protocol ipfix
  template data timeout <timeout>
```

Cisco Application Visibility and Control User Guide for IOS Release 15.4(3)T and IOS XE Release 3.13S

```
option interface-table timeout <timeout>
option vrf-table timeout <timeout>
option sampler-table timeout <timeout>
option application-table timeout <timeout>
option application-attributes timeout <timeout>
option sub-application-table timeout <timeout>
option c3pl-class-table timeout <timeout>
option c3pl-policy-table timeout <timeout>
```

NetFlow/IPFIX Show commands

Use the following commands to show NetFlow/IPFIX information:

```
show flow monitor type performance-monitor [<name> [cache [raw]]]
show flow record type performance-monitor
show policy-map type performance-monitor [<name> | interface]
```

Customizing NBAR Attributes

Use the following commands to customize the NBAR attributes:

```
[no] ip nbar attribute-map <attribute-map-name>
  attribute category <category>
  attribute sub-category <sub-category>
  attribute application-group <application-group>
  attribute tunnel <tunnel-info>
  attribute encrypted <encrypted-info>
  attribute p2p-technology <p2p-technology-info>
[no] ip nbar attribute-set <protocol-name> <attribute-map-name>
```

These commands support all attributes defined by the NBAR2 Protocol Pack, including custom-category, custom-sub-category, and custom-group available in Protocol Pack 3.1 and later.

Customizing Attribute Values

Cisco IOS Platforms	Cisco IOS XE Platforms
Added in IOS 15.4(1)T	Added in IOS XE 3.11

Background

Attribute maps enable users to map various attribute values to protocols, changing the built-in grouping of protocols. The "custom attributes value" feature enables users to add new values to existing attributes.

For example, when using custom protocols to define enterprise specific protocols, it can be useful to classify the custom protocols as a new group (example: my-db-protocols-group). Beginning in the current release, new values can be defined for:

- category
- sub-category
- application-group

Customized attributes can be used for QoS matching, and the customized values appear in AVC reports.

Future Protocol Pack versions may enable defining additional attributes. For information about viewing which attributes can be customized and how many new groups can be defined, see Additional Usage Guidelines, page 4-12.

Basic Usage

CLI

```
[no] ip nbar attribute <attribute name> custom <user-defined value> [<user-defined help
string>]
```

Backward Compatibility

Previous releases of AVC included the following pre-defined attribute values, which could not be user-customized:

- For the category attribute: custom-category
- For the sub-category attribute: custom-sub-category
- For the application-group attribute: custom-application-group

To provide backward compatibility with existing configurations, the current release supports configurations that were created for earlier releases and that include one or more of these attributes.

Examples—Defining Values

The following examples define custom values for the category and sub-category attributes, and provide the optional explanatory help string:

```
ip nbar attribute category custom dc_backup_category "Data center backup traffic"
ip nbar attribute sub-category custom hr_sub_category "HR custom applications traffic"
ip nbar attribute application-group custom Home_grown_finance_group "our finance tools
network traffic"
```

Example—Removing Custom Values

The following example removes the custom value ("XYZ-app-group") that had been assigned for the application-group attribute:

no ip nbar attribute application-group custom XYZ-app-group

Additional Usage Guidelines

Help

The following command provides help, indicating which attributes can have custom values.

ip nbar attribute ?

Displaying Customizable Attributes and Custom Values

The following command indicates which attributes can be defined with custom values (depends on the Protocol Pack version installed on the device), and displays the currently defined custom values.

show ip nbar attribute-custom

Customizing NBAR Protocols

Use the following commands to customize NBAR protocols and assign a protocol ID. A protocol can be matched based on HTTP URL/Host or other parameters:

ip nbar custom <protocol-name> [http {[url <urlregexp>] [host <hostregexp>]}] [offset
[format value]] [variable field-name field-length] [source | destination] [tcp | udp]
[range start end | port-number] [id <id>]

Packet Capture Configuration

Cisco IOS Platforms	Cisco IOS XE Platforms
Not available	Available

Use the following commands to enable packet capture:

```
policy-map type packet-services <policy-name>
    class <class-name>
        capture limit packet-per-sec <pps> allow-nth-pak <np> duration <duration>
            packets <packets> packet-length <len>
        buffer size <size> type <type>
interface <interface-name>
```

service-policy type packet-services <policy-name> [input|output]

QoS Metrics: Cisco IOS Platforms

This section applies to Cisco IOS platforms. (For information about QoS Metrics configuration for Cisco IOS XE platforms, see QoS Metrics: Cisco IOS XE Platforms, page 4-18.)

This section describes how to configure a performance monitor to include Quality of Service (QoS) metrics.

Background—QoS

QoS configuration is based on **class maps** and **policy maps**. Class maps categorize traffic; policy maps determine how to handle the traffic. Based on the policy identified for each packet, the packet is placed into a specific **QoS queue**, which determines the priority and pattern of transmission. Each queue is identified by a Queue ID field.

For additional information about QoS, see: http://www.cisco.com/go/qos

Г

Exported Metrics

AVC enables configuration of QoS Packet Drop and QoS Class Hierarchy monitors on an interface, using one or more of the following QoS metrics, which can be included in exported performance monitor records:

- Queue ID—Identifies a QoS queue.
- Queue Packet Drops—Packets dropped (on the monitored interface) per QoS queue, due to a QoS policy that limits resources available to a specific type of traffic.
- Class Hierarchy—Class hierarchy of the reported flow. The class hierarchy is determined by the QoS policy map and determines the traffic priority.

QoS Packet Drop Monitor Output in Exported Record

When a QoS Packet Drop monitor is configured, the performance monitor record includes packet drop data per QoS queue in the following format:

Queue id	Queue packet drops
1	100
2	20

QoS Class Hierarchy Information Included in Exported Record

QoS class hierarchy information is exported using the following performance monitor fields:

- Hierarchy policy for each flow (defined by the policy map)
- Queue ID for each flow

This section provides an example of a QoS policy map configuration, followed by the information provided in a performance monitor record for three flows governed by this configuration.

The example includes two levels of policy map hierarchy. In the example, the service-policy P11 statement in **bold** type creates a hierarchy with the P11 policy map as a child of the P1 policy map.



QoS class hierarchy reporting supports a hierarchy of five levels.

Based on the configuration, the following applies to a packet with, for example, a DSCP value of "ef" in the IP header:

- 1. The C1 class definition includes the packet by the match any statement.
- 2. The C11 class definition includes the packet by the match ip dscp of statement.
- **3.** Because the packet is included in class C1, policy map P1 defines the policy for the packet with the shaping average statement.

L

- 4. Policy map P1 invokes policy map P11 for class C1 with the service-policy P11 statement.
- 5. Because the packet is included in class C11, policy map P11 assigns the packet to a queue which has been allocated 10% of remaining bandwidth.

```
class-map match-all C1
   match any
class-map match-all C11
   match ip dscp ef
class-map match-all C12
   match ip dscp cs2
policy-map P11
   class C11
       bandwidth remaining percent 10
    class C12
       bandwidth remaining percent 70
    class class-default
       bandwidth remaining percent 20
policy-map P1
    class C1
       shaping average 16000000
       service-policy P11
```

Table 4-2 shows an example of the information provided in an FNF record for three flows governed by this configuration.

Flow	Hierarchy	Queue id
Flow 1	P1, C1, C11	1
Flow 2	P1, C1, C11	1
Flow 3	P1, C1, C12	2

 Table 4-2
 QoS Class Hierarchy Information in the Flow Record

In Table 4-2, policy and class information is shown using the true policy and class names, such as P1 and C1. However, the record exports policy and class names using numerical identifiers in place of policy and class names. The monitor periodically outputs a "policy option template" and a "class option template" indicating the policy names and class names that correspond to the numbers used in the exported records. These option templates are defined in the exporter configuration, using statements such as the following, which create the option templates and indicate the time interval at which the monitor outputs the option template information:

option c3pl-class-table timeout <timeout>
option c3pl-policy-table timeout <timeout>

Configuration

Configuring a QoS Packet Drop Monitor

A QoS Packet Drop monitor can only export the Queue ID and Queue Packet Drop fields. It cannot be combined with other monitors to export additional fields. At the given reporting interval, the monitor reports only on queues that have dropped packets (does not report value of 0).

Step 1: Create the QoS Packet Drop Monitor

Use the following performance monitor configuration to create a QoS Packet Drop monitor. The process specifies a flow record of type performance monitor named "qos-record" and attaches the record to a monitor of type performance monitor named "qos-monitor." In the steps that follow, the qos-monitor is attached to the desired policy map.

```
flow record type performance monitor qos-record
  match policy qos queue index
  collect policy qos queue drops
flow monitor type performance monitor qos-monitor
  exporter my-exporter
  record qos-record
  cache timeout synchronized 60
```

Step 2: Configure the QoS Policy

The following example shows configuration of a QoS policy map. It includes a hierarchy of three policies: avc, avc-parent, and avc-gparent. Note that avc-gparent includes avc-parent, and avc-parent includes avc.

```
policy-map avc
    class prec4
        bandwidth remaining ratio 3
    class class-default
        bandwidth remaining ratio 1
policy-map avc-parent
    class class-default
        shape average 10000000
        service-policy avc
policy-map avc-gparent
    class class-default
        shape average 10000000
        service-policy avc-parent
```

Step 3: Create the QoS Class Hierarchy Record

To correlate the queue drops collected from the QoS Drops monitor, create a flow record that includes the class hierarchy and Queue id and flow key fields. The data exported by this monitor indicates which flows are assigned to which QoS Queue Id.

The following example configuration creates a QoS class record. The process specifies a record of type performance monitor named "qos-class-record."

```
flow record type performance-monitor gos-class-record
match connection client ipv4 (or ipv6) address
match connection server ipv4 (or ipv6) address
match connection server transport port
collect policy gos class hierarchy
collect policy gos queue id
```

Step 4: Create the QoS Class Hierarchy Monitor

Use the following performance monitor configuration to create a QoS Class Hierarchy monitor. The process specifies a monitor of type "class-hier-monitor." In the steps that follow, the monitor is attached to the desired interface.

```
flow monitor type performance-monitor class-hier-monitor
  exporter my-exporter
  record qos-class-record
  cache timeout synchronized 60
```

Step 5: Create the Performance Monitor Policy

Use the following configuration to create a policy-map that will collect both monitors.

```
policy-map type performance monitor pm-qos
class http
flow monitor qos-monitor
flow monitor qos-class-record
```

Step 6: Attach the Performance Monitor and QoS Policy to an Interface

Use the following to attach the monitor to the desired interface. For *<interface>*, specify the interface type—for example: GigabitEthernet0/2/1

Specify the IP address of the interface in IPv4 or IPv6 format.

```
interface <interface>
    ip address <interface_IP_address>
    service-policy type performance monitor output pm-qos
    service-policy output avc-gparent
```

Verifying the QoS Packet Drop Monitor Configuration

This section provides commands that are useful for verifying or troubleshooting a QoS Packet Drop Monitor configuration.

Verifying that the Monitor is Allocated

Use the following command to verify that the QoS monitor exists:

show flow monitor type performance monitor

Use the following commands to verify additional monitor details:

show flow monitor type performance monitor qos-monitor show flow monitor type performance monitor qos-class-monitor

Verifying QoS Queue IDs, Queue Drops, and Class Hierarchies

The following show command displays the record collected:

show performance monitor history interval all

QoS Metrics: Cisco IOS XE Platforms

This section applies to Cisco IOS XE platforms. (For information about QoS Metrics configuration for Cisco IOS platforms, see QoS Metrics: Cisco IOS Platforms, page 4-13.)

This section describes how to configure Flexible NetFlow (FNF) monitors to include Quality of Service (QoS) metrics.

Background—FNF and QoS

FNF Monitors

Flexible NetFlow (FNF) enables monitoring traffic on router interfaces. FNF monitors are configured for a specific interface to monitor the traffic on that interface. At defined intervals, the monitor sends collected traffic data to a "collector," which can be a component within the router or an external component.

Beginning with Cisco AVC for IOS XE release 3.9, FNF records include new fields for QoS metrics.

QoS

QoS configuration is based on **class maps** and **policy maps**. Class maps categorize traffic; policy maps determine how to handle the traffic. Based on the policy identified for each packet, the packet is placed into a specific **QoS queue**, which determines the priority and pattern of transmission. Each queue is identified by a Queue ID field.

For additional information about QoS, see: http://www.cisco.com/go/qos

Exported Metrics

AVC enables configuration of QoS Packet Drop and QoS Class Hierarchy monitors on an interface, using one or more of the following QoS metrics, which can be included in exported FNF records:

- Queue ID—Identifies a QoS queue.
- Queue Packet Drops—Packets dropped (on the monitored interface) per QoS queue, due to a QoS policy that limits resources available to a specific type of traffic.
- Class Hierarchy—Class hierarchy of the reported flow. The class hierarchy is determined by the QoS policy map and determines the traffic priority.

QoS Packet Drop Monitor Output in Exported Record

When a QoS Packet Drop monitor is configured, the FNF record includes packet drop data per QoS queue in the following format:

Queue id	Queue packet drops
1	100
2	20

QoS Class Hierarchy Information Included in Exported Record

QoS class hierarchy information is exported using the following FNF fields:

- Hierarchy policy for each flow (defined by the policy map)
- Queue ID for each flow

This section provides an example of a QoS policy map configuration, followed by the information provided in an FNF record for three flows governed by this configuration.

The example includes two levels of policy map hierarchy. In the example, the service-policy P11 statement in **bold** type creates a hierarchy with the P11 policy map as a child of the P1 policy map.



QoS class hierarchy reporting supports a hierarchy of five levels.

Based on the configuration, the following applies to a packet with, for example, a DSCP value of "ef" in the IP header:

- 1. The C1 class definition includes the packet by the match any statement.
- 2. The C11 class definition includes the packet by the match ip dscp ef statement.
- **3.** Because the packet is included in class C1, policy map P1 defines the policy for the packet with the shaping average statement.
- 4. Policy map P1 invokes policy map P11 for class C1 with the service-policy P11 statement.
- 5. Because the packet is included in class C11, policy map P11 assigns the packet to a queue which has been allocated 10% of remaining bandwidth.

```
class-map match-all C1
   match any
class-map match-all C11
   match ip dscp ef
class-map match-all C12
   match ip dscp cs2
I
policy-map P11
    class C11
       bandwidth remaining percent 10
    class C12
       bandwidth remaining percent 70
    class class-default
       bandwidth remaining percent 20
policy-map P1
   class C1
       shaping average 16000000
       service-policy P11
```

Table 4-3 shows an example of the information provided in an FNF record for three flows governed by this configuration.

Flow	Hierarchy	Queue id
Flow 1	P1, C1, C11	1
Flow 2	P1, C1, C11	1
Flow 3	P1, C1, C12	2

 Table 4-3
 QoS Class Hierarchy Information in the FNF record

In Table 4-3, policy and class information is shown using the true policy and class names, such as P1 and C1. However, the FNF record exports policy and class names using numerical identifiers in place of policy and class names. The monitor periodically outputs a "policy option template" and a "class option template" indicating the policy names and class names that correspond to the numbers used in the exported FNF records. These option templates are defined in the exporter configuration, using statements such as the following, which create the option templates and indicate the time interval at which the monitor outputs the option template information:

option c3pl-class-table timeout <timeout>
option c3pl-policy-table timeout <timeout>

Configuration

Enabling QoS Metric Collection

Enabling

To enable the QoS metrics collection feature for the platform, enter global configuration mode using configure terminal, then use the following QoS configuration command. The command causes QoS to begin collecting QoS metrics for FNF.



Enabling QoS metrics collection requires resetting all performance monitors on the device.

platform qos performance-monitor

Verifying

To verify that QoS metrics collection is enabled, use the following command:

show platform hardware qfp active feature qos config global

The following is an example of the output of the command:

```
Marker statistics are: disabled
Match per-filter statistics are: disabled
Match per-ace statistics are: disabled
Performance-Monitor statistics are: enabled
```

Configuring a QoS Packet Drop Monitor

A QoS Packet Drop monitor can only export the Queue ID and Queue Packet Drop fields. It cannot be combined with other monitors to export additional fields. At the given reporting interval, the monitor reports only on queues that have dropped packets (does not report value of 0).

Step 1: Create the QoS Packet Drop FNF Monitor

Use the following FNF configuration to create a QoS Packet Drop monitor. The process specifies a flow record of type "qos-record" and attaches the record to a monitor of type "qos-monitor." In the steps that follow, the qos-monitor is attached to the desired interface.

```
<u>Note</u>
```

Ensure that QoS metrics collection is enabled. See Enabling QoS Metric Collection, page 4-20.

```
flow record gos-record
  match policy gos queue index
  collect policy gos queue drops
flow monitor gos-monitor
  exporter my-exporter
  record gos-record
```

Step 2: Configure the QoS Policy

The following example shows configuration of a QoS policy map. It includes a hierarchy of three policies: avc, avc-parent, and avc-gparent. Note that avc-gparent includes avc-parent, and avc-parent includes avc.

```
policy-map avc
    class prec4
        bandwidth remaining ratio 3
    class class-default
        bandwidth remaining ratio 1
policy-map avc-parent
    class class-default
        shape average 10000000
        service-policy avc
policy-map avc-gparent
    class class-default
        shape average 10000000
        service-policy avc-parent
```

Step 3: Attach the FNF Monitor and QoS Policy to an Interface

Use the following to attach the monitor to the desired interface. For *<interface>*, specify the interface type—for example: GigabitEthernet0/2/1

Specify the IP address of the interface in IPv4 or IPv6 format.

```
interface <interface>
    ip address <interface_IP_address>
    ip flow monitor qos-monitor output
    service-policy output avc-gparent
```

Verifying the QoS Packet Drop Monitor Configuration

This section provides commands that are useful for verifying or troubleshooting a QoS Packet Drop Monitor configuration.

Verifying that the Monitor is Allocated

Use the following command to verify that the QoS monitor exists:

show flow monitor

Use the following commands to verify additional monitor details:

```
show flow monitor qos-monitor
show flow monitor qos-monitor cache
show flow monitor qos-monitor statistics
show platform hardware qfp active feature fnf client flowdef name qos-record
show platform hardware qfp active feature fnf client monitor name qos-monitor
```

Verifying QoS queues and Class-Hierarchies

The following **show** commands display the statistics that QoS has collected. "gigX/X/X" refers to the interface for which the monitor has been configured.

```
show policy-map int gigX/X/X show platform hardware qfp active feature qos queue output all
```

Verifying FNF-QOS FIA Activation

Use the following **show** command to verify that the FNF-QoS FIA (feature activation array) is enabled on the interface (GigabitEthernet0/2/1 in this example):

show platform hardware qfp active interface if-name GigabitEthernet0/2/1

Verifying the FNF Monitor and Record

Use the following **debug** commands to verify that the FNF monitor and record have been created:

debug platform software flow flow-def errors
debug platform software flow monitor errors
debug platform software flow interface errors
debug platform hardware qfp active feature fnf server trace
debug platform hardware qfp active feature fnf server info
debug platform hardware qfp active feature fnf server error

Configuring a QoS Class Hierarchy Monitor

In contrast to the QoS Packet Drop monitor, a QoS Class Hierarchy monitor can be combined with another monitor to export additional metrics.

Step 1: Create the QoS Class Record

The following example configuration creates a QoS class record. The process specifies a record of type "qos-class-record." The example specifies "ipv4 source" and "ipv4 destination" addresses, but you can configure the record to match according to other criteria.



Ensure that QoS metrics collection is enabled. See Enabling QoS Metric Collection, page 4-20.

```
flow record qos-class-record
  match ipv4 source address
  match ipv4 destination address
  collect counter bytes
  collect counter packets
  collect policy qos classification hierarchy
  collect policy qos queue index
```

Step 2: Create the QoS Class Hierarchy Monitor

Use the following FNF configuration to create a QoS Class Hierarchy monitor. The process specifies a monitor of type "class-hier-monitor." In the steps that follow, the monitor is attached to the desired interface.

```
flow monitor class-hier-monitor
exporter my-exporter
record gos-class-record
```

Step 3: Attach the QoS Class Hierarchy Monitor to an Interface

Use the following to attach the monitor to the desired interface. For *<interface>*, specify the interface type—for example: GigabitEthernet0/2/1

Specify the IP address of the interface in IPv4 or IPv6 format.

Attaching the service-policy to the interface, as indicated by the "service-policy" statement below, is a required step.

```
interface <interface>
    ip address <interface_IP_address>
    ip flow monitor class-hier-monitor output
    service-policy output avc-gparent
```

Verifying the QoS Class Hierarchy Monitor Configuration

This section provides commands that are useful for verifying or troubleshooting a QoS Class Hierarchy Monitor configuration.

Verifying that the Monitor is Allocated

Use the following command to verify that the QoS monitor exists:

show flow monitor

Use the following commands to verify additional details:

show flow monitor class-hier-monitor show flow monitor class-hier-monitor cache show flow monitor class-hier-monitor statistics

show platform hardware qfp active feature fnf client flowdef name qos-class-record show platform hardware qfp active feature fnf client monitor name qos-monitor

Verifying FNF-QOS FIA Activation

In the following feature invocation array (FIA) verification example, the interface is GigabitEthernet0/2/1.

show platform hardware qfp active interface if-name GigabitEthernet0/2/1

Verifying the FNF Monitor and Record

Use the following **debug** commands to verify that the FNF monitor and record have been created:

debug platform software flow flow-def errors debug platform software flow monitor errors debug platform software flow interface errors

debug platform hardware qfp active feature fnf server trace debug platform hardware qfp active feature fnf server info debug platform hardware qfp active feature fnf server error

Connection/Transaction Metrics

Cisco IOS Platforms	Cisco IOS XE Platforms
Not available	Added in release 3.9S

Flexible NetFlow (FNF) monitors can report on individual transactions within a flow. This enables greater resolution for traffic metrics. This section describes how to configure connection and transaction metrics, including **transaction-id** and **connection id**, for FNF monitors. The connection/transaction monitoring feature is referred to as "Multi-transaction."

Note

The Multi-transaction feature requires an NBAR protocol pack that supports the feature. The protocol pack provided with Cisco AVC for IOS XE release 3.9S and later protocol packs support this feature.

Introduction

Flexible NetFlow (FNF) monitors typically report traffic metrics per flow. (A flow is defined as a connection between a specific source address/port and destination address/port.) A single flow can include multiple HTTP transactions. Enabling the Multi Transaction feature for a monitor enables reporting metrics for each transaction individually.

You can configure the FNF record to identify the flow or the flow+transaction, using one of the following two metrics:

- connection id—A 4-byte metric identifying the flow.
- transaction-id—An 8-byte metric composed of two parts:
 - MSB—Identifies the flow and is equivalent to the connection id metric.
 - LSB—Identifies the transaction. The value is a sequential index of the transaction, beginning with 0.

Configuration

The following subsections describe the Multi-transaction feature:

- Requirements, page 4-25
- Configuring Exporter, Record, and Monitor in Performance Monitor Mode, page 4-25
- Configuring Exporter, Record, and Monitor in Performance Monitor Mode, page 4-25
- Verifying and Troubleshooting the Configuration, page 4-26

Requirements

The following requirements apply when using the Multi-transaction feature:

- The record configuration must use match, not collect.
- Specify only "connection id" or "transaction-id," but not both.
- Include "application name" in the record.
- Include "cache timeout event transaction-end" which specifies that the record is transmitted immediately and not stored in the monitor cache.

Configuring Exporter, Record, and Monitor in Performance Monitor Mode

Flexible Netflow (FNF) performance monitor (perf-monitor) mode enables configuring monitors with advanced filtering options that filter data before reporting it. Options for configuring filtering include IP access list, policy-map, and so on.

The following perf-monitor example configures a monitor and specifies the **transaction-id** metric for the FNF record, as shown in **bold**. Alternatively, you can specify the **connection id** metric.

Note

See Configuring Exporter, Record, and Monitor in Performance Monitor Mode, page 4-25 for additional configuration information.

```
ip access-list extended mt_perf_acl
   permit ip any any
class-map match-all mt_perf_class
   match access-group name mt_perf_acl
   match protocol http
flow exporter mt_perf_exporter
   destination 64.128.128.128
   transport udp 2055
flow record type performance-monitor mt perf record
   match connection transaction-id
   collect counter packets
   collect application name
   collect application http url
flow monitor type performance-monitor mt_perf_monitor
   record mt_perf_record
   exporter mt_perf_exporter
   cache type normal
   cache timeout event transaction-end
policy-map type performance-monitor mt_perf_policy
   parameter default account-on-resolution
   class mt_perf_class
   flow monitor mt_perf_monitor
interface GigabitEthernet0/0/2
   service-policy type performance-monitor input mt_perf_policy
```

Verifying and Troubleshooting the Configuration

This section describes commands useful for verification and troubleshooting the FNF configuration. There are subsections for:

- Native or Performance Monitor Mode, page 4-26
- Native FNF Mode, page 4-26
- Performance Monitor Mode, page 4-26



For information about the **show** commands in the sections below, see the FNF command reference guide: http://www.cisco.com/c/en/us/td/docs/ios-xml/ios/fnetflow/command/fnf-cr-book.html

Native or Performance Monitor Mode

Verifying Multi-transaction Status

Display the Multi-transaction status:

show plat soft nbar statistics | inc is_multi_trs_enable

If Multi-transaction is enabled, the value is: is_multi_trs_enable==1

Native FNF Mode

Validating the Configuration

Use the following show commands to validate the configuration.

show flow exporter <exporter_name> templates
show flow monitor <monitor_name>
show platform hardware qfp active feature fnf client flowdef name <record_name>
show platform hardware qfp active feature fnf client monitor name <monitor_name>

Viewing Collected FNF Data and Statistics

Use the following show commands to view the collected FNF data and statistics.

show flow monitor <monitor_name> cache
show flow monitor <monitor_name> statistics
show flow exporter <exporter_name> statistics
show platform hardware qfp active feature fnf datapath aor

Performance Monitor Mode

Validating the Configuration

Use the following **show** commands to validate the configuration.

show flow exporter <exporter_name> templates
show flow record type performance-monitor <record_name>
show platform hardware qfp active feature fnf client monitor name <monitor_name>

Viewing Collected FNF Data and Statistics

Use the following **show** commands to view the FNF collected data and statistics.

show performance monitor cache monitor <monitor_name> detail
show flow exporter <exporter_name> statistics
show platform hardware qfp active feature fnf datapath aor

Easy Performance Monitor

Cisco IOS Platforms	Cisco IOS XE Platforms		
Added in release 15.4(1)T	Added in release 3.10S		
The following features were added in release 15.4(3)T:	The following features were added in release 3.13S:		
• Application Statistics profile. See Application Statistics Profile, page 4-30.	• Application Statistics profile. See Application Statistics Profile, page 4-30.		
• cache-type parameter. See Configuring Easy Performance Monitor, page 4-32.	• cache-type parameter. See Configuring Easy Performance Monitor, page 4-32.		



Before downgrading to an earlier Cisco IOS XE release, review ISSU Limitations, page 6-4. Configurations that employ features introduced in a later Cisco IOS XE release are not compatible with earlier releases.

Overview

The Easy Performance Monitor ("Easy perf-mon" or "ezPM") feature provides an "express" method of provisioning monitors. This new mechanism adds functionality and does not affect the existing methods for provisioning monitors.

Easy perf-mon does not provide the full flexibility of the traditional perf-mon configuration model. Easy perf-mon provides "profiles" that represent typical deployment scenarios. See Profiles, page 4-27. Easy perf-mon profiles include:

- Application Experience
- Application Statistics

After selecting a profile and specifying a small number of parameters, Easy perf-mon provides the remaining provisioning details.

For additional information about configuring Easy perf-mon, see: *Easy Performance Monitor*

Profiles

The following sections describe Easy perf-mon profiles:

- Application Experience Profile, page 4-28
- Application Statistics Profile, page 4-30

Application Experience Profile

The Application Experience profile enables use of five different traffic monitors, described in Table 4-4.

Application Experience implements the improved data exporting model introduced in Cisco IOS XE 3.10S, which is optimized for maximum performance, exporting the maximum possible amount of available information for monitored traffic. Based on the requirements of the reports that have been defined:

- For each type of traffic, the exported record contains all of the collected data required for the defined reports, with the required granularity.
- Exported records do not contain unnecessary data, such as data redundant with previously exported records or data that is not required for the defined reports.
- Exported records include server information.

Monitor Details

	Monitor Name	Default Traffic Classification
1	Application-Response-Time (ART)	All TCP
2	URL	HTTP applications ¹
3	Media	RTP applications over UDP
4	Conversation-Traffic-Stats	Remaining traffic not matching other classifications
5	Application-Traffic-Stats	DNS and DHT

Table 4-4 Application Experience Traffic Monitors

 The ezPM URL monitor is configured by default with a pre-defined class that contains a subset of HTTP-based protocols. To modify the list of monitored HTTP protocols, use the class-replace command (see Configuring Easy Performance Monitor) or configure the monitor manually. In a future release, this URL monitor will automatically support all HTTP-based protocols supported by the protocol pack; no modification by CLI will be required.

For the monitor parameters shown in Table 4-5, default values can be overridden to configure the monitors differently. For an example of how to configure parameters in the Application Experience profile, see Easy Perf-Mon Configuration Example 2: Application Experience Profile, page 4-35.

				Configurable Pa	rameters		
	Monitor Name	IPv4/ IPv6	ln / Out	Traffic Class	Sampler	Cache Size	Cache Type
1	Application-Response- Time (ART)	Y	N	 class-and for application only class-replace 	N	Y	Y
2	URL	Y	N	 class-and for application only class-replace 	Sampling Rate	Y	N
3	Media	Y	Y	 class-and for application only class-replace 	N	Y	N
4	Conversation-Traffic- Stats	Y	N	N	N	Y	Y
5	Application-Traffic- Stats	N	N	N	N	Y	N

Table 4-5 Application Experience Traffic Monitors: Configurable Parameters

Notes and Limitations

Cisco IOS Platforms

• **Context Limitation**—On Cisco IOS platforms, only a one context can be attached to any single interface. The context can be from any currently available profile, such as Application Experience or Application Statistics.

Cisco IOS XE Platforms

- **Infrastructure**—The Application Experience profile operates by provisioning performance monitor CLIs. It utilizes the performance monitor infrastructure, including performance monitor policy maps, performance monitor records, and so on.
- **Context Limitation**—A maximum of three (3) Application Statistics profile contexts can be attached to a single interface, in addition to one (1) Application Experience context, for a total of four contexts.

Export Model

Figure 4-3 illustrates how the Application Experience profile exports different types of traffic statistics.



Figure 4-3 Export Model—Application Experience Profile

Application Statistics Profile

Application Statistics is a simpler profile than Application Experience. In contrast to the Application Experience profile, it provides only application statistics and does not report performance statistics.

The Application Statistics profile provides two different traffic monitors, application-stats and application-client-server-stats, described in Table 4-6. The monitors operate on all IPv4 and IPv6 traffic.

Selecting a Monitor

The Application Statistics profile includes two monitors, but operates with only one or the other of the two monitors. It is not possible to run both monitors simultaneously, and doing so would not be useful because the **application-client-server-stats** monitor reports all of the same information as the **application-stats** monitor, plus additional information.

Consequently, when configuring this profile, the traffic monitor all command is not available.

Monitor Details

Table 4-6Application Statistics Traffic Monitors

	Monitor Name	Traffic Classification
1	application-stats	All IPv4 and IPv6 traffic
2	application-client-server-stats	All IPv4 and IPv6 traffic

Table 4-7 indicates the parameters that can be set differently from the default values when configuring monitors in the Application Statistics profile.

 Table 4-7
 Application Statistics Traffic Monitors: Configurable Parameters

			Configurable Parameters					
	Monitor Name	IPv4 / IPv6	ln / Out	Traffic Classification	Sampler	Cache Size	Cache Type	
1	application-stats	N	Ν	N/A	N	Y	Y	
2	application-client- server-stats	Y	N	N/A	N	Y	Y	

Notes and Limitations

Cisco IOS Platforms

- AOR—Account on Resolution (AOR) is supported.
- **Infrastructure**—On Cisco IOS platforms, the Application Statistics profile operates by provisioning in the performance monitor infrastructure, similarly to the Application Experience profile.

Although the Application Statistics profile operates using a different infrastructure on Cisco IOS XE platforms, provisioning is handled in the same way and the infrastructure differences are essentially transparent to the user.

Cisco IOS XE Platforms

- AOR—Account on Resolution (AOR) is not supported.
- **Infrastructure**—To provide maximum performance, on Cisco IOS XE platforms the Application Statistics profile operates by provisioning native FNF monitors on the interface. The profile does not include the complexity and flexibility of the performance monitor infrastructure, such as policy maps and so on.

Although the Application Statistics profile operates using a different infrastructure on Cisco IOS platforms, provisioning is handled in the same way and the infrastructure differences are essentially transparent to the user.

- **GETVPN Interoperability**—Because the Application Statistics profile operates on Cisco IOS XE platforms using native FNF, and FNF monitors encrypted traffic, GETVPN interoperability is not supported on these platforms.
- **Context Limitation**—A maximum of three (3) Application Statistics profile contexts can be attached to one interface, in addition to one (1) Application Experience context, for a total of four.

Configuring Easy Performance Monitor

Usage Guidelines

- Only traffic monitors available in the profile can be activated.
- Each traffic monitor is configured on a separate line. If only the traffic-monitor name is specified, the monitor is activated with the default configuration defined in the profile.

Configuration Steps



See Table 4-8 for information about which releases support each option.

- 1. enable
- 2. configure terminal
- 3. performance monitor context context-name profile profile-name
- 4. exporter destination {hostname | ipaddress} source interface interface-type number [port port-value transport udp vrf vrf-name]
- 5. (Optional) Repeat Step 4 to configure up to three (3) exporters.
- 6. traffic monitor {traffic-monitor-name [ingress | egress] } [[cache-size max-entries] | [cache-type {normal | synchronized }] | [{class-and | class-replace¹} class-name] | ipv4 | ipv6] [sampling-rate number]
- 7. To configure additional traffic monitor parameters, repeat Step 6.
- 8. exit
- 9. interface interface-type number
- **10. performance monitor context** *context-name*
- 11. exit
- 1. class-and and class-replace not applicable to Application Statistics profile

Option	Description	Added in Release
profile profile-name	Profile type. Options include the following:	Application Experience profile:
	• application-experience	IOS 15.4(1)T
	• application-statistics	IOS XE 3.10
		Application Statistics profile:
		IOS 15.4(3)T
		IOS XE 3.13
traffic monitor traffic-monitor-name	Traffic monitor type. Options include the following:	Application Experience profile:
	Application Experience profile:	IOS 15.4(1)T
	• url	IOS XE 3.10
	• application-response-time	
	• application-traffic-stats	Application Statistics
	• conversation-traffic-stats	profile:
	• media	IOS 15.4(3)T
	Application Statistics profile:	IOS XE 3.13
	• application-stats	
	• application-client-server-stats	
ingress	Selects whether monitor is active for	IOS 15.4(1)T
egress	ingress or egress traffic. If not specified, it is applied to both.	IOS XE 3.10
cache-size max-entries	Cache size: Maximum aggregate number	IOS 15.4(1)T
	of entries for all monitors.	IOS XE 3.10
	Examples	
	The following example includes four monitors: IPv4 in, IPv4 out, IPv6 in, IPv6 out. Each monitor can have a maximum of 1000 entries.	
	traffic-monitor media cache-size 4000	
	The following example includes two monitors: IPv4 in, IPv4 out. Each monitor can have a maximum of 2000 entries.	
	traffic-monitor media ipv4 cache-size 4000	

Easy Performance Monitor Configuration Options

Table 4-8

Cisco Application Visibility and Control User Guide for IOS Release 15.4(3)T and IOS XE Release 3.13S

Option	Description	Added in Release
cache-type	Specifies the cache type as one of the following:	IOS 15.4(3)T
	Tonowing.	IOS XE 3.13
	• synchronized	
	• normal	
class-and class-name	Restrict the default traffic classification.	IOS 15.4(1)T
	<i>class-name</i> represents a user defined class-map.	IOS XE 3.10
	Note : Not applicable to the Application Statistics profile.	
class-replace class-name	Replace the entire class hierarchy with a	IOS 15.4(1)T
	user pre-defined class.	IOS XE 3.11
	<i>class-name</i> represents a user defined class-map.	
	Note : Not applicable to the Application Statistics profile.	
ipv4	Selects whether monitor is active for IPv4	IOS 15.4(1)T
ipv6	or IPv6.	IOS XE 3.10
-	Default: both	
sampling-rate number	Optionally overrides the default	IOS: Not supported
	traffic-monitor sampling rate.	IOS XE 3.11
	The range of possible sampling-rate values is determined by the platform.	IOS XE 3.12: Added option to enter 1 as a
	A value of 1 disables the sampler.	value.

Related Topics

For additional information about configuring Easy perf-mon, see:

Easy Performance Monitor

Configuration Examples

Easy Perf-Mon Configuration Example 1

The following Easy perf-mon configuration example activates all traffic monitors in the profile and attaches the policy-maps, both ingress and egress, to the GigabitEthernet0/0/1 interface:

```
! Easy performance monitor context
! ------
!
performance monitor context my-avc profile application-experience
    exporter destination 1.2.3.4 source GigabitEthernet0/0/1 port 4739
    traffic-monitor all
!
!
! Interface attachments
! -------
interface GigabitEthernet0/0/1
performance monitor context my-avc
```

Easy Perf-Mon Configuration Example 2: Application Experience Profile

The following ezPM "Application Experience" profile configuration example activates three traffic monitors, and specifies monitoring only IPv4 traffic. The context is then attached to two interfaces:

```
1
! Easy performance monitor context
!
       _____
!
performance monitor context my-visibility profile application-experience
   exporter destination 1.2.3.4 source GigabitEthernet0/0/1 port 4739
  traffic-monitor application-response-time ipv4
  traffic-monitor conversation-traffic-stats ipv4
   traffic-monitor media ipv4
1
! Interface attachments
! ------
interface GigabitEthernet0/0/1
 performance monitor context my-visibility
interface GigabitEthernet0/0/2
 performance monitor context my-visibility
```

Easy Perf-Mon Configuration Example 3: Application Statistics Profile

The following ezPM "Application Statistics" profile configuration example uses the "app-usage" context and activates one traffic monitor: application-stats.

The application-stats monitor provides per interface/application/direction/protocol and IP version traffic (bytes/packets) and flow (new flows/concurrent flows) statistics.

```
performance monitor context app-usage profile application-statistics
  exporter destination 1.2.3.4 source GigabitEthernet0/0/1 port 4739
  traffic-monitor application-stats
```

```
interface GigabitEthernet0/0/1
  performance monitor context app-usage
```

Easy Perf-Mon Configuration Example 4: Two Contexts Configured on a Single Interface

The following ezPM configuration example combines two contexts on the GigabitEthernet0/0/1 interface:

- One context applies the "Application Statistics" profile, referred to as **fg** (fine grain). In the example, this context configures detailed reporting for critical applications.
- One context applies the "Application Statistics" profile, referred to as **cg** (coarse grain). This context configures more general reporting of application metrics for all traffic.

```
class-map match-any my-critical-apps
match protocol citrix
performance monitor context fg profile application-experience
   traffic-monitor application-response-time class-replace my-critical-apps
performance monitor context cg profile application-statistics
   traffic-monitor application-stats
interface GigabitEthernet0/0/1
   performance monitor context fg
   performance monitor context cg
```

Notes

- Defining multiple contexts to combine fine-grain and coarse-grain monitoring is currently available on Cisco IOS XE platforms only.
- It is possible to combine one fine-grain and one coarse-grain context on a single interface, but not two fine-grain contexts.

CLI Field Aliases

Cisco IOS Platforms	Cisco IOS XE Platforms
Added in release 15.4(1)T	Added in release 3.10S

Aliases provide a mechanism for simplifying configuration statements. The **all** alias refers to the set of all fields possible for a given statement. For example, "collect connection delay **all**" configures all fields that are possible to configure by the "collect connection delay" statement.

The following are examples:

```
collect connection delay all collect connection transaction all
```

	collect	connection	client	t all			
	collect	connection	serve	r all			
	collect	connection	delay	response	to-server	histogram	all
$\underline{\Lambda}$							
Caution	When us	ing aliases.	see Rer	noving Ali	iases before	Downgradi	ng f

When using aliases, see Removing Aliases before Downgrading from Cisco IOS 15.4(1)T / Cisco IOS XE 3.10 or Later, page 6-4 before downgrading from Cisco IOS release 15.4(1)T or later, or from Cisco IOS XE release 3.10S or later.

Identifying the Monitored Interface

Cisco IOS Platforms	Cisco IOS XE Platforms
—	Added in release 3.11S

The "observation point id" metric identifies a monitored interface for traffic in both directions (ingress and egress). A single flow definition using this metric can be used in place of **match interface input** and **match interface output**, making configuration more compact and enabling a single record collected on an interface to include metrics for traffic in both directions.

Usage Guidelines

Configure the monitor on both the ingress and egress directions.

Example

In the following example configuration, a single monitor identifies the interface for traffic in both directions:

```
flow record my-application-record
  match application name account-on-resolution
  match flow observation point
  match flow direction
  collect counter packets
  collect counter bytes
```

Configuration Examples

This section contains AVC configuration examples. These examples provide a general view of a variety of configuration scenarios, combining multiple AVC features. Configuration is flexible and supports different types of record configurations.

Conversation Based Records—Omitting the Source Port

The monitor configured in the following examples sends traffic reports based on conversation aggregation. For performance and scale reasons, it is preferable to send TCP performance metrics only for traffic that requires TCP performance measurements. It is recommended to configure two similar monitors:

- One monitor includes the required TCP performance metrics. In place of the line shown in **bold** in the example below (collect <any TCP performance metric>), include a line for each TCP metric for the monitor to collect.
- One monitor does not include TCP performance metrics.

The configuration is for IPv4 traffic. Similar monitors should be configured for IPv6.

Example 1: For Cisco IOS Platforms

flow record type performance-monitor conversation-record match connection client ipv4 (or ipv6) address match connection server ipv4 (or ipv6) address match connection server transport port match ipv4 (or ipv6) protocol match application name account-on-resolution collect interface input collect interface output collect connection server counter bytes long collect connection client counter bytes long collect connection server counter packets long collect connection client counter packets long collect connection sum-duration collect connection new-connections collect policy gos class hierarchy collect policy qos queue id collect <any TCP performance metric>

flow monitor type performance-monitor conversation-monitor record conversation-record exporter my-exporter history size 0 cache type synchronized cache timeout synchronized 60 cache entries <cache size>

flow record gos-record
 match policy gos queue index
 collect policy gos queue drops
flow monitor gos-monitor
 exporter my-exporter
 record gos-record

Example 2: For Cisco IOS XE Platforms

```
flow record type performance-monitor conversation-record
  match services waas segment account-on-resolution
  match connection client ipv4 (or ipv6) address
  match connection server ipv4 (or ipv6) address
  match connection server transport port
  match ipv4 (or ipv6) protocol
  match application name account-on-resolution
  collect interface input
  collect interface output
  collect connection server counter bytes long
```

collect connection client counter bytes long collect connection server counter packets long collect connection client counter packets long collect connection sum-duration collect connection new-connections collect policy qos class hierarchy collect policy qos queue id collect <any TCP performance metric>

```
flow monitor type performance-monitor conversation-monitor
  record conversation-record
  exporter my-exporter
  history size 0
  cache type synchronized
  cache timeout synchronized 60
  cache entries <cache size>
```

HTTP URL

The monitor configured in the following example sends the HTTP host and URL. If the URL is not required, the host can be sent as part of the conversation record (see Conversation Based Records—Omitting the Source Port, page 4-38).

```
flow record type performance-monitor url-record
   match transaction-id
   collect application name
   collect connection client ipv4 (or ipv6) address
   collect routing vrf input
   collect application http url
   collect application http host
   <other metrics could be added here if needed.
    For example bytes/packets to calculate BW per URL
    Or performance metrics per URL>
flow monitor type url-monitor
   record url-record
   exporter my-exporter
   history size 0
   cache type normal
   cache timeout event transaction-end
```

cache entries <cache size>

HTTP URI

The **uri statistics** command enables exporting the first level of a parsed URI address. The command exports the value in the URI statistics field, which contains the depth 1 URI value, followed by a URI hit count value.



Cisco IOS XE Platforms: The URI hit count value is always 1 because the URI statistics field can only be configured per connection or transaction.

If no backslash exists at all after the URL, a zero length field is exported.

If the depth 1 value of the parsed URI exceeds a maximum number of characters, the value is truncated to the maximum length.

Г

Note	

Cisco IOS XE Platforms: The **uri statistics** command must be configured with either the **connection id** or **transaction-id** commands.

Configuration Example

```
flow record er_uri_stat_record_1
  match connection transaction-id
  collect application name
  collect counter packets
   collect application http uri statistics
```

Example of Exported Value—Typical Address

Address: http://usr:pwd@www.test.com:81/dir/dir.2/index.htm?q1=0&&test1&test2=value#top

The uri statistics command exports: /dir:1

- /dir is the URI depth 1 level value.
- The ":" indicates a null character, followed by a URI hit count value of 1.

Example of Exported Value—No Backslash after URL

Address: http://usr:pwd@www.test.com

The uri statistics command exports a zero length field.

Application Traffic Statistics

The monitor configured in the following example collects application traffic statistics:

```
flow record type performance-monitor application-traffic-stats
   match ipv4 protocol
   match application name account-on-resolution
   match ipv4 version
   match flow direction
   collect connection initiator
   collect counter packets
   collect counter bytes long
   collect connection new-connections
   collect connection sum-duration
flow monitor type application-traffic-stats
   record application-traffic-stats
   exporter my-exporter
   history size 0
   cache type synchronized
   cache timeout synchronized 60
   cache entries <cache size>
```

Media RTP Report

The monitor configured in the following example reports on media traffic:

```
flow record type performance-monitor media-record
   match ipv4(or ipv6) protocol
   match ipv4(or ipv6) source address
   match ipv4(or ipv6) destination address
   match transport source-port
   match transport destination-port
   match transport rtp ssrc
   match routing vrf input
   collect transport rtp payload-type
   collect application name
   collect counter packets long
   collect counter bytes long
   collect transport rtp jitter mean sum
   collect transport rtp payload-type
   collect <other media metrics>
flow monitor type media-monitor
   record media-record
   exporter my-exporter
   history size 10 // default history
   cache type synchronized
   cache timeout synchronized 60
```

QoS Example 1: Control and Throttle Traffic

cache entries <cache size>

The following QoS configuration example illustrates how to control and throttle the peer-to-peer (P2P) traffic in the network to 1 megabit per second:

```
class-map match-all p2p-class-map
match protocol attribute sub-category p2p-file-transfer
policy-map p2p-attribute-policy
class p2p-class-map
police 1000000
interface Gig0/0/3
service-policy input p2p-attribute- policy
```

QoS Example 2: Assigning Priority and Allocating Bandwidth

The following QoS configuration example illustrates how to allocate available bandwidth on the eth0/0 interface to different types of traffic. The allocations are as follows:

- Business-critical Citrix application traffic for "access-group 101" users receives highest priority, with 50% of available bandwidth committed and traffic assigned to a priority queue. The police statement limits the bandwidth of business-critical traffic to 50% in the example.
- Web browsing receives a committed 30% of the remaining bandwidth after the business-critical traffic. This is a commitment of 15% of the total bandwidth available on the interface.
- Internal browsing, as defined by a specific domain (myserver.com in the example), receives a committed 60% of the browsing bandwidth.
- All remaining traffic uses the remaining 35% of the total bandwidth.

The policy statements commit minimum bandwidth in the percentages described for situations of congestion. When bandwidth is available, traffic can receive more than the "committed" amount. For example, if there is no business-critical traffic at a given time, more bandwidth is available to browsing and other traffic.

Figure 4-4 illustrates the priority and bandwidth allocation for each class. "Remaining traffic" refers to all traffic not specifically defined by the class mapping.





In class-map definition statements:

- **match-all** restricts the definition to traffic meeting all of the "match" conditions that follow. For example, the "business-critical" class only includes Citrix protocol traffic from IP addresses in "access-group 101."
- match-any includes traffic meeting one or more of the "match" conditions that follow.

```
class-map match-all business-critical
   match protocol citrix
   match access-group 101
class-map match-any browsing
   match protocol attribute category browsing
class-map match-any internal-browsing
   match protocol http url "*myserver.com*"
policy-map internal-browsing-policy
   class internal-browsing
       bandwidth remaining percent 60
policy-map my-network-policy
   class business-critical
       priority
       police cir percent 50
   class browsing
       bandwidth remaining percent 30
       service-policy internal-browsing-policy
interface eth0/0
   service-policy output my-network-policy
```