



Managing TLS Certificate, KeyStore, and TrustStore Files

This chapter contains the following sections:

- [Generating TLS Self-Signed Certification Between NDB Server and NDB Switch for NXAPI, on page 1](#)
- [Generating TLS 3rd Party Certification Between NDB Server and NDB Switch for NXAPI, on page 7](#)
- [Generating TLS Self-Signed Certification Between NDB Server and NDB Switch for OpenFlow, on page 14](#)
- [Generating TLS Self-Signed Certification Between WebUI Browser and NDB Server, on page 22](#)
- [Generating TLS 3rd Party Certification Between WebUI Browser and NDB Server, on page 34](#)

Generating TLS Self-Signed Certification Between NDB Server and NDB Switch for NXAPI

This section describes how to generate TLS self-signed certification between NDB server and NDB Switch. You need to generate certificates and keys for each switch to enable TLS. TLS communication between NDB switch and NDB server uses port 443 only.

Complete the following steps to generate TLS self-signed certification between NDB Server and NDB Switch for NXAPI:

- [Generating Self-Signed Certificate and Key, on page 2](#)
- [Creating the TLS TrustStore File, on page 4](#)
- [Starting NDB with TLS, on page 5](#)
- [Configuring TLS KeyStore and TrustStore Passwords on NDB, on page 6](#)



Note

You cannot configure a controller to communicate using port 80 after configuring TLS.

Generating Self-Signed Certificate and Key

This section describes how to generate self-signed certificate and key.

Before you begin

Ensure that you have domain name configured on the switch using **ip domain-name** command for each NDB switch that acts as the Fully Qualified Domain Name (FQDN) for the switch. For example:

```
conf t
ip domain-name cisco.com
hostname N9k-117
end
```

The FQDN for the switch is configured to N9K-117.cisco.com.

Step 1 Log in to the server.

Step 2 Generate the private key and self-signed certificate using the **openssl req** command.

Example:

```
docker@docker-virtual-machine:~/TLS$ openssl req -x509 -nodes -days 3650 -newkey rsa:2048 -out
sw1-ca.pem -outform PEM -keyout sw1-ca.key
```

Generating a 2048 bit RSA private key

...+++

.....+++

writing new private key to 'sw1-ca.key'

You are about to be asked to enter information that will be incorporated into your certificate request.

What you are about to enter is what is called a Distinguished Name or a DN.

There are quite a few fields but you can leave some blank

For some fields there will be a default value,

If you enter '.', the field will be left blank.

Country Name (2 letter code) [AU]:US

State or Province Name (full name) [Some-State]:CA

Locality Name (eg, city) []:SJ

Organization Name (eg, company) [Internet Widgits Pty Ltd]:cisco

Organizational Unit Name (eg, section) []:insbu

Common Name (e.g. server FQDN or YOUR name) []:N9K-117.cisco.com

Email Address []:myname@cisco.com

Note If you have multiple switches, generate the certificate file and private key for each switch.

This command creates a certificate file (sw1-ca.pem) and a private key (sw1-ca.key).

Step 3 Log in to the NDB switch.

Step 4 Copy the certificate file, sw1-ca.pem, and keyfile, sw1-ca.key, to the switch using the **copy** command.

Example:

```
N9K-117# copy scp://docker@10.16.206.250/home/docker/Mallik/TLS_CA_june_23/sw1-ca.pem bootflash:
Enter vrf (If no input, current vrf 'default' is considered): management
```

```

docker@10.16.206.250's password:
server.cer
                                     100% 4676
      4.6KB/s   00:00
Copy complete, now saving to disk (please wait)...

N9K-117# copy scp://docker@10.16.206.250/home/docker/Mallik/TLS_CA_june_23/sw1-ca.key bootflash:
Enter vrf (If no input, current vrf 'default' is considered): management

docker@10.16.206.250's password:
cert.key
                                     100%

Copy complete, now saving to disk (please wait)...

```

Note If you have multiple switches, repeat this step for all the switches.

Step 5 Configure the certificate file, sw1-ca.pem, and keyfile, sw1-ca.key in the switch using the **nxapi** command.

Example:

```

N9K-117 (config)# nxapi certificate httpskey keyfile bootflash:sw1-ca.key
Upload done. Please enable. Note cert and key must match.
N9K-117 (config)#
N9K-117 (config)# nxapi certificate httpsCRT certfile bootflash:sw1-ca.pem
Upload done. Please enable. Note cert and key must match.
N9K-117 (config)#

```

Note If you have multiple switches, configure the corresponding certificate and private key to each switch.

Step 6 Enable self-signed certificates on the switch using the **nxapi certificate** command.

Example:

```

N9K-117 (config)# nxapi certificate enable
N9K-117 (config)#

```

Note Ensure that there is no error while enabling self-signed certificates on the switch.

Step 7 Log in to the server.

Step 8 Copy and convert the sw1-ca.key and sw1-ca.pem files to .PEM format using the **copy** command.

Example:

```

cp sw1-ca.key sw1-xnc-privatekey.pem
cp sw1-ca.pem sw1-xnc-cert.pem

```

Step 9 Concatenate the private key and the certificate file using **cat** command.

Example:

```

docker@docker-virtual-machine:~/TLS$ cat sw1-xnc-privatekey.pem sw1-xnc-cert.pem > sw1-xnc.pem

```

Step 10 Convert the .pem file to .p12 file format using the **openssl** command. Enter the export password when prompted to create a password protected .p12 certificate file.

Example:

```

docker@docker-virtual-machine:~/TLS$ openssl pkcs12 -export -out sw1-xnc.p12 -in sw1-xnc.pem
Enter Export Password: cisco123
Verifying - Enter Export Password: cisco123

```

Enter a password at the prompt. Use the same password that you entered in the previous Step (cisco123)

- Step 11** Convert the sw1-xnc.p12 to a password protected Java KeyStore (tlsKeyStore) file using the **keytool** command. Use the relative path to jre/bin in the xnc directory to run the keytool command.

Example:

```
docker@docker-virtual-machine:~/TLS$ ./ (relativePath)/keytool -importkeystore -srckeystore sw1-xnc.p12
-srcstoretype pkcs12 -destkeystore tlsKeyStore -deststoretype jks
Enter Destination Keystore password:cisco123
Re-enter new password:cisco123
Enter source keystore password:cisco123
Entry for alias 1 successfully imported.
Import command completed: 1 entries successfully imported, 0 entries failed or cancelled.
```

Note By default an alias named “1” is stored in tlsKeyStore for the first switch. If the NDB controller is managing multiple switches, repeat this step for all the switches. When you add the second switch, the utility allows you to rename the first switch alias and also provides a provision to rename alias for the second switch. Refer examples as shown below.

```
keytool -importkeystore -srckeystore sw2-xnc.p12 -srcstoretype pkcs12 -destkeystore
tlsKeyStore -deststoretype jks
keytool -importkeystore -srckeystore sw3-xnc.p12 -srcstoretype pkcs12 -destkeystore
tlsKeyStore -deststoretype jks
```

- Step 12** List and verify content in the java tlsKeyStore using the **keytool** command.

Example:

```
docker@docker-virtual-machine:~/TLS$ keytool -list -v -keystore tlsKeyStore | more
```

What to do next

Proceed to the subsequent task, *Creating the TLS TrustStore File*.

Creating the TLS TrustStore File

TrustStore is created from the self-signed certificates that are generated for one or more switches. It holds certificates for one or more switches in the controller. This section describes how to create a Truststore using the self-signed certificate created in [Generating Self-Signed Certificate and Key](#) section. If you have multiple switches in the controller, each switch will have separate certificate file (For example, sw1-xnc-cert.pem, sw2-xnc-cert.pem)

- Step 1** Log in to the server.

- Step 2** Convert the certificate file (For example, sw1-xnc-cert.pem) to a Java TrustStore (tlsTrustStore) file using the **keytool** command. Enter a password when prompted to create a password protected Java TrustStore (tlsTrustStore) file. The password should be at least six characters. Use the relative path to jre/bin in the xnc directory to run the keytool command.

Example:

```
docker@docker-virtual-machine:~/TLS$ ./ (relativePath)/keytool -import -alias sw1 -file sw1-xnc-cert.pem
-keystore tlsTrustStore
Enter Export Password: cisco123
Verifying - Enter Export Password: cisco123
```

Enter a password at the prompt. Use the same password that you entered in the previous Step (cisco123)

Note If a NDB controller manages multiple switches, repeat this step for all the switches to add all switch keys into the same TrustStore. For example:

```
docker@docker-virtual-machine:~/TLS$ keytool -import -alias sw2 -file sw2-xnc-cert.pem
-keystore tlsTrustStore
docker@docker-virtual-machine:~/TLS$ keytool -import -alias sw3 -file sw3-xnc-cert.pem
-keystore tlsTrustStore
// Here sw2 and sw3 are alias for switch 2 and switch 3 for identification purpose.
```

Step 3 List and verify keys for multiple switches in the same tlsTrustStore using the **keytool** command.

Example:

```
docker@docker-virtual-machine:~/TLS$ keytool -list -v -keystore tlsTrustStore | more
```

Starting NDB with TLS

To start NDB with TLS, complete these steps:

Step 1 Log in to the NDB server.

Step 2 Stop the NDB application, if running, using the **runxnc.sh** command

Example:

```
./runxnc.sh -stop
Controller with PID: 17426 -- Stopped!
```

Step 3 Copy the tlsKeystore and tlsTruststore files that you created to configuration folder of NDB (xnc/configuration).

Example:

```
cp tlskeystore /root/xnc/configuration
cp tlsTrustStore /root/xnc/configuration
```

Step 4 Start the NDB application with TLS using the **runxnc.sh** script.

Example:

```
./runxnc.sh -tls -tlskeystore ./configuration/tlsKeyStore -tlstruststore ./configuration/tlsTrustStore
```

Example:

To start NDB with default username (admin) and a non-default password (for example, pwd123):

```
./runxnc.sh -osgiPasswordSync -tls -tlskeystore ./configuration/tlsKeyStore -tlstruststore
./configuration/tlsTrustStore
```

If XNC password is changed, OSGi webconsole password needs to be changed.

To set non-default OSGi webconsole password, enter XNC Admin Password [default]:
(Type the non-default password which was set)

Note To disable TLS, run the `./runxnc.sh -notls` command. To disable TLS and start NDB, run the `./runxnc.sh -notls -start` command. Before disabling TLS, ensure to `stop` NDB. After TLS is disabled, the port number for the devices connected to the NDB server should be changed to 80.

Configuring TLS KeyStore and TrustStore Passwords on NDB

You need to configure TLS KeyStore and TrustStore passwords to enable NDB to read password protected TLS KeyStore and TrustStore files. To configure TLS KeyStore and TrustStore passwords on NDB, complete these steps:

Step 1 Log in to the NDB server.

Step 2 Navigate to bin directory.

Example:

```
cd xnc/bin
```

Step 3 Configure the TLS KeyStore and TrustStore passwords using the `xnc config-keystore-passwords` command.

Example:

```
./xnc config-keystore-passwords --user admin --password admin --url https://10.16.206.250:8443
--verbose --prompt --keystore-password cisco123 --truststore-password cisco123
```

In case NDB is configured with AAA (Tacacs/LDAP/Radius), and if the above command, `ndb config-keystore-passwords` fails, and you see a `401 unauthorized` error, then:

- a. Go to the `xnc` directory.
- b. Stop the NDB server using `./runxnc.sh -stop`.
- c. Enable the flag **enable.LocalUser.Authentication** by changing the value from *false* to *true* in the NDB `config.ini` file.
- d. Start the NDB server using `./runxnc.sh -start`.
- e. Run the `ndb config-keystore-passwords` command again.

Note In a HA environment, you need to run the above procedure for all the NDB servers in the cluster.

After the TLS is enabled on NDB, all the connections between NDB server and NDB switch are established using port 443. Ensure that you change device connections in NDB to use port 443.

Up on successfully completing these steps, you can add nexus switch in the controller using port 443. Use FQDN of the switch to add the device to the NDB controller.

You can verify the Certificate information using the WebUI Sandbox of the switch.

Generating TLS 3rd Party Certification Between NDB Server and NDB Switch for NXAPI

This section describes how to generate TLS 3rd party certification between NDB server and NDB Switch. You need to request for a separate certificate and key for each switch in your network. TLS communication between NDB switch and NDB server uses port 443 only.

Complete the following steps to generate TLS 3rd party certification between NDB Server and NDB Switch for NXAPI:

- [Obtaining Certificates from a Certification Authority](#)
- [Creating TLS Keystore and Truststore Files for NDB Controller](#)
- [Starting NDB with TLS, on page 5](#)
- [Configuring TLS KeyStore and TrustStore Passwords on NDB, on page 6](#)

**Note**

Complete all the steps under both the sections to ensure successful communication between the controller and the switch over TLS.

Obtaining Certificates from a Certification Authority

You can obtain certificate from a Certification Authority (CA) in two ways. You can either directly approach a CA for both the private key and certificate. The CA will generate a private key on your behalf along with the certificate that contains the public key with issuing CA's signature.

In the other approach, you can generate a private key using tools such as openssl and generate a Certificate Signing Request (CSR) to a certificate issuing authority. The CA generates the certificates with public key using the user identity information from CSR.

Before you begin

Ensure that you have domain name configured in the switch using **ip domain-name** command for each NDB switch that acts as the Fully Qualified Domain Name (FQDN) for the switch. For example:

```
conf t
ip domain-name cisco.com
hostname N9k-117
end
```

The FQDN for the switch is configured to N9K-117.cisco.com.

Step 1

Log in to the server.

Step 2

Generate the private key (cert.key) and certificate signing request (cert.req) using openssl command.

Example:

```
docker@docker-virtual-machine:~/Mallik/TLS_CA$ openssl req -newkey rsa:2048 -sha256 -keyout cert.key
-keyform PEM -out cert.req -outform PEM
```

```

Generating a 2048 bit RSA private key
.....+++
.....+++
writing new private key to 'cert.key'
Enter PEM pass phrase:                ☐ cisco123
Verifying - Enter PEM pass phrase:    ☐ cisco123
-----
You are about to be asked to enter information that will be incorporated into your certificate
request.
What you are about to enter is what is called a Distinguished Name or a DN.
There are quite a few fields but you can leave some blank
For some fields there will be a default value,
If you enter '.', the field will be left blank.
-----
Country Name (2 letter code) [GB]:US
State or Province Name (full name) [Berkshire]:CA
Locality Name (eg, city) [Newbury]:SJ
Organization Name (eg, company) [My Company Ltd]:cisco
Organizational Unit Name (eg, section) []:insbu
Common Name (eg, your name or your server's hostname) []:N9K-117.cisco.com
Email Address []:myname@cisco.com

Please enter the following 'extra' attributes
to be sent with your certificate request
A challenge password []: ☐ cisco123
An optional company name []:☐ cisco123

docker@docker-virtual-machine: # ls
cert.key  cert.req

```

Step 3 Verify the CSR using the openssl command.

Example:

```
docker@docker-virtual-machine:~/Mallik/TLS_CA$ openssl req -noout -text -in cert.req
```

Step 4 The private key is generated with a security passphrase. You may need to unencrypt the private key. To remove the passphrase from the private key, use the openssl command.

Example:

```

docker@docker-virtual-machine:~/Mk/TLS_CA$ ls
cert.key  cert.req
docker@docker-virtual-machine:~/Mk/TLS_CA$ cp cert.key cert.keybkp
docker@docker-virtual-machine:~/Mk/TLS_CA$ rm cert.key
docker@docker-virtual-machine:~/Mk/TLS_CA$ openssl rsa -in cert.keybkp -out cert.key

Enter pass phrase for cert.keybkp: cisco123

```

Note Repeat this step to remove passphrase from private keys for all the switches.

Note Depending on the tier of the CA you choose, you can get up to three certificates (certificate chain) for each CSR. This means you get three certificates (root, intermediate and domain) from CA for each NDB switch. You need to check with CA to identify each type of certificate. Certificate naming convention might be different for different certifying authorities. For example: test-root-ca-2048.cer (root), test-ssl-ca.cer (intermediate), N9K-117.cisco.com.cer (domain).

Certificates are mostly shared in .PEM file format.

The cert.req file data needs to be submitted to 3rd party certification authority. Follow the relevant procedures and get the three (certificate) files.

- Step 5** Create a single certificate file from the three certificate files using the **cat** command. The concatenation should be done in the following order, domain certificate, root certificate, and intermediate certificate. Syntax for **cat** command: **Cat domain certificate root certificate intermediate certificate > server.cer.**

Example:

```
$cat N9K-117.cisco.com.cer test-root-ca-2048.cer test-ssl-ca.cer > server.cer
```

- Step 6** Edit the newly created server.cer file to separate the concatenated END and BEGIN lines. Do not delete anything in the file.

Example:

```
-----END CERTIFICATE-----BEGIN CERTIFICATE-----
```

```
//////// Modify the above line like this by adding a line feed between the two.
-----END CERTIFICATE-----
-----BEGIN CERTIFICATE-----
```

Note Repeat this step all the switches.

- Step 7** Log into the NDB switch.

- Step 8** Copy the private key (cert.key) and the certificate from CA (server.cer) to the switch using the copy command.

Example:

```
N9K-117# copy scp://docker@10.16.206.250/home/docker/Mallik/TLS_CA_june_23/server.cer bootflash:
Enter vrf (If no input, current vrf 'default' is considered): management
docker@10.16.206.250's password:
server.cer
100% 4676      4.6KB/s   00:00
Copy complete, now saving to disk (please wait)...
```

```
N9K-117# copy scp://docker@10.16.206.250/home/docker/Mallik/TLS_CA_june_23/cert.key bootflash:
Enter vrf (If no input, current vrf 'default' is considered): management
docker@10.16.206.250's password:
cert.key
100%
Copy complete, now saving to disk (please wait)...
```

Note Repeat this step for all the switches.

- Step 9** Configure the certificate file, sw1-ca.pem, and keyfile, sw1-ca.key in the switch using the **nxapi** command.

Example:

```
N9K-117 (config)# nxapi certificate httpskey keyfile bootflash:cert.key
Upload done. Please enable. Note cert and key must match.
N9K-117 (config)#
N9K-117 (config)# nxapi certificate httpsCRT certfile bootflash:server.cer
Upload done. Please enable. Note cert and key must match.
N9K-117 (config)#
```

Note If you have multiple switches, configure the corresponding certificate and private key to each switch.

- Step 10** Enable self-signed certificates on the switch using the **nxapi certificate** command.

Example:

```
N9K-117 (config)# nxapi certificate enable
N9K-117 (config)#
```

Note Ensure that there is no error while enabling self-signed certificates on the switch.

Creating TLS Keystore and Truststore Files for NDB Controller

NDB uses certificates and keys to secure communication between switches. It stores the keys and certificates in keystores. These files are stored as `tlsTruststore` and `tlsKeystore` files in NDB. Complete the following steps to generate the Java `tlsKeyStore` and `tlsTrustStore` files for NDB Controller:

Step 1 Create a TLS directory and navigate to it.

Example:

```
mkdir -p TLS
cd TLS
```

Step 2 Create three directories under `mypersonalca` and two prerequisite files.

Example:

```
mkdir -p mypersonalca/certs
mkdir -p mypersonalca/private
mkdir -p mypersonalca/crl
echo "01" > mypersonalca/serial
touch mypersonalca/index.txt
```

Generate the TLS private key and Certification Authority (CA) files for each switch connected to NDB using the command

Step 3 Generate the TLS private key and Certification Authority (CA) files for each switch connected to NDB using the **`openssl req -x509 -nodes -days 3650 -newkey rsa:2048 -out mypersonalca/certs/sw1-ca.pem -outform PEM -keyout mypersonalca/private/sw1-ca.key`** command.

This step generates the TLS private key in PEM format with a key length of 2048 bits, and the CA file (`mypersonalca/certs/sw1-ca.pem`, `mypersonalca/private/sw1-ca.key`). If you have multiple switches then you need to create `sw1-ca.pem` and `sw1-ca.key` file for all the switches with the exact values that were provided when generating CSR for these switches.

Note Use the same inputs which were provided when generating `cert.key` in the *Obtaining Certificates from a Certification Authority* section. Any mismatch in the inputs will generate a new key.

Example:

```
docker@docker-virtual-machine:~/TLS$ openssl req -x509 -nodes -days 3650 -newkey rsa:2048 -out
mypersonalca/certs/sw1-ca.pem -outform PEM -keyout mypersonalca/private/sw1-ca.key
Generating a 2048 bit RSA private key
...+++
.....+++
writing new private key to 'mypersonalca/private/sw1-ca.key'
-----
You are about to be asked to enter information that will be incorporated into your certificate
request.
What you are about to enter is what is called a Distinguished Name or a DN.
There are quite a few fields but you can leave some blank
For some fields there will be a default value,
```

```

If you enter '.', the field will be left blank.
-----
Country Name (2 letter code) [AU]:US
State or Province Name (full name) [Some-State]:CA
Locality Name (eg, city) []:SJ
Organization Name (eg, company) [Internet Widgits Pty Ltd]:cisco
Organizational Unit Name (eg, section) []:insbu
Common Name (e.g. server FQDN or YOUR name) []:N9K-117.cisco.com
Email Address []:myname@cisco.com

```

Copy the cert.key and server.cer created in Obtaining Certificates from a Certification Authority section into the current directory (TLS). Select the certificate and key files for a single switch. These files were earlier generated for all the switches connecting to the controller. Using the server.cer and cert.key for the current switch, create the TLS KeyStore File.

Step 4 Copy the cert.key and server.cer created in the *Obtaining Certificates from a Certification Authority* section into the current directory (TLS). Select the certificate and key files for a single switch. These files were earlier generated for all the switches connecting to the controller. Using the server.cer and cert.key for the current switch, create the TLS KeyStore File.

If multiple switches are connected, repeat this step for each switch separately.

Step 5 Copy and convert the server.cer and cert.key files to .PEM format using the **copy** command.

Example:

```

cp cert.key sw1-xnc-privatekey.pem
cp server.cer sw1-xnc-cert.pem

```

Step 6 Concatenate the private key (sw1-xnc-privatekey.pem) and certificate file (sw1-xnc-cert.pem) into a single .PEM file using the **cat** command.

Example:

```

cat sw1-xnc-privatekey.pem sw1-xnc-cert.pem > sw1-xnc.pem

```

Step 7 Convert the .PEM file to .P12 format using the **openssl** command. Enter the export password when prompted. The password must contain at least 6 characters, for example, cisco123. The sw1-xnc.pem file is converted to a password-protected sw1-xnc.p12 file.

Example:

```

docker@docker-virtual-machine:~/TLS$ openssl pkcs12 -export -out sw1-xnc.p12 -in sw1-xnc.pem
Enter Export Password: cisco123
Verifying - Enter Export Password: cisco123
Enter a password at the prompt. Use the same password that you entered in the previous Step (cisco123)

```

Step 8 Convert the sw1-xnc.p12 to a password protected Java KeyStore (tlsKeyStore) file using the **keytool** command. This command converts the sw1-xnc.p12 file to a password-protected tlsKeyStore file.

Example:

```

docker@docker-virtual-machine:~/TLS$ keytool -importkeystore -srckeystore sw1-xnc.p12 -srcstoretype
pkcs12 -destkeystore tlsKeyStore -deststoretype jks
Enter Destination Keystore password:cisco123

```

Note By default an alias named “1” is stored in `tlsKeyStore` for the first switch. If the NDB controller is managing multiple switches, repeat this step for all the switches. When you add the second switch, the utility allows you to rename the first switch alias and also provides a provision to rename alias for the new switch. For example, see below.

```
keytool -importkeystore -srckeystore sw2-xnc.pl2 -srcstoretype pkcs12 -destkeystore
tlsKeyStore -deststoretype jks
keytool -importkeystore -srckeystore sw3-xnc.pl2 -srcstoretype pkcs12 -destkeystore
tlsKeyStore -deststoretype jks
```

Step 9 List and verify content in the `java tlsKeyStore` using the `keytool` command.

Example:

```
docker@docker-virtual-machine:~/TLS$ keytool -list -v -keystore tlsKeyStore | more
```

Step 10 Convert the certificate file (`sw1-xnc-cert.pem`) to a Java TrustStore (`tlsTrustStore`) file using the **keytool** command. Enter a password when prompted to create a password protected Java TrustStore (`tlsTrustStore`) file. The password should be at least six characters.

Example:

```
docker@docker-virtual-machine:~/TLS$ keytool -import -alias sw1 -file sw1-xnc-cert.pem -keystore
tlsTrustStore
```

```
Enter keystore password: cisco123
```

```
Re-enter new password: cisco123
```

```
Owner: EMAILADDRESS=myname@cisco.com, CN=localhost, OU=insbu, O=cisco, L=SJ, ST=CA, C=US
```

```
Issuer: EMAILADDRESS=myname@cisco.com, CN=localhost, OU=insbu, O=cisco, L=SJ, ST=CA, C=US
```

```
Serial number: c557f668a0dd2ca5
```

```
Valid from: Thu Jun 15 05:43:48 IST 2017 until: Sun Jun 13 05:43:48 IST 2027
```

```
Certificate fingerprints:
```

```
MD5: C2:7B:9E:26:31:7A:74:25:55:DF:A7:91:C9:5D:20:A3
```

```
SHA1: 3C:DF:66:96:72:12:CE:81:DB:AB:58:30:60:E7:CC:04:4D:DF:6D:B2
```

```
SHA256:
```

```
DD:FB:3D:71:B4:B8:9E:CE:97:A3:E4:2D:D3:B6:90:CD:76:A8:5F:84:77:78:BE:49:6C:04:01:84:62:2C:2F:EB
```

```
Signature algorithm name: SHA256withRSA
```

```
Version: 3
```

```
Extensions:
```

```
#1: ObjectId: 2.5.29.35 Criticality=false
```

```
AuthorityKeyIdentifier [
```

```
KeyIdentifier [
```

```
0000: 0D B3 CF 81 66 4A 33 4E EF 86 7E 26 C3 50 9B 73 ....fJ3N...&.P.s
```

```
0010: 38 EF DF 40 8..@
```

```
]
```

```
]
```

```
#2: ObjectId: 2.5.29.19 Criticality=false
```

```
BasicConstraints:[
```

```
CA:true
```

```
PathLen:2147483647
```

```
]
```

```
#3: ObjectId: 2.5.29.14 Criticality=false
```

```
SubjectKeyIdentifier [
```

```
KeyIdentifier [
```

```
0000: 0D B3 CF 81 66 4A 33 4E EF 86 7E 26 C3 50 9B 73 ....fJ3N...&.P.s
```

```
0010: 38 EF DF 40 8..@
```

```
]
```

```
]
```

```
Trust this certificate? [no]: yes
Certificate was added to keystore
```

Note If a NDB controller manages multiple switches, repeat this step for all the switches to add all switch keys into the same TrustStore. For example:

```
keytool -import -alias sw2 -file sw2-xnc-cert.pem -keystore tlsTrustStore
keytool -import -alias sw3 -file sw3-xnc-cert.pem -keystore tlsTrustStore
```

Step 11 List and verify keys for multiple switches in the same `tlsTrustStore` using the `keytool` command.

Example:

```
docker@docker-virtual-machine:~/TLS$ keytool -list -v -keystore tlsTrustStore | more
```

Starting NDB with TLS

To start NDB with TLS, complete these steps:

Step 1 Log in to the NDB server.

Step 2 Stop the NDB application, if running, using the **`runxnc.sh`** command

Example:

```
./runxnc.sh -stop
Controller with PID: 17426 -- Stopped!
```

Step 3 Copy the `tlsKeystore` and `tlsTruststore` files that you created to configuration folder of NDB (`xnc/configuration`).

Example:

```
cp tlskeystore /root/xnc/configuration
cp tlsTrustStore /root/xnc/configuration
```

Step 4 Start the NDB application with TLS using the **`runxnc.sh`** script.

Example:

```
./runxnc.sh -tls -tlskeystore ./configuration/tlsKeyStore -tlstruststore ./configuration/tlsTrustStore
```

Example:

To start NDB with default username (admin) and a non-default password (for example, `pwd123`):

```
./runxnc.sh -osgiPasswordSync -tls -tlskeystore ./configuration/tlsKeyStore -tlstruststore
./configuration/tlsTrustStore
```

If XNC password is changed, OSGi webconsole password needs to be changed.

To set non-default OSGi webconsole password, enter XNC Admin Password [default]:
(Type the non-default password which was set)

Note To disable TLS, run the **`./runxnc.sh -notls`** command. To disable TLS and start NDB, run the **`./runxnc.sh -notls -start`** command. Before disabling TLS, ensure to *stop* NDB. After TLS is disabled, the port number for the devices connected to the NDB server should be changed to 80.

Configuring TLS KeyStore and TrustStore Passwords on NDB

You need to configure TLS KeyStore and TrustStore passwords to enable NDB to read password protected TLS KeyStore and TrustStore files. To configure TLS KeyStore and TrustStore passwords on NDB, complete these steps:

Step 1 Log in to the NDB server.

Step 2 Navigate to bin directory.

Example:

```
cd xnc/bin
```

Step 3 Configure the TLS KeyStore and TrustStore passwords using the **xnc config-keystore-passwords** command.

Example:

```
./xnc config-keystore-passwords --user admin --password admin --url https://10.16.206.250:8443
--verbose --prompt --keystore-password cisco123 --truststore-password cisco123
```

In case NDB is configured with AAA (Tacacs/LDAP/Radius), and if the above command, **ndb config-keystore-passwords** fails, and you see a *401 unauthorized* error, then:

- a. Go to the `xnc` directory.
- b. Stop the NDB server using `./runxnc.sh -stop`.
- c. Enable the flag **enable.LocalUser.Authentication** by changing the value from *false* to *true* in the NDB `config.ini` file.
- d. Start the NDB server using `./runxnc.sh -start`.
- e. Run the **ndb config-keystore-passwords** command again.

Note In a HA environment, you need to run the above procedure for all the NDB servers in the cluster.

After the TLS is enabled on NDB, all the connections between NDB server and NDB switch are established using port 443. Ensure that you change device connections in NDB to use port 443.

Up on successfully completing these steps, you can add nexus switch in the controller using port 443. Use FQDN of the switch to add the device to the NDB controller.

You can verify the Certificate information using the WebUI Sandbox of the switch.

Generating TLS Self-Signed Certification Between NDB Server and NDB Switch for OpenFlow

Complete the following steps to generate TLS self-signed certification between NDB Server and NDB Switch for OpenFlow:

Step 1 Create a TLS directory using the **mkdir directory_name** and navigate to the new directory.

Example:

```
[]# mkdir -p TLS
>[]# cd TLS
```

Step 2 Create 3 directories under mypersonalca folder for CA system.

Example:

```
[]# mkdir -p mypersonalca/certs
>[]# mkdir -p mypersonalca/private
>[]# mkdir -p mypersonalca/crl
```

Step 3 Initialize the serial file using the **echo** command. The serial file and the index.txt file are used by the CA to maintain its database of the certificate files.

Example:

```
[]# echo "01" > mypersonalca/serial
```

Step 4 Initialize the index file using the **touch** command.

Example:

```
[]# touch mypersonalca/index.txt
```

Step 5 Create a CA configuration file and configure the alt_names section with relevant IP Addresses.

Example:

```
[ ca ]
default_ca = mypersonalca
[ mypersonalca ]
#
# WARNING: if you change that, change the default_keyfile in the [req] section below too
# Where everything is kept
dir = ./mypersonalca
# Where the issued certs are kept
certs = $dir/certs
# Where the issued crl are kept
crl_dir = $dir/crl
# database index file
database = $dir/index.txt
# default place for new certs
new_certs_dir = $dir/certs
#
# The CA certificate
certificate = $dir/certs/ca.pem
# The current serial number
serial = $dir/serial
# The current CRL
crl = $dir/crl/crl.pem
# WARNING: if you change that, change the default_keyfile in the [req] section below too
# The private key
private_key = $dir/private/ca.key
# private random number file
RANDFILE = $dir/private/.rand
# The extensions to add to the cert
x509_extensions = usr_cert
# how long to certify for
default_days = 365
```

```

# how long before next CRL
default_crl_days= 30
# which md to use; people in comments indicated to use sha1 here
default_md = sha1
# keep passed DN ordering
preserve = no
# Section names
policy = mypolicy
x509_extensions = certificate_extensions
[ mypolicy ]
# Use the supplied information
commonName = supplied
stateOrProvinceName = optional
countryName = optional
emailAddress = optional
organizationName = optional
organizationalUnitName = optional
[ certificate_extensions ]
# The signed certificate cannot be used as CA
basicConstraints = CA:false
[ req ]
# same as private_key
default_keyfile = ./mypersonalca/private/ca.key
# Which hash to use
default_md = sha1
# No prompts
prompt = no
# This is for CA
subjectKeyIdentifier=hash
authorityKeyIdentifier=keyid:always,issuer
string_mask = utf8only
basicConstraints = CA:true
distinguished_name = root_ca_distinguished_name
x509_extensions = root_ca_extensions
[ root_ca_distinguished_name ]
commonName = Controller
stateOrProvinceName = Mass
countryName = US
emailAddress = root_ca_userid@cisco.com
organizationName = Cisco
[ root_ca_extensions ]
basicConstraints = CA:true

```

Step 6 Generate the TLS private key, certificate, and Certification Authority (CA) files using the **openssl req** command. The TLS private key is created in PEM format with a key length of 2048 bits and the CA file.

Example:

```

openssl req -x509 -nodes -days 3650 -newkey rsa:2048 -out mypersonalca/certs/ca.pem -outform PEM
-keyout mypersonalca/private/ca.key

```

Generating a 2048 bit RSA private key

.....+++

.....+++

writing new private key to 'mypersonalca/private/ca.key'

You are about to be asked to enter information that will be incorporated into your certificate request.

What you are about to enter is what is called a Distinguished Name or a DN.

There are quite a few fields but you can leave some blank

For some fields there will be a default value,

If you enter '.', the field will be left blank.


```

-----
Country Name (2 letter code) [AU]:US
State or Province Name (full name) [Some-State]:Mass
Locality Name (eg, city) []:San
Organization Name (eg, company) [Internet Widgits Pty Ltd]:Cisco
Organizational Unit Name (eg, section) []:NDB
Common Name (e.g. server FQDN or YOUR name) []:Controller
Email Address []:masavanu@cisco.com

```

Note This step generates the TLS private key in PEM format with a key length of 2048 bits, and the CA file.

Step 7 Generate the certificate key and certificate request files, using the **openssl req** command.

Example:

```

openssl req -newkey rsa:2048 -keyout cert.key -keyform PEM -out cert.req -outform PEM
Generating a 2048 bit RSA private key
.....+++
.....+++
writing new private key to 'cert.key'
Enter PEM pass phrase:(Enter pwd123 here)
Verifying - Enter PEM pass phrase:(Enter pwd123 here)
-----
You are about to be asked to enter information that will be incorporated
into your certificate request.
What you are about to enter is what is called a Distinguished Name or a DN.
There are quite a few fields but you can leave some blank
For some fields there will be a default value,
If you enter '.', the field will be left blank.
-----
Country Name (2 letter code) [AU]:US
State or Province Name (full name) [Some-State]:Mass
Locality Name (eg, city) []:San
Organization Name (eg, company) [Internet Widgits Pty Ltd]:Cisco
Organizational Unit Name (eg, section) []:NDB
Common Name (e.g. server FQDN or YOUR name) []:Controller
Email Address []:masavanu@cisco.com
Please enter the following 'extra' attributes
to be sent with your certificate request
A challenge password []:pwd123
An optional company name []:

```

Note This step generates the controller key (cert.key) and certificate request (cert.req) files in PEM format.

Step 8 Generate the certificate file, using the **openssl ca** command.

Example:

```

openssl ca -batch -notext -in cert.req -out cert.pem -config ca.cnf
Using configuration from ca.cnf
Check that the request matches the signature
Signature ok
The Subject's Distinguished Name is as follows

```

```
countryName :PRINTABLE:'US'
stateOrProvinceName :ASN.1 12:'Mass'
localityName :ASN.1 12:'San'
organizationName :ASN.1 12:'Cisco'
organizationalUnitName:ASN.1 12:'NDB'
commonName :ASN.1 12:'Controller'
emailAddress :IA5STRING:'masavanu@cisco.com'
Certificate is to be certified until May 17 02:59:40 2017 GMT (365 days)
Write out database with 1 new entries
Data Base Updated
```

Note This step generates the certificate (cert.pem) file in PEM format using the certificate request (cert.req) and the certificate configuration (ca.cnf) files.

Step 9 Configure the Cryptographic Keys on the Switch.

Example:

```
switch(config)# ip domain-name domain-name
//Configures the domain name for the switch
switch(config)# crypto key generate rsa label myKey2 exportable modulus 2048
//Generates the cryptographic key.
switch(config)# crypto ca trustpoint myCA
//Enters the trustpoint configuration mode and installs the trustpoint file on the switch
switch(config-trustpoint)# rsakeypair myKey2
//Installs the key files on the switch
switch(config-trustpoint)# exit
//Exits trustpoint configuration mode
switch# show crypto ca trustpoints
//(Optional) Verifies creation of the trustpoint files.
switch# show crypto key mypubkey rsa
//(Optional) Verifies creation of the key files.
cat mypersonalca/certs/ca.pem
//Displays the certificate file on the machine hosting the generated TLS certificates
switch(config)# crypto ca authenticate myCA
-----BEGIN CERTIFICATE-----
-----END CERTIFICATE-----
END OF INPUT:
Fingerprint(s): SHA1
Fingerprint=56:0F:56:85:6A:07:A1:44:6C:F4:4C:45:CF:CC:BA:47:22:17:1D:93
Do you accept this certificate [yes/no]:yes
```

```
switch(config)# crypto ca enroll myCA
//Generates the certificate request on the switch
```

```
Create the certificate request ..
Create a challenge password. You will need to verbally provide this
password to the CA Administrator in order to revoke your certificate.
For security reasons your password will not be saved in the configuration.
Please make a note of it.
Password:pwd123
The subject name in the certificate will be the name of the switch.
Include the switch serial number in the subject name [yes/no]:no
Include an IP address in the subject name [yes/no]:no
Include the Alternate Subject Name [yes/no]:no
The certificate request will be displayed...
-----BEGIN CERTIFICATE REQUEST-----
```

```

.....
-----END CERTIFICATE REQUEST-----
openssl ca -in n3k-cert.req -out newcert.pem -config ./ca.cnf
//Copies the certificate request from the switch to the file n3k-cert.req on your Linux machine,
and then uses it to generate the switch certificate.
Using configuration from ./ca.cnf
Check that the request matches the signature
Signature ok
The Subject's Distinguished Name is as follows
commonName :PRINTABLE:'ndb-3172-4.cisco.com'
Certificate is to be certified until May 17 04:27:57 2017 GMT (365 days)
Sign the certificate [y/n]:y
out of 1 certificate requests certified, commit [y/n]y
Write out database with 1 new entries
Data Base Updated

cat newcert.pem
//Copies the certificate (newcert.pem) to the switch

switch(config)# crypto ca import myCA certificate
switch(config)# crypto ca import myCA certificate
input (cut & paste) certificate in PEM format:

switch# show crypto ca certificates
//Displays the certificates on the switch

```

Step 10 Enable the TLS OpenFlow Switches

Example:

```

switch(config)# openflow
//Enters OpenFlow agent configuration mode on the switch.
switch(config-ofa)# switch 1
//Enters OpenFlow agent configuration mode for switch 1.
switch(config-ofa)# tls trust-point local myCA remote myCA
//Enables TLS certificate authority on the switch.
switch(config-ofa-switch)# pipeline{201/203}
//Configures the pipeline
switch(config-ofa-switch)#controller ipv4 {A.B.C.D} port 6653 vrf management security tls
//Enables TLS for OpenFlow switches

```

Step 11 Create the TLS KeyStore File

Example:

```

cp cert.key xnc-privatekey.pem
//Copy cert.key to xnc-privatekey.pem
cp cert.pem xnc-cert.pem
//Copy cert.pem to xnc-cert.pem under TLS folder
cat xnc-privatekey.pem xnc-cert.pem > xnc.pem
Creates the xnc.pem file, which contains the private key and certificate.

openssl pkcs12 -export -out xnc.p12 -in xnc.pem
//Convert the PEM file xnc.pem file to the file xnc.p12
Enter a password at the prompt
The xnc.pem file is converted to a password-protected .p12 file.
openssl pkcs12 -export -out xnc.p12 -in xnc.pem
Enter pass phrase for xnc.pem:(enter pass phrase as pwd123)
Enter Export Password:(Enter Export password as pwd123)
Verifying - Enter Export Password:(Enter as pwd123)

```

Step 12 Convert the xnc.p12 file to password protected TLS KeyStore**Example:**

```
keytool -importkeystore -srckeystore xnc.p12 -srcstoretype pkcs12 -destkeystore tlsKeyStore
-deststoretype jks
Enter destination keystore password: (Enter pwd123)
Re-enter new password: (Enter pwd123)
Enter source keystore password: (Enter pwd123)
Entry for alias 1 successfully imported.
Import command completed: 1 entries successfully imported, 0 entries failed or
cancelled
```

Step 13 Enter the TLS KeyStore password.**Step 14** Create the TLS TrustStore File.**Example:**

```
cp mypersonalca/certs/ca.pem sw-cacert.pem
//Copies the mypersonalca/certs/ca.pem file to sw-cacert.pem
keytool -import -alias swca1 -file sw-cacert.pem -keystore tlsTrustStore
Enter keystore password: (Enter pwd123)
Re-enter new password: (Enter pwd123)
Owner: EMAILADDRESS=masavanu@cisco.com, CN=Controller, OU=NDB, O=Cisco, L=San,
ST=Mass, C=US
Issuer: EMAILADDRESS=masavanu@cisco.com, CN=Controller, OU=NDB, O=Cisco, L=San,
ST=Mass, C=US
Serial number: d764c5b1e5e6b531
Valid from: Mon May 16 22:49:13 EDT 2016 until: Thu May 14 22:49:13 EDT 2026
Certificate fingerprints:
MD5: BD:C8:21:13:D0:7F:ED:A4:B4:FA:97:9A:D0:EA:12:78
SHA1: 56:0F:56:85:6A:07:A1:44:6C:F4:4C:45:CF:CC:BA:47:22:17:1D:93
SHA256:
09:32:74:12:BF:56:04:07:42:8C:D8:1B:78:AD:7A:40:0D:51:AA:56:91:B1:1A:18:90:6A:A5:A0:44:04:6A:EC
Signature algorithm name: SHA256withRSA
Version: 3
Extensions:
#1: ObjectId: 2.5.29.35 Criticality=false
AuthorityKeyIdentifier [
KeyIdentifier [
0000: 78 C5 2B 09 7F AF EC 86 FE 50 EA 6C 8A 56 B3 BE x.+.....P.l.V..
0010: BE F2 97 98 ....
]
]
#2: ObjectId: 2.5.29.19 Criticality=false
BasicConstraints:[
CA:true
PathLen:2147483647
]
#3: ObjectId: 2.5.29.14 Criticality=false
SubjectKeyIdentifier [
KeyIdentifier [
0000: 78 C5 2B 09 7F AF EC 86 FE 50 EA 6C 8A 56 B3 BE x.+.....P.l.V..
0010: BE F2 97 98 ....
]
]
```

```
]
Trust this certificate [no]: yes
Certificate was added to keystore
```

Note The sw-cacert.pem file is converted into a password-protected Java TrustStore (tlsTrustStore) file.

Starting the NDB Application with TLS Enabled

Complete the following steps to start NDB application with TLS enabled.

Before you begin

Copy TLS Truststore and TLS Keystore files created under TLS folder to the configuration directory of Cisco Nexus Data Broker.

Step 1 Start the NDB application using the **runxnc.sh** script.

Example:

```
./runxnc.sh -tls -tlskeystore ./configuration/tlsKeyStore -tlstruststore ./configuration/tlsTrustStore
```

Example:

To start NDB with default username (admin) and a non-default password (for example, pwd123):

```
./runxnc.sh -osgiPasswordSync -tls -tlskeystore ./configuration/tlsKeyStore -tlstruststore
./configuration/tlsTrustStore
```

If XNC password is changed, OSGi webconsole password needs to be changed, to set non-default OSGi webconsole password Enter XNC Admin Password [default]: (Type the non-default password which was set)

Example:

To start NDB with default username (admin) and password (admin):

```
./runxnc.sh -tls -tlskeystore ./configuration/tlsKeyStore -tlstruststore ./configuration/tlsTrustStore
```

Step 2 Configure the TLS KeyStore and TrustStore passwords in Cisco NDB. You need to configure TLS KeyStore and TrustStore Passwords to enable NDB to read the password-protected TLS KeyStore and TrustStore files.

Example:

```
xnc/bin directory# ./xnc config-keystore-passwords --user admin --password admin --url
https://NDB_URL:8443
--verbose --prompt --keystore-password pwd123 --truststore-password pwd123
```

If the TLS KeyStore and TrustStore passwords configuration fails with Failed to connect to the controller, you need to change the protocol to HTTP.

```
./xnc config-keystore-passwords --user admin --password admin --url https://localhost:8443 --verbose
--prompt --keystore-password pwd123 --truststore-password pwd123
[Info] Sending request: https://10.16.206.189:8443/controller/osgi/system/console/vmstat
---- REQUEST HEADERS ----
GET https://10.16.206.189:8443/controller/osgi/system/console/vmstat HTTP/1.1
-----
[Error] Failed to connect to the controller at "https://10.16.206.189:8443". Controller may not be
running.
```

```

javax.net.ssl.SSLHandshakeException: java.security.cert.CertificateException:
No subject alternative names present
at sun.security.ssl.Alerts.getSSLException(Alerts.java:192)
at sun.security.ssl.SSLSocketImpl.fatal(SSLSocketImpl.java:1949)
at sun.security.ssl.Handshaker.fatalSE(Handshaker.java:302)
at sun.security.ssl.Handshaker.fatalSE(Handshaker.java:296)
at sun.security.ssl.ClientHandshaker.serverCertificate(ClientHandshaker.java:1509)
at sun.security.ssl.ClientHandshaker.processMessage(ClientHandshaker.java:216)
at sun.security.ssl.Handshaker.processLoop(Handshaker.java:979)
at sun.security.ssl.Handshaker.process_record(Handshaker.java:914)
at sun.security.ssl.SSLSocketImpl.readRecord(SSLSocketImpl.java:1062)
at sun.security.ssl.SSLSocketImpl.performInitialHandshake(SSLSocketImpl.java:1375)
at sun.security.ssl.SSLSocketImpl.startHandshake(SSLSocketImpl.java:1403)
at sun.security.ssl.SSLSocketImpl.startHandshake(SSLSocketImpl.java:1387)
at sun.net.www.protocol.https.HttpsClient.afterConnect(HttpsClient.java:559)
at
sun.net.www.protocol.https.AbstractDelegateHttpsURLConnection.connect(AbstractDelegateHttpsURLConnection.java:185)

at sun.net.www.protocol.http.HttpURLConnection.getInputStream0(HttpURLConnection.java:1513)
at sun.net.www.protocol.http.HttpURLConnection.getInputStream(HttpURLConnection.java:1441)
at java.net.HttpURLConnection.getResponseCode(HttpURLConnection.java:480)
at sun.net.www.protocol.https.HttpsURLConnectionImpl.getResponseCode(HttpsURLConnectionImpl.java:338)

at com.cisco.csdn.cli.online.HttpClient$HttpResponse.<init>(HttpClient.java:191)
at com.cisco.csdn.cli.online.HttpClient.sendRequest(HttpClient.java:108)
at com.cisco.csdn.cli.online.HttpClient.get(HttpClient.java:92)
at com.cisco.csdn.cli.online.OnlineCommand.isRunning(OnlineCommand.java:88)
at
com.cisco.csdn.cli.online.ConfigKeyStorePasswordCommand.processCommand(ConfigKeyStorePasswordCommand.java:46)

at com.cisco.csdn.cli.Cli.processCommand(Cli.java:70)
at com.cisco.csdn.cli.Main.main(Main.java:33)
Caused by: java.security.cert.CertificateException: No subject alternative names present
at sun.security.util.HostnameChecker.matchIP(HostnameChecker.java:144)
at sun.security.util.HostnameChecker.match(HostnameChecker.java:93)
at sun.security.ssl.X509TrustManagerImpl.checkIdentity(X509TrustManagerImpl.java:455)
at sun.security.ssl.X509TrustManagerImpl.checkIdentity(X509TrustManagerImpl.java:436)
at sun.security.ssl.X509TrustManagerImpl.checkTrusted(X509TrustManagerImpl.java:200)
at sun.security.ssl.X509TrustManagerImpl.checkServerTrusted(X509TrustManagerImpl.java:124)
at sun.security.ssl.ClientHandshaker.serverCertificate(ClientHandshaker.java:1491)
... 20 more

//Change the protocol to HTTP.
./xnc config-keystore-passwords --user admin --password admin --url http://localhost:8080
--verbose --prompt --keystore-password pwd123 --truststore-password pwd123

```

Note Ensure that the `tlsKeyStore` and `tlsTrustStore` files are located in the configuration directory under `xnc` where the NDB.zip file is extracted.

Generating TLS Self-Signed Certification Between WebUI Browser and NDB Server

You can secure communication between a Web browser and NDB server running in centralized or embedded mode using self-signed certificates. This section describes how to generate a self-signed certificate to secure communication between a WebUI browser and NDB application. By default Cisco NDB is shipped with default certificate which is issued to Cisco XNC and issued by Cisco XNC with default validity. You can use the `generateWebUICertificate.sh` script under configuration folder to create self-signed certificates. For Cisco

NDB releases 3.5 and earlier, these certificates are valid for 6 months. Starting with Cisco NDB release 3.6, default validity of a certificate is 6 months but you can configure the validity of a certificate.



Note You can create self-signed TLS certificates for NDB in Centralized mode only. NDB in Embedded mode does not support self-signed TLS certificates.

- Generating TLS Self-Signed Certification Between WebUI Browser and NDB Server Running in Centralized Mode
- Generating TLS Self-Signed Certification Between WebUI Browser and NDB Server Running in Embedded Mode

Generating TLS Self-Signed Certification Between WebUI Browser and NDB Server Running in Centralized Environment

Complete the following steps to generate TLS self-signed certification between WebUI Browser and NDB Server running in Centralized mode:

Step 1 Log into the NDB server and change the current directory `\xnc\configuration`.

Example:

```
[root@RHEL-VM-NDB-ACI]# cd \xnc\configuration
```

Step 2 Generate the TLS self-signed certificate using the `generateWebUICertificate.sh` script.

Example:

```
[root@RHEL-VM-NDB-ACI configuration]# ./generateWebUICertificate.sh
```

```
*****
Enter Fully qualified domain name :
*****
NDB-browser□ This can be FQDN of the NDB java application as well
*****
Enter Organizational unit :
*****
INSBU
*****
Enter Organization :
*****
cisco
*****
Enter Location :
*****
SJ
*****
Enter State :
*****
CA
```

```

*****
Enter Country :
*****
USA
*****
Enter keypass :
*****
cisco123
*****
Enter storepass :
*****
cisco123
*****
Enter the validity in number of days :
*****
365 ☐ in NDB 3.5 this script will let you to specify the certificate validity.
*****
Below process will rename the existing key file to <old_keystore>, will generate
a new key file. Do you want to continue (y/n) ?
*****
Y
*****
Self-Signed Certificate Created
*****
Alias name: cisco
Creation date: Jan 6, 2019
Entry type: PrivateKeyEntry
Certificate chain length: 1
Certificate[1]:
Owner: CN=NDB-browser, OU=INSBU, O=cisco, L=SJ, ST=CA, C=USA
Issuer: CN=NDB-browser, OU=INSBU, O=cisco, L=SJ, ST=CA, C=USA
Serial number: b404be5
Valid from: Sun Jan 06 20:22:05 PST 2019 until: Mon Jan 06 20:22:05 PST 2020
Certificate fingerprints:
    MD5: 71:07:F6:4E:57:6A:08:3A:AD:06:32:B3:6C:5F:8F:52
    SHA1: 04:08:B9:D5:B7:EB:ED:E0:F9:22:49:14:FA:C6:09:39:22:32:43:A2
    SHA256:
34:D9:EB:34:0A:52:D1:4A:DD:F1:8B:14:D0:84:E4:1C:57:8B:2B:99:9B:E5:A1:4C:C7:8C:CD:AE:24:31:49:75

    Signature algorithm name: SHA256withRSA
    Version: 3

Extensions:

#1: ObjectId: 2.5.29.14 Criticality=false
SubjectKeyIdentifier [
KeyIdentifier [
0000: 63 8A 92 8F 6F 0F 45 BD EE 55 C5 A8 99 3B F6 F7 c...o.E..U...;...
0010: AC FA 4A 21 ..J!
]
]

```



```

*****
Displayed the generated keystore
*****
*****
Configured the keystore details on tomcat-server.xml
*****
*****
The newly generated key will used on next NDB restart. Do you want to restart NDB
now (y/n) ?
*****
Y
Doesn't seem any Controller daemon is currently running
Running controller in background with PID: 13573, to connect to it please SSH to
this host on port 2400
NDB GUI can be accessed using below URL:
[https://10.16.206.160:8443]
[https://[fe80::250:56ff:fe90:b764]:8443]
[https://10.16.206.159:8443]
[https://192.168.1.123:8443]
[https://[fe80::250:56ff:fe90:9c79]:8443]

*****
NDB Restarted
*****

```

Note The **generateWebUICertificate.sh** script reloads the NDB application to ensure that the browser starts using this certificate when we access NDB java application from the browser.

Step 3 Decode the generated certificate using the **keytool -list -v -keystore keystore_Name** command. Enter the store password when prompted.

Example:

```

[root@RHEL-VM-NDB-ACI configuration]# keytool -list -v -keystore keystore
Enter keystore password:

Keystore type: JKS
Keystore provider: SUN

Your keystore contains 1 entry

Alias name: cisco
Creation date: Jul 6, 2019
Entry type: PrivateKeyEntry
Certificate chain length: 1
Certificate[1]:
Owner: CN=NDB-browser, OU=INSBU, O=cisco, L=SJ, ST=CA, C=USA
Issuer: CN=NDB-browser, OU=INSBU, O=cisco, L=SJ, ST=CA, C=USA
Serial number: b404be5
Valid from: Sun Jan 06 20:22:05 PST 2019 until: Mon Jan 06 20:22:05 PST 2020
Certificate fingerprints:
    MD5: 71:07:F6:4E:57:6A:08:3A:AD:06:32:B3:6C:5F:8F:52
    SHA1: 04:08:B9:D5:B7:EB:ED:E0:F9:22:49:14:FA:C6:09:39:22:32:43:A2
    SHA256:
34:D9:EB:34:0A:52:D1:4A:DD:F1:8B:14:D0:84:E4:1C:57:8B:2B:99:9B:E5:A1:4C:C7:8C:CD:AE:24:31:49:75
Signature algorithm name: SHA256withRSA
Version: 3

```

Extensions:

```
#1: ObjectId: 2.5.29.14 Criticality=false
SubjectKeyIdentifier [
KeyIdentifier [
0000: 63 8A 92 8F 6F 0F 45 BD   EE 55 C5 A8 99 3B F6 F7   C...O.E..U...;..
0010: AC FA 4A 21               ..J!
]
]
```

```
*****
*****
```

Step 4 The self-signed certificates are generated in JKS format which is not compatible with the browsers. Hence, you need to convert these certificates into PKCS12 format before importing the certificate in the browser. Complete the following steps to convert JKS format certificate to PKCS12 format. Convert JKS format certificate into PKCS12 format using the **keytool** command.

Note Ensure that you keep a copy of the original certificates before proceeding with the conversion.

Example:

```
keytool -importkeystore -srckeystore keystore -srcstorepass cisco123 -srckeypass cisco123 -destkeystore
keystore.p12 -deststoretype PKCS12 -srcalias cisco -deststorepass cisco123 -destkeypass cisco123
```

Note The inputs in the **keytool** command should match the inputs provided during UI certificate generation.

Note The resulting certificate file (keystore.p12) is in PKCS12 format.

Step 5 Add this certificate to Trusted Root certificate store on the browser. See help for respective Web browsers about how to add the certificate to the Trusted Root certificate store.

Generating TLS Self-Signed Certification Between Web Browser and NDB Server Running in Embedded Mode

You can generate TLS self-signed certification between a Web browser and NDB server running in Embedded mode for two environments: Guestshell Environment and OVA Environment.

- Generating TLS 3rd Party Certification Between Web Browser and NDB Server Running in Embedded Mode - Guestshell Environment
- Generating TLS 3rd Party Certification Between Web Browser and NDB Server Running in Embedded Mode - OVA Environment

Generating TLS Self-Signed Certificate Between Web Browser and NDB Server Running in Embedded Mode Using Guest Shell Environment

To generate TLS self-signed certificate between Web browser and NDB server running in embedded mode using Guest Shell environment, complete the following steps.

Step 1 Connect to Guest Shell using **guestshell** command.

Example:

```
N9K-C93108TC-EX-108# guestshell
[admin@guestshell ~]$
[admin@guestshell ~]$
```

Step 2 Change the current directory to `\xnc\configuration`.

Example:

```
[admin@guestshell ~]$ cd \xnc\configuration
```

Step 3 Edit the `generateWebUICertificate.sh` script. Update the Keytool attribute in the file (two instances) with the NDB OVA JRE path.

Example:

```
cmd1=echo /home/admin/xnc/jre/bin/keytool -genkey -noprompt -trustcacerts -keyalg RSA -alias cisco
-dname "CN=$CN, OU=$OU, O=$O, L=$L, ST=$ST, C=$C" -keypass $Keypass -keystore $eig -storepass
$Storepass -validity $validityVal

cmd2=echo /home/admin/xnc/jre/bin/keytool -alias cisco -list -v -keystore keystore -storepass $Storepass;
```

Step 4 Set Java home path using the **export** command.

Example:

```
[admin@guestshell ~]$ export JAVA_HOME='/usr/lib/jvm/i586-wrs-jre'
```

Step 5 Generate the TLS self-signed certificate using the `/home/admin/xnc/configuration/generateWebUICertificate.sh` script.

Example:

```
[root@RHEL-VM-NDB-ACI configuration]# ./generateWebUICertificate.sh

*****
Entor Fully qualified domain name :
*****
NDB-browser This can be FQDN of the NDB java application as well
*****
Entor Organizational unit :
*****
INSBU
*****
Entor Organization :
*****
cisco
*****
Entor Location :
*****
SJ
*****
Entor State :
*****
```

```

CA
*****
Enter Country :
*****
USA
*****
Enter keypass :
*****
cisco123
*****
Enter storepass :
*****
cisco123
*****
Enter the validity in number of days :
*****
365 ☐ in NDB 3.5 this script will let you to specify the certificate validity.
*****
Below process will rename the existing key file to <old_keystore>, will generate
a new key file. Do you want to continue (y/n) ?
*****
Y
*****
Self-Signed Certificate Created
*****
Alias name: cisco
Creation date: Jan 6, 2019
Entry type: PrivateKeyEntry
Certificate chain length: 1
Certificate[1]:
Owner: CN=NDB-browser, OU=INSBU, O=cisco, L=SJ, ST=CA, C=USA
Issuer: CN=NDB-browser, OU=INSBU, O=cisco, L=SJ, ST=CA, C=USA
Serial number: b404be5
Valid from: Sun Jan 06 20:22:05 PST 2019 until: Mon Jan 06 20:22:05 PST 2020
Certificate fingerprints:
    MD5: 71:07:F6:4E:57:6A:08:3A:AD:06:32:B3:6C:5F:8F:52
    SHA1: 04:08:B9:D5:B7:EB:ED:E0:F9:22:49:14:FA:C6:09:39:22:32:43:A2
    SHA256:
34:D9:EB:34:0A:52:D1:4A:DD:F1:8B:14:D0:84:E4:1C:57:8B:2B:99:9B:E5:A1:4C:C7:8C:CD:AE:24:31:49:75

    Signature algorithm name: SHA256withRSA
    Version: 3

Extensions:

#1: ObjectId: 2.5.29.14 Criticality=false
SubjectKeyIdentifier [
KeyIdentifier [
0000: 63 8A 92 8F 6F 0F 45 BD EE 55 C5 A8 99 3B F6 F7 c...o.E..U...;...
0010: AC FA 4A 21 ..J!
]

```

```

]

*****
Displayed the generated keystore
*****
*****
Configured the keystore details on tomcat-server.xml
*****
*****
The newly generated key will used on next NDB restart. Do you want to restart NDB
now (y/n) ?
*****
Y
Doesn't seem any Controller daemon is currently running
Running controller in background with PID: 13573, to connect to it please SSH to
this host on port 2400
NDB GUI can be accessed using below URL:
[https://10.16.206.160:8443]
[https://[fe80::250:56ff:fe90:b764]:8443]
[https://10.16.206.159:8443]
[https://192.168.1.123:8443]
[https://[fe80::250:56ff:fe90:9c79]:8443]

*****
NDB Restarted
*****

```

Note The **generateWebUICertificate.sh** script reloads the NDB application to ensure that the browser starts using this certificate when we access NDB java application from the browser.

Step 6 Decode the generated certificate using the **keytool -list -v -keystore keystore_Name** command. Enter the store password when prompted.

Example:

```

[root@RHEL-VM-NDB-ACI configuration]# /home/admin/xnc/jre/bin/keytool -list -v -keystore keystore
Enter keystore password:

Keystore type: JKS
Keystore provider: SUN

Your keystore contains 1 entry

Alias name: cisco
Creation date: Jul 6, 2019
Entry type: PrivateKeyEntry
Certificate chain length: 1
Certificate[1]:
Owner: CN=NDB-browser, OU=INSBU, O=cisco, L=SJ, ST=CA, C=USA
Issuer: CN=NDB-browser, OU=INSBU, O=cisco, L=SJ, ST=CA, C=USA
Serial number: b404be5
Valid from: Sun Jan 06 20:22:05 PST 2019 until: Mon Jan 06 20:22:05 PST 2020
Certificate fingerprints:
    MD5: 71:07:F6:4E:57:6A:08:3A:AD:06:32:B3:6C:5F:8F:52
    SHA1: 04:08:B9:D5:B7:EB:ED:E0:F9:22:49:14:FA:C6:09:39:22:32:43:A2
    SHA256:
34:D9:EB:34:0A:52:D1:4A:DD:F1:8B:14:D0:84:E4:1C:57:8B:2B:99:9B:E5:A1:4C:C7:8C:CD:AE:24:31:49:75

```

```
Signature algorithm name: SHA256withRSA
Version: 3
```

```
Extensions:
```

```
#1: ObjectId: 2.5.29.14 Criticality=false
SubjectKeyIdentifier [
KeyIdentifier [
0000: 63 8A 92 8F 6F 0F 45 BD   EE 55 C5 A8 99 3B F6 F7   c...o.E..U...;..
0010: AC FA 4A 21               ..J!
]
]
```

```
*****
*****
```

Step 7 The self-signed certificates are generated in JKS format which is not compatible with the browsers. You need to convert these certificates into PKCS12 format before importing the certificate in the browser. Complete the following steps to convert JKS format certificate to PKCS12 format. Convert JKS format certificate into PKCS12 format using the **keytool** command.

Note Ensure that you keep a copy of the original certificates before proceeding with the conversion.

Example:

```
/home/admin/xnc/jre/bin/keytool -importkeystore -srckeystore keystore -srcstorepass cisco123
-srckeypass cisco123 -destkeystore keystore.p12 -deststoretype PKCS12 -srcalias cisco -deststorepass
cisco123 -destkeypass cisco123
```

Note The inputs in the **keytool** command should match the inputs provided during UI certificate generation.

Note The resulting certificate file (keystore.p12) is in PKSC12 format.

Step 8 Upload the CA certificate into Trusted Root certificate store of Web browser. See help for respective Web browsers about how to add the certificate to the Trusted Root certificate store. Use the password that you created while creating the certificate when prompted while uploading the certificate to the Web browser.

Step 9 Restart the Guest Shell to restart the NDB.

Generating TLS Self-Signed Certificate Between Web Browser and NDB Server Running in Embedded Mode Using OVA Environment

To generate TLS self-signed certificate between Web browser and NDB server running in embedded mode using OVA environment, complete the following steps.

Step 1 Connect to virtual service console using the **virtual-service connect** command.

Example:

```
N3K-3172# virtual-service connect name ova console
Connecting to virtual-service. Exit using ^c^c^c
Entering character mode
Escape character is '^]'.
root@N3K-3172:~#
root@N3K-3172:~#
```

Step 2 Change current directory to /xnclite/xnc/configuration.

Example:

```
root@ N9396TX-116:~# cd /xnclite/xnc/configuration
root@ N9396TX-116:/xnclite/xnc/configuration#
```

Step 3 Edit the generateWebUICertificate.sh script. Update the Keytool attribute in the file(two instances) with the NDB OVA JRE path.

Example:

```
cmd1=echo /usr/lib/jvm/i586-wrs-jre/bin/keytool -genkey -noprompt -trustcacerts -keyalg RSA -alias
cisco -dname "CN=$CN, OU=$OU, O=$O, L=$L, ST=$ST, C=$C" -keypass $Keypass -keystore $eig -storepass
$Storepass -validity $validityVal
```

```
cmd2=echo /usr/lib/jvm/i586-wrs-jre/bin/keytool -alias cisco -list -v -keystore keystore -storepass
$Storepass;
```

Step 4 Set Java home path using the **export** command.

Example:

```
export JAVA_HOME='/usr/lib/jvm/i586-wrs-jre'
```

Step 5 Generate the TLS self-signed certificate using the /home/admin/xnc/configuration/generateWebUICertificate.sh script.

Example:

```
[root@RHEL-VM-NDB-ACI configuration]# ./generateWebUICertificate.sh
```

```
*****
Enter Fully qualified domain name :
*****
NDB-browser This can be FQDN of the NDB java application as well
*****
Enter Organizational unit :
*****
INSBU
*****
Enter Organization :
*****
cisco
*****
Enter Location :
*****
SJ
*****
Enter State :
*****
CA
*****
Enter Country :
*****
USA
*****
```

```

Enter keypass :
*****
cisco123
*****
Enter storepass :
*****
cisco123
*****
Enter the validity in number of days :
*****
365 ☐ in NDB 3.5 this script will let you to specify the certificate validity.
*****
Below process will rename the existing key file to <old_keystore>, will generate
a new key file. Do you want to continue (y/n) ?
*****
Y
*****
Self-Signed Certificate Created
*****
Alias name: cisco
Creation date: Jan 6, 2019
Entry type: PrivateKeyEntry
Certificate chain length: 1
Certificate[1]:
Owner: CN=NDB-browser, OU=INSBU, O=cisco, L=SJ, ST=CA, C=USA
Issuer: CN=NDB-browser, OU=INSBU, O=cisco, L=SJ, ST=CA, C=USA
Serial number: b404be5
Valid from: Sun Jan 06 20:22:05 PST 2019 until: Mon Jan 06 20:22:05 PST 2020
Certificate fingerprints:
    MD5: 71:07:F6:4E:57:6A:08:3A:AD:06:32:B3:6C:5F:8F:52
    SHA1: 04:08:B9:D5:B7:EB:ED:E0:F9:22:49:14:FA:C6:09:39:22:32:43:A2
    SHA256:
34:D9:EB:34:0A:52:D1:4A:DD:F1:8B:14:D0:84:E4:1C:57:8B:2B:99:9B:E5:A1:4C:C7:8C:CD:AE:24:31:49:75

    Signature algorithm name: SHA256withRSA
    Version: 3

Extensions:

#1: ObjectId: 2.5.29.14 Criticality=false
SubjectKeyIdentifier [
KeyIdentifier [
0000: 63 8A 92 8F 6F 0F 45 BD EE 55 C5 A8 99 3B F6 F7 c...o.E..U...;...
0010: AC FA 4A 21 ..J!
]
]

*****
Displayed the generated keystore
*****
*****

```



```

Configured the keystore details on tomcat-server.xml
*****
*****
The newly generated key will used on next NDB restart. Do you want to restart NDB
now (y/n) ?
*****
y
Doesn't seem any Controller daemon is currently running
Running controller in background with PID: 13573, to connect to it please SSH to
this host on port 2400
NDB GUI can be accessed using below URL:
[https://10.16.206.160:8443]
[https://[fe80::250:56ff:fe90:b764]:8443]
[https://10.16.206.159:8443]
[https://192.168.1.123:8443]
[https://[fe80::250:56ff:fe90:9c79]:8443]

*****
NDB Restarted
*****

```

Note The **generateWebUICertificate.sh** script reloads the NDB application to ensure that the browser starts using this certificate when we access NDB java application from the browser.

Step 6 Decode the generated certificate using the **keytool -list -v -keystore keystore_Name** command. Enter the store password when prompted.

Example:

```

[root@RHEL-VM-NDB-ACI configuration]# /usr/lib/jvm/i586-wrs-jre/bin/keytool -list -v -keystore keystore
Enter keystore password:

Keystore type: JKS
Keystore provider: SUN

Your keystore contains 1 entry

Alias name: cisco
Creation date: Jul 6, 2019
Entry type: PrivateKeyEntry
Certificate chain length: 1
Certificate[1]:
Owner: CN=NDB-browser, OU=INSBU, O=cisco, L=SJ, ST=CA, C=USA
Issuer: CN=NDB-browser, OU=INSBU, O=cisco, L=SJ, ST=CA, C=USA
Serial number: b404be5
Valid from: Sun Jan 06 20:22:05 PST 2019 until: Mon Jan 06 20:22:05 PST 2020
Certificate fingerprints:
    MD5: 71:07:F6:4E:57:6A:08:3A:AD:06:32:B3:6C:5F:8F:52
    SHA1: 04:08:B9:D5:B7:EB:ED:E0:F9:22:49:14:FA:C6:09:39:22:32:43:A2
    SHA256:
34:D9:EB:34:0A:52:D1:4A:DD:F1:8B:14:D0:84:E4:1C:57:8B:2B:99:9B:E5:A1:4C:C7:8C:CD:AE:24:31:49:75
    Signature algorithm name: SHA256withRSA
    Version: 3

Extensions:

#1: ObjectId: 2.5.29.14 Criticality=false
SubjectKeyIdentifier [
KeyIdentifier [

```

```

0000: 63 8A 92 8F 6F 0F 45 BD   EE 55 C5 A8 99 3B F6 F7   c...O.E..U...;..
0010: AC FA 4A 21                   ..J!
]
]

```

```

*****
*****

```

- Step 7** Convert the `ndb-server-xnc.p12` to a password protected Java KeyStore (`ndb-server-keystore`) file using the **keytool** command. This command converts the `sw1-xnc.p12` file to a password-protected `ndb-server-keystore` file. Create a new password for the destination JKS store and enter the source keystore password when prompted.

Example:

```

root@ N9396TX-116:/xnc-lite/xnc/configuration# /usr/lib/jvm/i586-wrs-jre/bin/keytool keytool
-importkeystore -srckeystore keystore -srcstorepass cisco123 -srckeypass cisco123 -destkeystore
keystore.p12 -deststoretype PKCS12 -srcalias cisco -deststorepass cisco123 -destkeypass cisco123

```

Entry for alias 1 successfully imported.

Import command completed: 1 entries successfully imported, 0 entries failed or cancelled

Note This command creates final self-signed certificate (`keystore.p12`) in PKCS12 format.

- Step 8** Upload the self-signed certificate into Trusted Root certificate store of your Web browser. See help for respective Web browsers about how to add a certificate to the Trusted Root certificate store. Use the password that you used while creating the certificate when prompted while uploading the certificate to the Web browser.
- Step 9** Deactivate and activate the virtual service to restart the NDB.

Generating TLS 3rd Party Certification Between WebUI Browser and NDB Server

You can secure communication between a Web browser and NDB server running in centralized or embedded mode. This section describes how to generate CA certificates, convert the certificates into JKS format, and upload the certificates into a Web browser. To generate a CA certificate, you need to generate a Certificate Signing Request (CSR) and send it to a Certificate issuing authority (CA). You can use an open source tool to generate a CSR.

- Generating TLS 3rd Party Certification Between WebUI Browser and NDB Server Running in Centralized Mode
- Generating TLS 3rd Party Certification Between WebUI Browser and NDB Server Running in Embedded Mode

Generating TLS 3rd Party Certification Between WebUI Browser and NDB Server Running in Centralized Mode

Complete these steps to generate TLS 3rd party certification between WebUI browser and NDB server running in centralized mode:

Step 1

Generate Certificate Signing Request (CSR) using the **openssl req** command.

Example:

```
[root@NDB-server ~]# openssl req -newkey rsa:2048 -sha256 -keyout ndb-server.key -keyform PEM -out
ndb-server.req -outform PEM
Generating a 2048 bit RSA private key
...+++
.....+++
writing new private key to 'ndb-server.key'
Enter PEM pass phrase: [ ] cisco123
Verifying - Enter PEM pass phrase: [ ] cisco123
-----
You are about to be asked to enter information that will be incorporated
into your certificate request.
What you are about to enter is what is called a Distinguished Name or a DN.
There are quite a few fields but you can leave some blank
For some fields there will be a default value,
If you enter '.', the field will be left blank.
-----
Country Name (2 letter code) [GB]:US
State or Province Name (full name) [Berkshire]:CA
Locality Name (eg, city) [Newbury]:SJ
Organization Name (eg, company) [My Company Ltd]:cisco
Organizational Unit Name (eg, section) []:insbu
Common Name (eg, your name or your server's hostname) []:ndb-server.cisco.com
Email Address []:chburra@cisco.com

Please enter the following 'extra' attributes
to be sent with your certificate request
A challenge password []:cisco123
An optional company name []:cisco123
```

```
[root@NDB-server ~]# ls
ndb-server.req  ndb-server.key
```

Note The ndb-server.req (CSR) file is submitted to the certificate issuing authority (CA).

Note You need to use the same information when exporting the CA provided certificate into browser. The CSR file, cert.req, is submitted to CA.

Step 2

To verify or view the CSR request, use the **openssl req** command.

Example:

```
[root@NDB-server ~]# openssl req -noout -text -in ndb-server.req
Certificate Request:
  Data:
    Version: 0 (0x0)
    Subject: C=US, ST=CA, L=SJ, O=cisco, OU=insbu,
CN=ndb-server.cisco.com/emailAddress=chburra@cisco.com
    Subject Public Key Info:
```

```

Public Key Algorithm: rsaEncryption
RSA Public Key: (2048 bit)
  Modulus (2048 bit):
    00:b5:30:75:e8:c8:5f:05:3b:0e:4f:aa:00:d9:64:
    8d:bf:b2:80:20:56:c3:be:b0:4c:e0:52:e5:be:d8:
    d2:74:85:4e:8a:ba:d3:1e:30:76:bf:e5:de:7d:51:
    11:79:8e:bc:96:38:7a:23:5a:26:31:50:50:fa:29:
    44:ab:56:b6:0d:41:38:ba:d1:d5:b4:e3:ba:a3:6c:
    4a:35:73:27:d9:fd:5c:4b:21:85:1a:f9:4d:b0:9e:
    f3:ae:ce:49:98:ef:a2:f8:11:ab:bd:7e:64:ee:68:
    68:19:6e:8f:3c:54:30:0f:28:01:13:b0:3d:34:b8:
    f9:f5:cc:4a:84:d8:e5:d2:27:47:cc:83:76:92:ad:
    92:62:f3:a3:35:be:14:ce:38:af:2a:c5:2e:fa:b8:
    31:6b:71:cd:56:00:1f:0d:cc:b0:f8:fc:b0:52:91:
    f8:9c:cf:45:13:c9:b5:86:fa:30:dd:88:78:01:15:
    fb:5c:c9:6f:5b:b7:80:28:6c:86:54:c0:f2:5f:35:
    70:82:49:5c:79:1c:f2:23:dd:50:d5:47:12:37:a3:
    3f:f9:1d:90:8f:c0:e8:18:09:2e:66:8d:c3:72:17:
    7f:7d:27:da:b1:cc:26:2d:8c:6b:ee:c5:e8:b5:78:
    31:7c:bb:ba:6d:2c:e5:a3:29:7e:c1:4a:93:19:ed:
    9a:e7
  Exponent: 65537 (0x10001)
Attributes:
  unstructuredName      :cisco123
  challengePassword     :cisco123
Signature Algorithm: sha256WithRSAEncryption
  9c:9a:51:e0:1d:e4:0b:8f:c1:c6:f5:e0:d2:f6:30:0e:18:af:
  a7:b2:a4:4a:57:d7:07:44:cd:9c:fa:2d:0e:8b:c9:31:5b:16:
  6b:84:42:0b:ed:06:5c:ed:30:d8:9b:ee:5d:79:f4:8a:e3:52:
  3c:b3:4a:eb:6c:22:a2:f4:35:80:28:3a:67:62:7f:5f:dc:80:
  e0:74:f0:3c:39:26:39:3a:76:6a:6a:98:e9:68:f9:b7:58:bf:
  e7:44:2e:e7:73:0a:9c:62:28:b2:c6:09:41:81:b2:53:46:14:
  e6:e4:dc:ca:90:81:5a:5e:dc:1b:dc:36:2c:86:5f:37:29:4c:
  b0:ee:85:2b:34:f2:82:8a:d4:fc:a0:ce:10:e4:44:4e:d0:7a:
  37:6d:3e:f9:ff:a1:19:8c:db:06:bf:be:87:57:a1:cb:05:15:
  0b:9f:6c:8b:c2:ad:22:25:10:f0:4d:0f:4d:b7:be:71:87:f7:
  85:24:e7:2d:f9:59:86:1a:b7:88:57:16:93:31:1f:d7:e5:07:
  42:77:00:f9:ac:44:3b:6c:35:0f:80:5d:00:6f:ea:be:fe:e7:
  28:53:0c:6b:5f:0c:76:bf:8c:a7:60:57:63:05:06:ff:ac:3d:
  f1:63:54:d0:d0:13:44:b1:e9:53:6b:32:11:e2:83:26:04:f5:
  23:67:6b:de

```

Step 3

The private key, `ndb-server.key`, is secured with the passphrase. You need to unencrypt the certificate private key. Unencrypt the private key using the **openssl rsa** command.

Example:

```

[root@NDB-server ~]# cp ndb-server.key ndb-server.keybkp
[root@NDB-server ~]# rm ndb-server.key
[root@NDB-server ~]# openssl rsa -in ndb-server.keybkp -out ndb-server.key
Enter pass phrase for ndb-server.keybkp: cisco123
writing RSA key

```

Note Depending on the tier of the CA you choose, you can get up to three certificates (certificate chain) for each CSR. This means you get three certificates (root, intermediate and domain) from CA for each NDB switch. You need to check with CA to identify each type of certificate. Certificate naming convention might be different for different certifying authorities. For example: qvrca2.cer (root), hydssl2.cer (intermediate), ndb-server.cisco.com-39891.cer (domain).

Certificates are mostly shared in .PEM file format.

Step 4 Create a single certificate file from the three certificate files using the cat command. The concatenation should be done in the following order, domain certificate, root certificate, and intermediate certificate. Syntax for cat command: **cat domain certificate root certificate intermediate certificate > ndb-server.cer**.

Example:

```
[root@NDB-server ~]# cat ndb-server.cisco.com-39891.cer qvrca.cer hydssl2.cer > ndb-server.cer
```

Step 5 Edit the newly created server.cer file to separate the concatenated END and BEGIN lines. Do not delete anything in the file.

Example:

```
-----END CERTIFICATE-----BEGIN CERTIFICATE-----
```

```
///// Modify the above line like this by adding a line feed between the two.
-----END CERTIFICATE-----
-----BEGIN CERTIFICATE-----
```

Step 6 Create the TLS NDB Server Keystore file using the ndb-server.cer and ndb-server.key files. Copy the files to switch using the copy command.

Example:

```
cp ndb-server.key ndb-server-xnc-privatekey.pem
cp ndb-server.cer ndb-server-xnc-cert.pem
```

Step 7 Combine the provate key and certificate file into a single .PEM file using the cat command.

Example:

```
cat ndb-server-xnc-privatekey.pem ndb-server-xnc-cert.pem > ndb-server-xnc.pem
```

Step 8 CA provides certificates in PEM format and extension of the certificate is .pem. You need to convert the PEM format certificate to PKCS12 format. Convert the PEM file, ndb-server-xnc.pem, to .P12 file format using the **openssl pkcs12** command. Enter the export password when prompted. The password must contain at least 6 characters, for example, cisco123. The ndb-server-xnc.pem file is converted to a password-protected ndb-server-xnc.p12 file.

Example:

```
[root@NDB-server ~]# openssl pkcs12 -export -out ndb-server-xnc.p12 -in ndb-server-xnc.pem
Enter Export Password: cisco123
Verifying - Enter Export Password: cisco123
```

Step 9 Convert the ndb-server-xnc.p12 to a password protected Java KeyStore (ndb-server-keystore) file using the **keytool** command. This command converts the sw1-xnc.p12 file to a password-protected ndb-server-keystore file. Create a new password for the destination JKS store and enter the source keystore password when prompted.

Example:

```
[root@NDB-server ~]# keytool -importkeystore -srckeystore ndb-server-xnc.p12 -srcstoretype pkcs12
-destkeystore ndb-server-keystore -deststoretype jks
Enter destination keystore password: cisco123
Re-enter new password: cisco123
```

```
Enter source keystore password:--cisco123
Entry for alias 1 successfully imported.
Import command completed: 1 entries successfully imported, 0 entries failed or
cancelled
[root@NDB-server ~]#
```

Step 10 List and verify content in the java tlsKeyStore using the **keytool** command.

Example:

```
[root@NDB-server ~]#keytool -list -v -keystore ndb-server-keystore
```

Step 11 Configure the tomcat-server.xml (stored in configuration folder) with key store password that was provided while generating the certificate. You can use VI editor and edit the following lines with keystore and keystorepass.

Example:

```
keystoreFile="configuration/ndb-server-keystore"
keystorePass="cisco123" server="Cisco XNC"
```

Step 12 Restart the NDB.

Step 13 Upload the CA certificate into Trusted Root certificate store of Web browser. See help for respective Web browsers about how to add the certificate to the Trusted Root certificate store. Use the password that you created while creating the certificate when prompted while uploading the certificate to the Web browser.

Generating TLS 3rd Party Certification Between Web Browser and NDB Server Running in Embedded Mode

You can generate TLS 3rd party certificate between Web browser and NDB server running in embedded mode for two environments: Guestshell Environment and OVA Environment.

- Generating TLS 3rd Party Certification Between Web Browser and NDB Server Running in Embedded Mode - Guestshell Environment
- Generating TLS 3rd Party Certification Between Web Browser and NDB Server Running in Embedded Mode - OVA Environment

Generating TLS 3rd Party Certificate Between Web Browser and NDB Server Running in Embedded Mode Using Guest Shell Environment

To generate TLS 3rd party certificate between Web browser and NDB server running in embedded mode using guest shell environment, complete the following steps.

Step 1 Enable bash-shell feature on the switch using the feature command.

Example:

```
N9396TX-116(config)# feature bash-shell
```

Step 2 Enter bash-shell mode on the switch using the run command.

Example:

```
N9396TX-116(config)# run bash
bash-4.2$
```

Step 3 Generate Certificate Signing Request (CSR) using the **openssl req** command. Enter the required information when prompted.

Example:

```
bash-4.2$ openssl req -newkey rsa:2048 -sha256 -keyout ndb-server.key -keyform PEM -out ndb-server.req -outform PEM
Generating a 2048 bit RSA private key
...+++
.....+++
writing new private key to 'ndb-server.key'
Enter PEM pass phrase: ☐ cisco123
Verifying - Enter PEM pass phrase: ☐ cisco123
-----
You are about to be asked to enter information that will be incorporated
into your certificate request.
What you are about to enter is what is called a Distinguished Name or a DN.
There are quite a few fields but you can leave some blank
For some fields there will be a default value,
If you enter '.', the field will be left blank.
-----
Country Name (2 letter code) [GB]:US
State or Province Name (full name) [Berkshire]:CA
Locality Name (eg, city) [Newbury]:SJ
Organization Name (eg, company) [My Company Ltd]:cisco
Organizational Unit Name (eg, section) []:insbu
Common Name (eg, your name or your server's hostname) []:ndb-server.cisco.com
Email Address []:chburra@cisco.com

Please enter the following 'extra' attributes
to be sent with your certificate request
A challenge password []:cisco123
An optional company name []:cisco123
```

```
bash-4.2$ ls
```

```
ndb-server.req  ndb-server.key
```

Note The openssl command creates a private key, ndb-server.key, and a certificate signing request file, ndb-server.req. The ndb-server.req (CSR) file is submitted to the certificate issuing authority (CA).

Note You need to use the same information when exporting the CA provided certificate into browser. The CSR file, cert.req, is submitted to CA.

Step 4 To view the content or verify the CSR request, use the **openssl req** command.

Example:

```
bash-4.2$ openssl req -noout -text -in ndb-server.req
Certificate Request:
  Data:
    Version: 0 (0x0)
    Subject: C=US, ST=CA, L=SJ, O=cisco, OU=insbu,
    CN=ndb-server.cisco.com/emailAddress=chburra@cisco.com
    Subject Public Key Info:
      Public Key Algorithm: rsaEncryption
      RSA Public Key: (2048 bit)
      Modulus (2048 bit):
```

```

00:b5:30:75:e8:c8:5f:05:3b:0e:4f:aa:00:d9:64:
8d:bf:b2:80:20:56:c3:be:b0:4c:e0:52:e5:be:d8:
d2:74:85:4e:8a:ba:d3:1e:30:76:bf:e5:de:7d:51:
11:79:8e:bc:96:38:7a:23:5a:26:31:50:50:fa:29:
44:ab:56:b6:0d:41:38:ba:d1:d5:b4:e3:ba:a3:6c:
4a:35:73:27:d9:fd:5c:4b:21:85:1a:f9:4d:b0:9e:
f3:ae:ce:49:98:ef:a2:f8:11:ab:bd:7e:64:ee:68:
68:19:6e:8f:3c:54:30:0f:28:01:13:b0:3d:34:b8:
f9:f5:cc:4a:84:d8:e5:d2:27:47:cc:83:76:92:ad:
92:62:f3:a3:35:be:14:ce:38:af:2a:c5:2e:fa:b8:
31:6b:71:cd:56:00:1f:0d:cc:b0:f8:fc:b0:52:91:
f8:9c:cf:45:13:c9:b5:86:fa:30:dd:88:78:01:15:
fb:5c:c9:6f:5b:b7:80:28:6c:86:54:c0:f2:5f:35:
70:82:49:5c:79:1c:f2:23:dd:50:d5:47:12:37:a3:
3f:f9:1d:90:8f:c0:e8:18:09:2e:66:8d:c3:72:17:
7f:7d:27:da:b1:cc:26:2d:8c:6b:ee:c5:e8:b5:78:
31:7c:bb:ba:6d:2c:e5:a3:29:7e:c1:4a:93:19:ed:
9a:e7
Exponent: 65537 (0x10001)
Attributes:
  unstructuredName          :cisco123
  challengePassword         :cisco123
Signature Algorithm: sha256WithRSAEncryption
9c:9a:51:e0:1d:e4:0b:8f:c1:c6:f5:e0:d2:f6:30:0e:18:af:
a7:b2:a4:4a:57:d7:07:44:cd:9c:fa:2d:0e:8b:c9:31:5b:16:
6b:84:42:0b:ed:06:5c:ed:30:d8:9b:ee:5d:79:f4:8a:e3:52:
3c:b3:4a:eb:6c:22:a2:f4:35:80:28:3a:67:62:7f:5f:dc:80:
e0:74:f0:3c:39:26:39:3a:76:6a:6a:98:e9:68:f9:b7:58:bf:
e7:44:2e:e7:73:0a:9c:62:28:b2:c6:09:41:81:b2:53:46:14:
e6:e4:dc:ca:90:81:5a:5e:dc:1b:dc:36:2c:86:5f:37:29:4c:
b0:ee:85:2b:34:f2:82:8a:d4:fc:a0:ce:10:e4:44:4e:d0:7a:
37:6d:3e:f9:ff:a1:19:8c:db:06:bf:be:87:57:a1:cb:05:15:
0b:9f:6c:8b:c2:ad:22:25:10:f0:4d:0f:4d:b7:be:71:87:f7:
85:24:e7:2d:f9:59:86:1a:b7:88:57:16:93:31:1f:d7:e5:07:
42:77:00:f9:ac:44:3b:6c:35:0f:80:5d:00:6f:ea:be:fe:e7:
28:53:0c:6b:5f:0c:76:bf:8c:a7:60:57:63:05:06:ff:ac:3d:
f1:63:54:d0:d0:13:44:b1:e9:53:6b:32:11:e2:83:26:04:f5:
23:67:6b:de

```

Step 5 The private key, `ndb-server.key`, is secured with the passphrase. You need to unencrypt the certificate private key. Unencrypt the private key using the **openssl rsa** command.

Example:

```

bash-4.2$ cp ndb-server.key ndb-server.keybkp
bash-4.2$ rm ndb-server.key
bash-4.2$ openssl rsa -in ndb-server.keybkp -out ndb-server.key
Enter pass phrase for ndb-server.keybkp: ☐cisco123
writing RSA key

```

Note Depending on the tier of the CA you choose, you can get up to three certificates (certificate chain) for each CSR. This means you get three certificates (root, intermediate and domain) from CA for each NDB switch. You need to check with CA to identify each type of certificate. Certificate naming convention might be different for different certifying authorities. For example: `qvrca2.cer` (root), `hydssl2.cer` (intermediate), `ndb-server.cisco.com-39891.cer` (domain).

Certificates are mostly shared in .PEM file format.

Step 6 Create a single certificate file from the three certificate files using the `cat` command. The concatenation should be done in the following order, domain certificate, root certificate, and intermediate certificate. Syntax for `cat` command: **cat domain certificate root certificate intermediate certificate > ndb-server.cer**.

Example:

```
bash-4.2$ cat ndb-server.cisco.com-39891.cer qvrca.cer hydssl2.cer > ndb-server.cer
```

Step 7

Edit the newly created server.cer file to separate the concatenated END and BEGIN lines. Do not delete anything in the file.

Example:

```
-----END CERTIFICATE-----BEGIN CERTIFICATE-----
```

```
//////// Modify the above line like this by adding a line feed between the two.
```

```
-----END CERTIFICATE-----
-----BEGIN CERTIFICATE-----
```

Step 8

Create the TLS NDB Server Keystore file using the ndb-server.cer and ndb-server.key files. Copy the files to switch using the **copy** command.

Example:

```
cp ndb-server.key ndb-server-xnc-privatekey.pem
cp ndb-server.cer ndb-server-xnc-cert.pem
```

Step 9

Combine the private key and certificate file into a single .PEM file using the **cat** command.

Example:

```
cat ndb-server-xnc-privatekey.pem ndb-server-xnc-cert.pem > ndb-server-xnc.pem
```

Step 10

CA provides certificates in PEM format and extension of the certificate is .pem. You need to convert the PEM format certificate to PKCS12 format. Convert the PEM file, ndb-server-xnc.pem, to .P12 file format using the **openssl pkcs12** command. Enter the export password when prompted. The password must contain at least 6 characters, for example, cisco123. The ndb-server-xnc.pem file is converted to a password-protected ndb-server-xnc.p12 file.

Example:

```
bash-4.2$ openssl pkcs12 -export -out ndb-server-xnc.p12 -in ndb-server-xnc.pem
Enter Export Password: [cisco123
Verifying - Enter Export Password: [cisco123
```

Step 11

Copy the certificate file to the NDB configuration folder.

Example:

```
bash-4.2$ cp ndb-server-xnc.p12
/isan/vdc_1/virtual-instance/guestshell+/rootfs/home/admin/xnc/configuration/
```

Step 12

Exit the bash shell mode using the **exit** command.

Example:

```
bash-4.2$ exit
exit
N9396TX-116#
```

Step 13

Connect to guest shell using guestshell command.

Example:

```
N9396TX-116# guestshell
[admin@guestshell ~]$
```

Step 14

Change current directory to xnc\configuration.

Example:

```
[admin@guestshell ~]$ cd xnc\configuration
```

Step 15 Set Java home path using the **export** command.

Example:

```
[admin@guestshell ~]$ export JAVA_HOME='/usr/lib/jvm/i586-wrs-jre'
```

Step 16 Convert the ndb-server-xnc.p12 to a password protected Java KeyStore (ndb-server-keystore) file using the **keytool** command. This command converts the swl-xnc.p12 file to a password-protected ndb-server-keystore file. Create a new password for the destination JKS store and enter the source keystore password when prompted.

Example:

```
[admin@guestshell configuration]$ /home/admin/xnc/jre/bin/keytool -importkeystore -srckeystore
ndb-server-xnc.p12 -srcstoretype pkcs12 -destkeystore ndb-server-keystore -deststoretype jks
Enter destination keystore password: [cisco123
Re-enter new password: [cisco123
Enter source keystore password: [cisco123
Entry for alias 1 successfully imported.
Import command completed: 1 entries successfully imported, 0 entries failed or cancelled
```

Step 17 List and verify content in the java tlsKeyStore using the **keytool** command.

Example:

```
[admin@guestshell configuration]$ /home/admin/xnc/jre/bin/keytool -list -v -keystore
ndb-server-keystore
```

Step 18 Configure the tomcat-server.xml (stored in configuration folder) with key store password that was provided while generating the certificate. You can use VI editor and edit the following lines with keystore and keystorepass.

Example:

```
keystoreFile="configuration/ndb-server-keystore"
keystorePass="cisco123" server="Cisco XNC"
```

Step 19 Upload the CA certificate into Trusted Root certificate store of Web browser. See help for respective Web browsers about how to add the certificate to the Trusted Root certificate store. Use the password that you created while creating the certificate when prompted while uploading the certificate to the Web browser.

Step 20 Restart the NDB.

Generating TLS 3rd Party Certificate Between Web Browser and NDB Server Running in Embedded Mode Using OVA Environment

To generate TLS 3rd party certificate between Web browser and NDB server running in embedded mode using OVA environment, complete the following steps.

Step 1 Enable bash-shell feature on the switch using the feature command.

Example:

```
N9396TX-116(config)# feature bash-shell
```

Step 2 Enter bash-shell mode on the switch using the run command.

Example:

```
N9396TX-116(config)# run bash
bash-4.2$
```

Step 3 Generate Certificate Signing Request (CSR) using the **openssl req** command. Enter the required information when prompted.

Example:

```
bash-4.2$ openssl req -newkey rsa:2048 -sha256 -keyout ndb-server.key -keyform PEM -out ndb-server.req
-outform PEM
Generating a 2048 bit RSA private key
...+++
.....+++
writing new private key to 'ndb-server.key'
Enter PEM pass phrase: ☐ cisco123
Verifying - Enter PEM pass phrase: ☐ cisco123
-----
You are about to be asked to enter information that will be incorporated
into your certificate request.
What you are about to enter is what is called a Distinguished Name or a DN.
There are quite a few fields but you can leave some blank
For some fields there will be a default value,
If you enter '.', the field will be left blank.
-----
Country Name (2 letter code) [GB]:US
State or Province Name (full name) [Berkshire]:CA
Locality Name (eg, city) [Newbury]:SJ
Organization Name (eg, company) [My Company Ltd]:cisco
Organizational Unit Name (eg, section) []:insbu
Common Name (eg, your name or your server's hostname) []:ndb-server.cisco.com
Email Address []:chburra@cisco.com

Please enter the following 'extra' attributes
to be sent with your certificate request
A challenge password []:cisco123
An optional company name []:cisco123
```

```
bash-4.2$ ls
```

```
ndb-server.req  ndb-server.key
```

Note The openssl command creates a private key, ndb-server.key, and a certificate signing request file, ndb-server.req. The ndb-server.req (CSR) file is submitted to the certificate issuing authority (CA).

Note You need to use the same information when exporting the CA provided certificate into browser. The CSR file, cert.req, is submitted to CA.

Step 4 To view the content or verify the CSR request, use the **openssl req** command.

Example:

```
bash-4.2$ openssl req -noout -text -in ndb-server.req
Certificate Request:
Data:
  Version: 0 (0x0)
  Subject: C=US, ST=CA, L=SJ, O=cisco, OU=insbu,
  CN=ndb-server.cisco.com/emailAddress=chburra@cisco.com
  Subject Public Key Info:
    Public Key Algorithm: rsaEncryption
    RSA Public Key: (2048 bit)
    Modulus (2048 bit):
```

```

00:b5:30:75:e8:c8:5f:05:3b:0e:4f:aa:00:d9:64:
8d:bf:b2:80:20:56:c3:be:b0:4c:e0:52:e5:be:d8:
d2:74:85:4e:8a:ba:d3:1e:30:76:bf:e5:de:7d:51:
11:79:8e:bc:96:38:7a:23:5a:26:31:50:50:fa:29:
44:ab:56:b6:0d:41:38:ba:d1:d5:b4:e3:ba:a3:6c:
4a:35:73:27:d9:fd:5c:4b:21:85:1a:f9:4d:b0:9e:
f3:ae:ce:49:98:ef:a2:f8:11:ab:bd:7e:64:ee:68:
68:19:6e:8f:3c:54:30:0f:28:01:13:b0:3d:34:b8:
f9:f5:cc:4a:84:d8:e5:d2:27:47:cc:83:76:92:ad:
92:62:f3:a3:35:be:14:ce:38:af:2a:c5:2e:fa:b8:
31:6b:71:cd:56:00:1f:0d:cc:b0:f8:fc:b0:52:91:
f8:9c:cf:45:13:c9:b5:86:fa:30:dd:88:78:01:15:
fb:5c:c9:6f:5b:b7:80:28:6c:86:54:c0:f2:5f:35:
70:82:49:5c:79:1c:f2:23:dd:50:d5:47:12:37:a3:
3f:f9:1d:90:8f:c0:e8:18:09:2e:66:8d:c3:72:17:
7f:7d:27:da:b1:cc:26:2d:8c:6b:ee:c5:e8:b5:78:
31:7c:bb:ba:6d:2c:e5:a3:29:7e:c1:4a:93:19:ed:
9a:e7
Exponent: 65537 (0x10001)
Attributes:
  unstructuredName          :cisco123
  challengePassword         :cisco123
Signature Algorithm: sha256WithRSAEncryption
9c:9a:51:e0:1d:e4:0b:8f:c1:c6:f5:e0:d2:f6:30:0e:18:af:
a7:b2:a4:4a:57:d7:07:44:cd:9c:fa:2d:0e:8b:c9:31:5b:16:
6b:84:42:0b:ed:06:5c:ed:30:d8:9b:ee:5d:79:f4:8a:e3:52:
3c:b3:4a:eb:6c:22:a2:f4:35:80:28:3a:67:62:7f:5f:dc:80:
e0:74:f0:3c:39:26:39:3a:76:6a:6a:98:e9:68:f9:b7:58:bf:
e7:44:2e:e7:73:0a:9c:62:28:b2:c6:09:41:81:b2:53:46:14:
e6:e4:dc:ca:90:81:5a:5e:dc:1b:dc:36:2c:86:5f:37:29:4c:
b0:ee:85:2b:34:f2:82:8a:d4:fc:a0:ce:10:e4:44:4e:d0:7a:
37:6d:3e:f9:ff:a1:19:8c:db:06:bf:be:87:57:a1:cb:05:15:
0b:9f:6c:8b:c2:ad:22:25:10:f0:4d:0f:4d:b7:be:71:87:f7:
85:24:e7:2d:f9:59:86:1a:b7:88:57:16:93:31:1f:d7:e5:07:
42:77:00:f9:ac:44:3b:6c:35:0f:80:5d:00:6f:ea:be:fe:e7:
28:53:0c:6b:5f:0c:76:bf:8c:a7:60:57:63:05:06:ff:ac:3d:
f1:63:54:d0:d0:13:44:b1:e9:53:6b:32:11:e2:83:26:04:f5:
23:67:6b:de

```

Step 5 The private key, `ndb-server.key`, is secured with the passphrase. You need to unencrypt the certificate private key. Unencrypt the private key using the **openssl rsa** command.

Example:

```

bash-4.2$ cp ndb-server.key ndb-server.keybkp
bash-4.2$ rm ndb-server.key
bash-4.2$ openssl rsa -in ndb-server.keybkp -out ndb-server.key
Enter pass phrase for ndb-server.keybkp: ☐cisco123
writing RSA key

```

Note Depending on the tier of the CA you choose, you can get up to three certificates (certificate chain) for each CSR. This means you get three certificates (root, intermediate and domain) from CA for each NDB switch. You need to check with CA to identify each type of certificate. Certificate naming convention might be different for different certifying authorities. For example: `qvrca2.cer` (root), `hydssl2.cer` (intermediate), `ndb-server.cisco.com-39891.cer` (domain).

Certificates are mostly shared in .PEM file format.

Step 6 Create a single certificate file from the three certificate files using the `cat` command. The concatenation should be done in the following order, domain certificate, root certificate, and intermediate certificate. Syntax for `cat` command: **cat domain certificate root certificate intermediate certificate > ndb-server.cer**.

Example:

```
bash-4.2$ cat ndb-server.cisco.com-39891.cer qvrca.cer hydssl2.cer > ndb-server.cer
```

Step 7

Edit the newly created server.cer file to separate the concatenated END and BEGIN lines. Do not delete anything in the file.

Example:

```
-----END CERTIFICATE-----BEGIN CERTIFICATE-----
```

```
//////// Modify the above line like this by adding a line feed between the two.
```

```
-----END CERTIFICATE-----
-----BEGIN CERTIFICATE-----
```

Step 8

Create the TLS NDB Server Keystore file using the ndb-server.cer and ndb-server.key files. Copy the files to switch using the **copy** command.

Example:

```
cp ndb-server.key ndb-server-xnc-privatekey.pem
cp ndb-server.cer ndb-server-xnc-cert.pem
```

Step 9

Combine the private key and certificate file into a single .PEM file using the **cat** command.

Example:

```
cat ndb-server-xnc-privatekey.pem ndb-server-xnc-cert.pem > ndb-server-xnc.pem
```

Step 10

CA provides certificates in PEM format and extension of the certificate is .pem. You need to convert the PEM format certificate to PKCS12 format. Convert the PEM file, ndb-server-xnc.pem, to .P12 file format using the **openssl pkcs12** command. Enter the export password when prompted. The password must contain at least 6 characters, for example, cisco123. The ndb-server-xnc.pem file is converted to a password-protected ndb-server-xnc.p12 file.

Example:

```
bash-4.2$ openssl pkcs12 -export -out ndb-server-xnc.p12 -in ndb-server-xnc.pem
Enter Export Password: [cisco123
Verifying - Enter Export Password: [cisco123
```

Step 11

Copy the certificate file to the NDB configuration folder.

Example:

```
bash-4.2$ cp ndb-server-xnc.p12
/isan/vdc_1/virtual-instance/guestshell+/rootfs/home/admin/xnc/configuration/
```

Step 12

Exit the bash shell mode using the **exit** command.

Example:

```
bash-4.2$ exit
exit
N9396TX-116#
```

Step 13

Connect to virtual service console using the **virtual-service connect** command.

Example:

```
N9396TX-116# virtual-service connect name ova console
Connecting to virtual-service. Exit using ^c^c^c
Entering character mode
Escape character is '^]'.
root@ N9396TX-116:~#
root@ N9396TX-116:~#
```

Step 14 Change current directory to /xnclite/xnc/configuration.

Example:

```
root@ N9396TX-116:~# cd /xnclite/xnc/configuration
root@ N9396TX-116:/xnclite/xnc/configuration#
```

Step 15 Set Java home path using the **export** command.

Example:

```
[admin@guestshell ~]$ export JAVA_HOME='/usr/lib/jvm/i586-wrs-jre'
```

Step 16 Convert the ndb-server-xnc.p12 to a password protected Java KeyStore (ndb-server-keystore) file using the **keytool** command. This command converts the sw1-xnc.p12 file to a password-protected ndb-server-keystore file. Create a new password for the destination JKS store and enter the source keystore password when prompted.

Example:

```
root@ N9396TX-116:/xnclite/xnc/configuration# /usr/lib/jvm/i586-wrs-jre/bin/keytool
-importkeystore -srckeystore ndb-server-xnc.p12 -srcstoretype pkcs12 -destkeystore
ndb-server-keystore -deststoretype jks
Enter destination keystore password: [cisco123
Re-enter new password: [cisco123
Enter source keystore password: [cisco123
Entry for alias 1 successfully imported.
Import command completed: 1 entries successfully imported, 0 entries failed or cancelled
```

Step 17 List and verify content in the java tlsKeyStore using the **keytool** command.

Example:

```
root@ N9396TX-116:/xnclite/xnc/configuration# /usr/lib/jvm/i586-wrs-jre/bin/keytool -list -v -keystore
ndb-server-keystore
```

Step 18 Configure the tomcat-server.xml (stored in configuration folder) with key store password that was provided while generating the certificate. You can use VI editor and edit the following lines with keystore and keystorepass.

Example:

```
keystoreFile="configuration/ndb-server-keystore"
keystorePass="cisco123" server="Cisco XNC"
```

Step 19 Upload the CA certificate into Trusted Root certificate store of Web browser. See help for respective Web browsers about how to add the certificate to the Trusted Root certificate store. Use the password that you created while creating the certificate when prompted while uploading the certificate to the Web browser.

Step 20 Deactivate and activate the virtual service to restart the NDB.
