



Unknown Unicast and Multicast Flood Blocking

This chapter describes how to configure the unknown unicast flood blocking (UUFb) and unknown multicast flood blocking (UMFB) features on the Cisco 7600 series routers.



Note

For complete syntax and usage information for the commands used in this chapter, refer to the *Cisco IOS Master Command List*, Release 12.2SX at this URL:

http://www.cisco.com/en/US/docs/ios/mcl/122sxmcl/12_2sx_mcl_book.html



Tip

For additional information (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/routers/ps368/tsd_products_support_series_home.html

Understanding UUFb or UMFB

By default, unknown unicast and multicast traffic is flooded to all Layer 2 ports in a VLAN. You can prevent this behavior by using the UUFb and UMFB features to prevent or limit this traffic. The UUFb and UMFB features block unknown unicast and multicast traffic flooding at a specific port, only permitting egress traffic with MAC addresses that are known to exist on the port. The UUFb and UMFB features are supported on all ports that are configured with the **switchport** command, including private VLAN (PVLAN) ports.



Note

Entering the **switchport block multicast** command on nonreceiver (router) ports of the VLAN could disrupt routing protocols. This command could also disrupt ARP functionality and other protocols, such as Network Time Protocol (NTP), that make use of local subnetwork multicast control groups in the 224.0.0.0/24 range.

Configuring UUFB

To configure UUFB or UFMB, perform this task:

	Command	Purpose
Step 1	Router# configure terminal	Enters global configuration mode.
Step 2	Router(config)# interface {{type ¹ slot/port} {port-channel number}}	Selects the interface to configure.
Step 3	Router(config-if)# switchport	Configures the port for Layer 2 switching.
Step 4	Router(config-if)# switchport block {unicast multicast}	Enables unknown unicast or multicast flood blocking on the port.
Step 5	Router(config-if)# do show interfaces [type ¹ slot/port] switchport include Unknown	Verifies the configuration.

1. *type* = ethernet, fastethernet, gigabitethernet, or tengigabitethernet

This example shows how to configure UUFB on Fast Ethernet port 5/12 and how to verify the configuration:

```
Router# configure terminal
Router(config)# interface fastethernet 5/12
Router(config-if)# switchport
Router(config-if)# switchport block unicast
Router(config-if)# do show interface fastethernet 5/12 switchport | include Unknown
Unknown unicast blocked: enabled
```



Tip

For additional information (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/routers/ps368/tsd_products_support_series_home.html