

DiffServ Compliant WRED

DiffServ Compliant WRED extends the functionality of Weighted Random Early Detection to enable support for DiffServ and Assured Forwarding (AF) per hop behavior (PHB). This feature enables customers to implement AF PHB by coloring packets according to Differentiated Services Code Point (DSCP) values and then assigning preferential drop probabilities to those packets.



Note

This feature can be used with IP packets only. It is not intended for use with Multiprotocol Label Switching (MPLS)-encapsulated packets.

- Information About DiffServ Compliant WRED, on page 1
- How to Configure DiffServ Compliant WRED, on page 2
- Configuration Examples for DiffServ Compliant WRED, on page 5

Information About DiffServ Compliant WRED

Differentiated Services for WRED

Differentiated Services is a multiple service model that can satisfy differing Quality of Service (QoS) requirements. With Differentiated Services, the network tries to deliver a particular kind of service based on the QoS specified by each packet. This specification can occur in different ways. The DiffServ Compliant WRED feature enables WRED to use either the 6-bit differentiated services code point (DSCP) or the IP Precedence setting in IP packets when it calculates the drop probability for a packet. The DSCP value is the first six bits of the IP type of service (ToS) byte.

Usage Guidelines for DiffServ Compliant WRED

To configure the DiffServ Compliant WRED feature, first specify the policy map, add the class, and configure the bandwidth or shape for the class. If you want WRED to use the DSCP value when it calculates the drop probability, use the *dscp-based* argument with the **random-detect** command to specify the DSCP value and then use the **random-detect dscp** command to modify the default minimum and maximum thresholds for the DSCP value. If you want WRED to use the IP Precedence value when it calculates the drop probability, use the *precedence-based* argument with the **random-detect** command to specify the IP Precedence value. This

configuration can then be applied wherever policy maps are attached (for example, at the interface level, the per-VC level, or the shaper level).

Remember the following points when using the commands included with this feature:

- If you use the dscp-based argument, WRED will use the DSCP value to calculate the drop probability.
- If you use the *precedence-based* argument, WRED will use the IP Precedence value to calculate the drop probability.
- The *dscp-based* and *precedence-based* arguments are mutually exclusive.
- If you do not specify either argument, WRED will use the IP Precedence value to calculate the drop probability (the default method).
- If WRED is configured in microsecond, you need to explicitly configure the Qlimit in microsecond. The units of both the Qlimit and WRED should be same. This changes the threshold value for Min and Max. The same holds true for WRED configuration in bytes.

How to Configure DiffServ Compliant WRED

Configuring DiffServ Compliant WRED

Procedure

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Device> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 3	class-map class-map-name	Specifies the name of the class map to be
	Example:	created and enters QoS class-map configuration mode.
	Device(config)# class-map c1	
Step 4	match match-criterion	Configures the match criteria for a class map.
	Example:	Note Cisco RSP3 Module supports WRED with classification based on
	Device(config-cmap)# match any	match qos-group.
Step 5	policy-map policy-map-name	Creates or modifies a policy map that can be
	Example:	attached to one or more interfaces to specify

	Command or Action	Purpose
	Device(config-cmap)# policy-map p1	a service policy, and enters QoS policy-map configuration mode.
Step 6	class {class-name class-default}	Specifies the name of the class whose policy
	Example:	you want to create or change or specifies the default class (commonly known as the
	Device(config-pmap)# class c1	class-default class) before you configure its policy.
		Enters QoS policy-map class configuration mode.
Step 7	bandwidth {kbps remaining percentage percent percentage}	Specifies the bandwidth allocated for a class belonging to a policy map.
	Example:	
	Device(config-pmap-c)# bandwidth percent	
Step 8	random-detect [dscp-based precedence-based cos-based discard-class based]	Configures WRED to use the differentiated services code point (DSCP) value when it calculates the drop probability for a packet
	Example:	Note Cisco RSP3 Module supports random-detect command based on
	Device(config-pmap-c)# random-detect dscp-based	discard-class argument.
Step 9	random-detect dscp dscp-value min-threshold max-threshold [mark-probability-denominator]	Changes the minimum and maximum packet thresholds for the differentiated services code point (DSCP) value.
	Example:	
	Device(config-pmap-c)# random-detect dscp af11 10000 30000 25	
Step 10	exit	Exits QoS policy-map class configuration
	Example:	mode.
	Device(config-pmap-c)# exit	
Step 11	exit	Exits QoS policy-map configuration mode.
	Example:	
	Device(config-pmap)# exit	
Step 12	interface type number [name-tag]	Configures an interface type and enters
	Example:	interface configuration mode.Enter the interface type and number.

Command or Action	Purpose
Device(config)# interface GigabitEthernet 0/0/0	
service-policy output policy-map-name	Attaches a policy map to an output interface.
Example:	Enter the policy map name.
Device(config-if)# service-policy output pl	Note Policy maps can be configured on ingress or egress routers. They can also be attached in the input or output direction of an interface. The direction (input or output) and the router (ingress or egress) to which the policy map should be attached varies according your network configuration. When using the service-policy command to attach the policy map to an interface, be sure to choose the router and the interface direction that are appropriate for your network configuration.
end	Returns to privileged EXEC mode.
Example:	
Device(config-if)# end	
show policy-map interface type number	(Optional) Displays the traffic statistics of all
Example:	classes that are configured for all service policies either on the specified interface or
Device# show policy-map interface GigabitEthernet 0/0/0	subinterface or on a specific PVC on the interface.
	Enter the interface type and number.
exit	(Optional) Exits privileged EXEC mode.
Example:	
Device# exit	
	Device (config) # interface GigabitEthernet 0/0/0 service-policy output policy-map-name Example: Device (config-if) # service-policy output pl end Example: Device (config-if) # end show policy-map interface type number Example: Device# show policy-map interface GigabitEthernet 0/0/0 exit Example:

Configuration Examples for DiffServ Compliant WRED

Example: DiffServ compliant WRED

The following example enables WRED to use the DSCP value 8 for the class c1. The minimum threshold for the DSCP value 8 is 24 and the maximum threshold is 40. The last line attaches the traffic policy to the output interface or VC p1.

```
Device(config) # class-map c1
Device(config-cmap) # match ip precedence 1
Device(config-cmap) # policy-map p1
Device(config-pmap) # class c1
Device(config-pmap-c) # bandwidth 48
Device(config-pmap-c) # random-detect dscp-based
Device(config-pmap-c) # random-detect dscp 8 24 40 (bytes/ms)
Device(config-if) # service-policy output p1
```



Note

Cisco RSP3 Module supports match qos-group at egress match condition.

Example: DiffServ compliant WRED