



## Configuring Connectivity to Devices

---

- [About In-Band Management for Devices, on page 1](#)
- [Configuring In-Band Management for Devices Using the GUI, on page 2](#)
- [Troubleshooting In-Band Management for Devices Using the GUI, on page 3](#)

### About In-Band Management for Devices

The Cisco Application Policy Infrastructure Controller (Cisco APIC) provides a mechanism for managing devices within each tenant in-band through the Cisco Application Centric Infrastructure (ACI) fabric. This configuration option provides device management connectivity without requiring the management IP addresses used on devices to be routable within the infra tenant and mgmt tenant.



---

**Note** This feature is separate from in-band management for the Cisco APICs and fabric nodes. In-band management for the fabric is not required for you to manage devices in-band.


---

In-band management communication between the Cisco APICs and devices is enabled by configuring unique IP addresses on the Cisco APICs. The IP addresses are known as controller endpoints. These IP addresses are not actually configured on the Cisco APIC interfaces, but instead are used in conjunction with Network Address Translation (NAT) to establish management communication with the devices. The NAT addresses that are used by the Cisco APICs are automatically selected by the Cisco APIC and fall within the 169.254.0.0/16 address range.

In addition, each device management IP address is presented to the Cisco APICs as a translated IP address. This translated address is referred to as the mapped host address.

The following figure depicts the address translation between the Cisco APIC and the devices:

Figure 1: Network Address Translation Between the Cisco APIC and the Devices



## Configuring In-Band Management for Devices Using the GUI

You can configure in-band management for devices using the GUI.

- 
- Step 1** On the menu bar, choose **Tenants > All Tenants**.
- Step 2** In the Work pane, double click the tenant's name.
- Step 3** In the Navigation pane, choose **Tenant *tenant\_name* > Services > L4-L7 > Devices**.
- Step 4** In the Work pane, choose **Actions > Create L4-L7 Devices**
- Step 5** In the **Create L4-L7 Devices** dialog box, fill in the fields as required, except as specified below:
- For the **APIC to Device Management Connectivity** radio buttons, choose **In-Band**.
  - In the **EPG** drop-down list, choose **Create Management EPG**.
- Step 6** In the **Create Management EPG** dialog box, fill in the fields as required, except as specified below:
- In the **Application Profile** drop-down list, choose an existing application profile where the EPG will reside. Optionally, create a new application profile by choosing **Create Application Profile**.  
If you create a new application profile, leave the **EPG** section and **Contracts** section blank.
  - In the **Name** field, enter a name for the management EPG.
  - In the **Bridge Domain** drop-down list, choose a domain.
  - In the **Domains** section, add a domain profile.
  - In the **Reserved IP addresses for APICs** section, click + to create a new IP address pool.
- Step 7** In the **Create IP Address Pool** dialog box, fill in all of the fields and click **OK**.  
The IP address pool defines the controller endpoint addresses. The IP addresses in the pool are the IP addresses that the devices will see as the Application Policy Infrastructure Controller (APIC) IP addresses.  
If the address range that you defined for the controller endpoints is not part of the same subnet as the management IP addresses that you defined for the devices, you must define a subnet under the management EPG bridge domain that provides a next-hop gateway for the devices to reach the controller endpoints.
- Step 8** In the **Create Management EPG** dialog box, click **Submit**.  
The domain name for the management EPG should now be populated.

- Step 9** In the **Create L4-L7 Devices** dialog box, complete the device setup. Be sure to include the management interface in the configuration of the interfaces.
- 

## Troubleshooting In-Band Management for Devices Using the GUI

If you chose an existing endpoint group (EPG) as the management EPG for the devices, you must manually add the management IP address pools and controller management policies. You can add these using the GUI.

---

- Step 1** On the menu bar, choose **Tenants > All Tenants**.
- Step 2** In the Work pane, double click the tenant's name.
- Step 3** In the Navigation pane, choose *tenant\_name* > **Application Profiles** > *application\_profile\_name* > **Application EPGs** > *EPG\_name* > **L4/L7 IP Address Pool**.
- Step 4** In the Work pane, choose **Actions > Create Address Pool**.
- Step 5** In the **Create IP Address Pool** dialog box, fill in the fields as required.  
This adds the management IP address pool.
- Step 6** In the Navigation pane, choose **Tenant *tenant\_name* > Services > L4-L7 > Inband Management Configuration for L4-L7 devices**.
- Step 7** In the Work pane, in the **Controller Management Policies** section, click + and fill in the fields as follows:  
a) In the **Private Networks** drop-down list, choose a private network.  
b) In the **Address Pool** drop-down list, choose the pool that you just created.
- Step 8** Click **Update**.  
This adds the controller management policy.
-

