

Configuring OSPFv3 Fast Convergence - LSA and SPF Throttling

- Information About OSPFv3 Fast Convergence: LSA and SPF Throttling, on page 1
- How to Configure OSPFv3 Fast Convergence: LSA and SPF Throttling, on page 1
- Example: Configuring LSA and SPF Throttling for OSPFv3 Fast Convergence, on page 4
- Additional References, on page 4
- Feature History for OSPFv3 Fast Convergence: LSA and SPF Throttling , on page 4

Information About OSPFv3 Fast Convergence: LSA and SPF Throttling

The Open Shortest Path First version 3 (OSPFv3) link-state advertisement (LSAs) and shortest-path first (SPF) throttling feature provides a dynamic mechanism to slow down link-state advertisement updates in OSPFv3 during times of network instability. It also allows faster OSPFv3 convergence by providing LSA rate limiting in milliseconds.

OSPFv3 can use static timers for rate-limiting SPF calculation and LSA generation. Although these timers are configurable, the values used are specified in seconds, which poses a limitation on OSPFv3 convergence. LSA and SPF throttling achieves subsecond convergence by providing a more sophisticated SPF and LSA rate-limiting mechanism that is able to react quickly to changes and also provide stability and protection during prolonged periods of instability.

How to Configure OSPFv3 Fast Convergence: LSA and SPF Throttling

The following sections provide configuration information about OSPFv3 Fast Convergence: LSA and SPF throttling.

Tuning LSA and SPF Timers for OSPFv3 Fast Convergence

To tune LSA and SPF timers for OSPFv3 fast convergence, perform this procedure:

SUMMARY STEPS

- 1. enable
- **2**. configure terminal
- 3. router ospfv3 [process-id]
- 4. timers lsa arrival milliseconds
- 5. timers pacing flood milliseconds
- 6. timers pacing lsa-group seconds
- 7. timers pacing retransmission milliseconds

DETAILED STEPS

	Command or Action	Purpose	
Step 1	enable	Enables privileged EXEC mode.	
	Example:	Enter your password if prompted.	
	Device> enable		
Step 2	configure terminal	Enters global configuration mode.	
	Example:		
	Device# configure terminal		
Step 3	router ospfv3 [process-id]	Enables OSPFv3 router configuration mode for the IPv4 or IPv6 address family.	
	Example:		
	Device(config)# router ospfv3 1		
Step 4	timers lsa arrival milliseconds	Sets the minimum interval at which the software accepts	
	Example:	the same LSA from OSPFv3 neighbors.	
	Device(config-rtr)# timers lsa arrival 300		
Step 5	timers pacing flood milliseconds	Configures LSA flood packet pacing.	
	Example:		
	<pre>Device(config-rtr)# timers pacing flood 30</pre>		
Step 6	timers pacing lsa-group seconds	Changes the interval at which OSPFv3 LSAs are collected into a group and refreshed, checksummed, or aged.	
	Example:		
	Device(config-router) # timers pacing lsa-group 300		
Step 7	timers pacing retransmission milliseconds	Configures LSA retransmission packet pacing in IPv4	
	Example:	OSPFv3.	
	Device(config-router)# timers pacing retransmission 100		
	Device(config-router)# timers pacing retransmission		

Configuring LSA and SPF Throttling for OSPFv3 Fast Convergence

To configure LSA and SPF throttling for OSPFv3 fast convergence, perform this procedure:

SUMMARY STEPS

- 1. enable
- **2**. configure terminal
- 3. ipv6 router ospf process-id
- **4.** timers throttle spf spf-start spf-hold spf-max-wait
- 5. timers throttle lsa start-interval hold-interval max-interval
- 6. timers lsa arrival milliseconds
- 7. timers pacing flood milliseconds

DETAILED STEPS

	Command or Action	Purpose	
Step 1	enable	Enables privileged EXEC mode.	
	Example:	• Enter your password if prompted.	
	Device> enable		
Step 2	configure terminal	Enters global configuration mode.	
	Example:		
	Device# configure terminal		
Step 3	ipv6 router ospf process-id	Enables OSPFv3 router configuration mode.	
	Example:		
	<pre>Device(config)# ipv6 router ospf 1</pre>		
Step 4	timers throttle spf spf-start spf-hold spf-max-wait	Turns on SPF throttling.	
	Example:		
	Device(config-rtr)# timers throttle spf 200 200 200		
Step 5	timers throttle lsa start-interval hold-interval max-interval	Sets rate-limiting values for OSPFv3 LSA generation.	
	Example:		
	Device(config-rtr)# timers throttle lsa 300 300 300		
Step 6	timers lsa arrival milliseconds	Sets the minimum interval at which the software accepts	
	Example:	the same LSA from OSPFv3 neighbors.	
	Device(config-rtr)# timers lsa arrival 300		
Step 7	timers pacing flood milliseconds	Configures LSA flood packet pacing.	
	Example:		
	Device(config-rtr)# timers pacing flood 30		

Example: Configuring LSA and SPF Throttling for OSPFv3 Fast Convergence

The following example show how to display the configuration values for SPF and LSA throttling timers:

```
Device# show ipv6 ospf
Routing Process "ospfv3 1" with ID 10.9.4.1
Event-log enabled, Maximum number of events: 1000, Mode: cyclic
It is an autonomous system boundary router
Redistributing External Routes from,
    ospf 2
Initial SPF schedule delay 5000 msecs
Minimum hold time between two consecutive SPFs 10000 msecs
Maximum wait time between two consecutive SPFs 10000 msecs
Minimum LSA interval 5 secs
Minimum LSA arrival 1000 msecs
```

Additional References

Related Documents

Related Topic	Document Title
IPv6 addressing and connectivity	IPv6 Configuration Guide
OSPFv3 Fast Convergence: LSA and SPF Throttling	OSPF Shortest Path First Throttling module

Standards and RFCs

Standard/RFC	Title
RFCs for	IPv6
IPv6	RFCs

Feature History for OSPFv3 Fast Convergence: LSA and SPF Throttling

This table provides release and related information for the features explained in this module.

These features are available in all the releases subsequent to the one they were introduced in, unless noted otherwise.

Release	Feature	Feature Information
Cisco IOS XE Gibraltar 16.11.1	OSPFv3 Fast Convergence - LSA and SPF Throttling	The Open Shortest Path First version 3 (OSPFv3) LSAs and SPF throttling feature provides a dynamic mechanism to slow down link-state advertisement updates in OSPFv3 during times of network instability

Use the Cisco Feature Navigator to find information about platform and software image support. To access Cisco Feature Navigator, go to http://www.cisco.com/go/cfn.