



Named VSANs

- [Named VSANs](#), on page 1
- [Fibre Channel Uplink Trunking for Named VSANs](#), on page 2
- [Guidelines and Recommendations for VSANs](#), on page 2
- [Creating a Named VSAN Accessible to Both Fabric Interconnects \(Fibre Channel Uplink Mode\)](#), on page 4
- [Creating a Named VSAN Accessible to Both Fabric Interconnects \(Fibre Channel Storage Mode\)](#), on page 5
- [Creating a Named VSAN Accessible to One Fabric Interconnect \(Fibre Channel Uplink Mode\)](#), on page 6
- [Creating a Named VSAN Accessible to One Fabric Interconnect \(Fibre Channel Storage Mode\)](#), on page 8
- [Displaying a Named VSAN](#), on page 9
- [Deleting a Named VSAN](#), on page 11
- [Changing the VLAN ID for the FCoE Native VLAN for a Named VSAN](#), on page 12
- [Changing the VLAN ID for the FCoE Native VLAN for a Storage VSAN](#), on page 12
- [Enabling or Disabling Fibre Channel Uplink Trunking](#), on page 13
- [Configuring Breakout VSAN and Member Port](#), on page 14

Named VSANs

A named VSAN creates a connection to a specific external SAN. The VSAN isolates traffic to that external SAN, including broadcast traffic. The traffic on one named VSAN knows that the traffic on another named VSAN exists, but cannot read or access that traffic.

Like a named VLAN, the name that you assign to a VSAN ID adds a layer of abstraction that allows you to globally update all servers associated with service profiles that use the named VSAN. You do not need to reconfigure the servers individually to maintain communication with the external SAN. You can create more than one named VSAN with the same VSAN ID.

Named VSANs in Cluster Configurations

In a cluster configuration, a named VSAN can be configured to be accessible only to the Fibre Channel uplink ports on one fabric interconnect or to the Fibre Channel uplink ports on both fabric interconnects.

Named VSANs and the FCoE VLAN ID

You must configure each named VSAN with an FCoE VLAN ID. This property determines which VLAN is used for transporting the VSAN and its Fibre Channel packets.

For FIP-capable, converged network adapters, such as the Cisco UCS CNA M72KR-Q and the Cisco UCS CNA M72KR-E, the named VSAN must be configured with a named VLAN that is not the native VLAN for the FCoE VLAN ID. This configuration ensures that FCoE traffic can pass through these adapters.

In the following sample configuration, a service profile with a vNIC and vHBA mapped to fabric A is associated with a server that has FIP capable, converged network adapters:

- The vNIC is configured to use VLAN 10.
- VLAN 10 is also designated as the native VLAN for the vNIC.
- The vHBA is configured to use VSAN 2.
- Therefore, VSAN 2 cannot be configured with VLAN 10 as the FCoE VLAN ID. VSAN 2 can be mapped to any other VLAN configured on fabric A.

Fibre Channel Uplink Trunking for Named VSANs

You can configure Fibre Channel uplink trunking for the named VSANs on each fabric interconnect. If you enable trunking on a fabric interconnect, all named VSANs in a Cisco UCS domain are allowed on all Fibre Channel uplink ports on that fabric interconnect.

Guidelines and Recommendations for VSANs

The following guidelines and recommendations apply to all named VSANs, including storage VSANs.

VSAN 4079 is a Reserved VSAN ID

Do not configure a VSAN as 4079. This VSAN is reserved and cannot be used in either FC switch mode or FC end-host mode.

If you create a named VSAN with ID 4079, Cisco UCS Manager marks that VSAN with an error and raises a fault.

Reserved VSAN Range for Named VSANs in FC Switch Mode

If you plan to use FC switch mode in a Cisco UCS domain, do not configure VSANs with an ID in the range from 3040 to 4078.

VSANs in that range are not operational if the fabric interconnects are configured to operate in FC switch mode. Cisco UCS Manager marks that VSAN with an error and raises a fault.

Reserved VSAN Range for Named VSANs in FC End-Host Mode

If you plan to use FC end-host mode in a Cisco UCS domain, do not configure VSANs with an ID in the range from 3840 to 4079.

VSANs in that range are not operational if the following conditions exist in a Cisco UCS domain:

- The fabric interconnects are configured to operate in FC end-host mode.
- The Cisco UCS domain is configured with Fibre Channel trunking or SAN port channels.

If these configurations exist, Cisco UCS Manager does the following:

1. Renders all VSANs with an ID in the range from 3840 to 4079 non-operational.
2. Raises a fault against the non-operational VSANs.
3. Transfers all non-operational VSANs to the default VSAN.
4. Transfers all vHBAs associated with the non-operational VSANs to the default VSAN.

If you disable Fibre Channel trunking and delete any existing SAN port channels, Cisco UCS Manager returns all VSANs in the range from 3840 to 4078 to an operational state and restores any associated vHBAs back to those VSANs.

Range Restrictions for Named VSAN IDs in FC Switch Mode

If you plan to use FC switch mode in a Cisco UCS domain, do not configure VSANs in the range from 3040 to 4078.

When a fabric interconnect operating in FC switch mode is connected to MDS as the upstream switch, VSANs configured in Cisco UCS Manager in the range from 3040 to 4078 and assigned as port VSANs cannot be created in MDS. This configuration results in a possible port VSAN mismatch.

Guidelines for FCoE VLAN IDs



Note FCoE VLANs in the SAN cloud and VLANs in the LAN cloud must have different IDs. Using the same ID for an FCoE VLAN in a VSAN and a VLAN results in a critical fault and traffic disruption for all vNICs and uplink ports using that FCoE VLAN. Ethernet traffic is dropped on any VLAN with an ID that overlaps with an FCoE VLAN ID.

VLAN 4048 is user configurable. However, Cisco UCS Manager uses VLAN 4048 for the following default values. If you want to assign 4048 to a VLAN, you must reconfigure these values:

- After an upgrade to Cisco UCS, Release 2.0—The FCoE storage port native VLAN uses VLAN 4048 by default. If the default FCoE VSAN was set to use VLAN 1 before the upgrade, you must change it to a VLAN ID that is not used or reserved. For example, consider changing the default to 4049 if that VLAN ID is not in use.
- After a fresh install of Cisco UCS, Release 2.0—The FCoE VLAN for the default VSAN uses VLAN 4048 by default. The FCoE storage port native VLAN uses VLAN 4049.

Creating a Named VSAN Accessible to Both Fabric Interconnects (Fibre Channel Uplink Mode)



Note FCoE VLANs in the SAN cloud and VLANs in the LAN cloud must have different IDs. Using the same ID for an FCoE VLAN in a VSAN and a VLAN results in a critical fault and traffic disruption for all vNICs and uplink ports using that FCoE VLAN. Ethernet traffic is dropped on any VLAN with an ID that overlaps with an FCoE VLAN ID.

Procedure

	Command or Action	Purpose
Step 1	UCS-A# scope fc-uplink	Enters Fibre Channel uplink mode.
Step 2	UCS-A /fc-uplink # create vsan <i>vsan-name</i> <i>vsan-id fcoe-id</i>	Creates the specified named VSAN, specifies the VSAN name, VSAN ID and FCoE VLAN ID, and enters Fibre Channel uplink VSAN mode. <ul style="list-style-type: none"> • After an upgrade to Cisco UCS, Release 2.0—The FCoE storage port native VLAN uses VLAN 4048 by default. If the default FCoE VSAN was set to use VLAN 1 before the upgrade, you must change it to a VLAN ID that is not used or reserved. For example, consider changing the default to 4049 if that VLAN ID is not in use. • After a fresh install of Cisco UCS, Release 2.0—The FCoE VLAN for the default VSAN uses VLAN 4048 by default. The FCoE storage port native VLAN uses VLAN 4049.
Step 3	UCS-A /fc-uplink/vsan # set fc-zoning { disabled enabled }	Configures Fibre Channel zoning for the VSAN, as follows: <ul style="list-style-type: none"> • disabled—The upstream switch configures and controls the Fibre Channel zoning or Fibre Channel zoning is not implemented on this VSAN. • enabled—Cisco UCS Manager configures and controls Fibre Channel zoning.
Step 4	UCS-A /fc-uplink/vsan # commit-buffer	Commits the transaction to the system configuration.

Example

The following example creates a named VSAN for both fabric interconnects, names the VSAN accounting, assigns the VSAN ID 2112, assigns the FCoE VLAN ID 4021, enables the VSAN for Cisco UCS Manager-based Fibre Channel zoning, and commits the transaction:

```
UCS-A# scope fc-uplink
UCS-A /fc-uplink* # create vsan accounting 2112 4021
UCS-A /fc-uplink/vsan # set fc-zoning enabled
UCS-A /fc-uplink/vsan* # commit-buffer
UCS-A /fc-uplink/vsan #
```

Creating a Named VSAN Accessible to Both Fabric Interconnects (Fibre Channel Storage Mode)



Note FCoE VLANs in the SAN cloud and VLANs in the LAN cloud must have different IDs. Using the same ID for an FCoE VLAN in a VSAN and a VLAN results in a critical fault and traffic disruption for all vNICs and uplink ports using that FCoE VLAN. Ethernet traffic is dropped on any VLAN with an ID that overlaps with an FCoE VLAN ID.

Procedure

-
- Step 1** UCS-A# **scope fc-storage**
Enters Fibre Channel storage mode.
- Step 2** UCS-A /fc-storage # **create vsan** *vsan-name vsan-id fcoe-id*
Creates the specified named VSAN, specifies the VSAN name, VSAN ID, and FCoE VLAN ID, and enters Fibre Channel storage VSAN mode.
- After an upgrade to Cisco UCS, Release 2.0—The FCoE storage port native VLAN uses VLAN 4048 by default. If the default FCoE VSAN was set to use VLAN 1 before the upgrade, you must change it to a VLAN ID that is not used or reserved. For example, consider changing the default to 4049 if that VLAN ID is not in use.
 - After a fresh install of Cisco UCS, Release 2.0—The FCoE VLAN for the default VSAN uses VLAN 4048 by default. The FCoE storage port native VLAN uses VLAN 4049.
- Step 3** UCS-A /fc-storage/vsan # **create member-port** {**fc** | **fcoe**} {**a** | **b**} *slot-id port-id*
Creates a member port; specifies whether the port type, fabric, slot ID and port ID.
- Step 4** UCS-A /fc-storage/vsan # **set fc-zoning** {**disabled** | **enabled**}
Configures Fibre Channel zoning for the VSAN, as follows:

- disabled—The upstream switch configures and controls the Fibre Channel zoning or Fibre Channel zoning is not implemented on this VSAN.
- enabled—Cisco UCS Manager configures and controls Fibre Channel zoning.

Step 5 UCS-A /fc-storage/vsan # **commit-buffer**

Commits the transaction to the system configuration.

Example

The following example creates a named VSAN, names the VSAN finance, assigns the VSAN ID 3955, assigns the FCoE VLAN ID 4021, creates a member port and assigns it to member port A, slot 1 port 40, enables the VSAN for Cisco UCS Manager-based Fibre Channel zoning, and commits the transaction:

```
UCS-A# scope fc-storage
UCS-A /fc-storage/ # create VSAN finance 3955 4021
UCS-A /fc-storage/vsan # create member-port fcoe a 1 40
UCS-A /fc-storage/vsan # set fc-zoning enabled
UCS-A /fc-storage/vsan/member-port* # commit-buffer
UCS-A /fc-storage/vsan/member-port #
```

Creating a Named VSAN Accessible to One Fabric Interconnect (Fibre Channel Uplink Mode)



Note FCoE VLANs in the SAN cloud and VLANs in the LAN cloud must have different IDs. Using the same ID for an FCoE VLAN in a VSAN and a VLAN results in a critical fault and traffic disruption for all vNICs and uplink ports using that FCoE VLAN. Ethernet traffic is dropped on any VLAN with an ID that overlaps with an FCoE VLAN ID.

Procedure

	Command or Action	Purpose
Step 1	UCS-A# scope fc-uplink	Enters Fibre Channel uplink mode.
Step 2	UCS-A /fc-uplink # scope fabric {a b}	Enters Fibre Channel uplink fabric interconnect mode for the specified fabric interconnect (A or B).
Step 3	UCS-A /fc-uplink/fabric # create vsan <i>vsan-name vsan-id fcoe-id</i>	Creates the specified named VSAN, specifies the VSAN name, VSAN ID, and FCoE VLAN ID, and enters Fibre Channel uplink VSAN mode.

	Command or Action	Purpose
		<ul style="list-style-type: none"> • After an upgrade to Cisco UCS, Release 2.0—The FCoE storage port native VLAN uses VLAN 4048 by default. If the default FCoE VSAN was set to use VLAN 1 before the upgrade, you must change it to a VLAN ID that is not used or reserved. For example, consider changing the default to 4049 if that VLAN ID is not in use. • After a fresh install of Cisco UCS, Release 2.0—The FCoE VLAN for the default VSAN uses VLAN 4048 by default. The FCoE storage port native VLAN uses VLAN 4049.
Step 4	UCS-A /fc-uplink/vsan # set fc-zoning {disabled enabled}	Configures Fibre Channel zoning for the VSAN, as follows: <ul style="list-style-type: none"> • disabled—The upstream switch configures and controls the Fibre Channel zoning or Fibre Channel zoning is not implemented on this VSAN. • enabled—Cisco UCS Manager configures and controls Fibre Channel zoning.
Step 5	UCS-A /fc-uplink/fabric/vsan # commit-buffer	Commits the transaction to the system configuration.

Example

The following example creates a named VSAN for fabric interconnect A, names the VSAN finance, assigns the VSAN ID 3955, assigns the FCoE VLAN ID 2221, enables the VSAN for Cisco UCS Manager-based Fibre Channel zoning, and commits the transaction:

```
UCS-A# scope fc-uplink
UCS-A /fc-uplink # scope fabric a
UCS-A /fc-uplink/fabric # create vsan finance 3955 2221
UCS-A /fc-uplink/vsan # set fc-zoning enabled
UCS-A /fc-uplink/fabric/vsan* # commit-buffer
UCS-A /fc-uplink/fabric/vsan #
```

Creating a Named VSAN Accessible to One Fabric Interconnect (Fibre Channel Storage Mode)



Note FCoE VLANs in the SAN cloud and VLANs in the LAN cloud must have different IDs. Using the same ID for an FCoE VLAN in a VSAN and a VLAN results in a critical fault and traffic disruption for all vNICs and uplink ports using that FCoE VLAN. Ethernet traffic is dropped on any VLAN with an ID that overlaps with an FCoE VLAN ID.

Procedure

	Command or Action	Purpose
Step 1	UCS-A# scope fc-storage	Enters Fibre Channel storage mode.
Step 2	UCS-A /fc-storage # scope fabric {a b}	Enters Fibre Channel storage mode for the specified fabric interconnect.
Step 3	UCS-A /fc-storage/fabric # create vsan vsan-name vsan-id fcoe-id	Creates the specified named VSAN, specifies the VSAN name, VSAN ID, and FCoE VLAN ID, and enters Fibre Channel storage VSAN mode. <ul style="list-style-type: none"> • After an upgrade to Cisco UCS, Release 2.0—The FCoE storage port native VLAN uses VLAN 4048 by default. If the default FCoE VSAN was set to use VLAN 1 before the upgrade, you must change it to a VLAN ID that is not used or reserved. For example, consider changing the default to 4049 if that VLAN ID is not in use. • After a fresh install of Cisco UCS, Release 2.0—The FCoE VLAN for the default VSAN uses VLAN 4048 by default. The FCoE storage port native VLAN uses VLAN 4049.
Step 4	UCS-A /fc-storage/fabric/vsan # create member-port {fc fcoe} {a b} slot-id port-id	Creates a member port on the specified VSAN.
Step 5	UCS-A /fc-storage/vsan # set fc-zoning {disabled enabled}	Configures Fibre Channel zoning for the VSAN, as follows: <ul style="list-style-type: none"> • disabled—The upstream switch configures and controls the Fibre Channel zoning or Fibre Channel zoning is not implemented on this VSAN.

	Command or Action	Purpose
		<ul style="list-style-type: none"> enabled—Cisco UCS Manager configures and controls Fibre Channel zoning.
Step 6	UCS-A /fc-storage/fabric/vsan # commit-buffer	Commits the transaction to the system configuration.

Example

The following example creates a named VSAN on fabric A, names the VSAN finance, assigns the VSAN ID 3955, assigns the FCoE VLAN ID 2221, creates a member port and assigns the it to member port A, slot 1 port 40, and commits the transaction:

```
UCS-A# scope fc-storage
UCS-A /fc-storage/ # scope fabric a
UCS-A /fc-storage/fabric # create VSAN finance 3955 2221
UCS-A /fc-storage/fabric/vsan # create member-port a 1 40
UCS-A /fc-storage/fabric/vsan # set fc-zoning enabled
UCS-A /fc-storage/fabric/vsan/member-port* # commit-buffer
UCS-A /fc-storage/fabric/vsan/member-port #
```

Displaying a Named VSAN

The UCS Manager displays the named VSAN membership information.

Procedure

	Command or Action	Purpose
Step 1	UCS-A# scope fc-uplink	Enters Fibre Channel uplink mode.
Step 2	UCS-A /fc-uplink # scope vsan <i>vsan-name</i>	<p>Scopes the specified named VSAN.</p> <p>You can proceed to Step 3 or Step 4 based on the Fabric Interconnect series.</p>
Step 3	UCS-A /fc-uplink #/vsan # show member-port	<p>Displays the named VSAN member details.</p> <p>Note This command is supported on Cisco UCS 6200, 6300, 6400 and 6500 Series Fabric Interconnects.</p>
Step 4	UCS-A /fc-uplink #/vsan # show member-aggr-port	<p>Displays the named VSAN aggregate member port details.</p> <p>Note This command is supported only on Cisco UCS 6500 Series Fabric Interconnects.</p>
Step 5	(Optional) UCS-A /fc-uplink #/vsan # show member-aggr-port expand	Displays the expanded view of the named VSAN aggregate member port details.

	Command or Action	Purpose
		Note This command is supported only on Cisco UCS 6500 Series Fabric Interconnects.

Example

Example 1

The following example shows how to view the details of a named VSAN on Cisco UCS 6200, 6300, and 6400 Series Fabric Interconnects.

```
UCS-A# scope fc-uplink
UCS-A /fc-uplink # scope vsan #vsan name#
UCS-A /fc-uplink #/vsan# show member port
UCS-A /fc-uplink #
```

Example 2

The following example shows how to view the details of a named VSAN aggregate member port details on Cisco UCS 6500 series Fabric Interconnect:

```
UCS-A# scope fc-uplink
UCS-A /fc-uplink # scope vsan #vsan name#
UCS-A /fc-uplink #/vsan# show member-aggr-port
UCS-A /fc-uplink #
```

Output:

```
Member Aggregate-Port:
Fabric ID Slot Id Aggr Port Id
-----
A          1 35
A          1 36
```

Example 3

The following example shows how to view the details of a named VSAN aggregate member port details in an expanded view on Cisco UCS 6500 Series Fabric Interconnect.

```
UCS-A# scope fc-uplink
UCS-A /fc-uplink # scope vsan #vsan name#
UCS-A /fc-uplink #/vsan# show member-aggr-port expand
UCS-A /fc-uplink #
```

Output:

```
Member Aggregate-Port:
Fabric ID: A
Slot Id: 1
Aggr Port Id: 35

Breakout FC Member Port:
Fabric ID Slot ID Aggr-Port ID Port ID Oper State State Reason Oper
Speed
-----
A          1 35          2          Sfp Not Present SFP not present
indeterminate
A          1 35          3          Sfp Not Present SFP not present
```

```

indeterminate
  A                1 35          4          Sfp Not Present  SFP not present

indeterminate
  Fabric ID: A
  Slot Id: 1
  Aggr Port Id: 36

  Breakout FC Member Port:
    Fabric ID Slot ID  Aggr-Port ID Port ID  Oper State      State Reason Oper
Speed -----
  A                1 36          2          Sfp Not Present  SFP not present

indeterminate
  A                1 36          3          Sfp Not Present  SFP not present

indeterminate
  A                1 36          4          Sfp Not Present  SFP not present

indeterminate
    
```

Deleting a Named VSAN

If Cisco UCS Manager includes a named VSAN with the same VSAN ID as the one you delete, the VSAN is not removed from the fabric interconnect configuration until all named VSANs with that ID are deleted.

Procedure

	Command or Action	Purpose
Step 1	UCS-A# scope fc-uplink	Enters Fibre Channel uplink mode.
Step 2	UCS-A /fc-uplink # delete vsan <i>vsan-name</i>	Deletes the specified named VSAN.
Step 3	UCS-A /fc-uplink # commit-buffer	Commits the transaction to the system configuration.

Example

The following example shows how to delete a named VSAN and commit the transaction:

```

UCS-A# scope fc-uplink
UCS-A /fc-uplink # delete vsan finance
UCS-A /fc-uplink* # commit-buffer
UCS-A /fc-uplink #
    
```

Changing the VLAN ID for the FCoE Native VLAN for a Named VSAN



Note FCoE VLANs in the SAN cloud and VLANs in the LAN cloud must have different IDs. Using the same ID for an FCoE VLAN in a VSAN and a VLAN results in a critical fault and traffic disruption for all vNICs and uplink ports using that FCoE VLAN. Ethernet traffic is dropped on any VLAN with an ID that overlaps with an FCoE VLAN ID.

Procedure

	Command or Action	Purpose
Step 1	UCS-A# scope fc-uplink	Enters Fibre Channel uplink mode.
Step 2	UCS-A /fc-uplink # scope vsan <i>vsan-name</i>	Enters VSAN mode for the specified named VSAN.
Step 3	UCS-A /fc-uplink/vsan # set fcoe-vlan <i>fcoe-vlan-id</i>	Sets the unique identifier assigned to the VLAN used for Fibre Channel connections.
Step 4	UCS-A /fc-uplink/vsan # commit-buffer	Commits the transaction to the system configuration.

Example

The following example changes the VLAN ID for the FCoE Native VLAN on a named VSAN called *finance* to 4000 and commits the transaction:

```
UCS-A# scope fc-uplink
UCS-A /fc-uplink # scope vsan finance
UCS-A /fc-uplink/vsan # set fcoe-vlan 4000
UCS-A /fc-uplink/vsan* # commit-buffer
UCS-A /fc-uplink/vsan #
```

Changing the VLAN ID for the FCoE Native VLAN for a Storage VSAN



Note FCoE VLANs in the SAN cloud and VLANs in the LAN cloud must have different IDs. Using the same ID for an FCoE VLAN in a VSAN and a VLAN results in a critical fault and traffic disruption for all vNICs and uplink ports using that FCoE VLAN. Ethernet traffic is dropped on any VLAN with an ID that overlaps with an FCoE VLAN ID.

Procedure

	Command or Action	Purpose
Step 1	UCS-A# scope fc-storage	Enters Fibre Channel storage mode.
Step 2	UCS-A /fc-storage # set fcoe-storage-native-vlan <i>fcoe-id</i>	Sets the unique identifier assigned to the VLAN used for Fibre Channel connections.
Step 3	UCS-A /fc-storage # commit-buffer	Commits the transaction to the system configuration.

Example

The following example changes the VLAN ID for the FCoE Native VLAN on a storage VSAN called finance to 4000 and commits the transaction:

```
UCS-A# scope fc-storage
UCS-A /fc-storage # set fcoe-storage-native-vlan 4000
UCS-A /fc-storage* # commit-buffer
UCS-A /fc-storage #
```

Enabling or Disabling Fibre Channel Uplink Trunking



Note If the fabric interconnects are configured for Fibre Channel end-host mode, enabling Fibre Channel uplink trunking renders all VSANs with an ID in the range from 3840 to 4079 non-operational.



Note Before enabling VSAN trunking on a Fabric Interconnect, ensure that all host OS storage path redundancies are functioning. For more information on steps to monitor and ensure the Fibre Channel paths are recovered, see the [Verification that the Data Path is Ready](#) section. This should be followed to avoid an all paths down to the Fibre Channel Uplinks.

After confirmation, enable Fibre Channel Uplink Trunking on secondary Fabric Interconnect and wait until the secondary Fibre Channel VIF paths recover. Then move to enabling the primary Fabric Interconnect Fibre Channel Trunking after validating data paths.

Procedure

	Command or Action	Purpose
Step 1	UCS-A# scope fc-uplink	Enters Fibre Channel uplink mode.
Step 2	UCS-A /fc-uplink # scope fabric {a b }	Enters Fibre Channel uplink mode for the specified fabric.

	Command or Action	Purpose
Step 3	UCS-A /fc-uplink/fabric # set uplink-trunking { enabled disabled }	Enables or disables uplink trunking.
Step 4	UCS-A /fc-uplink/fabric # commit-buffer	Commits the transaction to the system configuration.

Example

The following example enables Fibre Channel uplink trunking for fabric A and commits the transaction:

```
UCS-A# scope fc-uplink
UCS-A /fc-uplink # scope fabric a
UCS-A /fc-uplink/fabric # set uplink-trunking enabled
UCS-A /fc-uplink/fabric* # commit-buffer
UCS-A /fc-uplink/fabric #
```

Configuring Breakout VSAN and Member Port

The following steps describe about creating a breakout VSAN and adding a member to breakout VSAN:

Procedure

	Command or Action	Purpose
Step 1	UCS-A# scope fc-uplink	Enters Fibre Channel uplink mode.
Step 2	UCS-A /fc-uplink # scope fabric a	Enters Fibre Channel uplink fabric mode for the specified fabric.
Step 3	UCS-A /fc-uplink/fabric # create vsan testVsan 2020 2022	Creates VSAN on the specified Fibre Channel uplink port, and enters Fibre Channel uplink fabric VSAN mode.
Step 4	UCS-A /fc-uplink/fabric/vsan* # create member-aggr-port a/ 36	Creates the interface for the specified aggregate (main) Fibre Channel uplink port.
Step 5	UCS-A /fc-uplink/fabric/vsan* # create member-aggr-port a/ 36	Creates the interface for the specified aggregate (main) Fibre Channel uplink port.
Step 6	UCS-A /fc-uplink/fabric/vsan/member-aggr-port* # create br-member-portbr-fc 3	Creates a breakout member port for the specified Fibre Channel Uplink port.
Step 7	UCS-A /fc-uplink/fabric/vsan/member-aggr-port/br-fc* # commit-buffer	Commits the transaction to the system configuration.

	Command or Action	Purpose
Step 8	UCS-A /fc-uplink/fabric/vsan/member-aggr-port/br-fc # up	
Step 9	UCS-A /fc-uplink/fabric/vsan/member-aggr-port # show br-member-port br-fc br-fc	Displays the output.

Example

The following is the example for creating and adding a member to a breakout VSAN:

Breakout FC Member Port:

```

Fabric ID Slot ID   Aggr-Port ID Port ID   Oper State   State Reason Oper Speed
-----
A                1 36         3           Sfp Not Present  SFP not present
                                                    indeterminate

```

```

UCS-A /fc-uplink/fabric/vsan/member-aggr-port # up
UCS-A /fc-uplink/fabric/vsan # show member-aggr-port

```

Member Aggregate-Port:

```

Fabric ID Slot Id Aggr Port Id
-----
A                1 36
UCS-A /fc-uplink/fabric/vsan #

```

