

Server Management Overview

Cisco UCS Manager enables you to manage general and complex server deployments. For example, you can manage a general deployment with a pair of Fabric Interconnects (FIs), which is the redundant server access layer that you get with the first chassis that can scale up to 20 chassis' and up to 160 physical servers. This can be a combination of blades and rack mount servers to support the workload in your environment. As you add more servers, you can continue to perform server provisioning, device discovery, inventory, configuration, diagnostics, monitoring, fault detection, and auditing.

Beginning with release 4.0(2a), Cisco UCS Manager extends support for all existing features on the following Cisco UCS hardware unless specifically noted:

- Cisco UCS C480 M5 ML Server
- Cisco UCS VIC 1495
- Cisco UCS VIC 1497

Beginning with release 4.0(1a), Cisco UCS Manager extends support for all existing features on the following Cisco UCS hardware unless specifically noted:

- Cisco UCS 6454 Fabric Interconnect
- Cisco UCS VIC 1455
- Cisco UCS VIC 1457
- Cisco UCS C125 M5 Server

Beginning with release 4.0(1a), Cisco UCS Manager does not support UCS M2 servers.

By default, the Cisco UCS 6454 Fabric Interconnects, the Cisco UCS 6332 Fabric Interconnects, the UCS Mini 6324 Fabric Interconnects, and the UCS 6200 Series Fabric Interconnects include centralized management. You can manage the UCS Blade Servers and Rack-Mount Servers that are in the same domain from one console. You can also manage the UCS Mini from the Cisco UCS Manager.

To ensure the optimum server performance, you can configure the amount of power that you allocate to servers. You can also set the server boot policy, the location from which the server boots, and the order in which the boot devices are invoked. You can create service profiles for the UCS B-Series Blade Servers and the UCS Mini to assign to servers. Service profiles enable you to assign BIOS settings, security settings, the number of vNICs and vHBAs, and anything else that you want to apply to a server.

Cisco UCS Manager User Documentation, on page 2

Cisco UCS Manager User Documentation

Cisco UCS Manager offers you a new set of smaller, use-case based documentation described in the following table:

| Guide | Description |
|---|--|
| Cisco UCS Manager Getting Started Guide | Discusses Cisco UCS architecture and Day 0 operations, including Cisco UCS Manager initial configuration and configuration best practices. |
| Cisco UCS Manager Administration Guide | Discusses password management, role-based access configuration, remote authentication, communication services, CIMC session management, organizations, backup and restore, scheduling options, BIOS tokens, and deferred deployments. |
| Cisco UCS Manager Infrastructure Management Guide | Discusses physical and virtual infrastructure components used and managed by Cisco UCS Manager. |
| Cisco UCS Manager Firmware Management Guide | Discusses downloading and managing firmware, upgrading through Auto Install, upgrading through service profiles, directly upgrading at endpoints using firmware auto sync, managing the capability catalog, deployment scenarios, and troubleshooting. |
| Cisco UCS Manager Server Management Guide | Discusses the new licenses, registering Cisco UCS domain with Cisco UCS Central, power capping, server boot, server profiles, and server-related policies. |
| Cisco UCS Manager Storage Management Guide | Discusses all aspects of storage management, such as SAN and VSAN in Cisco UCS Manager. |
| Cisco UCS Manager Network Management Guide | Discusses all aspects of network management, such as LAN and VLAN connectivity in Cisco UCS Manager. |
| Cisco UCS Manager System Monitoring Guide | Discusses all aspects of system and health monitoring, including system statistics in Cisco UCS Manager. |
| Cisco UCS S3260 Server Integration with Cisco UCS Manager | Discusses all aspects of management of UCS S-Series servers that are managed through Cisco UCS Manager. |