



Phone Information and Display Configuration

- [Phone Information and Display Settings, on page 1](#)
- [Configure the Phone Name, on page 1](#)
- [Customize the Startup Screen, on page 2](#)
- [Customize Wallpaper for the Phone Display, on page 3](#)
- [Configure the Screen Saver with the Phone Web Interface, on page 4](#)
- [Adjust Backlight Timer from the Phone Web Interface, on page 7](#)
- [Customize the Product Configuration Version, on page 7](#)
- [Keep Focus on the Active Call, on page 8](#)

Phone Information and Display Settings

The phone web user interface allows you to customize settings such as the phone name, background picture, logo, and screen saver.

Configure the Phone Name

Before you begin

Access the phone administration web page. See [Access the Phone Web Interface](#).

Procedure

Step 1 Select **Voice > Phone**.

Step 2 Under **General**, enter the phone name in the **Station Display Name** field.

This name displays on the phone screen. You can also configure this parameter in the configuration file (cfg.xml) by entering a string in this format:

```
<Station_Display_Name ua="na">Recetion Desk</Station_Display_Name>
```

Step 3 Click **Submit All Changes**.

Customize the Startup Screen

You can create a text or an image logo to display when the Cisco IP Phone boots up. A logo displays during the boot sequence for a short period after the Cisco logo displays.

Before you begin

Access the phone administration web page. See [Access the Phone Web Interface](#).

Procedure

Step 1 Click **Voice > User**.

Step 2 In the **Screen** section, select any option from the **Boot Display** field.

- **Default:** Displays a blank screen or existing screen as the startup screen.
- **Download Picture:** Displays a picture as the startup screen. Enter the path in the **Picture Download URL** field.
- **Logo:** Displays a logo as the startup screen. Enter the path in the **Logo URL** field.
- **Text:** Displays a text as the startup screen. Enter text in the **Text Display** field.

You can also configure this parameter in the configuration file (cfg.xml) by entering a string in this format:

```
<Boot_Display ua="na">Logo</Boot_Display>
```

The allowed values are Default|Download Picture|Logo|Text. The default option is Default.

Step 3 To display a picture or a logo, enter the path in the **Picture Download URL** or **Logo URL** field.

For example:

```
http://10.64.84.147/pictures/image04.png
```

When you enter an incorrect URL to download the image, the phone fails to upgrade to the new image and displays the existing image. If the phone does not have any image downloaded earlier, it displays a gray screen.

The logo must be a .jpg or a .png file. The phone has a fixed display area. So, if the original logo size doesn't fit into the display area, you need to scale it to fit the screen. The display area size of the Cisco IP Phone 7832 is 48x48.

The logo must be a .jpg or a .png file. The phone has a fixed display area. So, if the original logo size doesn't fit into the display area, you need to scale it to fit the screen. The display area size of the Cisco IP Phone 8832 is 48x48.

You can also configure this parameter in the configuration file (cfg.xml) by entering a string in this format:

```
<Picture_Download_URL
ua="na">http://10.64.84.147/pictures/bootimage1.jpg</Picture_Download_URL>
<Logo_URL ua="na">http://10.64.84.147/pictures/logo_image.jpg</Logo_URL>
```

Step 4 To display text at bootup, enter the text to display in the **Text Display** field following the requirements:

- Enter up to two lines of text with less than 32 characters for each line.

- Insert a new line character (\n) and escape code (%0a) between the two lines.

For example,

```
Super\n%0aTelecom
```

displays:

```
 Super  
Telecom
```

- Use the + character to add spaces for formatting. You can add multiple + characters before and after the text to center it.

You can also configure this parameter in the configuration file (cfg.xml) by entering a string in this format:

```
<Text_Display ua="na">Super\n%0aTelecom</Text_Display>
```

Step 5 Click **Submit All Changes**.

The phone reboots, retrieves the image file, and displays the picture, logo, or text when it boots next time.

Customize Wallpaper for the Phone Display

You can set the phone to display a custom logo or picture as the background on the phone screen.

The maximum file size of wallpaper that you can add is 625k bytes.

Procedure

Step 1 On the phone web interface, select **Voice > User**.

User can also change the wallpaper in the phone web interface.

Step 2 In the **Screen** section, choose one of the options for the **Phone Background** field:

- **Default**—Keeps the system default background.
- **Download Picture**—Displays a picture downloaded from a TFTP, FTP, or HTTPS server. When select this option, enter the URL for the picture in the **Picture Download URL** field.
- **Logo**—Displays a logo downloaded from a TFTP, FTP, or HTTPS server. When select this option, enter the URL for the logo image in the **Logo URL** field.

You can also configure this parameter in the configuration file (cfg.xml) by entering a string in this format:

```
<Phone_Background ua="na">Logo</Phone_Background>
```

Step 3 Upload the custom wallpaper to a TFTP, HTTP, or HTTPS server.

The image is a .jpg or .png file. Preferred dimension is 480x128 pixels. If the image is not the preferred size, user still can upload it but it will resize to fit the screen.

Step 4 In the **Picture Download URL** field, enter the path where the wallpaper image has been uploaded.

The URL must include the TFTP, HTTP, or HTTPS server name (or IP address), directory, and file name. Don't exceed 255 characters for the URL.

Example:

```
http://10.64.84.147/pictures/image04.jpg
```

When you enter an incorrect URL to download a new wallpaper, the phone fails to upgrade to the new wallpaper and displays the existing downloaded wallpaper. If the phone does not have any wallpaper downloaded earlier, it displays a gray screen.

You can also configure this parameter in the configuration file (cfg.xml) by entering a string in this format:

```
<Picture_Download_URL ua="na">http://10.64.84.147/pictures/image04.jpg</Picture_Download_URL>
```

Step 5 Upload the logo image to a TFTP, HTTP, or HTTPS server.

The logo must be a .jpg or a .png file. The phone has a fixed display area. So, if the original logo size doesn't fit into the display area, you need to scale it to fit the screen. The display area size of the Cisco IP Phone 7832 is 48x48.

The logo must be a .jpg or a .png file. The phone has a fixed display area. So, if the original logo size doesn't fit into the display area, you need to scale it to fit the screen. The display area size of the Cisco IP Phone 8832 is 48x48.

Step 6 In the **Logo URL** field, enter the path where the logo image has been uploaded.

The URL must include the TFTP, HTTP, or HTTPS server name (or IP address), directory, and file name. Don't exceed 255 characters for the URL.

Example:

```
http://10.64.84.147/pictures/logo_image.jpg
```

When you enter an incorrect URL to download a new logo, the phone fails to upgrade to the newer logo and displays the existing downloaded logo. If the phone does not have any logo downloaded earlier, it displays a gray screen.

You can also configure this parameter in the configuration file (cfg.xml) by entering a string in this format:

```
<Logo_URL ua="na">http://10.64.84.147/pictures/logo_image.jpg</Logo_URL>
```

Step 7 Click **Submit All Changes**.

The phone reboots after you change the background image URL.

Configure the Screen Saver with the Phone Web Interface

You can configure a screen saver for the phone. When the phone is idle for a specified time, it enters screen saver mode.

Any button press returns the phone to normal mode.

You can also configure the parameters in the phone configuration file with XML (cfg.xml) code. To configure each parameter, see the syntax of the string in [Parameters for Screen Saver, on page 5](#).

Before you begin

Access the phone administration web interface. See [Access the Phone Web Interface](#).

Procedure

-
- Step 1** On the phone web page, select **Voice > User**.
The user can select **User Login > Voice > User** to add screen saver to the phone.
- Step 2** In the **Screen** section, set up the fields as described in [Parameters for Screen Saver, on page 5](#).
- Step 3** Click **Submit All Changes**.
-

Parameters for Screen Saver

The following table defines the function and usage of the screen saver parameters in the **Screen** section under the **Voice > User** tab in the phone web interface. It also defines the syntax of the string that is added in the phone configuration file (cfg.xml) with XML code to configure a parameter.

Table 1: Parameters for Screen Saver

Parameter	Description
Screen Saver Enable	<p>Select Yes to enable a screen saver on the phone. When the phone is idle for a specified amount of time, the screen saver is displayed.</p> <p>Perform one of the following:</p> <ul style="list-style-type: none"> In the phone configuration file with XML(cfg.xml), enter a string in this format: <code><Screen_Saver_Enable ua="rw">Yes</Screen_Saver_Enable></code> In the phone web interface, set this field to Yes to enable screen saver. <p>Allowed values: Yes No</p> <p>Default: No</p>

Parameter	Description
Screen Saver Type	<p>Types of screen saver. Options you can choose:</p> <ul style="list-style-type: none"> • Clock—Displays a digital clock on a plain background. • Download Picture—Displays a picture pushed from the phone webpage. Enter • Logo: Displays a logo on the phone screen. Add a logo image in the Logo URL <p>Perform one of the following:</p> <ul style="list-style-type: none"> • In the phone configuration file with XML(cfg.xml), enter a string in this format <pre><Screen_Saver_Type ua="rw">Clock</Screen_Saver_Type></pre> • In the phone web interface, select a screen saver. <p>Allowed values: Clock Download Picture Logo Default: Clock</p>
Screen Saver Wait	<p>Amount of idle time before screen saver displays.</p> <p>Enter the number of seconds of idle time to elapse before the screen saver starts.</p> <p>Perform one of the following:</p> <ul style="list-style-type: none"> • In the phone configuration file with XML(cfg.xml), enter a string in this format <pre><Screen_Saver_Wait ua="rw">300</Screen_Saver_Wait></pre> • In the phone web interface, set the time in seconds. <p>Allowed values: An integer from 30 through 65000 Default: 300</p>
Picture Download URL	<p>URL locating the (.png) file to display on the phone screen background. The image is displayed at bootup depending on the settings of the Phone Background, Screen Saver Type</p> <p>When you enter an incorrect URL to download a new image, the phone fails to update the image. If the phone does not have any image downloaded earlier, it displays a gray screen.</p> <p>Perform one of the following:</p> <ul style="list-style-type: none"> • In the phone configuration file with XML(cfg.xml), enter a string in this format <pre><Picture_Download_URL ua="rw">http://10.74.3.52/images/screensaver</Picture_Download_URL></pre> • In the phone web interface, specify the URL where the picture is located. <p>Allowed values: A valid URL not exceeding 255 characters Default: Empty</p>

Parameter	Description
Logo URL	<p>Enter a URL or path for the location where the logo image is saved. The logo image is displayed on the phone screen at bootup depending on the settings of the Screen Saver Type, Boot Display, and Screen Saver.</p> <p>Perform one of the following:</p> <ul style="list-style-type: none"> In the phone configuration file with XML(cfg.xml), enter a string in this format: <pre><Logo_URL ua="rw">http://10.74.3.52/images/Logo1.png</Logo_URL></pre> In the phone web interface, specify the URL where the logo image is located. <p>Allowed values: A valid URL not exceeding 255 characters</p> <p>Default: Empty</p>

Adjust Backlight Timer from the Phone Web Interface

You can save energy by disabling the backlight on each phone at a preset time.

Procedure

-
- Step 1** Select **Voice > User**.
- Step 2** In the **Screen** section, select a duration for the **Back Light Timer** parameter.
- You can also configure this parameter in the configuration file (cfg.xml) by entering a string in this format:
- ```
<Back_Light_Timer ua="rw">30s</Back_Light_Timer>
```
- Step 3** Click **Submit All Changes**.
- 

## Customize the Product Configuration Version

You can customize the configuration version of the product in the phone configuration file (cfg.xml). After the change takes effect, the user can view the configuration version of the product information on the phone.

### Procedure

- 
- Step 1** Edit the phone configuration file (cfg.xml) in a text or XML editor.
- Step 2** Add a value for the element `<Device_Config_Version>` in the cfg.xml file.
- For example:
- ```
<Device_Config_Version ua="na">2021-01-05-v1</Device_Config_Version>
```
- Default: Empty
- Value range: 0 to 64 characters

If the tag doesn't exist in the `cfg.xml` file or the parameter value is empty, then the **Configuration version** menu item doesn't display on the phone screen **Product information**.

Step 3 Save the changes to the `cfg.xml` file.

Keep Focus on the Active Call

You can configure the phone to ensure that the active call is still in focus when the user has an incoming call.

By default, the focus on the phone screen automatically moves from the active call to the incoming call. However, you can configure the phone to ensure that the active call always remains in focus, even when the user has an incoming call.

The focus still moves to an incoming call in the following situations:

- The user places an active call on hold and then receives one or more incoming calls, the focus automatically moves to the first incoming call.
- The user is on an active call and receives one or more incoming calls, if the user places the active call on hold, then the focus automatically moves to the first incoming call.

Before you begin

Access the phone administration web page. See [Access the Phone Web Interface](#).

Procedure

Step 1 Select **Voice > User**.

Step 2 In the **Supplementary Services** section, set the parameter **Keep Focus On Active Call** to **Yes**.

You can also configure this parameter in the configuration file:

```
<Keep_Focus_On_Active_Call ua="na">Yes</Keep_Focus_On_Active_Call>
```

Allowed values: Yes and No

Default: No

Step 3 Click **Submit All Changes**.
