



Configure Voice-Mail Call-Handling Parameters

Use this procedure to configure call-handling parameters.

Step 1 Click **Voice Mail > Call Handling**. The Voice Mail Call Handling window appears.

Step 2 Enter the data in the following fields:

- Voice Mail Phone Number
- Voice Mail Language
- Maximum Sessions
- Voice Mail Operator Number
- Application Parameter Settings Script
- Administration via Telephone (AvT) call-in number
- Administration via Telephone (AvT) prompt language

Step 3 Click **Apply** to save your changes.
