



PCC-Quota Service Configuration Mode Commands



Important

This configuration mode is supported from StarOS Release 12.1 onward.

Command Modes

The PCC-Quota Service Configuration mode provides a mechanism for Intelligent Policy Control Function (IPCF) to manage the external interfaces required for quota management purpose. The PCC-Quota service uses **Gx** interface towards PCEF/DPI node for Volume-Reporting-Over-Gx (VRoGx) for Quota management and messaging based on a Diameter dictionary. This mode exists within Context Configuration mode.

Exec > Global Configuration > Context Configuration > PCC Service Configuration > PCC Quota Service Configuration

configure > **context** *context_name* > **pcc-quota-service** *service_name*



Important

The commands or keywords/variables that are available are dependent on platform type, product version, and installed license(s).



Important

For information on common commands available in this configuration mode, refer to the [Common Commands](#) chapter.

- [associate pcc-service, on page 1](#)
- [diameter dictionary, on page 2](#)
- [diameter origin end-point, on page 3](#)
- [max total-charging-sessions, on page 4](#)

associate pcc-service

This command is used to associate a pre-configured PCC-Service with a PCC-Quota service for IPCF configuration.

Product	IPCF
Privilege	Security Administrator, Administrator
Command Modes	Exec > Global Configuration > Context Configuration > PCC Service Configuration > PCC Quota Service Configuration configure > context <i>context_name</i> > pcc-quota-service <i>service_name</i>
Syntax Description	associate pcc-service <i>pcc_service_name</i> [no] associate pcc-service no Removes/disassociate the configured PCC-service from this PCC-Quota service instance configured for IPCF configuration. <i>pcc_service_name</i> Specifies the name of a pre-configured PCC-service configured in Context Configuration mode for IPCF configuration. The <i>pcc_service_name</i> is name of a predefined PCC-Service instance and must be an alphanumeric string from 1 through 63 characters.
Usage Guidelines	Use this command to associate a pre-configured PCC-Service instance for IPCF configuration.

**Important**

For more information on PCC-Service configuration, refer *PCC-Service Configuration Mode Commands*.

Example

Following command binds a PCC-Service named *pcc_svc1* with in a PCC-Quota service.

```
associate pcc-service pcc_svc1
```

Following command removes an associated PCC-Service named *pcc_svc1* from a PCC-Quota service.

```
no associate pcc-service pcc_svc1
```

diameter dictionary

This command is used to assign a 3GPP Rel. 8 Gx standard Diameter dictionary for **VRoGx** messaging with a PCC-Quota service for IPCF configuration.

Product	IPCF
Privilege	Security Administrator, Administrator
Command Modes	Exec > Global Configuration > Context Configuration > PCC Service Configuration > PCC Quota Service Configuration

```
configure > context context_name > pcc-quota-service service_name
```

Syntax Description

```
[no]diameter dictionary standard
```

no

Removes the assigned a 3GPP Rel. 8 Gx standard Diameter dictionary for **VRoGx** messaging with a PCC-Quota service for IPCF configuration.

Usage Guidelines

Use this command to assign a 3GPP Rel. 8 Gx standard Diameter dictionary for **VRoGx** messaging in PCC-Quota service for quota management.

Example

Following command sets the PCC-Quota service to use 3GPP Rel. 8 standard dictionary over **Gx** interface and **VRoGx** supported quota management related messaging in a PCC-Quota service:

```
diameter dictionary standard
```

diameter origin end-point

This command is used to bind/associate a pre-configured Diameter host/realm (SSC/SPR) over **Sp** interface with a PCC-Quota service to be used for subscriber quota management.

Product

IPCF

Privilege

Security Administrator, Administrator

Command Modes

Exec > Global Configuration > Context Configuration > PCC Service Configuration > PCC Quota Service Configuration

```
configure > context context_name > pcc-quota-service service_name
```

Syntax Description

```
diameter origin endpoint dia_endpoint_name  
no diameter origin endpoint
```

no

Removes the associated Diameter Origin Endpoint configuration from PCC-Quota service instance configured for IPCF configuration.

any

Sets the PCC-Quota service instance to use any available PCEF/DPI node over **Sp** interface for quota management.

dia_endpoint_name

The *dia_endpoint_name* is a predefined Diameter origin endpoint node and must be an alphanumeric string from 1 through 63 characters.

Usage Guidelines

Use this command to bind the SSC/SPR node over **Sp** interface by associating a pre-configured Diameter Origin Endpoint with a PCC-Quota service.

The Diameter origin endpoint must be a pre-configured instance in the Context Configuration Mode. For more information on Diameter origin endpoint configuration, refer *Diameter Endpoint Configuration Mode Commands* chapter.

Example

Following command associates a pre-configured Diameter endpoint node configuration named *ssc1* with a PCC-Quota service for subscriber quota management.

```
diameter origin endpointssc1
```

Following command removes the pre-associated Diameter endpoint node configuration named *ssc1* with a PCC-Quota service.

```
no diameter origin endpoint
```

max total-charging-sessions

This command is used configure the maximum limit of the charging sessions allowed in a PCC-Quota service instance on IPCF.

Product

IPCF

Privilege

Security Administrator, Administrator

Command Modes

Exec > Global Configuration > Context Configuration > PCC Service Configuration > PCC Quota Service Configuration

```
configure > context context_name > pcc-quota-service service_name
```

Syntax Description

```
max total-charging-sessions max_session
default max total-charging-sessions
```

default

Sets the maximum charging sessions allowed in PCC-Quota service instance to default value of charging sessions.

max_session

Default: 1

Specifies the maximum number of charging sessions configured in PCC-Quota service to allow to be connected in PCC-Quota service instance.

max_session must be an integer between 0 and 113.

Usage Guidelines

Use this command to set the maximum number of charging sessions allowed by a PCC-Quota service instance on IPCF.

Example

Following command sets the maximum number of charging sessions allowed in PCC-Quota service instance to 10000.

```
default max total-charging-sessions
```

max total-charging-sessions