

Пример начальной конфигурации модуля служб CSM и SSL

Содержание

[Введение](#)

[Предварительные условия](#)

[Требования](#)

[Используемые компоненты](#)

[Условные обозначения](#)

[Настройка](#)

[Схема сети](#)

[Конфигурации](#)

[Проверка](#)

[Устранение неполадок](#)

[Дополнительные сведения](#)

Введение

Этот документ предоставляет пример конфигурации для настройки Модуля коммутации контента (CSM) с Протоколом SSL.

Предварительные условия

Требования

Для этого документа отсутствуют особые требования.

Используемые компоненты

Сведения, содержащиеся в данном документе, касаются следующих версий программного обеспечения и оборудования:

- Маршрутизатор Cisco 7202 рабочий Cisco IOS® 12.1
- Cisco Catalyst 6509 рабочих IOS 12.1
- CSM с набором функций Модуля оконечного устройства SSL (STE) рабочий IOS 12.2 (11) и SSL (0.86)
- Маршрутизатор Cisco 7606 рабочий IOS 12.1
- Сборка CSM 3.1 (0.119)

Сведения, представленные в этом документе, были получены от устройств, работающих в специальной лабораторной среде. Все устройства, описанные в этом документе, были

запущены с чистой (стандартной) конфигурацией. В рабочей сети необходимо изучить потенциальное воздействие всех команд до их использования.

Условные обозначения

[Дополнительные сведения об условных обозначениях см. в документе Технические рекомендации Cisco. Условные обозначения.](#)

Настройка

В этом разделе содержатся сведения о настройке функций, описанных в этом документе.

Примечание: [Поиск дополнительной информации о командах в данном документе можно выполнить с помощью средства "Command Lookup" \(Поиск команд\) \(только для зарегистрированных клиентов\).](#)

Схема сети

В настоящем документе используется следующая схема сети:

В этой топологии Протокол HSRP работает на основе Функциональной Карты Многоуровневого Коммутатора (MSFC) 1 (MSFC1) и Функциональной Карты Многоуровневого Коммутатора (MSFC) 2 (MSFC2). Существует две группы HSRP, одна в клиентской стороне и другая в стороне CSM. CSM настроен как режим координации между MSFC и Модулем оконечного устройства SSL (STE) и адресным режимом между STE и Реальными серверами. CSM балансирует нагрузку подключений SSL между двумя STEs.

Конфигурации

Эти конфигурации используются в данном документе:

- 7202 маршрутизатора
- 6509 коммутаторов
- STE-1
- 7606 коммутаторов
- STE-2

Это контрольные примеры:

1. Репликация подключения SSL в CSM
2. Сложная репликация SSL в CSM
3. Аварийное переключение CSM с подключением SSL оставило открытым
4. Аварийное переключение активного MSFC с открытым подключением SSL
5. Аварийное переключение шасси с подключениями SSL оставило открытым
6. Повторное согласование соединения SSL в том же соединении и возобновление с новым подключением SSL (новая характеристика)
7. Закрепленные функциональные возможности CSM с несколькими подключениями SSL с возобновлением

```
7202-Reg#show run
Building configuration...
Current configuration : 1042 bytes
!
version 12.1
service timestamps debug uptime
service timestamps log uptime
no service password-encryption
!
hostname 7202-Reg
!
boot system flash disk0:c7200-jk2o3s-mz.121-11b.E
enable password lab
!
ip subnet-zero
!
!
no ip domain-lookup
ip host defib 223.255.254.242
!
ip cef
ip audit notify log
ip audit po max-events 100
ip ssh time-out 120
ip ssh authentication-retries 3
!
controller ISA 1/1
!
controller ISA 2/1
!
interface Loopback0
 ip address 192.10.10.1 255.255.255.255
!
interface FastEthernet0/0
 ip address 15.10.10.21 255.0.0.0
 duplex auto
 speed auto
!
interface FastEthernet0/1
 ip address 11.0.0.1 255.0.0.0
 duplex auto
 speed auto
!
interface GigabitEthernet5/0
 ip address 10.0.0.100 255.0.0.0
 negotiation auto
!
ip classless
ip route 12.0.0.0 255.0.0.0 11.0.0.100
ip route 192.0.0.0 255.0.0.0 147.10.10.1
ip route 223.255.254.0 255.255.255.0 15.0.100.1
no ip http server
no ip http secure-server
!
line con 0
 exec-timeout 0 0
line aux 0
line vty 0 4
 password lab
 login
line vty 5 15
 login
!
```

```
end
```

6509

```
6509-1#show run
Building configuration...
Current configuration : 7932 bytes
!
version 12.1
service timestamps debug uptime
service timestamps log uptime
no service password-encryption
service internal
!
hostname 6509-1
!
boot system flash slot0:
logging buffered 5000000 debugging
enable password lab
!
!--- Configures the VLANs allowed over the trunk to the
SSL services module. !--- The admin VLAN is included.
The SSL module is located in slot 9. !
ssl-proxy module 9 allowed-vlan 4,15
diagnostic level complete
ip subnet-zero
!
!
no ip domain-lookup
!
mls flow ip destination
mls flow ipx destination
!
spanning-tree extend system-id
no spanning-tree vlan 2
!
!--- The CSM is located in slot 7. The module is
running as Active. !
module ContentSwitchingModule 7
vlan 3 client
ip address 12.0.0.23 255.0.0.0
gateway 12.0.0.100
!
vlan 4 server
ip address 12.0.0.23 255.0.0.0
!
vlan 5 server
ip address 20.0.0.23 255.0.0.0
alias 20.0.0.100 255.0.0.0
!
probe ICMP icmp
interval 5
failed 10
!
!--- These are the server farm HTTP and real server
members. serverfarm HTTP
nat server
no nat client
real 20.0.0.7
inservice
real 20.0.0.8
inservice
real 20.0.0.9
inservice
```

```
real 20.0.0.10
  inservice
real 20.0.0.11
  inservice
real 20.0.0.12
  inservice
!
!--- These are the server farm HTTPS and real server
members. serverfarm HTTPS
  no nat server
  no nat client
  real 12.0.0.50
    inservice
  real 12.0.0.51
    inservice
  probe ICMP
!
sticky 1 ssl timeout 5
sticky 2 netmask 255.0.0.0 timeout 5
!
!--- Virtual server HTTP. vserver HTTP
!--- The virtual server IP address is specified with TCP
port www.
virtual 12.0.0.124 tcp www
!--- The VLAN from where the CSM accepts traffic for a
specified virtual server.
vlan 4
!--- Destination server farm.
serverfarm HTTP
sticky 5 group 2
!--- Enables connection redundancy. !--- Replicates the
sticky database to the backup CSM.
replicate csrp sticky
!--- Replicates connections to the backup CSM.
replicate csrp connection
persistent rebalance
inservice
!
!--- Virtual server HTTPS. vserver HTTPS
!--- The virtual server IP address is specified with
TCP port HTTP over SSL. virtual 12.0.0.123 tcp https
!--- The VLAN from where the CSM accepts traffic for a
specified virtual server. vlan 3
!--- Destination server farm.
serverfarm HTTPS
ssl-sticky offset 20 length 6
sticky 5 group 1
!--- Enables connection redundancy. !--- Replicates the
sticky database to the backup CSM.
replicate csrp sticky
!--- Replicates connections to the backup CSM.
replicate csrp connection
!--- Disables HTTP 1.1 persistence for connections in
the virtual server.
no persistent rebalance
inservice
!
  ft group 1 vlan 2
!
!
redundancy
  mode rpr-plus
  main-cpu
  auto-sync running-config
```

```
    auto-sync standard
!
power redundancy-mode combined
!
interface Loopback0
  ip address 192.10.10.2 255.255.255.255
!
interface GigabitEthernet1/1
  no ip address
  switchport
  switchport trunk encapsulation dot1q
  switchport trunk allowed vlan 1-5,1002-1005
  switchport mode trunk
!
interface GigabitEthernet1/2
  no ip address
  shutdown
!
interface FastEthernet4/13
  ip address 11.0.0.5 255.0.0.0
  no ip redirects
  standby 2 ip 11.0.0.100
  standby 2 priority 101
  standby 2 preempt
  standby 2 name Client-Side
!
interface FastEthernet4/14
  no ip address
  shutdown
!
interface FastEthernet4/48
  no ip address
  switchport
  switchport access vlan 15
  switchport mode access
!
interface GigabitEthernet5/1
  no ip address
  switchport
  switchport access vlan 5
  switchport mode access
!
interface GigabitEthernet5/2
  no ip address
  switchport
  switchport access vlan 5
  switchport mode access
!
interface GigabitEthernet5/3
  no ip address
  switchport
  switchport access vlan 5
  switchport mode access
!
interface Vlan1
  no ip address
  shutdown
!
interface Vlan3
  ip address 12.0.0.1 255.0.0.0
  no ip redirects
  standby 1 ip 12.0.0.100
  standby 1 priority 101
  standby 1 preempt
```

```

standby 1 name CSM-Side
standby 1 track FastEthernet4/13
!
interface Vlan15
 ip address 15.0.1.1 255.0.0.0
!
ip classless
ip route 10.0.0.0 255.0.0.0 11.0.0.1
no ip http server
!
alias exec sc show module csm 7
!
line con 0
 exec-timeout 0 0
line vty 0 4
 password lab
 login
 transport input lat pad mop telnet rlogin udptn nasi
!
scheduler runtime netinput 300
end

```

STE-1

```

ssl-proxy-9#show run brief
Building configuration...
Current configuration : 1437 bytes
!
version 12.2
no service pad
service timestamps debug datetime msec
service timestamps log datetime msec
no service password-encryption
!
hostname ssl-proxy-9
!
enable password lab
!
username braghu secret 5 $1$7Pdr$7dNm7l71.BJzELfi.QUzp/
ip subnet-zero
ip tftp source-interface Ethernet0/0.15
no ip domain lookup
!
ip ssh rsa keypair-name ssh-key
!
!
!--- Adds a proxy service HTTPS that identifies a
virtual IP address !--- and a server IP address for each
proxy.
ssl-proxy service https
 virtual ipaddr 12.0.0.123 protocol tcp port 443
secondary
 server ipaddr 12.0.0.124 protocol tcp port 80
 certificate rsa general-purpose trustpoint TP-2048-
pkcs12
 inservice
!--- Configures this VLAN as administrative.
ssl-proxy vlan 15
 ipaddr 15.0.10.4 255.0.0.0
 gateway 15.0.100.1
 admin
!--- Adds an interface to VLAN 4 on the SSL services
module.
ssl-proxy vlan 4

```

```
ipaddr 12.0.0.50 255.0.0.0
gateway 12.0.0.100
ssl-proxy mac address 00e0.b0ff.f0c4
!
!--- Declares the trustpoint that the module is to use.
crypto ca trustpoint TP-2048-pkcs12
!--- Specifies the key pair to associate with the
certificate.
rsakeypair TP-2048-pkcs12
!
!--- Declares the trustpoint that the module is to use.
crypto ca trustpoint TP-1024-pkcs12
!--- Specifies the key pair to associate with the
certificate.
rsakeypair TP-1024-pkcs12
!--- Specifies the certificate and key to be
associated.
crypto ca certificate chain TP-2048-pkcs12
certificate ca 313AD6510D25ABAE4626E96305511AC4
certificate 3C2DF2E50001000000DC
crypto ca certificate chain TP-1024-pkcs12
certificate 3C2CD2330001000000DB
certificate ca 313AD6510D25ABAE4626E96305511AC4
!
ip classless
ip route 0.0.0.0 0.0.0.0 15.0.100.1
ip http server
!
no cdp run
!
line con 0
exec-timeout 0 0
line 1 3
no exec
transport input all
flowcontrol software
line vty 0 1
exec-timeout 0 0
password lab
login
line vty 2 4
exec-timeout 0 0
password lab
login
no exec
flowcontrol software
!
end
```

7606

```
7606-2#show run
Building configuration...
Current configuration : 7375 bytes
!
version 12.1
service timestamps debug uptime
service timestamps log uptime
no service password-encryption
!
hostname 7606-2
!
boot system flash slot0:
enable password lab
```



```
!  
!--- Configures the VLANs allowed over the trunk to the  
SSL services module. !--- The admin VLAN is included.  
The SSL module is located in slot 3.  
ssl-proxy module 3 allowed-vlan 4,15  
ip subnet-zero  
!  
no ip domain-lookup  
ip host mat 223.255.254.228  
ip host defib 223.255.254.242  
!  
mls flow ip destination  
mls flow ipx destination  
!  
spanning-tree extend system-id  
no spanning-tree vlan 2,10  
!--- The CSM is located in slot 5. The module running  
as Active.  
module ContentSwitchingModule 5  
  vlan 3 client  
    ip address 12.0.0.24 255.0.0.0  
    gateway 12.0.0.100  
  !  
  vlan 4 server  
    ip address 12.0.0.24 255.0.0.0  
  !  
  vlan 5 server  
    ip address 20.0.0.24 255.0.0.0  
    alias 20.0.0.100 255.0.0.0  
  !  
  probe ICMP icmp  
    interval 5  
    failed 10  
  !  
!--- These are the server farm HTTP and real server  
members. serverfarm HTTP  
  nat server  
  no nat client  
  real 20.0.0.7  
    inservice  
  real 20.0.0.8  
    inservice  
  real 20.0.0.9  
    inservice  
  real 20.0.0.10  
    inservice  
  real 20.0.0.11  
    inservice  
  real 20.0.0.12  
    inservice  
  !  
!--- These are the server farm HTTPS and real server  
members. serverfarm HTTPS  
  no nat server  
  no nat client  
  real 12.0.0.50  
    inservice  
  real 12.0.0.51  
    inservice  
  probe ICMP  
  !  
  sticky 1 ssl timeout 5  
  sticky 2 netmask 255.0.0.0 timeout 5  
  !
```

```

!--- Virtual server HTTP.
vserver HTTP
  !--- The virtual server IP address is specified with
  TCP port www.
  virtual 12.0.0.124 tcp www
!--- This is the VLAN from where the CSM accepts traffic
for a specified !--- virtual server.
  vlan 4
  !--- This is the destination server farm.
  serverfarm HTTP
  sticky 5 group 2
  !--- Enables connection redundancy. !--- Replicates
the sticky database to the backup CSM.
  replicate csrp sticky
  !--- Replicates connections to the backup CSM.
  replicate csrp connection
  persistent rebalance
  inservice
!
!--- This is the virtual server HTTPS.
vserver HTTPS
  !--- The virtual server IP address is specified with
  TCP port HTTP over SSL.
  virtual 12.0.0.123 tcp https
  !--- This is the VLAN from where the CSM accepts
  traffic for a specified !--- virtual server.
  vlan 3
  !--- Destination server farm.
  serverfarm HTTPS
  !--- The CSM load balances an incoming SSL connection
  to the SSL !--- termination engine that generated that
  SSL ID.
  ssl-sticky offset 20 length 6
  sticky 5 group 1
  !--- Enables connection redundancy. !--- Replicates
the sticky database to the backup CSM.
  replicate csrp sticky
  !--- Replicates connections to the backup CSM.
  replicate csrp connection
  no persistent rebalance
  inservice
!
ft group 1 vlan 2
!
redundancy
  mode rpr-plus
  main-cpu
  auto-sync running-config
  auto-sync standard
!
interface Loopback0
  ip address 192.10.10.3 255.255.255.0
!
interface GigabitEthernet1/1
  no ip address
  switchport
  switchport trunk encapsulation dot1q
  switchport trunk allowed vlan 1-5,1002-1005
  switchport mode trunk
  no cdp enable
!
interface GigabitEthernet1/2
  no ip address
  shutdown

```

```
no cdp enable
!
interface FastEthernet2/1
no ip address
switchport
switchport access vlan 5
switchport mode access
no cdp enable
!
interface FastEthernet2/2
no ip address
switchport
switchport access vlan 5
switchport mode access
no cdp enable
!
interface FastEthernet2/3
no ip address
switchport
switchport access vlan 5
switchport mode access
no cdp enable
!
interface FastEthernet2/13
ip address 11.0.0.6 255.0.0.0
no ip redirects
no cdp enable
standby 2 ip 11.0.0.100
standby 2 preempt
standby 2 name Client-Side
!
interface FastEthernet2/48
no ip address
switchport
switchport access vlan 15
switchport mode access
no cdp enable
!
interface Vlan1
no ip address
shutdown
!
interface Vlan3
ip address 12.0.0.2 255.0.0.0
no ip redirects
standby 1 ip 12.0.0.100
standby 1 preempt
standby 1 name CSM-Side
standby 1 track FastEthernet2/13
!
interface Vlan15
ip address 15.0.1.2 255.0.0.0
!
ip classless
ip route 10.0.0.0 255.0.0.0 11.0.0.1
no ip http server
!
no cdp run
!
alias exec sc show module csm 5
!
line con 0
exec-timeout 0 0
line vty 0 4
```

```
password lab
login
transport input lat pad mop telnet rlogin udptn nasi
!
end
```

STE-2

```
ssl-proxy-3#show run br
Building configuration...
Current configuration : 1216 bytes
!
version 12.2
no service pad
service timestamps debug datetime msec
service timestamps log datetime msec
no service password-encryption
!
hostname ssl-proxy-3
!
enable password lab
!
ip subnet-zero
ip tftp source-interface Ethernet0/0.15
no ip domain lookup
ip host defib 223.255.254.242
ip host mat 223.255.254.228
!
!
!  
!--- Adds a proxy service HTTPS that identifies a virtual IP address !--- and a server IP address for each proxy.
ssl-proxy service https
  virtual ipaddr 12.0.0.123 protocol tcp port 443
secondary
  server ipaddr 12.0.0.124 protocol tcp port 80
  certificate rsa general-purpose trustpoint TP-2048-pkcs12
inservice
!--- Configures this VLAN as administrative.
ssl-proxy vlan 15
  ipaddr 15.0.10.5 255.0.0.0
  gateway 15.0.100.1
  admin
!--- Adds an interface to VLAN 4 on the SSL services module.
ssl-proxy vlan 4
  ipaddr 12.0.0.51 255.0.0.0
  gateway 12.0.0.100
ssl-proxy mac address 0001.6446.a1c0
!
!--- Declares the trustpoint that the module is to use.
crypto ca trustpoint TP-2048-pkcs12
  !--- Specifies key pair to associate with the certificate.
  rsakeypair TP-2048-pkcs12
  !--- Specifies the certificate and key to be associated.
  crypto ca certificate chain TP-2048-pkcs12
    certificate 3C2DF2E50001000000DC
    certificate ca 313AD6510D25ABAE4626E96305511AC4
!
!
```

```
!  
!  
ip classless  
ip route 0.0.0.0 0.0.0.0 15.0.100.1  
ip http server  
!  
!  
no cdp run  
!  
line con 0  
  exec-timeout 0 0  
line 1 3  
  no exec  
  transport input all  
  flowcontrol software  
line vty 0 1  
  exec-timeout 0 0  
  password lab  
  login  
line vty 2 4  
  exec-timeout 0 0  
  password lab  
  login  
  no exec  
  flowcontrol software  
!  
end
```

Проверка

Используйте эту информацию для проверки конфигурации:

```
Router# sh module contentSwitchingModule all vservers
```

- **покажите сервер/клиента сервиса ssl-proxy** — Эта команда показывает, как отобразить статус сервиса proxy SSL - сервера.
- **покажите mod** — Эта команда показывает статус VLAN между сервисным модулем SSL и Supervisor Engine.
- **покажите stats hdr ssl-proxy** — Эта команда показывает, как отобразить данные вставки заголовка.
- **покажите stats ssl-proxy ssl** — Эта команда показывает, как отобразить статистику SSL.
- **покажите сервис stats ssl-proxy и show standby** — Эти команды показывают, как отобразить статистику, чтобы показать, что распределение нагрузки происходит в двух сервисных модулях SSL.
- **покажите con ssl-proxy** — Эта команда показывает, как отобразить статистику, когда соединения активны.

Устранение неполадок

См. [Testing SSL Proxy Services](#) для советов по устранению проблем.

Дополнительные сведения

- [Аппаратная поддержка модуля коммутации контента](#)

- [Загрузки программного обеспечения модуля коммутации контента только для зарегистрированных пользователей\)](#)
- [Cisco Systems – техническая поддержка и документация](#)