Configuring RIP

- Information About RIP, on page 1
- How to Configure Routing Information Protocol, on page 2
- Configuration Examples for Routing Information Protocol, on page 11
- Feature History for Routing Information Protocol, on page 12

Information About RIP

The Routing Information Protocol (RIP) is an interior gateway protocol (IGP) created for use in small, homogeneous networks. It is a distance-vector routing protocol that uses broadcast User Datagram Protocol (UDP) data packets to exchange routing information. The protocol is documented in RFC 1058. You can find detailed information about RIP in *IP Routing Fundamentals,* published by Cisco Press.

Note RIP is supported in the Network Essentials feature set.

Using RIP, the switch sends routing information updates (advertisements) every 30 seconds. If a router does not receive an update from another router for 180 seconds or more, it marks the routes served by that router as unusable. If there is still no update after 240 seconds, the router removes all routing table entries for the non-updating router.

RIP uses hop counts to rate the value of different routes. The hop count is the number of routers that can be traversed in a route. A directly connected network has a hop count of zero; a network with a hop count of 16 is unreachable. This small range (0 to 15) makes RIP unsuitable for large networks.

If the router has a default network path, RIP advertises a route that links the router to the pseudonetwork 0.0.0.0. The 0.0.0.0 network does not exist; it is treated by RIP as a network to implement the default routing feature. The switch advertises the default network if a default was learned by RIP or if the router has a gateway of last resort and RIP is configured with a default metric. RIP sends updates to the interfaces in specified networks. If an interface's network is not specified, it is not advertised in any RIP update.

RIP for IPv6

Routing Information Protocol (RIP) for IPv6 is a distance-vector protocol that uses hop count as a routing metric. It includes support for IPv6 addresses and prefixes and the all-RIP-routers multicast group address FF02::9 as the destination address for RIP update messages.

For configuring RIP for IPv6, see the *Configuring RIP for IPv6* section.

For more information about RIP for IPv6, see the "Implementing RIP for IPv6" chapter in the *Cisco IOS IPv6 Configuration Library* on Cisco.com.

Summary Addresses and Split Horizon

Routers connected to broadcast-type IP networks and using distance-vector routing protocols normally use the split-horizon mechanism to reduce the possibility of routing loops. Split horizon blocks information about routes from being advertised by a router on any interface from which that information originated. This feature usually optimizes communication among multiple routers, especially when links are broken.

How to Configure Routing Information Protocol

The following sections provide configurational information about RIP.

Default RIP Configuration

Table 1: Default RIP Configuration

Feature	Default Setting
Auto summary	Enabled.
Default-information originate	Disabled.
Default metric	Built-in; automatic metric translations.
IP RIP authentication key-chain	No authentication. Authentication mode: clear text.
IP RIP triggered	Disabled
IP split horizon	Varies with media.
Neighbor	None defined.
Network	None specified.
Offset list	Disabled.
Output delay	0 milliseconds.
Timers basic	• Update: 30 seconds. • Invalid: 180 seconds. • Hold-down: 180 seconds. • Flush: 240 seconds.

Feature	Default Setting
Validate-update-source	Enabled.
Version	Receives RIP Version 1 and 2 packets; sends Version 1 packets.

Configuring Basic RIP Parameters

To configure RIP, you enable RIP routing for a network and optionally configure other parameters. On the switch, RIP configuration commands are ignored until you configure the network number.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Device> enable`	Enables privileged EXEC mode. • Enter your password, if prompted.
Step 2	**configure terminal** **Example:** `Device# configure terminal`	Enters global configuration mode.
Step 3	**ip routing** **Example:** `Device(config)# ip routing`	Enables IP routing. (Required only if IP routing is disabled.)
Step 4	**router rip** **Example:** `Device(config)# router rip`	Enables a RIP routing process, and enter router configuration mode.
Step 5	**network** *network number* **Example:** `Device(config-router)# network 12.0.0.0`	Associates a network with a RIP routing process. You can specify multiple **network** commands. RIP routing updates are sent and received through interfaces only on these networks. **Note** You must configure a network number for the RIP commands to take effect.
Step 6	**neighbor** *ip-address* **Example:**	(Optional) Defines a neighboring router with which to exchange routing information. This step allows routing updates from RIP

	Command or Action	Purpose
	`Device(config-router)# neighbor 10.2.5.1`	(normally a broadcast protocol) to reach nonbroadcast networks.
Step 7	**offset-list** [*access-list number* | *name*] {**in** | **out**} *offset* [*type number*] **Example:** `Device(config-router)# offset-list 103 in 10`	(Optional) Applies an offset list to routing metrics to increase incoming and outgoing metrics to routes learned through RIP. You can limit the offset list with an access list or an interface.
Step 8	**timers basic** *update invalid holddown flush* **Example:** `Device(config-router)# timers basic 45 360 400 300`	(Optional) Adjusts routing protocol timers. Valid ranges for all timers are 0 to 4294967295 seconds. • *update*—The time between sending routing updates. The default is 30 seconds. • *invalid*—The timer after which a route is declared invalid. The default is 180 seconds. • *holddown*—The time before a route is removed from the routing table. The default is 180 seconds. • *flush*—The amount of time for which routing updates are postponed. The default is 240 seconds.
Step 9	**version** {**1** | **2**} **Example:** `Device(config-router)# version 2`	(Optional) Configures the switch to receive and send only RIP Version 1 or RIP Version 2 packets. By default, the switch receives Version 1 and 2 but sends only Version 1. You can also use the interface commands **ip rip** {**send** | **receive**} **version 1** | **2** | **1 2**} to control what versions are used for sending and receiving on interfaces.
Step 10	**no auto summary** **Example:** `Device(config-router)# no auto summary`	(Optional) Disables automatic summarization. By default, the switch summarizes subprefixes when crossing classful network boundaries. Disable summarization (RIP Version 2 only) to advertise subnet and host routing information to classful network boundaries.
Step 11	**output-delay** *delay* **Example:** `Device(config-router)# output-delay 8`	(Optional) Adds interpacket delay for RIP updates sent. By default, packets in a multiple-packet RIP update have no delay added between packets. If you are sending packets to a lower-speed device, you can add

	Command or Action	Purpose
		an interpacket delay in the range of 8 to 50 milliseconds.
Step 12	**end** **Example:** `Device(config-router)# end`	Returns to privileged EXEC mode.
Step 13	**show ip protocols** **Example:** `Device# show ip protocols`	Verifies your entries.
Step 14	**copy running-config startup-config** **Example:** `Device# copy running-config startup-config`	(Optional) Saves your entries in the configuration file.

Configuring RIP Authentication

RIP Version 1 does not support authentication. If you are sending and receiving RIP Version 2 packets, you can enable RIP authentication on an interface. The key chain specifies the set of keys that can be used on the interface. If a key chain is not configured, no authentication is performed, not even the default.

The switch supports two modes of authentication on interfaces for which RIP authentication is enabled: plain text and MD5. The default is plain text.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Device> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Device# configure terminal`	Enters global configuration mode.
Step 3	**interface** *interface-id* **Example:**	Enters interface configuration mode, and specifies the interface to configure.

	Command or Action	Purpose
	`Device(config)# interface gigabitethernet 1/0/1`	
Step 4	**ip rip authentication key-chain** *name-of-chain* **Example:** `Device(config-if)# ip rip authentication key-chain trees`	Enables RIP authentication.
Step 5	**ip rip authentication mode** {**text** | **md5**} **Example:** `Device(config-if)# ip rip authentication mode md5`	Configures the interface to use plain text authentication (the default) or MD5 digest authentication.
Step 6	**end** **Example:** `Device(config)# end`	Returns to privileged EXEC mode.
Step 7	**show running-config** **Example:** `Device# show running-config`	Verifies your entries.
Step 8	**copy running-config startup-config** **Example:** `Device# copy running-config startup-config`	(Optional) Saves your entries in the configuration file.

Configuring RIP for IPv6

For more information about configuring RIP routing for IPv6, see the “Implementing RIP for IPv6” chapter in the *Cisco IOS IPv6 Configuration Library* on Cisco.com,

To configure RIP routing for IPv6, perform this procedure:

Before you begin

Before configuring the switch to run IPv6 RIP, you must enable routing by using the **ip routing** command in global configuration mode, enable the forwarding of IPv6 packets by using the **ipv6 unicast-routing** command in global configuration mode, and enable IPv6 on any Layer 3 interfaces on which IPv6 RIP is to be enabled.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Device> enable`	Enables privileged EXEC mode. Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Device# configure terminal`	Enters global configuration mode.
Step 3	**ipv6 router rip** *name* **Example:** `Device(config)# ipv6 router rip cisco`	Configures an IPv6 RIP routing process, and enters router configuration mode for the process.
Step 4	**maximum-paths** *number-paths* **Example:** `Device(config-router)# maximum-paths 6`	(Optional) Define the maximum number of equal-cost routes that IPv6 RIP can support. The range is from 1 to 32, and the default is 16 routes.
Step 5	**exit** **Example:** `Device(config-router)# exit`	Returns to global configuration mode.
Step 6	**interface** *interface-id* **Example:** `Device(config)# interface gigabitethernet 1/0/1`	Enters interface configuration mode, and specifies the Layer 3 interface to configure.
Step 7	**ipv6 rip** *name* **enable** **Example:** `Device(config-if)# ipv6 rip cisco enable`	Enables the specified IPv6 RIP routing process on the interface.
Step 8	**ipv6 rip** *name* **default-information** {**only** | **originate**} **Example:** `Device(config-if)# ipv6 rip cisco default-information only`	(Optional) Originates the IPv6 default route (::/0) into the RIP routing process updates sent from the specified interface. **Note** To avoid routing loops after the IPv6 default route (::/0) is originated from any interface, the routing process ignores all default routes received on any interface. • **only**—Select to originate the default route, but suppress all other routes in the updates sent on this interface.

	Command or Action	Purpose
		• **originate**—Select to originate the default route in addition to all other routes in the updates sent on this interface.
Step 9	**end** **Example:** `Device(config)# end`	Returns to privileged EXEC mode.

Step 10	Use one of the following:
	• **show ipv6 rip** [*name*] [**interface** *interface-id*] [**database**] [**next-hops**]
	• **show ipv6 rip**
	Example:
	`Device# show ipv6 rip cisco interface gigabitethernet 2/0/1`
	or
	`Device# show ipv6 rip`
		• Displays information about current IPv6 RIP processes.
		• Displays the current contents of the IPv6 routing table.

Step 11	**copy running-config startup-config** **Example:** `Device# copy running-config startup-config`	(Optional) Saves your entries in the configuration file.

Configuring Summary Addresses and Split Horizon

Note In general, disabling split horizon is not recommended unless you are certain that your application requires it to properly advertise routes.

If you want to configure an interface running RIP to advertise a summarized local IP address pool on a network access server for dial-up clients, use the **ip summary-address rip** interface configuration command.

Note If split horizon is enabled, neither autosummary nor interface IP summary addresses are advertised.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:**	Enables privileged EXEC mode. • Enter your password if prompted.

	Command or Action	Purpose
	`Device> enable`	
Step 2	**configure terminal** **Example:** `Device# configure terminal`	Enters global configuration mode.
Step 3	**interface** *interface-id* **Example:** `Device(config)# interface gigabitethernet 1/0/1`	Enters interface configuration mode, and specifies the Layer 3 interface to configure.
Step 4	**ip address** *ip-address subnet-mask* **Example:** `Device(config-if)# ip address 10.1.1.10 255.255.255.0`	Configures the IP address and IP subnet.
Step 5	**ip summary-address rip ip address** *ip-network mask* **Example:** `Device(config-if)# ip summary-address rip ip address 10.1.1.30 255.255.255.0`	Configures the IP address to be summarized and the IP network mask.
Step 6	**no ip split horizon** **Example:** `Device(config-if)# no ip split horizon`	Disables split horizon on the interface.
Step 7	**end** **Example:** `Device(config)# end`	Returns to privileged EXEC mode.
Step 8	**show ip interface** *interface-id* **Example:** `Device# show ip interface gigabitethernet 1/0/1`	Verifies your entries.
Step 9	**copy running-config startup-config** **Example:**	(Optional) Saves your entries in the configuration file.

	Command or Action	Purpose
	`Device# copy running-config startup-config`	

Configuring Split Horizon

Routers connected to broadcast-type IP networks and using distance-vector routing protocols normally use the split-horizon mechanism to reduce the possibility of routing loops. Split horizon blocks information about routes from being advertised by a router on any interface from which that information originated. This feature can optimize communication among multiple routers, especially when links are broken.

Note In general, we do not recommend disabling split horizon unless you are certain that your application requires it to properly advertise routes.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Device> enable`	Enables privileged EXEC mode. Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Device# configure terminal`	Enters global configuration mode.
Step 3	**interface** *interface-id* **Example:** `Device(config)# interface gigabitethernet 1/0/1`	Enters interface configuration mode, and specifies the interface to configure.
Step 4	**ip address** *ip-address subnet-mask* **Example:** `Device(config-if)# ip address 10.1.1.10 255.255.255.0`	Configures the IP address and IP subnet.
Step 5	**no ip split-horizon** **Example:**	Disables split horizon on the interface.

	Command or Action	Purpose
	`Device(config-if)# no ip split-horizon`	
Step 6	**end** **Example:** `Device(config)# end`	Returns to privileged EXEC mode.
Step 7	**show ip interface** *interface-id* **Example:** `Device# show ip interface gigabitethernet 1/0/1`	Verifies your entries.
Step 8	**copy running-config startup-config** **Example:** `Device# copy running-config startup-config`	(Optional) Saves your entries in the configuration file.

Configuration Examples for Routing Information Protocol

The following sections provide configuration examples for RIP.

Configuration Example for Summary Addresses and Split Horizon

In this example, the major net is 10.0.0.0. The summary address 10.2.0.0 overrides the autosummary address of 10.0.0.0 so that 10.2.0.0 is advertised out interface Gigabit Ethernet port 2, and 10.0.0.0 is not advertised. In the example, if the interface is still in Layer 2 mode (the default), you must enter a **no switchport** interface configuration command before entering the **ip address** interface configuration command.

Note If split horizon is enabled, neither autosummary nor interface summary addresses (those configured with the **ip summary-address rip** router configuration command) are advertised.

```
Device(config)# router rip
Device(config-router)# interface gigabitethernet1/0/2
Device(config-if)# ip address 10.1.5.1 255.255.255.0
Device(config-if)# ip summary-address rip 10.2.0.0 255.255.0.0
Device(config-if)# no ip split-horizon
Device(config-if)# exit
Device(config)# router rip
Device(config-router)# network 10.0.0.0
Device(config-router)# neighbor 2.2.2.2 peer-group mygroup
Device(config-router)# end
```

Example: Configuring RIP for IPv6

This example shows how to enable the RIP routing process *cisco* with a maximum of eight equal-cost routes and to enable it on an interface:

```
Device> enable
Devce# configure terminal
Device(config)# ipv6 router rip cisco
Device(config-router)# maximum-paths 8
Device(config)# exit
Device(config)# interface gigabitethernet2/0/11
Device(config-if)# ipv6 rip cisco enable
```

Feature History for Routing Information Protocol

This table provides release and related information for the features explained in this module.

These features are available in all the releases subsequent to the one they were introduced in, unless noted otherwise.

Release	Feature	Feature Information
Cisco IOS XE Everest 16.6.1	Routing Information Protocol	The Routing Information Protocol is an interior gateway protocol (IGP) created for use in small and homogeneous networks.
Cisco IOS XE Cupertino 17.7.1	Routing Information Protocol	This feature was implemented on the supervisor modules C9400X-SUP-2 and C9400X-SUP-2XL.

Use the Cisco Feature Navigator to find information about platform and software image support. To access Cisco Feature Navigator, go to https://cfnng.cisco.com/.