A

AC power 6
AC-input power supplies
  connection guidelines 3
audience
  description iii

B

bracket
  re-install 8
brackets
  front rack mount, installation 7

C

cabinet 4
cabinet installation guidelines 2
cabinets
  requirements 1
  See also racks
  space requirements 1
Cables and connectors 3
cabling 2
  console port 2
  MGMT 10/100/1000 Ethernet port 3
  requirements 2
  SFP transceivers 7, 8
chassis 4
  installing guidelines 4
  unpacking 2
chassis (MDS 9513 Director)
  serial number location 2
Command-Line Interface vii
connecting
  console port 2
  Fibre Channel ports 3
connector 3
console port 2
  cabling 2
  connecting 2
  pinouts 2
contact and site information 6
customer service, contacting 1

D

DC power 6

E

electrostatic discharge 11
environmental specifications 1
ESD 14
Ethernet port 3

F

fan modules
  removing and installing 18
FCoE ports 1
fiber optic cables, maintaining 9
Fibre Channel ports 1
  connecting 3
  connecting with LC-type cables (figure) 8

G

grounding
  attaching the ESD wrist strap 12

establishing the system ground 13
required tools and equipment 14
grounding lug kit 3

I

installing
equipment required 3
guidelines 4
rack mount brackets 5
rack-mounting guidelines 2
SFP transceiver cables 8
SFP transceivers (note) 5
installing SFP transceivers 7

L

LC-type cables
connecting to Fibre Channel ports 8
figure 8
LEDs 3

M

maintaining
fiber optic cables 9
SFP transceivers 9
maintenance records 1
MGMT 10/100/1000 Ethernet port 3
cabling 3
pinouts 3
MGMT 10/100/1000 port 3

N

NEBS 12
network connections, preparing 2

O

open racks 1
open racks, standard (requirements) 2
organization
description iii

P

physical specifications (table) 2
pinouts 2
console port 2
MGMT 10/100/1000 Ethernet port 3
plugs supported for power supplies 4
power cords, length 4
power supplies
circuits 4
starting up the switch 14
supported plugs 4
voltage specifications 3
See also AC-input power supplies
power supplies (Cisco MDS 9509 Director)
specifications 2
powering up the switch 15
pre-installation
guidelines 2
rack mount brackets 3

R

rack-mount installation options 2
racks
EIA installing 4
open, requirements 2
required equipment 3
requirements 1
See also cabinets.
space requirements 1
records 1
chassis and module information 7
contact and site information 6
site planning and maintenance 1
removing

SFP transceiver cables 7
SFP transceivers 5
required tools and equipment 14

S

SFP and SFP+ transceivers
specifications 4
SFP transceivers
cabling 7, 8
description 7, 4
Fibre Channel 7
Fibre Channel specifications 3, 4
Fibre Channel supported 3, 4
installing 7
latches supported 4
removing 5
SFP+ transceivers
description 4
shelf brackets 6
site planning preparation checklist 2
specifications
cables 1
environmental 1
pinouts 1
power, MDS 9509 Director 2
SFP and SFP+ transceivers 4
Supervisor-2
Ethernet port 3
supported power cords and plugs 4
system grounding 11

T

technical specifications
voltage 3
transceivers 7
description 7
supported SFP transceivers 7
supported X2 transceiver 7
troubleshooting 1
contacting customer service 1

U

unpacking 2

V

voltage
specifications (table) 3