Configuration of LAN and Remote Management Web Access on the RV130 and RV130W

For a video showing how to configure LAN and remote management, visit https://youtu.be/9R0Rd5bS1W8

Objective

Clients that are connected to the LAN or WAN interface of the router can access the router's web configuration utility. Configuration of LAN/VPN Web Access can allow clients on the Local Area Network to connect to the router securely via Secure Socket Layer. Configuration of Remote Management Web Access can allow clients from outside the corporate network to connect to the router via its IP Address. Remote Management Web Access may be useful if an administrator wants to access or configure the router from a remote location.

The objective of this document is to show you how to configure the LAN and Remote Management Web Access on the RV130 and RV130W routers.

Applicable Devices

- RV130
- RV130W

Software Version

• v1.0.1.3

LAN/VPN and Remote Management Web Access Configuration

Step 1. Log in to the web configuration utility and choose **Firewall > Basic Settings**. The *Basic Settings* page opens:

Basic Settings	
IP Address Spoofing Protection:	Enable
DoS Protection:	Enable
Block WAN Ping Request:	Enable
LAN/VPN Web Access:	
Remote Management:	Enable
Remote Access:	○ HTTP
Remote Upgrade:	Enable
Allowed Remote IP Address:	Any IP Address
	0.0.0.0-0
Remote Management Port	443 (Range: 1 - 65535, Default: 443)
IPv4 Multicast Passthrough:(IGMP Proxy)	🗹 Enable
IPv4 Multicast Immediate Leave:(IGMP Proxy Immediate Leave)	Enable
SIP ALG	Enable
UPnP	🖉 Enable
Allow Users to Configure	🗹 Enable
Allow Users to Disable Internet Access	Enable
Block Java:	🔲 🖲 Auto 🔿 Manual Port:
Block Cookies:	🔲 🖲 Auto 🔘 Manual Port:
Block ActiveX:	🔲 🖲 Auto 🔿 Manual Port:
Block Proxy:	🔲 🖲 Auto 🔿 Manual Port:
Save Cancel	

Step 2. In the *LAN/VPN Web Access* field, check the check boxes corresponding to the desired type(s) of Web Access protocols. The protocols are used to connect to the device from members of the LAN interface.

LAN/VPN Web Access:	
Remote Management:	Enable
Remote Access:	○ HTTP [®] HTTPS
Remote Upgrade:	Enable
Allowed Remote IP Address:	Any IP Address
	0.0.0.0-0
Remote Management Port	443 (Range: 1 - 65535, Default: 443)

The available options are defined as follows:

• HTTP — Clients can connect to internal web sites via the standard Hypertext Transfer Protocol (HTTP). HTML elements from your websites are sent directly to the client device. Connecting to web sites via HTTP is faster than HTTPS.

• HTTPS — Using the HyperText Transfer Protocol Secure (HTTPS), clients can connect to internal websites only when the digital certificates installed on the web site is authenticated with the web server associated with it. This prevents any man-in-the-middle attacks between the client and the web site. Checking this option also provides bidirectional encryption between the client and the web site.

Note: Check only the **HTTP** check box if web pages on your domain do not have the required SSL Certificates installed. Check only the **HTTPS** check box if all of the web pages on your domain have the SSL Certificates installed. You can check both check boxes for HTTP and HTTPS if you want versatility in how your clients access the router.

Step 3. In the *Remote Management* field, check the **Enable** check box to enable administrators remote access to the device web configuration utility. By default, Remote Management is disabled. If unchecked, skip to Step 8.

Note: When Remote Management is enabled, the router can be accessed by anyone who knows its IP address. It is important to change the default password of the device before enabling this feature.

Step 4. In the *Remote Access* field, select a desired radio button corresponding to the type of Remote Access protocol. The protocol will be used to connect devices from a remote Wide Area Network (WAN) directly to the router. HTTPS is more secure than HTTP and is the recommended option.

LAN/VPN Web Access:	ITTP HTTPS
Remote Management:	Enable
Remote Access:	© HTTP
Remote Upgrade:	Enable
Allowed Remote IP Address:	Any IP Address
	◎ 0 . 0 . 0 . 0 - 0
Remote Management Port	443 (Range: 1 - 65535, Default: 443)

The available options are defined as follows.

• HTTP — Clients can connect to internal web sites via the standard Hypertext Transfer Protocol (HTTP). HTML elements from your websites are sent directly to the client device. Connecting to web sites via HTTP is faster than HTTPS.

• HTTPS — Using the HyperText Transfer Protocol Secure (HTTPS), clients can connect to internal websites only when the digital certificates installed on the web site is authenticated with the web server associated with it. This prevents any man-in-the-middle attacks between the client and the web site. Checking this option also provides bidirectional encryption between the client and the web site.

Step 5. In the *Remote Upgrade* field, check the **Enable** check box to allow administrators to upgrade the device from a remote WAN.

LAN/VPN Web Access:	ITTP HTTPS
Remote Management:	Enable
Remote Access:	O HTTP O HTTPS
Remote Upgrade:	🗹 Enable
Allowed Remote IP Address:	Any IP Address
	◎ 0 . 0 . 0 . 0 - 0
Remote Management Port	443 (Range: 1 - 65535, Default: 443)

Step 6. In the *Allowed Remote IP Address* field, choose which IP addresses will have remote access to the device. Click the **Any IP Address** radio button to allow any remote device to connect, or click the radio button below it to manually enter a range of allowed IP addresses.

LAN/VPN Web Access:	ITTP HTTPS
Remote Management:	Enable
Remote Access:	© HTTP [●] HTTPS
Remote Upgrade:	Enable
Allowed Remote IP Address:	Any IP Address
	◎ 0 . 0 . 0 . 0 - 0
Remote Management Port	443 (Range: 1 - 65535, Default: 443)

Step 7. Enter the port on which remote access is allowed. The default port is 443.

LAN/VPN Web Access:	ITTP HTTPS
Remote Management:	Enable
Remote Access:	© HTTP
Remote Upgrade:	Enable
Allowed Remote IP Address:	O Any IP Address
	192 . 168 . 1 . 75 - 100
Remote Management Port	443 (Range: 1 - 65535, Default: 443)

Note: When remotely accessing the router, you must enter the remote management port as part of the IP address. For example: https://<remote-ip>:<remote-port>, or https://168.10.1.11:443.

Step 8. Click **Save** to save your settings.

LAN/VPN Web Access:	
Remote Management:	Ø Enable
Remote Access:	O HTTP @ HTTPS
Remote Upgrade:	I Enable
Allowed Remote IP Address:	O Any IP Address
	192 . 169 . 1 . 75 - 100 10
Remote Management Port	443 (Range: 1 - 65535, Default: 443)
IPv4 Multicast Passthrough:(IGMP Proxy)	I Enable
IPv4 Multicast Immediate Leave:(IGMP Proxy Immediate Leave)	Enable
SIP ALG	Enable
UPnP	✓ Enable
Allow Users to Configure	C Enable
Allow Users to Disable Internet Access	Enable
Block Java:	C @ Auto C Manual Port
Block Cookies:	🕼 🐵 Auto 🖱 Manual Port
Block ActiveX:	🗐 🐵 Auto 🖱 Manual Port
Block Proxy:	🗐 🐵 Auto 🖱 Manual Port
Save Cancel	