

Removing the Configuration on a Cisco ESR 10000 Line Card Once the Card Is Physically Removed from the Chassis

Document ID: 12780

Introduction

Prerequisites

Requirements

Components Used

Related Products

How to Remove the Configuration

Related Information

Introduction

When a line card is removed from a Cisco Edge Services Router (ESR) 10000 chassis, the line card configuration does not go away. This document explains how to remove the configuration for an ESR line card once that line card is physically removed from the chassis.

Prerequisites

Requirements

There are no specific requirements for this document.

Components Used

The information in this document is based on these software and hardware versions:

- ESR 10008 with the one-port OC12 ATM line card that runs Cisco IOS® Software Version 12.2(15)BZ

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure that you understand the potential impact of any command.

Related Products

The instructions in this document work for any line card in the ESR 10000. Cisco IOS Software Release 12.0(17)ST or later releases must be running on the Cisco 10000 series ESR. Here are some more listings and how they show up in the configuration:

- 1oc12pos-1: 1 port OC12 POS
- 1choc12-1: 1 port channelized OC12
- 6cht3-1: 6 port channelized DS3
- 1gigethernet-1: 1 port Gigabit Ethernet

How to Remove the Configuration

The ESR 10000 differs from other Cisco routers because when a line card is removed from the chassis, the configuration is still present after a **show run** command. You can see whether or not the line card is still in the chassis using some common **show** commands such as **show interfaces** and **show diag**.

Below is the output of a **show interfaces** command for an ATM line card when it is removed from the chassis. As you can see, it states that "Hardware is not present."

```
10008-1a# show interfaces atm5/0/0

ATM5/0/0 is down, line protocol is down

Hardware is not present

Hardware is OC12 ATM 1 Port, address is 0001.6380.c03c (bia 0000.0000.0000)

MTU 4470 bytes, sub MTU 4470, BW 622000 Kbit, DLY 80 usec, rely 255/255,

load 1/255

Encapsulation ATM, loopback not set

Encapsulation(s): AAL5, PVC mode

2000 maximum active VCs, 0 current VCCs

Last input never, output never, output hang never

Last clearing of "show interface" counters never

Input queue: 0/27230/0/0 (size/max/drops/flushes); Total output drops: 0

Queueing strategy: fifo

Output queue: 0/16384 (size/max)

5 minute input rate 0 bits/sec, 0 packets/sec

5 minute output rate 0 bits/sec, 0 packets/sec

0 packets input, 0 bytes, 0 no buffer

Received 0 broadcasts, 0 runts, 0 giants, 0 throttles

0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort

0 packets output, 0 bytes, 0 underruns

0 output errors, 0 collisions, 1 interface resets

0 output buffer failures, 0 output buffers swapped out
```

On the other hand, a **show diag** command for the same slot does not return any information, meaning that the line card is probably removed from the chassis.

```
10008-1a# show diag 5/0
10008-1a#
```

While the line card is physically removed from the chassis, the configuration can be modified like any other interface. The interface does not go into an up/up state.

To remove the configuration from the router for a line card that has been removed from the chassis, go into configuration mode and remove the **card** command. Every card in the chassis is identified by this **card** command. Once a **no card** command is issued, the configuration is removed. For the example above, go into configuration mode and type:

```
10008-1a(config)# no card 5/0 1oc12atm-1
```

In the above command, **5/0** refers to the slot/subslot and **1oc12atm-1** refers to the OC-12 ATM line card that has been removed. See the relevant Command Reference for details on the command usage.

This removes the line card interface from the configuration. A message appears telling the user that the card is physically removed from the chassis. Here is the message when the **no card 5/0 1oc12atm-1** command is run with the line card already physically removed:

```
%C10K-3-DEACTIVATED: card in slot [5/0] disabled
```

Related Information

- [Cisco 10000 Series Router – Support Page](#)
- [Technical Support & Documentation – Cisco Systems](#)

[Contacts & Feedback](#) | [Help](#) | [Site Map](#)

© 2009 – 2010 Cisco Systems, Inc. All rights reserved. [Terms & Conditions](#) | [Privacy Statement](#) | [Cookie Policy](#) | [Trademarks of Cisco Systems, Inc.](#)

Updated: Jul 07, 2005

Document ID: 12780
