

# Telnet, Console and AUX Port Passwords on Cisco Routers Configuration Example

Document ID: 45843

---

## **Introduction**

### **Prerequisites**

Requirements

Components Used

Conventions

### **Background Information**

#### **Configure Passwords on the Line**

Configuration Procedure

Verify the Configuration

Troubleshoot Login Failure

#### **Configure Local User-Specific Passwords**

Configuration Procedure

Verify the Configuration

Troubleshoot User-specific Password Failure

#### **Configure AAA Authentication for Login**

Configuration Procedure

Verify the Configuration

Troubleshoot AAA Login Failure

### **Related Information**

---

## **Introduction**

This document provides sample configurations for configuring password protection for inbound EXEC connections to the router.

## **Prerequisites**

### **Requirements**

In order to perform the tasks described in this document, you must have privileged EXEC access to the router's command line interface (CLI). For information on using the command line and for understanding command modes, see *Using Cisco IOS Software*.

For instructions on connecting a console to your router, refer to the documentation that accompanied your router, or refer to the online documentation for your equipment.

### **Components Used**

The information in this document is based on these software and hardware versions:

- Cisco 2509 router
- Cisco IOS® Software Version 12.2(19)

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure

that you understand the potential impact of any command.

## Conventions

For more information on document conventions, refer to the Cisco Technical Tips Conventions.

## Background Information

The use of password protection to control or restrict access to the command line interface (CLI) of your router is one of the fundamental elements of an overall security plan.

Protecting the router from unauthorized remote access, typically Telnet, is the most common security that needs configuring, but protecting the router from unauthorized local access cannot be overlooked.

**Note:** Password protection is just one of the many steps you should use in an effective in-depth network security regimen. Firewalls, access-lists, and control of physical access to the equipment are other elements that must be considered when implementing your security plan.

Command line, or EXEC, access to a router can be made in a number of ways, but in all cases the inbound connection to the router is made on a TTY line. There are four main types of TTY lines, as seen in this sample **show line** output:

```
2509#show line
  Tty Typ      Tx/Rx    A Modem  Roty AccO AccI   Uses   Noise  Overruns  Int
*   0 CTY                - -      - - -    0      0      0/0     -
    1 TTY    9600/9600 - -      - - -    0      0      0/0     -
    2 TTY    9600/9600 - -      - - -    0      0      0/0     -
    3 TTY    9600/9600 - -      - - -    0      0      0/0     -
    4 TTY    9600/9600 - -      - - -    0      0      0/0     -
    5 TTY    9600/9600 - -      - - -    0      0      0/0     -
    6 TTY    9600/9600 - -      - - -    0      0      0/0     -
    7 TTY    9600/9600 - -      - - -    0      0      0/0     -
    8 TTY    9600/9600 - -      - - -    0      0      0/0     -
    9 AUX    9600/9600 - -      - - -    0      0      0/0     -
   10 VTY                - -      - - -    0      0      0/0     -
   11 VTY                - -      - - -    0      0      0/0     -
   12 VTY                - -      - - -    0      0      0/0     -
   13 VTY                - -      - - -    0      0      0/0     -
   14 VTY                - -      - - -    0      0      0/0     -

2509#
```

The **CTY** line-type is the Console Port. On any router, it appears in the router configuration as **line con 0** and in the output of the **show line** command as **cty**. The console port is mainly used for local system access using a console terminal.

The **TTY** lines are asynchronous lines used for inbound or outbound modem and terminal connections and can be seen in a router or access server configuration as **line x**. The specific line numbers are a function of the hardware built into or installed on the router or access server.

The **AUX** line is the Auxiliary port, seen in the configuration as **line aux 0**.

The **VTY** lines are the Virtual Terminal lines of the router, used solely to control inbound Telnet connections. They are virtual, in the sense that they are a function of software – there is no hardware associated with them. They appear in the configuration as **line vty 0 4**.

Each of these types of lines can be configured with password protection. Lines can be configured to use one password for all users, or for user-specific passwords. User-specific passwords can be configured locally on the router, or you can use an authentication server to provide authentication.

There is no prohibition against configuring different lines with different types of password protection. It is, in fact, common to see routers with a single password for the console and user-specific passwords for other inbound connections.

Below is an example of router output from the **show running-config** command:

```
2509#show running-config
Building configuration...

Current configuration : 655 bytes
!
version 12.2
.
.
.

!--- Configuration edited for brevity

line con 0
line 1 8
line aux 0
line vty 0 4
!
end
```

## Configure Passwords on the Line

To specify a password on a line, use the **password** command in line configuration mode. To enable password checking at login, use the **login** command in line configuration mode.

**Note:** To find additional information on the commands used in this document, use the Command Lookup Tool (registered customers only) .

## Configuration Procedure

In this example, a password is configured for all users attempting to use the console.

1. From the privileged EXEC (or "enable") prompt, enter configuration mode and then switch to line configuration mode using the following commands. Notice that the prompt changes to reflect the current mode.

```
router#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
router(config)#line con 0
router(config-line)#
```

2. Configure the password, and enable password checking at login.

```
router(config-line)#password letmein
router(config-line)#login
```

3. Exit configuration mode.

```
router(config-line)#end
router#
```

```
%SYS-5-CONFIG_I: Configured from console by console
```

**Note:** Do not save configuration changes to **line con 0** until your ability to log in has been verified.

**Note:** Under the line console configuration, **login** is a required configuration command to enable password checking at login. Console authentication requires both the **password** and the **login** commands to work.

## Verify the Configuration

Examine the configuration of the router to verify that the commands have been properly entered:

Certain **show** commands are supported by the Output Interpreter Tool ( registered customers only) , which allows you to view an analysis of **show** command output.

- **show running-config** – displays the current configuration of the router.

```
router#show running-config
Building configuration...
...

!--- Lines omitted for brevity

!
line con 0
password letmein
login
line 1 8
line aux 0
line vty 0 4
!
end
```

To test the configuration, log off the console and log in again, using the configured password to access the router:

```
router#exit

router con0 is now available

Press RETURN to get started.

User Access Verification
Password:

!--- Password entered here is not displayed by the router

router>
```

**Note:** Before performing this test, ensure that you have an alternate connection into the router, such as Telnet or dial-in, in case there is a problem logging back into the router.

## Troubleshoot Login Failure

If you cannot log back into the router and you have not saved the configuration, reloading the router will eliminate any configuration changes you have made.

If the configuration changes were saved and you cannot login to the router, you will have to perform a password recovery. See Password Recovery Procedures to find instructions for your particular platform.

## Configure Local User–Specific Passwords

To establish a username–based authentication system, use the **username** command in global configuration mode. To enable password checking at login, use the **login local** command in line configuration mode.

### Configuration Procedure

In this example, passwords are configured for users attempting to connect to the router on the VTY lines using Telnet.

1. From the privileged EXEC (or "enable") prompt, enter configuration mode and enter username/password combinations, one for each user for whom you want to allow access to the router:

```
router#configure terminal
      Enter configuration commands, one per line.  End with CNTL/Z.
router(username)# russ password montecito
router(username)# cindy password belgium
router(username)# mike password rottweiler
```

2. Switch to line configuration mode, using the following commands. Notice that the prompt changes to reflect the current mode.

```
router(config)#line vty 0 4
router(config-line)#
```

3. Configure password checking at login.

```
router(config-line)#login local
```

4. Exit configuration mode.

```
router(config-line)#end
router#
%SYS-5-CONFIG_I: Configured from console by console
```

### Verify the Configuration

Examine the configuration of the router to verify that the commands have been properly entered:

- **show running-config** – displays the current configuration of the router.

```
router#show running-config
Building configuration...
!
!--- Lines omitted for brevity

!
username russ password 0 montecito
username cindy password 0 belgium
username mike password 0 rottweiler
!
!--- Lines omitted for brevity
```

```
!  
line con 0  
line 1 8  
line aux 0  
line vty 0 4  
  login local  
!  
end
```

To test this configuration, a Telnet connection must be made to the router. This can be done by connecting from a different host on the network, but you can also test from the router itself by telnetting to the IP address of any interface on the router that is in an up/up state as seen in the output of the **show interfaces** command.

Here is a sample output if the address of **interface ethernet 0** were 10.1.1.1:

```
router#telnet 10.1.1.1  
Trying 10.1.1.1 ... Open  
  
User Access Verification  
  
Username: mike  
Password:  
  
!--- Password entered here is not displayed by the router  
  
router
```

## Troubleshoot User-specific Password Failure

Usernames and passwords are case-sensitive. Users attempting to log in with an incorrectly cased username or password will be rejected.

If users are unable to log into the router with their specific passwords, reconfigure the username and password on the router.

## Configure AAA Authentication for Login

To enable authentication, authorization, and accounting (AAA) authentication for logins, use the **login authentication** command in line configuration mode. AAA services must also be configured.

### Configuration Procedure

In this example, the router is configured to retrieve users' passwords from a TACACS+ server when users attempt to connect to the router.

**Note:** Configuring the router to use other types of AAA servers (RADIUS, for example) is similar. See *Configuring Authentication* for additional information.

**Note:** This document does not address configuration of the AAA server itself. Refer to *Security Server Protocols* for information on configuring the AAA server.

1. From the privileged EXEC (or "enable") prompt, enter configuration mode and enter the commands to configure the router to use AAA services for authentication:

```
config# terminal
Enter configuration commands, one per line. End with CNTL/Z.
router(config)#aaa new-model
router(config)#aaa authentication login my-auth-list tacacs+
router(config)#tacacs-server host 192.168.1.101
router(config)#tacacs-server key letmein
```

2. Switch to line configuration mode using the following commands. Notice that the prompt changes to reflect the current mode.

```
router(config)#line 1 8
router(config-line)#
```

3. Configure password checking at login.

```
router(config-line)#login authentication my-auth-list
```

4. Exit configuration mode.

```
router(config-line)#end
router#
%SYS-5-CONFIG_I: Configured from console by console
```

## Verify the Configuration

Examine the configuration of the router to verify that the commands have been properly entered:

- **show running-config** – displays the current configuration of the router.

```
router#write terminal
Building configuration...

Current configuration:
!
version 12.0
service timestamps debug uptime
service timestamps log uptime
no service password-encryption
!
hostname router
!
aaa new-model
aaa authentication login my-auth-list tacacs+
!

!--- Lines omitted for brevity

...
!
tacacs-server host 192.168.1.101
tacacs-server key letmein
!
line con 0
line 1 8
  login authentication my-auth-list
line aux 0
line vty 0 4
!
end
```

To test this particular configuration, an inbound or outbound connection must be made to the line. See the Modem – Router Connection Guide for specific information on configuring async lines for modem connections.

Alternately, you can configure one or more VTY lines to perform AAA authentication and perform your testing thereupon.

## Troubleshoot AAA Login Failure

Before issuing **debug** commands, see Important Information on Debug Commands.

To troubleshoot a failed login attempt, use the **debug** command appropriate to your configuration:

- `debug aaa authentication`
- `debug radius`
- `debug kerberos`

---

## Related Information

- [Configuring Authentication](#)
- [Cisco IOS Debug Command Reference](#)
- [Technical Support – Cisco Systems](#)

---

[Contacts & Feedback](#) | [Help](#) | [Site Map](#)

© 2007 – 2008 Cisco Systems, Inc. All rights reserved. [Terms & Conditions](#) | [Privacy Statement](#) | [Cookie Policy](#) | [Trademarks of Cisco Systems, Inc.](#)

---

Updated: Jun 30, 2008

Document ID: 45843

---