Configure Terminal Server through Menu Options

Contents

Introduction						
Prerequisites						
Requirements						
Components Used						
<u>Configure</u>						
Network Diagram						
Configurations						
<u>Verify</u>						
Troubleshoot						
Related Information						

Introduction

This document describes the use of Menu options to manage the access of devices connected to a Router terminal server.

Prerequisites

Requirements

Cisco recommends that you have knowledge of these topics:

- Terminal Server Setup
- Octal cables

Components Used

The information in this document is based on Integrated Service Routers Generation 2 (ISR G2) with an async module like HWIC-8A.

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, ensure that you understand the potential impact of any command.

Configure

Network Diagram



Configurations

Step 1. Configure a loopback interface on the Router and assign IP address to the same.

<#root>
Terminalserver(config)#
interface loopback 1
Terminalserver(config-if)#
ip address 10.1.1.1 255.255.255.0

Step 2. Check the physical connections from the terminal server to the end devices and make a note of line number corresponds to each device. HWIC-8A provides 8 lines as you can see in the output.

<#root>

Terminalserver#

show line

	Tty Li	ne Typ	Tx/Rx	A Modem	ı Roty A	ACCO A	ccI	Uses	Noise C	verruns	Int
*	0	0 CTY			-	-	-	7	0	0/0	-
	1	1 AUX	9600/9600		-	-	-	0	0	0/0	-
	2	2 TTY	9600/9600		-	-	-	0	0	0/0	-
	0/0/0	3 TTY	9600/9600	– DTR–	Act -	-	-	2	3	0/0	-
	0/0/1	4 TTY	9600/9600	– DTR–	Act -	-	-	3	2	0/0	-
	0/0/2	5 TTY	9600/9600	– DTR–	Act -	-	-	0	0	0/0	-

0/0/3	6 TTY	9600/9600	- DTR-Act	-	-	-	0	0	0/0	-
0/0/4	7 TTY	9600/9600	- DTR-Act	-	-	-	0	0	0/0	-
0/0/5	8 TTY	9600/9600	- DTR-Act	-	-	-	0	0	0/0	-
0/0/6	9 TTY	9600/9600	- DTR-Act	-	-	-	0	0	0/0	-
0/0/7	10 TTY	9600/9600	- DTR-Act	-	-	-	0	0	0/0	-

Step 3. Configure IP host mappings for each device as in the next example. Port numbers can be obtained by adding 2000 to the line number corresponds to each device. For example, line number for a device connected to port 0/0/1 is 4 as you can see in the preceding output. Port number for connecting to the device is 2004 (2000+4).

```
<#root>
Terminalserver(config)#
ip host R1 2003 10.1.1.1
Terminalserver(config)#
ip host R2 2004 10.1.1.1
```

Step 4. In order to configure menu options, you can first configure a banner or title for the terminal server as shown in this example:

Step 5. This command needs to be configured to as it gives the options to make selections in a Menu.

```
<#root>
Terminalserver(config)#
menu cisco prompt $
Enter TEXT message. End with the character '$'.
Choose your option
$
```

Step 6. You have to configure **line-mode** to enforce the need to hit **Enter** after you select an option. Menu runs directly after the selection an option, if you do not use this command.

<#root>

Terminalserver(config)# menu cisco line-mode

Step 7. In order to setup a new connection, these menu commands are used.

```
<#root>
Terminalserver(config)#
menu cisco command 1 telnet 10.1.1.1 2003
Terminalserver(config)#
menu cisco text 1 login to R1
```

Step 8. This menu command opens a new connection or resumes the connection that exists to the configured host.

```
<#root>
Terminalserver(config)#
menu cisco command 2 resume R2 / connect telnet R2
Terminalserver(config)#
menu cisco text 2 login to R2
```

Step 9. In order to clear the screen after it enters the menu, this command is used.

<#root> Terminalserver(config)# menu cisco clear-screen

Step 10. In order to display user status on the top of the screen, this command is used.

<#root>
Terminalserver(config)#
menu main status-line

Step 11. These menu command needs to be configured for the exit from the menu.

```
<#root>
Terminalserver(config)#
menu cisco command e menu-exit
Terminalserver(config)#
menu cisco text e menu-exit
```

Step 12. In order to quit a Terminal Server connection, use these menu commands.

```
<#root>
Terminalserver(config)#
menu cisco command q exit
Terminalserver(config)#
menu cisco text q disconnect from terminal server
```

Step 13. These commands are configured under the VTY lines for automatic menu execution, when a user logs in via Telnet or Secure Shell (SSH).

```
<#root>
Terminalserver(config)#
line vty 0 4
Terminalserver(config-line)#
autocommand menu cisco
Terminalserver(config-line)#
login local
Terminalserver(config-line)#
transport input ssh
Terminalserver(config-line)#
transport output all
```

Verify

Use this section in order to confirm that your configuration works properly.

Telnet to R1

<#root>

Terminalserver#

menu cisco

1 login to R1
2 login to R2
e menu-exit
q disconnect from terminal server

Choose your option

1

R1#

Terminalserver#

show sessions

Conn	Host	Address	Byte	Idle	Conn Name
* 1	10.1.1.1	10.1.1.1	0	0	10.1.1.1

Telnet to R2

<#root>

1 login to R1 2 login to R2 e menu-exit q disconnect from terminal server

Choose your option

2

Terminalserver#

show sessions

C	Conn	Host	Address	Byte	Idle	Conn Name
	1	10.1.1.1	10.1.1.1	0	0	10.1.1.1
*	2	10.1.1.1	10.1.1.1	0	0	

Exit from the Menu option.

Exit from the Terminal Server.

Press RETURN to get started.

Troubleshoot

You can observe these error sometimes when you attempt to connect to an end device from a Terminal server.

<#root> Terminalserver# telnet R1 Trying R1 (10.1.1.1, 2003)...

% Connection refused by remote host

In order to resolve this, you need to clear the corresponding line from the Terminal Server as in this example:

<#root>

Terminalserver#

clear line 3

[confirm] [OK] Terminalserver#

telnet R1

Trying R1 (10.1.1.1,2003)...open R1>

Related Information

<u>Cisco Technical Support & Downloads</u>