



## About this Guide

---

Revised: June 13, 2011, OL-24172-01

## Introduction

This preface describes who should read the *Cisco Service Control Value Added Services Solution Guide*, how it is organized, and its document conventions.

This guide is for experienced network administrators who are responsible for configuring and maintaining the Cisco Service Control solution.

# Document Revision History

Table 1 records changes to this document.

**Table 1**      **Document Revision History**

<b>Revision</b>	<b>Cisco Service Control Release and Date</b>	<b>Change Summary</b>
OL-24172-01	Supports all 3.7.x releases June 13, 2011	The <i>Cisco Service Control Value Added Services Solution Guide</i> was created.

# Organization

This guide contains the following sections:

**Table 2**      **Document Organization**

Section	Title	Description
1	<a href="#">Overview of the Cisco Service Control Value Added Services Feature</a>	Provides an overview of the Cisco Service Control Value Added Services feature.
2	<a href="#">Configuring the SCE Platform to Support VAS Traffic Forwarding</a>	Describes how to configure the SCE platform to support Cisco Service Control Value Added Services (VAS). From the SCE platform, you can do the following: <ul style="list-style-type: none"> <li>• Enable VAS support</li> <li>• Configure global VAS parameters</li> <li>• Configure VAS servers</li> <li>• Configure VAS server groups</li> </ul>
3	<a href="#">Configuring the SCA BB Application to Support VAS Traffic Forwarding</a>	Describes how to configure packages for VAS support. From the SCA BB console, you can do the following: <ul style="list-style-type: none"> <li>• Enable VAS support</li> <li>• Assign meaningful names to VAS server groups</li> <li>• Assign specific traffic flows to specific VAS server groups</li> </ul>
4	<a href="#">Monitoring VAS Traffic Forwarding</a>	Describes how to monitor VAS support.
5	<a href="#">VAS Configuration Example</a>	Provides a complete VAS configuration example.

## Related Publications

Your SCE platform and the software running on it contain extensive features and functionality, which are documented in the following resources:

- For further information about the Service Control CLI and a complete listing of all CLI commands, see these guides:
  - [Cisco SCE 8000 CLI Command Reference](#)
  - [Cisco SCE 2000 and SCE 1000 CLI Command Reference](#)
- For further information about configuring the SCE platform, see these guides:
  - [Cisco SCE 8000 10GBE Software Configuration Guide](#)
  - [Cisco SCE 8000 GBE Software Configuration Guide](#)
  - [Cisco SCE 2000 and SCE 1000 Software Configuration Guide](#)
- For further information about configuring the SCA BB application, see the [Cisco Service Control Application for Broadband User Guide](#).
- For viewing Cisco documentation or obtaining general information about the documentation, see the following sources:
  - [Obtaining Documentation and Submitting a Service Request, page xii](#)
  - The Cisco Information Packet that shipped with your SCE platform.

# Conventions

This document uses the following conventions:

**Table 3**      **Conventions**

Convention	Indication
<b>bold font</b>	Commands and keywords and user-entered text appear in <b>bold font</b> .
<i>italic font</i>	Document titles, new or emphasized terms, and arguments for which you supply values are in <i>italic font</i> .
[ ]	Elements in square brackets are optional.
{x   y   z}	Required alternative keywords are grouped in braces and separated by vertical bars.
[x   y   z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
<code>courier font</code>	Terminal sessions and information the system displays appear in <code>courier font</code> .
< >	Nonprinting characters such as passwords are in angle brackets.
[ ]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.



**Note**

Means *reader take note*.



**Tip**

Means *the following information will help you solve a problem*.



**Caution**

Means *reader be careful*. In this situation, you might perform an action that could result in equipment damage or loss of data.



**Timesaver**

Means *the described action saves time*. You can save time by performing the action described in the paragraph.



**Warning**

Means *reader be warned*. In this situation, you might perform an action that could result in **bodily injury**.

## Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly What's New in Cisco Product Documentation, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the What's New in Cisco Product Documentation as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.