·IIIII CISCO

CISCO SERVICE CONTROL SOLUTION GUIDE



Cisco Service Control Guide to Upgrading to Cisco SCA BB 5.0.x

- 1 Overview
- 2 Upgrading the Cisco SCA BB
- **3** Upgrading the Subscriber Manager
- 4 Upgrading the Cisco Service Control Collection Manager
- **5** Upgrading the SCE Platform Software
- 6 Upgrade Procedure Limitations
- 7 Obtaining Documentation and Submitting a Service Request

1 Overview

Upgrading from Version 4.0.x or 4.1.x to Version 5.0.x

This guide describes the process of upgrading the Cisco Service Control solution from Version 4.0.x or 4.1.x to Version 5.0.x. It describes the upgrade process for each of the four components:

- Cisco Service Control Application for Broadband (SCA BB)
- Service Control Engine (SCE)
- Subscriber Manager (SM)
- Collection Manager (CM)

The procedure describes a scenario where the Service Control deployment is required to continue functioning throughout the upgrade procedure, with SCE platforms running SCA BB 3.x, 4.x operating concurrently (using the same Collection Manager and Subscriber Manager servers).

This procedure aims to minimize service downtime (for however long the upgrade process takes), bound to several limitations, as described in the preceding sections.

Note	This is a high-level description of the procedure.

Step 1 Upgrade Cisco SCA BB.

.

- **a**. Install the 5.0.x console.
- **b.** (Optional) Install the Cisco SCA BB Service Configuration Utility Version 5.0.x, servconf, in an empty directory.
- **Step 2** Upgrading the Subscriber Manager from older version to the Subscriber Manager 5.0.x is not supported. However, you can migrate from Version 4.1.x configuration to Version 5.0.x configuration using the **upgrade-cfg.sh** script.
- Step 3 Deploy a new Collection Manager running 5.0.x. See Chapter 4, "Upgrading the Cisco Service Control Collection Manager".
 - If additional Collection Manager and database are deployed for the transition phase (two Collection Manager databases in total, collection works for all SCE platforms (both older versions and 5.0.x). For nonbundled databases, there may be several ways to implement this; consult a database specialist if you are using a nonbundled database.
 - Each Collection Manager collects Raw Data Records (RDRs) from a single version to a distinct database and comma-separated values (CSV) repository.

- **Step 4** You need to replace Cisco SCE 8000 device with Cisco SCE 10000 device and upgrade the SCE platform software by using the SCE Software Upgrade Wizard. For more information on Cisco SCE 10000 device installation, see *Cisco SCE 10000 Installation and Configuration Guide*.
 - Make sure the upgraded SCE platform RDRs are directed to the Collection Manager that runs version 5.0.x. Service downtime (from a collection perspective) depends on the Collection Manager configuration that you have implemented (single or dual) during the upgrade.

At this stage, the entire solution is upgraded and fully operational.

Step 5 (If two Collection Manager are used during the upgrade) Remove the Collection Manager running the former version after upgrading all the SCE platforms.

Supported Working Configurations

The Cisco SCA BB release 5.0.x supports a combination of component versions:

- Cisco Service Control Operating System (SCOS) 5.0.x
- Application SCA BB 5.0.x (PQI for installation on SCE platform)
- Cisco Service Control Subscriber Manager 5.0.x (if a Subscriber Manager is required for the deployment)
- Cisco Service Control Collection Manager 5.0.x (if a Collection Manager is required for the deployment)



This document covers the upgrade of a system that includes a Subscriber Manager and a Collection Manager. In cases where one or both of these components are not required, the corresponding sections can be ignored.

Rollback Procedure

A software rollback might be required for Cisco SCE in cases where the upgrade process has failed, or has impaired the service. It requires a downgrade to the previous release to mitigate the damage to the network.

Generally, no automatic downgrade scripts are available for the solution components. To enable downgrade, the older configuration should be backed up before upgrading. To downgrade, a clean installation of the older release is required for each component.



When downgrading the SCE, you must first uninstall the SCA BB PQI using the **PQI uninstall file** command. You require the new PQI file to run this command. However, the **PQI uninstall file** command works only if the PQI was installed from the CLI, and not from the SCA BB Console. But, installing the older package will overwrite the PQI. If SCA BB PQI or SPQI is installed from SCA BB Console, use the **no application** command to remove the application.

Note

Cisco SCE does not support direct downgrade of higher PP versions to a lower PP version. While downgrading the protcol pack from a higher version to a lower version, the Cisco SCA BB console displays an error message and prevents you from applying the policy on the Cisco SCE.

2 Upgrading the Cisco SCA BB

This chapter details the procedure for upgrading from a functional Cisco SCA BB 4.0.x or 4.1.x deployment to Cisco SCA BB 5.0.x.

Upgrading Cisco SCA BB

Upgrading Cisco SCA BB consists of two steps:

- **1**. Installing the 5.0.xconsole.
- 2. (Optional) Installing the 5.0.x service configuration utility.

How to Install the Console

Navigate to the console installation file, sca-bb-console-5.0.x.exe, and double-click it. A standard installation wizard opens. Follow the standard procedure to install the console.

How to Upgrade the Cisco SCA BB Service Configuration Utility

To upgrade the Cisco SCA BB service configuration utility, complete these steps:

- Step 1 From the SCA BB installation package, extract the *scas_bb_util.tgz* file, and copy it to a Windows or Linux workstation.
- **Step 2** Unpack the file to a new folder.

The following files are under the bin folder:

- The SCA BB Service Configuration Utility (servconf)
- The SCA BB Signature Configuration Utility (sigconf)

3 Upgrading the Subscriber Manager

Upgrading the Subscriber Manager from older version to the Subscriber Manager 5.0.x is not supported. However, you can migrate from Version 4.1.x configuration to Version 5.0.x configuration using the upgrade-cfg.sh script.

Contents of the Distribution Files

The Cisco Service Control Subscriber Manager components are supplied in three distribution files:

- Subscriber Manager for Linux 64
- Login Event Generators (LEGs)

Note

Each distribution file is supplied as a tar file, which is compressed by gzip and has an extension of .tar.gz. For details, see the *Cisco Service Control Management Suite Subscriber Manager User Guide*.

Upgrading the Subscriber Manager

The Subscriber Manager supports several types of upgrade procedures, according to the Subscriber Manager version that was previously installed and the requirement (or lack of requirement) for fail-over in the new installation.

The following sections provide details on three types of upgrade procedures:

- How to Upgrade a Standalone Setup, page 6
- How to Upgrade from a Standalone Setup to a Cluster Setup, page 7
- How to Upgrade a Cluster Setup, page 8

Data Duplication Procedure

The data duplication procedure enables you to duplicate or copy the entire database from one machine to the other, and then keep the databases synchronized by running the replication agent at the end. Some of the upgrade procedures use this procedure.

For details of the procedure, see the Database Duplication Recovery section of Cisco Service Control Management Suite Subscriber Manager User Guide.

Automatic Upgrade of Subscribers with VLAN Mappings

VLAN mappings are related to VPN rather than to a subscriber. During the upgrade procedure, the SM automatically creates a VPN with the VLAN-ID of the subscriber and associates a subscriber with the full range IP mapping to the new VPN.

For example, subscriber *sub1* with VLAN-ID=15 results in the creation of VPN 15 with VLAN-ID=15 and subscriber *sub1* with the mapping, 0.0.0.0/0@VLAN-ID.

Configuring the Required Memory Settings

To prepare the Subscriber Manager for the upgrade, configure the system kernel configuration file on the Subscriber Manager. Subscriber Manager database requires that certain changes be made in the operating system kernel configuration file:

• For Linux, modify the /etc/sysctl.conf file.

These changes increase the shared memory and semaphore resources on Solaris machines from their defaults.



It is recommended that you review the /etc/system or the /etc/systl.conf file before running the tt-sysconf.sh script, because the script overwrites the current file settings with the values listed in the *To make the required changes manually* procedure. If you want to keep some or all of the current file settings, edit the system configuration file and perform the changes manually.

You can make the required changes automatically or manually.

• To make the required changes automatically, run the tt-sysconf.sh script.

The root user must invoke this script file, without arguments, as follows:

- # tt-sysconf.sh
- To make the required changes manually:

Note

Editing the configuration file manually is required when you require support for more than 100,000 subscribers in the Subscriber Manager. The sizing requirements of your system affect only the shared memory size. To determine the correct configuration values for your system, "Installation and Upgrading" chapter of the *Cisco Service Control Management Suite Subscriber Manager User Guide*.

- For Linux, make the required changes manually by adding the following lines to the /etc/sysctl.conf file and configuring the shared memory size:

```
*---- Begin settings for SMdatabase
kernel.shmmax = 536870912
kernel.sem = 250 32000 100 100
*---- End of settings for SMdatabase
```

How to Upgrade a Standalone Setup



Upgrading the Subscriber Manager from older version to the Subscriber Manager 5.0.x is not supported. However, you can migrate from Version 4.1.x configuration to Version 5.0.x configuration using the upgrade-cfg.sh script.

The following upgrade procedure is supported only by Release 3.x software versions. You can directly upgrade from version 3.7.2 or 3.8.x to 4.0.0. To upgrade the Subscriber Manager from a Release 2.x software version, you must first upgrade the Subscriber Manager environment to a Release 3.1.x software version and then perform an additional upgrade to Release 3.6.0. To upgrade from Version 3.5.5 to Version 3.7.0, you must first upgrade to Version 3.6.0 and then to 3.7.0. You can upgrade directly from Version 3.6.5 to Version 3.7.0. To upgrade from Version 3.7.0 to Version 3.8.5, you must first upgrade to Version 3.8.0 and then to 3.8.5.

For more information about how to upgrade from a Release 2.x software version to a Release 3.1.x software version, refer to the Release 3.1.x manuals.

This procedure applies to the Subscriber Manager 4.1.x and later.

This upgrade procedure requires service down-time.

Note

For the upgrade procedure from a standalone setup to a cluster setup, see the "How to Upgrade from a Standalone Setup to a Cluster Setup" section on page 7.

Step 1 Extract the distribution files.

Before you upgrade the Subscriber Manager, you must first load and extract the distribution files on the installed machine or in a directory that is mounted to the installed machine.

- a. Download the distribution files from the Cisco.com.
- **b**. Use an FTP to load the distribution files to the Subscriber Manager.
- **c**. Unzip the files by using the **gunzip** command.

gunzip SM_dist_<version>_B<build number>.tar.gz

d. Extract the tar the file using the tar command.

tar -xvf SM_dist_<version>_B<build number>.tar

Step 2 Edit the install-def-cfg file.

Edit the install-def-cfg configuration file and set the PermSize and TempSize parameters according to the recommendations described in "Configuring the Required Memory Settings" section on page 5. For further information, see the *Cisco Service Control Product Installation Guide*.

Step 3 Run the **upgrade-sm.sh** script.

To upgrade from noncluster setups, the Subscriber Manager distribution provides an upgrade script that implements an upgrade from previous versions. The upgrade procedure script preserves the subscriber database and the entire Subscriber Manager configuration, including network elements, domains, and application-specific components.



For Linux—64-bit VM and database.



If the /etc/motd file exists, you can not run the script. Move or remove the file before you run the upgrade-sm.sh script.

From your workstation shell prompt, run the upgrade-sm.sh script:

upgrade-sm.sh

Step 4 Add a user for PRPC authentication.

To add a user for PRPC authentication, use the p3rpc CLU. For example:

>p3rpc --set-user --username=username --password=password

Step 5 Configure the SCE platforms.

If using a cascade SCE setup, configure the cascade SCE pair in the **p3sm.cfg** file as described in the SCE.XXX section in the Configuration File Options appendix of *Cisco Service Control Management Suite Subscriber Manager User Guide*.

How to Upgrade from a Standalone Setup to a Cluster Setup



Note

You can directly upgrade from Version 3.8.x or 4.0.x to Version 4.1.x. You can upgrade directly from version Version 3.7.x or 3.8.x to version 4.0.x. To upgrade from Version 3.5.5 to Version 3.7.0, you must first upgrade to Version 3.6.0 and then to 3.7.0. You can upgrade directly from Version 3.6.5 to Version 3.7.0. To upgrade from Version 3.7.0 to Version 3.8.5, you must first upgrade to Version 3.8.0 and then to 3.8.5.

The following upgrade procedure is supported only from Release 3.x software versions. To upgrade Subscriber Manager from a Release 2.x software version, you must first upgrade the Subscriber Manager environment to a Release 3.1.x software version and then perform an additional upgrade to Release 3.6.0. From Version 3.6.0, you can upgrade to Version 3.7.0.

For more information about how to upgrade from Release 2.x software to Release 3.1.x software, the Release 3.1.x manuals. For details on how to upgrade to Version 3.6.0, see the Subscriber Manager 3.6.x manuals. For details on how to upgrade to Version 3.7.0, see the Subscriber Manager 3.7.x manuals.

This section describes the procedure for upgrading from a standalone setup to a cluster setup. This procedure applies to the Subscriber Manager from version 3.0.x and later.

This section describes the basic procedure for upgrading from a standalone setup to a cluster setup. This upgrade procedure requires service down-time.

Note This procedure attempts to minimize the Subscriber Manager downtime as much as possible. Therefore, if subscriber service is not an issue, use the procedure for installing a new machine and upgrading a new machine instead.

In the following procedure, SM-A is the original Subscriber Manager machine and SM-B is the new Subscriber Manager machine being added for redundancy.

Step 1 Install the VCS on both machines.

Step 2 Install SM-B.

To install SM-B, follow the procedure described in the Installing the Subscriber Manager section of *Cisco Service Control Product Installation Guide*.

Step 3 Upgrade SM-A.

To upgrade SM-A, follow the procedure described in the "How to Upgrade a Standalone Setup" section on page 6.



From this step until the upgrade procedure is completed, there is no Subscriber Manager to handle subscribers.

Step 4 Replicate the Subscriber Manager configuration from SM-A to SM-B (copy all the configuration files from the ~pcube/sm/server/root/config folder).

Copy the **p3sm.cfg** configuration file manually from SM-A to SM-B and load the configuration file by using the following CLU command:

p3sm --load-config

Step 5 Duplicate the subscriber database.

See the "Data Duplication Procedure" section on page 5 for the data duplication procedure.

Configure the replication scheme for the data store replication to the redundant machine.

>p3db --set-rep-scheme



Step 6 Create a cluster.

a. Configure both SM-A and SM-B to support a cluster.

On each machine, open the **p3sm.cfg** configuration file in any standard text editor and in the [SM High Availability Setup] section, set topology=cluster.

Load the updated configuration file by using the following CLU command:

- p3sm --load-config
- b. Make SM-B standby.

Use the p3cluster --standby CLU command.

c. Ensure that SM-A is active.

Use the p3cluster --active CLU command.

- d. Configure the VCS.
- e. Run the VCS on the setup.

Step 7 Configure the LEG applications to send logins to the cluster virtual IP.

How to Upgrade a Cluster Setup

This section describes the procedure for upgrading from a cluster setup to a cluster setup without a service downtime. This section contains the following subsections:

- Before You Start, page 8
- Upgrading a Cluster Setup, page 10

Before You Start



Upgrading the Subscriber Manager from older version to the Subscriber Manager 5.0.x is not supported. However, you can migrate from Version 4.1.x configuration to Version 5.0.x configuration using the upgrade-cfg.sh script.

- You can upgrade from Version 3.8.x or 4.0.x to Version 4.1.x. You can upgrade from Version 3.8.x to Version 4.0.x. You can also upgrade directly from Cisco Service Control Subscriber Manager (SM) Version 3.6.5 to SM Version 3.7.0 or Version 3.7.x to Version 3.8.x. However, to upgrade from SM Version 3.5.5 or earlier to SM Version 3.7.0, you must first upgrade to SM Version 3.6.0 and then to SM Version 3.7.0. To upgrade from SM Version 2.x to SM Version 3.6, you must first upgrade to SM Version 3.0 or SM Version 3.1.
- Identify the devices in the cluster setup.
- Understand the Java Virtual Machine (JVM) used by the Cisco Service Control Subscriber Manager on your operating system:
 - The Linux platform is used only with a 32-bit JVM and database.

- Understand how to download and extract the distribution files. For details, see the "Downloading and Extracting the Distribution Files" section on page 9.
- Understand the scripts used while upgrading a cluster setup. For details, see the "Understanding the Scripts Used During Upgrade" section on page 9.

Downloading and Extracting the Distribution Files

Before you upgrade the Subscriber Manager, you must download and extract the distribution files on the installed machine or in a directory that is mounted to the installed machine.

- Step 1 Download the distribution files from Cisco.com.Step 2 Use an FTP to load the distribution files to the Subscriber Manager.
- **Step 3** Unzip the files by using the **gunzip** command:

gunzip SM_dist_<version>_B<build number>.tar.gz

Step 4 Extract the tar file using the tar command: tar -xvf SM_dist_<version>_B<build number>.tar

Understanding the Scripts Used During Upgrade

During the process of upgrading a cluster, you might use the following scripts:

- cluster-upgrade.sh. For details, see the "Understanding the cluster-upgrade.sh script" section on page 9.
- install-vcs-agents.sh. For details, see the "Understanding the install-vcs-agents.sh script" section on page 10.

Understanding the cluster-upgrade.sh script

Use this script, which is provided with the Subscriber Manager, to upgrade a cluster setup with earlier versions of Cisco Service Control Subscriber Manager to a cluster setup with the latest version of the Cisco Service Control Subscriber Manager.

The cluster-upgrade.sh script preserves the subscriber database and the entire Subscriber Manager configuration, including network elements, domains, and application-specific components.

The script performs the following actions:

- Detects the current Subscriber Manager version.
- Detects the new version of the Subscriber Manager.
- Verifies whether Java is installed on the machine.
- Verifies whether the user **pcube** exists.
- Verifies whether Subscriber Manager Version 3.x or later is present on the system.
- Verifies the values, if any, configured in install-def.cfg.
- Stops the Subscriber Manager, if it is running.
- Backs up the contents in the subscriber database to an external file.
- Removes the Subscriber Manager database.
- Backs up the Subscriber Manager configuration files.
- Installs the updated version of the Subscriber Manager and the Subscriber Manager Database.
- Invokes a separate program for upgrading the Subscriber Manager and the database configuration files.
- Restores the contents of the subscriber database that were backed up.
- When activated on the second machine, the script copies the contents of the database from the currently active Subscriber Manager; because the currently active Subscriber Manager contains the latest data.

You do not have to start the Subscriber Manager after running the script.

Table 1 lists the command options for the cluster-upgrade.sh script.

Options	Description
-h	Use this option to see the details on how to use the command options.
-1	Use this option when activating the script on the first machine.
-2	Use this option when activating the script on the second machine.

Table 1 Command options for cluster-upgrade.sh

Understanding the install-vcs-agents.sh script

For details about the install-vcs-agents.sh script, see the Cisco Service Control Management Suite Subscriber Manager User Guide.

Upgrading a Cluster Setup

Note

Upgrading the Subscriber Manager from older version to the Subscriber Manager 5.0.x is not supported. However, you can migrate from Version 4.1.x configuration to Version 5.0.x configuration using the upgrade-cfg.sh script.

To upgrade a cluster setup, complete the following steps:

Step No.	Action	Notes
Step 1	 Configure the system kernel configuration file on both the machines: a. Configure the system kernel configuration file on the standby Subscriber Manager. b. Reboot the standby SM. 	Before starting the upgrade procedure, configure the system kernel configuration file on both the machines.
	c. Manually trigger a failover by using the Veritas Cluster Manager and wait until the standby SM becomes active and the active SM shifts to the standby SM.	For details about the system kernel configuration procedure,
	d. Run the following VCS CLU command from /opt/VRTSvcs/bin:	see the "Configuring the
	#./hagrp -switch service group name -to System	Settings" section on
	e. Repeat Step a. and Step b. on the new standby Subscriber Manager.	page 5.
Step 2	Extract the distribution files on both the machines.	For details about downloading and extracting the distribution files, see the "Downloading and Extracting the Distribution Files" section on page 9.
Step 3	Stop VCS monitoring on the standby machine:	—
	a. Log in as the <i>root</i> user.	
	b. Use the following VCS CLU command from /opt/VRTSvcs/bin to stop VCS monitoring of the Subscriber Manager:	
	#./hastop -local	
Step 4	Edit the install-def.cfg file on both the machines and set the PermSize and TempSize parameters according to the recommendations described in "Configuring the Required Memory Settings" section on page 5.	For details about the required memory settings, see the Cisco Service Control Product Installation Guide.

Step No.	Action	Notes
Step 5	Pause database replication on the active machine:	This step is applicable only
	a. On the active machine, change the directory to the location where you extracted the distribution files.	when upgrading the first Subscriber Manager
	b. Run this CLU command from the scripts directory:	machine.
	p3dbrep-pause	
	c. Run this CLU command from the scripts directory and verify that replication is in <i>pause</i> state:	
	p3dbrep-status	
	d . Return to the standby machine.	
Step 6	Run the cluster-upgrade.sh script on the standby machine:	For details about the
	<pre># cluster-upgrade.sh [command-options]</pre>	cluster-upgrade.sh script,
	Do not start the SM after running cluster-upgrade.sh.	Scripts Used During Upgrade" section on page 9
Step 7	Wait until the cluster-upgrade.sh script finishes all tasks.	
Step 8	Stop the replication and start the SM on the standby machine.	Because the database
	The following steps should be performed only when performing upgrade on the first machine.	schema was changed, there is a need to load the SM for the first time without
	a. Stop the SM replication:	replicating the changes to
	-bash-3.1\$ p3dbrep-stop	the standby machine.
	b. Start the SM:	The SM boot time after the
	-bash-3.1\$ p3smstartwait	usual due to the extra time
	c. Use the p3sm CLU command to verify the status of the SM.	taken to initialize the
	-bash-3.1\$ p3smsm-status	database indexes.
		indicates a failure, stop the upgrade. For details on troubleshooting the SM in failure mode, see the Cisco Service Control Management Suite Subscriber Manager User Guide.
Step 9	Run the install-vcs-agents.sh script on the standby machine:	—
	# install-vcs-agents.sh [command-options]	
Step 10	Restart Veritas Cluster Server (VCS) monitoring on the standby machine:	The ./hastart command starts the replication agent
	a. Run the following VCS CLU command from /opt/VRTSvcs/bin:	schema on the active
	#./hastart	machine.
	VCS monitoring starts the SM process automatically in the initialization state.	After this operation is performed, you cannot
	b. Use the p3sm CLU command to check whether the SM is up:	downgrade to an earlier
	-bash-3.1\$ p3smsm-status	
	c. Use the p3cluster CLU command to set the SM to the standby state:	
	-bash-3.1\$ poctusterStandby	

Step No.	Action	Notes
Step 11	Continue database replication on the active machine:	This step is applicable only when upgrading the first
	a. On the <i>Active</i> machine, change the directory to the location where you extracted the distribution files.	machine and only if Step 5
	b. Run therep-continue CLU command.	was periorineu.
	c. Run therep-status CLU command and verify that replication is in the <i>start</i> state.	
	d. Return to the standby workstation.	
Step 12	Verify that the changed data has been replicated.	When upgrading the
	Wait until the replication of all the data that was changed while the upgrade script was running.	second Subscriber Manager, add a subscriber with a name
	• On the active Subscriber Manager add a dummy subscriber using the p3subs CLU:	other than <i>dummySub</i> because you have already
	-bash-3.1\$ p3subsadd -s dummySub	added a subscriber with
	• On the standby Subscriber Manager, login as <i>root</i> user, and run the p3subs show command:	this name while upgrading the first Subscriber Manager.
	# p3subsshow -s dummySub	C C
Step 13	(Optional) Install the MPLS/VPN BGP LEG.	For more information, see the Cisco Service Control SM LEGs User Guide.
Step 14	Manually trigger a failover using the Veritas Cluster Manager and wait until the standby SM becomes active and the active SM becomes the standby:	For more information about the hagrp CLU command, refer to your
	Run the following VCS CLU command from /opt/VRTSvcs/bin:	Veritas Cluster Server
	# hagrp -switch service group name -to System	After performing the manual failover, the standby SM on which you perform the upgrade procedure becomes the active SM. The previously active SM becomes the new standby SM.
Step 15	Repeat the upgrade procedure on the standby SM.	
	To upgrade the second SM, repeat the procedure from Step 2. But, do not perform Step 5, Step 8, and Step 11.	

Step No.	Action	Notes
Step 16	 Upgrade the database replication protocol version: a. Stop VCS monitoring of the standby SM. Use the following VCS CLU command from /opt/VRTSvcs/bin: #./hastop -local b. Change the replication protocol. On the standby SM, run the following CLU command: 	Perform this operation after both the SMs are upgraded. Run the commands described in this step as the admin user on both the machines to upgrade the database replication
	 -bash-3.1\$ p3dbupgrade-rep-protocol c. Restart VCS monitoring. From the /opt/VRTSvcs/bin folder, run the following VCS CLU command: #./hastart VCS monitoring starts the SM process automatically in the initialization state. d. Use the p3cluster CLU command to set the SM to the standby state: -bash-3.1\$ p3clusterstandby e. Manually trigger a failover using the Veritas Cluster Manager and wait until the standby SM becomes active and the active SM becomes the standby one. f. Run the following VCS CLU command from /opt/VRTSvcs/bin: # hagrp -switch service group name -to System 	 action representation protocol version. The p3db -upgrade-rep-protocol CLU command performs the following actions: Removes the DB security flag Stops the SM Restarts the DB daemon Starts the SM Starts SM replication For more information about the hagrp command, refer to your Veritas Cluster Server documentation
Step 17	g. Repeat Step a. to Step f. on the new standby SM. Add a user for PRPC authentication using the p3rpc CLU, for example: -bash-3.1\$ p3rpcset-userusername=usernamepassword=passwordremote=OTHER_SM_IP[:port]	If you are upgrading from a version of the SM prior to Version 3.0.5, it is necessary to add a user for PRPC authentication because Cisco SCA BB requires a username and password to connect to the SM.
Step 18	Configure the Cisco SCE platforms.	If you have a cascade SCE setup, configure the cascade SCE pair in the p3sm.cfg file. For details, see the Cisco Service Control Management Suite Subscriber Manager User Guide.
Step 19	Remove the dummy subscribers. On the new active SM, run the following CLU: -bash-3.1\$ p3subsremove -subscriber=first dummy subscriber name -bash-3.1\$ p3subsremove -subscriber=second dummy subscriber name	After successfully upgrading both the SMs we recommend that you remove the dummy subscribers that were added in order to verify replication during the upgrade.

Migrating 4.1.x Subscriber Manager Data to 5.0.x

This section describes the procedure to migrate the Subscriber Manager data from Version 4.1.x to Version 5.0.x.

```
      Step 1 Export the subscriber database in 4.1.x Subscriber Manager by running the p3subsdb CLU.

      -bash-3.1$ p3subsdb --export --output=output filename

      Step 2 Import the subscribers back into the database in 5.0.x Subscriber Manager by running the p3subsdb CLU.

      -bash-3.1$ p3subsdb --import --file=file name from Step 1

      Note
      Ensure that the ~pcube/sm/server/root/ssu/subaware.pro file must be same as Step 1 and Step 2.
```

How to Downgrade the Subscriber Manager

This section describes the procedure to downgrade the Subscriber Manager to an earlier version.

- **Step 1** Perform the uninstall procedure described in the Installing and Upgrading chapter, the How to Uninstall the Subscriber Manager section of *Cisco Service Control Management Suite Subscriber Manager User Guide*.
- **Step 2** Perform the installation procedure described in the Installing the Subscriber Manager section of *Cisco Service Control Product Installation Guide*.



The upgrade-sm.sh and cluster-upgrade.sh upgrade scripts do not support Subscriber Manager downgrade.

4 Upgrading the Cisco Service Control Collection Manager

This chapter describes the procedures for upgrading the Collection Manager.

When upgrading a complete system, it is recommended that you install a second Collection Manager running the new version and then uninstall the Collection Manager running the earlier version. This procedure provides a seamless transition to the new version. In this case, no upgrade procedure is run on the Collection Manager.



You can upgrade to Cisco Service Control Collection Manager, Release 5.0.x from Cisco Service Control Collection Manager, Releases 4.0.x and 4.1.x. To upgrade to Release 5.0.x from a version earlier than 3.8.5, you must first upgrade to version 4.0.x or 4.1.x.

To install the Collection Manager, see the Installing the Collection Manager section of Cisco Service Control Product Installation Guide.

How to Upgrade the Collection Manager to Version 5.0.x

- **Step 1** Get the Cisco Service Control Collection Manager software as described in the Cisco Service Control Management Suite Collection Manager Quick Start Guide.
- **Step 2** Change the directory to install-scripts under the distribution kit root.
- **Step 3** As the scmscm user, stop the Cisco Service Control Collection Manager server:
 - \$ ~scmscm/cm/bin/cm stop
- Step 4 As the root user, run the install-cm.sh script:

./install-cm.sh -o

Step 5 (Optional) Enable verbose mode:

Do you want to enable verbose mode (for detailed installation) (yes/no)[no]:

Step 6 (Optional) Upgrade the Cisco Service Control Collection Manager tables to the latest schema:

Do you want to upgrade the CM Tables to latest Schema? (It will take time if the table have huge data) (yes/no)[yes]:

Note

If you select the no option, run the ~scmscm/scripts/ upgradeRDRTables.sh as a scmscm user before manually starting Cisco Service Control Collection Manager. After the table upgrade, when Cisco Service Control Collection Manager comes up for the first time, the database tables that are new are created automatically.

Step 7 (Optional) Start the Cisco Service Control Collection Manager:

Would you like to start CM now? (yes/no)[yes]: yes

Note

If you enter no, manually start the Cisco Service Control Collection Manager using the ~scmscm/cm/bin/cm start command.

Note

The ~scmscm/cm/config/apps/scasbb/latest/dbtables.xml file is backed up in the same folder. The latest XML file is used for the Collection Manager process. To retain any configuration from earlier release, you must update the file manually.

Verifying that the Server Is Operational

To verify that the server is functioning correctly, use the alive.sh script:

~scmscm/setup/alive.sh

The script verifies that the Collection Manager is operational. If it is down, the script issues an error message.

As the scmscm user, run the alive.sh script.



It takes time for the components to initialize after a startup; after a restart, wait for five minutes before you run this script.

5 Upgrading the SCE Platform Software

This chapter describes the wizard that upgrades the SCE platform software.

The console SCE Software Upgrade Wizard performs a software upgrade on one or more SCE platforms. The wizard allows you to select the following:

- SCE platforms to be upgraded
- Firmware (pkg) version to upgrade to
- Application (pqi) version to upgrade to
- Service configuration (pqb) to apply

• Protocol pack (spqi) to apply

Before You Start

Before you begin the SCE platform upgrade, make sure that you do the following:

- If the IP address of all SCE platforms to be upgraded are not defined in the Network Navigator, gather the IP addresses of all SCE platforms to be upgraded.
- Download the relevant pkg file, pqi file, and protocol pack to a local location or to a location accessible by FTP. If using an FTP site, make sure to have the complete FTP location and path for each file.
- Decide what service configuration to use:
 - Default service configuration—Creates a default pqb file and applies to each SCE platform.
 - *Current service configuration*—Retrieves the current service configuration before the upgrade and then reapplies after the upgrade is complete.
 - Service Configuration from a Local File—Specifies the pqb file to be applied.

How to Upgrade the Cisco SCE Platform Software

Step 1In the Network Navigator of the console, select the Cisco SCE platforms to be upgraded. Right-click the corresponding
Cisco SCE platform name and choose SCE Software Upgrade Wizard (see Figure 1).

If the Cisco SCE platforms are not yet defined in the Network Navigator, you can select the site node.

Figure 1 Network Navigator

	Telnet Session SCE Software Upgrade Wizard Apply Zones and Flavors Apply Service Configuration		
• () () () () () () () () () () () () ()	Online Status Generate Tech Support Info File Install OS Fingerprinting Signature Install Protocol Pack (SPOI)		
	Advanced Configuration Wizards	+ +	
	Editing Show Properties View	•	363799

The SCE Software Upgrade Wizard opens. Click Next (see Figure 2).

Figure 2 SCE Software Upgrade Wizard

¥ SCE Software Upgrade Wizard	×
SCE Software Upgrade	3
This wizard helps to upgrade set of SCE devices with most recent software, including SCOS and Application, and also apply policy settings through PQB and Protocol Packs.	
< Back Next > Finish Cancel] [02793

Step 2 In the SCE IP Addresses pane (see Figure 3), verify that the IP addresses of all the Cisco SCE platforms to be upgraded are displayed. If any of the IP addresses are not displayed, enter the details and click Next.

Figure 3 SCE Software Upgrade Wizard—SCE IP Addresses

¥ SCE Software Upgrade Wizard			
SCE IP Addresses			
Configuring the SCE platforms requires that they are first added to the Network Navigator. To add SCE platforms to the Network Navigator, type their IP addresses in the text box below (For example: 10.56.216.37, 10.56.216.38):			
↓0.78.242.49			
< Back Next > Finish Cancel			

Step 3 In the SCE Usernames and Passwords pane (see Figure 4), enter the username and password required to access the Cisco SCE platform. You can use the same username and password for all the platforms or enter a different username and password for each platform and click Next.

Figure 4 SCE Software Upgrade Wizard—SCE Usernames and Passwords Window

¥ SCE Software Upgrade Wizard
SCE Usernames and Passwords
A password for the SCE 10.78.248.168 is missing
In order to connect to the SCE platforms, a username and a password need to be specified for each SCE. I use a gommon username and a common password for all SCE platforms: Username: admin Password: PBPC Port: 14374 Use geparate usernames and passwords for each SCE platform: SCE IP Address Username Password PRPCPort 10.78.248.168 admin 14374
< <u>Back</u> Next > Einish Cancel

Step 4 In the SCE Firmware (PKG) Installation pane (see Figure 5), specify the location of the firmware file to be installed on all the selected Cisco SCE platforms and click Next.

Figure 5 SCE Software Upgrade Wizard—SCE Firmware (PKG) Installation

🗚 SCE Software Upgrade Wizard	×
SCE Firmware (PKG) Installation	
Configure the SCE firmware installation options.	
C Install SCE Firmware from a Local File	
Eile name: C:\simba_05000543_K9 .pkg	1
Use local FTP server (requires less disk space)	
\bigcirc Install SCE Firmware from a <u>R</u> emote File (FTP)	
(e.g. ftp://user:password@10.56.216.129:21/scos.pkg)	
FTP URL:	
O Skip SCE Firmware Installation	
Erase SCE Startup Configuration Clean SCE file system if there is no disk space	
Set SCE Clock Same As Local Clock	
< <u>Back N</u> ext > <u>Finish</u> Cancel	

Step 5 In the SCE Application Software (PQI) Installation pane (see Figure 6), specify the location of the PQI file to be installed on all the selected Cisco SCE platforms and click Next.

Figure 6 SCE Software Upgrade Wizard—SCE Application Software (PQI) Installation

🗚 SCE Software Upgrade Wizard	
SCE Application Software (PQI) Installation	
Configure the SCE application software installation options.	
• Install SCE Application Software from a Local File	
Eile name: C:\sca-bb-agents-5.0.0-32\SCE10000\en50032.pqi	Browse
Use local FTP server (requires less disk space)	
C Install SCE Application Software from a <u>R</u> emote File (FTP)	
(e.g. ftp://user:password@10.56.216.129:21/software.pqi)	
FTP URL:	~
O Skip SCE Application Software Installation	
< <u>B</u> ack <u>N</u> ext > <u>Einish</u>	Cancel

Step 6 In the Protocol Pack (SPQI) Update pane (see Figure 7), check Skip Protocol Pack Update and click Next.



If you install the protocol pack during the upgrade, it must be the same version or a later version of the protocol pack you are upgrading from.

Figure 7 SCE Software Upgrade Wizard—Protocol Pack (SPQI) Update



Step 7 In the Service Configuration (PQB) Update pane (see Figure 8), check Apply the Default Service Configuration and click Next.

Figure 8 SCE Software Upgrade Wizard—Service Configuration (PQB) Update

¥ SCE Software Upgrade Wizard	
Service Configuration (PQB) Update Configure the PQB update options.	
 Apply the Current Service Configuration Apply the Default Service Configuration Apply a Service Configuration from a Local File 	
File name:	Browse
< Back Next > Finish	Cancel

- **Step 8** The Connectivity Test pane of the SCE Software Upgrade Wizard is displayed (see Figure 9). Click Next.
 - Note If a connection to one or more devices cannot be made, or if there is a problem with the connection (such as invalid version of the device), an error is displayed next to the device. (You can skip these tests by clicking Skip connectivity test). The connections are validated when you click Finish.

Figure 9 Connectivity Test

¥ SCE	Software Upg	rade Wizard				
Connectivity Test All connectivity tests have passed.						
The wizard will now test the connectivity to the devices that you specified, to verify that correct IP addresses, usernames and passwords were used. Please wait for the connectivity test to complete. In case of an error, you may use the 'Back' button to go back to previous steps and correct the IP addresses, usernames or passwords, if necessary. You may also choose to skip or retry the connectivity test using the buttons below.						
Туре	IP Address	Status				
	10.78.242.49					
(Skip co	onnectivity test	Retry connectivity test)			
		< Back N	ext > Finish	Cancel		

- **Step 9** The Summary pane summarizes all the information (see Figure 10). Verify that all the IP addresses and file locations are correct. In this pane, you can:
 - Click **Back** to edit any information.
 - Click Finish to begin the upgrade process as specified.

Figure 10 SCE Software Upgrade Wizard—Summary

🗲 SCE Software Upgrade Wizard	
Summary Page	
The following upgrade process will take place when you click the 'Finish' button: SCE platforms participating in the process: 10.78.248.168 SCE Firmware: C:\simba_05000543_K9.pkg (local file system) SCE Application Software: C:\sca-bb-agents-5.0.0-32\SCE10000\en50032.pqi (local file system) Protocol Pack: Skipped Service Configuration: Keep current configuration	×
< <u>Back</u> Next > <u>Finish</u>	Cancel

This system checks the following:

- The specified SCE platforms can be located by supplied IP addresses.
- If the PKG and/or PQI files are located at the remote FTP server, its availability is verified.
- Supplied credentials are valid for all SCE platforms.
- Specified PKG, PQI, PP, and PQB versions comply.

If the user requested that any of these components not be upgraded (selected **Skip** for any file), the version of those files is retrieved from SCE platform for this verification. For instance, if the user requested to skip PKG installation and install PQI Version 3.6.0, version information about the installed PKG file is retrieved.

A list of all problems and errors is displayed when the verification process is complete.

The basic steps being performed during the upgrade are as follows (assuming all components are upgraded):

- Retrieve the current service configuration from the SCE platform (only if the current service configuration is going to be reinstalled after the upgrade).
- Uninstall the existing application software (PQI).
- Upgrade SCE platform firmware (PKG).
- Install application software (PQI).
- Apply service configuration (PQB).
- Install the protocol pack (SPQI).

The specified SCE platforms are upgraded simultaneously, with the upgrade process for each SCE platform running in separate thread.

Step 10 The system keeps you informed of the progress of the upgrade (see Figure 11).

Click Run in Background to run the upgrade in the background.

Figure 11 Main SCE Software Upgrade Task

¥ Main SCE Software Upgrade Task 📃 🗖 🗙	
Waiting for SCE upgrade tasks to complete	
	L
Always run in background Run in Background Cancel Details >>	070070

The upgrade runs in the background (see Figure 12).

Figure 12 Network Navigator

🗚 Network Navigator - SCA BB Console			
ile Tools Window Help			
🔢 🗄 💼 Send Report by E-MAIL			
📸 🔲 Network Navigator			
Network Navigator 🕄 💦 🕹	r 🗖 🗖 Properties 🕱		
Image: Image: Image: Image: <td< th=""><th>Property ProgressWiew 83 Main SCE Software Upgrade Tas Walting for SCE upgrade tasks t Upgrading SCE at 10.56.216.12 Apply policy</th><th>Value Value</th><th></th></td<>	Property ProgressWiew 83 Main SCE Software Upgrade Tas Walting for SCE upgrade tasks t Upgrading SCE at 10.56.216.12 Apply policy	Value Value	
🖳 Console 🕱			🔓 🛃 🛃 - 👩 • 🦳 🕻
Console			
+ 11/10/08 2:01:31 PM GMT INFO Reading Sct platform data + 11/10/08 2:01:31 PM GMT INFO Sending configuration scrip + 11/10/08 2:01:36 PM GMT INFO Executing configuration scrip	ot for SCE2000 - 4xGBE		
S.			26

6 Upgrade Procedure Limitations

This chapter provides details of limitations to the Cisco Service Control solution upgrade procedure.

SCE Platform

Link Downtime Because of LIC Re-Burning

Link downtime is expected during SCE platform upgrade (the LIC chip firmware is reburned). The expected downtime depends on the auto-negotiation configuration of the system, and can be up to one minute.

Misclassification of Flows Initiated Before Upgrade Completion

Flows that were initiated before upgrade completion can be misclassified. Gradual classification restoration is expected when SCE software upgrade is completed, or when a standby SCE becomes active. This reclassification is needed because the previous classification decision of the flow is lost. This reclassification would usually be inaccurate because an accurate classification depends on analyzing the beginning of the flow. Therefore, the flow would usually be reclassified according to the corresponding Generic or Behavioral signature. This downtime ends when all these reclassified flows are closed.

Service Downtime

Service downtime is expected during SCE platform upgrade on non-high-availability setups and on high-availability setups.

- On non-high-availability setups, the SCE platform does not perform traffic classification, reporting, and control during the SCE platform upgrade. These capabilities are restored after upgrade completion (restoration is gradual, due to misclassification of traffic flows that were initiated before upgrade completion). See the "Misclassification of Flows Initiated Before Upgrade Completion" section on page 29 for further information.
- On high-availability setups, service downtime is not expected (as the cascaded SCE platforms alternate on upgrade), except for gradual service buildup when switching SCE platforms because of misclassification of traffic flows that were initiated before upgrade completion. See the "Misclassification of Flows Initiated Before Upgrade Completion" section on page 29 for further information.

Loss of Aggregated Unreported Data

During SCE platform upgrade, subscriber quota and usage information maintained in the SCE platform that was not reported to a collection system is lost. Depending on the system data export frequency (configurable through periods between RDRs of all sorts), the amount of such information can be kept to a minimum.

This is true also for high-availability configurations.

Loss of Configuration

Any non-default assignments of RDR tags to categories are lost when upgrading; the default mapping is restored after the upgrade. If any non-default assignments were made, you should reconfigure them manually after the upgrade.

SCA BB Clients and Service Configuration

SCA BB Console, which incorporates the service configuration editor and Subscriber Manager GUI is not backward compatible and can work only with the 4.1.x system components (SCE platform, Collection Manager, and Subscriber Manager).

Cisco SCA BB Console Interoperability

Version 4.1.x of the Network Navigator cannot apply service configurations to earlier versions of the SCE platforms. Nevertheless, the Network Navigator 4.1.x can upgrade the SCE platform to 4.1.x, and then service configurations can be applied.

Subscriber Manager

In non-High Availability Subscriber Manager setups, the SM upgrade procedure causes downtime for subscriber provisioning and subscriber status awareness (LEG communication).

Quota Manager

If the Quota Manager is not deployed as a cluster, service downtime is expected. This downtime is the same service downtime that is expected during a Subscriber Manager upgrade.

Collection Manager

Upgrading the Collection Manager imposes downtime for the upgraded machine during the entire process. To avoid data collection downtime, an alternate Collection Manager can be used.

The SCE platform supports sending RDRs to an alternate Collection Manager.

Configuration

When upgrading the Collection Manager to Version 5.0.x, the user configuration on the Collection Manager server (the PRPC users file, prpc.usr) is deleted. It is necessary to redefine the users after the upgrade is completed.

7 Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS Version 2.0.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

© 2014 Cisco Systems, Inc. All rights reserved



Americas Headquarters Cisco Systems, Inc. San Jose, CA Asia Pacific Headquarters Cisco Systems (USA) Pte. Ltd. Singapore Europe Headquarters Cisco Systems International BV Amsterdam, The Netherlands

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco Website at www.cisco.com/go/offices.

Printed in the USA on recycled paper containing 10% postconsumer waste.