



# Segment Routing with IS-IS Protocol

- [About IS-IS, on page 1](#)
- [Configuring Segment Routing with IS-IS Protocol, on page 1](#)

## About IS-IS

IS-IS is an Interior Gateway Protocol (IGP) based on Standardization (ISO)/International Engineering Consortium (IEC) 10589 and RFC 1995. Cisco NX-OS supports Internet Protocol version 4 (IPv4) and IPv6. IS-IS is a dynamic link-state routing protocol that can detect changes in the network topology and calculate loop-free routes to other nodes in the network. Each router maintains a link-state database that describes the state of the network and sends packets on every configured link to discover neighbors. IS-IS floods the link-state information across the network to each neighbor. The router also sends advertisements and updates on the link-state database through all the existing neighbors

Segment routing on the IS-IS protocol supports the following:

- IPv4
- Level 1, level 2, and multi-level routing
- Prefix SIDs
- Multiple IS-IS instances on the same loopback interface for domain border nodes
- Adjacency SIDs for adjacencies

## Configuring Segment Routing with IS-IS Protocol

You can configure segment routing with IS-IS protocol.

### Before you begin

IS-IS segment routing is fully enabled when the following conditions are met:

- The **mpls segment-routing** feature is enabled.
- The IS-IS feature is enabled.
- Segment routing is enabled for at least one address family under IS-IS.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	<b>configure terminal</b>	Enters global configuration mode.
<b>Step 2</b>	<b>router isis <i>instance-tag</i></b>	Creates a new IS-IS instance with the configured instance tag.
<b>Step 3</b>	<b>net <i>network-entity-title</i></b>	Configures the NET for this IS-IS instance.
<b>Step 4</b>	<b>address-family <i>ipv4</i> unicast</b>	Enters address family configuration mode.
<b>Step 5</b>	<b>segment-routing mpls</b>	Configures segment routing with IS-IS protocol.  <b>Note</b> <ul style="list-style-type: none"> <li>• The IS-IS command is supported only on the IPv4 address family. It is not supported on the IPv6 address family.</li> <li>• Redistribution is not supported from any other protocol to ISIS for the SR prefixes. You need to enable <b>ip router isis</b> command on all the prefix SID interfaces.</li> </ul>