



DSP Operational State Notifications

Last Updated: October 10, 2011

The DSP Operational State Notifications feature enables notifications to be generated when digital signaling processor (DSP) failure and recovery events occur. These notifications help facilitate troubleshooting and lessen downtime.

This feature module describes updates to the Cisco DSP Management MIB (CISCO-DSP-MGMT-MIB) for enabling and generating DSP operational state notifications. Also described is how to enable the feature either using the command-line interface (CLI) or by modifying settings at the network management device.

- [Finding Feature Information, page 1](#)
- [Prerequisites for DSP Operational State Notifications, page 1](#)
- [Information About DSP Operational State Notifications, page 2](#)
- [How to Enable DSP Operational State Notifications, page 2](#)
- [Configuration Examples for DSP Operational State Notifications, page 4](#)
- [Additional References, page 5](#)
- [Feature Information for DSP Operational State Notifications, page 5](#)

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest feature information and caveats, see the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the Feature Information Table at the end of this document.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Prerequisites for DSP Operational State Notifications

- Familiarity with the CISCO-DSP-MGMT-MIB and Simple Network Management Protocol (SNMP).



Americas Headquarters:
Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

Information About DSP Operational State Notifications

To enable DSP operational state notifications when a DSP fails and when it recovers, you should understand the following concepts:

- [CISCO-DSP-MGMT-MIB, page 2](#)
- [DSP Operational State Notification, page 2](#)
- [Benefits of DSP Operational State Notifications, page 2](#)

CISCO-DSP-MGMT-MIB

The CISCO-DSP-MGMT-MIB monitors DSP resources and status.

DSP Operational State Notification

A DSP notification consists of a DSP ID that indicates which DSP is affected and an operational state that indicates whether the DSP has failed or recovered.

When this feature is configured using the **snmp-server enable traps dsp oper-state** command, a notification is generated when a single DSP fails instead of after all DSPs have failed. For example, a DSP fails, and you lose your voice calls. In a DSP failure notification, the problem is identified. If no DSP failure notification is generated, a network management station (NMS) has to poll the router for configuration and status information to diagnose the problem.

Benefits of DSP Operational State Notifications

The DSP Operational State Notifications feature enables the generation of notifications when DSP failure and recovery events occur. These notifications help facilitate troubleshooting and lessen downtime because an NMS does not have to poll the router for configuration and status information to diagnose the problem..

How to Enable DSP Operational State Notifications

DSP operational state notifications can be configured in two ways. To configure these notifications, perform one of the following tasks:

- [Enabling DSP Operational State Notifications from the CLI, page 2](#)
- [Enabling DSP Operational State Notifications Using an SNMP Application, page 3](#)

Enabling DSP Operational State Notifications from the CLI

Perform this task to enable DSP operational state notifications from the CLI.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **snmp-server enable traps** [*notification-type*][**vrrp**]
4. **end**
5. **exit**

DETAILED STEPS

Command or Action	Purpose
Step 1 enable Example: <pre>Router> enable</pre>	Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted.
Step 2 configure terminal Example: <pre>Router# configure terminal</pre>	Enters global configuration mode.
Step 3 snmp-server enable traps [<i>notification-type</i>][vrrp] Example: <pre>Router(config)# snmp-server enable traps dsp oper-state</pre>	Enables the generation of DSP notifications made up of the DSP ID that indicates which DSP is affected and the operational state that indicates whether the DSP has failed or recovered.
Step 4 end Example: <pre>Router(config)# end</pre>	Returns the device to privileged EXEC mode.
Step 5 exit Example: <pre>Router# exit</pre>	Returns the device to user EXEC mode.

Enabling DSP Operational State Notifications Using an SNMP Application

Perform this task to enable DSP operational state notifications using your SNMP application.

SUMMARY STEPS

1. `setany -v2c 1.4.198.75 test cdspEnableOperStateNotification.0 -i 1`

DETAILED STEPS

```
setany -v2c 1.4.198.75 test cdspEnableOperStateNotification.0 -i 1
```

This SNMP command sets the enable operation state notification object identifier (OID) to true.

After entering this command, the system returns the following response: `cdspEnableOperStateNotification.0 = true(1)`.

Configuration Examples for DSP Operational State Notifications

- [Enabling DSP Operational State Notifications Using the CLI Example, page 4](#)
- [Enabling DSP Operational State Notifications Using an SNMP Application Example, page 4](#)

Enabling DSP Operational State Notifications Using the CLI Example

The following sample configuration code shows how to enable DSP operational state notifications using the CLI:

```
Router> enable
Router# configure terminal
Router(config)# snmp-server enable traps dsp oper-state
```

The following example shows a typical DSP failure notification:

```
*Jun 1 02:37:05.720:SNMP:V1 Trap, ent cdspMIBNotificationPrefix, addr 1.4.198.75, gentrap
6, spectrap 2
cdspOperState.37 = 2
entPhysicalEntry.7.37 = DSP (C549) 1/2/0
```

The following example shows a typical DSP recover notification:

```
*Jun 1 02:37:10.820:SNMP:V1 Trap, ent cdspMIBNotificationPrefix, addr 1.4.198.75, gentrap
6, spectrap 2
cdspOperState.37 = 1
entPhysicalEntry.7.37 = DSP (C549) 1/2/0
```

Enabling DSP Operational State Notifications Using an SNMP Application Example

The following sample configuration code shows how to enable DSP operational state notifications from your SNMP application:

In your SNMP application, you type the following command:

```
setany -v2c 1.4.198.75 test cdspEnableOperStateNotification.0 -i 1
```

The application shows the following response:

```
cdspEnableOperStateNotification.0 = true(1)
```

Additional References

The following sections provide references related to the DSP Operational State Notifications feature.

Related Documents

Related Topic	Document Title
Network management commands	<i>Cisco IOS Network Management Command Reference</i>

MIBs

MIB	MIBs Link
<ul style="list-style-type: none"> CISCO-DSP-MGMT-MIB CISCO-DSP-MGMT-CAPABILITY-MIB 	<p>To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL:</p> <p>http://www.cisco.com/go/mibs</p>

Technical Assistance

Description	Link
<p>The Cisco Support and Documentation website provides online resources to download documentation, software, and tools. Use these resources to install and configure the software and to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password.</p>	<p>http://www.cisco.com/cisco/web/support/index.html</p>

Feature Information for DSP Operational State Notifications

Table 1 **Feature Information for DSP Operational State Notifications**

Feature Name	Releases	Feature Information
DSP Operational State Notifications	12.4(4)T	The following command was modified: snmp-server enable traps

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at www.cisco.com/go/trademarks. Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1005R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2011 Cisco Systems, Inc. All rights reserved.