

Configuring IP SLAs DHCP Operations

Last Updated: July 18, 2011

This module describes how to configure an IP Service Level Agreements (SLAs) Dynamic Host Control Protocol (DHCP) operation to measure the response time between a Cisco device and a DHCP server to obtain an IP address.

- Finding Feature Information, page 1
- Information About IP SLAs DHCP Operations, page 1
- How to Configure IP SLAs DHCP Operations, page 2
- Configuration Examples for IP SLAs DHCP Operations, page 9
- Additional References, page 10
- Feature Information for IP SLAs DHCP Operations, page 11

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest feature information and caveats, see the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the Feature Information Table at the end of this document.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Information About IP SLAs DHCP Operations

- DHCP Operation, page 2
- IP SLAs DHCP Relay Agent Options, page 2

DHCP Operation

DHCP provides a mechanism for allocating IP addresses dynamically so that addresses can be reused when hosts no longer need them. The DHCP operation measures the round-trip time (RTT) taken to discover a DHCP server and obtain a leased IP address from it. IP SLAs releases the leased IP address after the operation.

You can use the RTT information to determine DHCP performance levels.

There are two modes for the DHCP operation. By default, the DHCP operation sends discovery packets on every available IP interface on the router. If a specific server is configured on the router, discovery packets are sent only to the specified DHCP server.

IP SLAs DHCP Relay Agent Options

A DHCP relay agent is any host that forwards DHCP packets between clients and servers. Relay agents are used to forward requests and replies between clients and servers when they are not on the same physical subnet. Relay agent forwarding is distinct from the normal forwarding of an IP router, where IP packets are switched between networks somewhat transparently. Relay agents receive DHCP messages and then generate a new DHCP message to send out on another interface.

The IP SLAs DHCP operation contains a relay agent information option--Option 82--which is inserted by the DHCP relay agent when forwarding client-originated DHCP packets to a DHCP server. Servers recognizing the relay agent information option may use the information to implement IP address or other parameter assignment policies. The DHCP server echoes the option back verbatim to the relay agent in server-to-client replies, and the relay agent strips the option before forwarding the reply to the client.

Option 82 includes three suboptions that convey information known by the relay agent:

- circuit-id --identifies the incoming circuit.
- remote-id --provides a trusted identifier for a remote high-speed modem.
- **subnet-mask** --identifies the mask of the logical IP subnet from which the relay agent received the client DHCP packet.

How to Configure IP SLAs DHCP Operations



There is no need to configure an IP SLAs responder on the destination device.

- Configuring a DHCP Operation on the Source Device, page 2
- Scheduling IP SLAs Operations, page 7

Configuring a DHCP Operation on the Source Device

Perform one of the following tasks:

- Configuring a Basic DHCP Operation, page 3
- Configuring a DHCP Operation with Optional Parameters, page 4

Configuring a Basic DHCP Operation

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- **3. ip sla** *operation-number*
- **4. dhcp** {destination-ip-address | destination-hostname} [**source-ip** {ip-address | hostname}] [**option-82** [**circuit-id** circuit-id] [**remote-id** remote-id] [**subnet-mask** subnet-mask]]
- **5. frequency** *seconds*
- **6. end**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
		Enter your password if prompted.
	Example:	
	Router> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Router# configure terminal	
Step 3	ip sla operation-number	Begins configuration for an IP SLAs operation and enters IP SLA configuration mode.
	Example:	
	Router(config)# ip sla 10	
Step 4	dhcp {destination-ip-address destination-hostname} [source-ip {ip-address hostname}] [option-82 [circuit-id circuit-id] [remote-id remote-id] [subnet-mask subnet-mask]]	Defines a DHCP operation and enters IP SLA DHCP configuration mode.
	Example:	
	Router(config-ip-sla)# dhcp 10.10.10.3	
Step 5	frequency seconds	(Optional) Sets the rate at which a specified IP SLAs operation repeats.
	Example:	
	Router(config-ip-sla-dhcp)# frequency 30	

	Command or Action	Purpose
Step 6	end	Exits to privileged EXEC mode.
	Example:	
	Router(config-ip-sla-dhcp)# end	

Configuring a DHCP Operation with Optional Parameters

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- **3. ip sla** *operation-number*
- **4. dhcp** { destination-ip-address | destination-hostname } [**source-ip** { ip-address | hostname }] [**option-82** [**circuit-id**] [**remote-id**] [**subnet-mask** subnet-mask]]
- 5. history buckets-kept size
- 6. history distributions-of-statistics-kept size
- 7. history enhanced [interval seconds] [buckets number-of-buckets]
- 8. history filter $\{none \mid all \mid overThreshold \mid failures\}$
- **9. frequency** *seconds*
- 10. history hours-of-statistics-kept hours
- 11. history lives-kept lives
- 12. owner owner-id
- 13. history statistics-distribution-interval milliseconds
- **14.** tag *text*
- 15. threshold milliseconds
- **16. timeout** *milliseconds*
- 17. end

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
		• Enter your password if prompted.
	Example:	
	Router> enable	

Command or Action	Purpose
configure terminal	Enters global configuration mode.
Example:	
Router# configure terminal	
ip sla operation-number	Begins configuration for an IP SLAs operation and enters IP SLA configuration mode.
Example:	
Router(config)# ip sla 10	
<pre>dhcp {destination-ip-address destination-hostname} [source- ip {ip-address hostname}] [option-82 [circuit-id circuit-id] [remote-id remote-id] [subnet-mask subnet-mask]]</pre>	Defines a DHCP operation and enters IP SLA DHCP configuration mode.
Example:	
Router(config-ip-sla)# dhcp 10.10.10.3 option-82 circuit-id 10005A6F1234	
history buckets-kept size	(Optional) Sets the number of history buckets that are kept during the lifetime of an IP SLAs operation.
Example:	
Router(config-ip-sla-dhcp)# history buckets-kept 25	
history distributions-of-statistics-kept size	(Optional) Sets the number of statistics distributions kept per hop during an IP SLAs operation.
Example:	
Router(config-ip-sla-dhcp)# history distributions-of-statistics-kept 5	
history enhanced [interval seconds] [buckets number-of-buckets]	(Optional) Enables enhanced history gathering for an IP SLAs operation.
Example:	
Router(config-ip-sla-dhcp)# history enhanced interval 900 buckets 100	
	configure terminal Example: Router# configure terminal ip sla operation-number Example: Router(config)# ip sla 10 dhcp {destination-ip-address destination-hostname} [source-ip {ip-address hostname}] [option-82 [circuit-id circuit-id] [remote-id remote-id] [subnet-mask subnet-mask]] Example: Router(config-ip-sla)# dhcp 10.10.10.3 option-82 circuit-id 10005A6F1234 history buckets-kept size Example: Router(config-ip-sla-dhcp)# history buckets-kept 25 history distributions-of-statistics-kept size Example: Router(config-ip-sla-dhcp)# history distributions-of-statistics-kept 5 history enhanced [interval seconds] [buckets number-of-buckets] Example: Router(config-ip-sla-dhcp)# history enhanced interval

	Command or Action	Purpose
Step 8	history filter {none all overThreshold failures}	(Optional) Defines the type of information kept in the history table for an IP SLAs operation.
	Example:	
	Router(config-ip-sla-dhcp)# history filter failures	
Step 9	frequency seconds	(Optional) Sets the rate at which a specified IP SLAs operation repeats.
	Example:	
	Router(config-ip-sla-dhcp)# frequency 30	
Step 10	history hours-of-statistics-kept hours	(Optional) Sets the number of hours for which statistics are maintained for an IP SLAs operation.
	Example:	
	Router(config-ip-sla-dhcp)# history hours-of- statistics-kept 4	
Step 11	history lives-kept lives	(Optional) Sets the number of lives maintained in the history table for an IP SLAs operation.
	Example:	
	Router(config-ip-sla-dhcp)# history lives-kept 5	
Step 12	owner owner-id	(Optional) Configures the Simple Network Management Protocol (SNMP) owner of an IP SLAs operation.
	Example:	
	Router(config-ip-sla-dhcp)# owner admin	
Step 13	history statistics-distribution-interval milliseconds	(Optional) Sets the time interval for each statistics distribution kept for an IP SLAs operation.
	Example:	
	Router(config-ip-sla-dhcp)# history statistics-distribution-interval 10	
Step 14	tag text	(Optional) Creates a user-specified identifier for an IP SLAs operation.
	Example:	
	Router(config-ip-sla-dhcp)# tag TelnetPollServer1	

	Command or Action	Purpose
Step 15	threshold milliseconds	(Optional) Sets the upper threshold value for calculating network monitoring statistics created by an IP SLAs operation.
	Example:	
	Router(config-ip-sla-dhcp)# threshold 10000	
Step 16	timeout milliseconds	(Optional) Sets the amount of time an IP SLAs operation waits for a response from its request packet.
	Example:	
	Router(config-ip-sla-dhcp)# timeout 10000	
Step 17	end	Exits to privileged EXEC mode.
	Example:	
	Router(config-ip-sla-dhcp)# end	

Scheduling IP SLAs Operations



- All IP SLAs operations to be scheduled must be already configured.
- The frequency of all operations scheduled in a multioperation group must be the same.
- List of one or more operation ID numbers to be added to a multioperation group is limited to a maximum of 125 characters, including commas (,).

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- **3.** Do one of the following:
 - ip sla schedule operation-number [life {forever | seconds}] [start-time {hh : mm[: ss] [month day | day month] | pending | now | after hh : mm : ss}] [ageout seconds] [recurring]
 - **ip sla group schedule** group-operation-number operation-id-numbers **schedule-period** schedule-period-range [**ageout** seconds] [**frequency** group-operation-frequency] [**life{forever** | seconds}] [**start-time**{hh:mm[:ss] [month day | day month] | **pending** | **now** | **after** hh:mm:ss}]
- 4. exit
- 5. show ip sla group schedule
- 6. show ip sla configuration

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
		Enter your password if prompted.
	Example:	
	Router> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Router# configure terminal	
Step 3	Do one of the following:	For individual IP SLAs operations only:
	 ip sla schedule operation-number [life {forever seconds}] [start-time {hh : mm[: ss] [month day day month] pending now after hh : mm : ss}] [ageout seconds] [recurring] ip sla group schedule group-operation-number operation-id-numbers schedule-period schedule-period-range [ageout seconds] [frequency group-operation-frequency] [life{forever seconds}] [start-time{hh:mm[:ss] [month day day month] pending now after hh:mm:ss}] Example: Example:	Configures the scheduling parameters for an individual IP SLAs operation. or For multioperation scheduler only: Specifies an IP SLAs operation group number and the range of operation numbers to be scheduled in global configuration mode.
	Example:	
	Router(config)# ip sla group schedule 1 3,4,6-9	
Step 4	exit	Exits to privileged EXEC mode.
	Example:	
	Router(config)# exit	
Step 5	show ip sla group schedule	(Optional) Displays the IP SLAs group schedule details.
	Example:	
	Router# show ip sla group schedule	

	Command or Action	Purpose
Step 6		(Optional) Displays the IP SLAs configuration details.
	Example:	
	Router# show ip sla configuration	

- Troubleshooting Tips, page 9
- What to Do Next, page 9

Troubleshooting Tips

- If the IP SLAs operation is not running and generating statistics, add the verify-data command to the
 configuration of the operation (while configuring in IP SLA configuration mode) to enable data
 verification. When enabled, each operation response is checked for corruption. Use the verify-data
 command with caution during normal operations because it generates unnecessary overhead.
- Use the **debugipsla trace** and **debug ip sla error** commands to help troubleshoot issues with an IP SLAs operation.

What to Do Next

To add proactive threshold conditions and reactive triggering for generating traps, or for starting another operation, to an IP SLAs operation, see the "Configuring Proactive Threshold Monitoring" section.

To view and interpret the results of an IP SLAs operation use the **show ip sla statistics** command. Checking the output for fields that correspond to criteria in your service level agreement will help you determine whether the service metrics are acceptable.

Configuration Examples for IP SLAs DHCP Operations

• Example Configuration for an IP SLAs DHCP Operation, page 9

Example Configuration for an IP SLAs DHCP Operation

In the following example, IP SLAs operation number 12 is configured as a DHCP operation enabled for DHCP server 172.16.20.3. Note that DHCP option 82 is used to specify the circuit ID.

Router B Configuration

```
ip dhcp-server 172.16.20.3
!
ip sla 12
dhcp 10.10.10.3 option-82 circuit-id 10005A6F1234
frequency 30
timeout 5000
tag DHCP_Test
!
ip sla schedule 12 start-time now
```

Additional References

Related Documents

Related Topic	Document Title
Cisco IOS commands	Cisco IOS Master Commands List, All Releases
Cisco IOS IP SLAs commands	Cisco IOS IP SLAs Command Reference
Cisco IOS IP SLAs: general information	Configuring IOS IP SLAs Overview chapter of the Cisco IP SLAs Configuration Guide.

Standards

Standards	Title
No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature.	

MIBs

MIBs	MIBs Link
CISCO-RTTMON-MIB	To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL:
	http://www.cisco.com/go/mibs

RFCs

RFCs	Title
No new or modified RFCs are supported by this feature, and support for existing RFCs has not been modified by this feature.	

Technical Assistance

Description	Link
The Cisco Support and Documentation website provides online resources to download documentation, software, and tools. Use these resources to install and configure the software and to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password.	http://www.cisco.com/cisco/web/support/index.html

Feature Information for IP SLAs DHCP Operations

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Table 1 Feature Information for IP SLAs DHCP Operations

Feature Name	Releases	Feature Information
IP SLAs DHCP Operation	12.2(31)SB2	The Cisco IOS IP SLAs Dynamic Host Control Protocol (DHCP) operation allows you to schedule and measure the network response time between a Cisco device and a DHCP server to obtain an IP address.
	12.2(33)SRB1	
	12.2(33)SXH	
	12.3(14)T	
	15.0(1)S	
	Cisco IOS XE 3.1.0SG	

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at www.cisco.com/go/trademarks. Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1005R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.