

Port-Shaper and LLQ in the Presence of EFPs

The Port-Shaper and LLQ in the Presence of EFPs feature allows network designers to configure port and class policies on ports that contain Ethernet Flow Points (EFPs). These policies support Low Latency Queueing (LLQ) and traffic prioritization across the EFPs.

- Finding Feature Information, on page 1
- Restrictions for Port-Shaper and LLQ in the Presence of EFPs, on page 1
- Information About Port-Shaper and LLQ in the Presence of EFPs, on page 2
- How to Configure Port-Shaper and LLQ in the Presence of EFPs, on page 2
- Configuration Examples for Port-Shaper and LLQ in the Presence of EFPs, on page 10
- Additional References, on page 12
- Feature Information for Port-Shaper and LLQ in the Presence of EFPs, on page 13

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest caveats and feature information, see Bug Search Tool and the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the feature information table.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Restrictions for Port-Shaper and LLQ in the Presence of EFPs

- If you configure port level shaper with the policy applied at EFP level then port shaper does not work. However, 3 level HQoS policy with port and logical shaper can be applied at the EFP level. Logical shaper configured at logical level does work but port shaper does not work.
- If you configure a class-based HQOS or LLQ policy on the port, you cannot configure service-policies on Ethernet Flow Points (EFPs). The only exception to this is the class-default shaper policy and match EFP policy.
- If you configure a class-based policy on the port, you cannot configure service-policies on EFPs.
- If you configure a class-default port-shaper based policy on the port, you can configure service-policy on EFPs.

• Usage of bandwidth remaining percentage (BRP) in the absence of priority class, allocates the available bandwidth in an iterative way. For example, the bandwidth is allocated for the first BRP class as per the percentage of share configured in the respective class-map and the remaining bandwidth is iteratively allocated to all other BRP classes until the bandwidth is exhausted.

Information About Port-Shaper and LLQ in the Presence of EFPs

Ethernet Flow Points and LLQ

An Ethernet Flow Point (EFP) is a forwarding decision point in the provider edge (PE) router, which gives network designers flexibility to make many Layer 2 flow decisions within the interface. Many EFPs can be configured on a single physical port. (The number varies from one device to another.) EFPs are the logical demarcation points of an Ethernet virtual connection (EVC) on an interface. An EVC that uses two or more User-Network Interfaces (UNIs) requires an EFP on the associated ingress and egress interfaces of every device that the EVC passes through.

The Egress HQoS with Port Level Shaping feature allows network designers to configure port and class policies on ports that contain EFPs. These policies support Low Latency Queueing (LLQ) and traffic prioritization across the EFPs.

For information on how to configure LLQ, see the QoS Congestion Management Configuration Guide.

How to Configure Port-Shaper and LLQ in the Presence of EFPs

To configure the Port-Shaper and LLQ in the Presence of EFPs feature, you first create either a hierarchical or flat policy map that supports Low Latency Queueing (LLQ), which you then attach to an EFP interface.

Configuring Hierarchical Policy Maps

To configure hierarchical policy maps, you create child policies which you then attach to a parent policy. The parent policy is then attached to an interface.

- 1. enable
- 2. configure terminal
- 3. policy-map policy-map-name
- 4. class class-map-name
- 5. set cos value
- 6. bandwidth percent percent
- 7. exit
- 8. class class-map-name
- 9. bandwidth percent percent
- **10**. exit
- **11.** policy-map policy-map-name
- 12. class class-default

13. service-policy *policy-map-name*

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Device> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 3	policy-map policy-map-name	Creates or modifies the child policy and enters QoS
	Example:	policy-map configuration mode.
	Device(config)# policy-map child-llq	child-llq is the name of the child policy map.
Step 4	class class-map-name	Assigns the traffic class you specify to the policy map and
	Example:	enters QoS policy-map class configuration mode.
	Device(config-pmap)# class precedenc-1	 precedenc-1 is the name of a previously configured class map and is the traffic class for which you want to define QoS actions.
Step 5	set cos value	(Optional) Sets the Layer 2 class of service (CoS) value
	Example:	of an outgoing packet.
	Device(config-pmap-c)# set cos 5	• The value is a specific IEEE 802.1Q CoS value from 0 to 7.
Step 6	bandwidth percent percent	(Optional) Specifies a bandwidth percent for class-level
	Example:	queues to be used during congestion to determine the amount of excess bandwidth (unused by priority traffic)
	Device(config-pmap-c)# bandwidth percent 20	to allocate to nonpriority queues.
Step 7	exit	Exits QoS policy-map class configuration mode.
	Example:	
	Device(config-pmap-c)# exit	
Step 8	class class-map-name	Assigns the traffic class you specify to the policy map and
	Example:	enters QoS policy-map class configuration mode.
	Device(config-pmap)# class precedenc-2	 precedenc-2 is the name of a previously configured class map and is the traffic class for which you want to define QoS actions.

	Command or Action	Purpose
		Note match on qos-group is supported on the Cisco RSP3 Module.
Step 9	<pre>bandwidth percent percent Example: Device(config-pmap-c) # bandwidth percent 80</pre>	(Optional) Specifies a bandwidth percent for class-level queues to be used during congestion to determine the amount of excess bandwidth (unused by priority traffic) to allocate to nonpriority queues.
Step 10	exit	Exits QoS policy-map class configuration mode.
	Example:	
	Device(config-pmap-c)# exit	
Step 11	policy-map policy-map-name	Creates or modifies the parent policy.
	Example:	• parent-llq is the name of the parent policy map.
	Device(config-pmap)# policy-map parent-llq	
Step 12	class class-default	Configures or modifies the parent class-default class and
	Example:	enters QoS policy-map class configuration mode.
	Device(config-pmap)# class class-default	You can configure only the class-default class in a parent policy. Do not configure any other traffic class.
Step 13	service-policy policy-map-name	Applies the child policy to the parent class-default class.
	Example:	• child-llq is the name of the child policy map configured in step 1.
	Device(config-pmap-c)# service-policy child-llq	

Configuring Class-default Port-Shaper Policy Maps

To configure hierarchical policy maps, first create the child policies and then attach it to a parent policy. The parent policy must be attached to an interface.

- 1. enable
- 2. configure terminal
- 3. policy-map policy-map-name
- 4. class class-default
- **5. shape-average** *shape-value*
- 6. exit

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Device> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 3	policy-map policy-map-name	Creates or modifies the child policy and enters QoS
	Example:	policy-map configuration mode.
	Device(config)# policy-map child-llq	child-llq is the name of the child policy map.
Step 4	class class-default	Configures or modifies the parent class-default class and
	Example:	enters QoS policy-map class configuration mode.
	Device(config-pmap)# class class-default	You can configure only the class-default class in a parent policy. Do not configure any other traffic class.
Step 5	shape-average shape-value	Configures a shape entity with a Comitted Information Rate
	Example:	of 200 Mb/s.
	Device(config-pmap-c)#shape average 200000000	
Step 6	exit	Exits QoS policy-map class configuration mode.
	Example:	
	Device(config-pmap-c)# exit	

Configuring Port-Shaper Policy Maps

- 1. enable
- 2. configure terminal
- 3. policy-map policy-map-name
- 4. class class-default
- **5. shape-average** *shape-value*
- **6. service-policy** *policy-map-name*

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Device> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 3	policy-map policy-map-name	Creates or modifies the child policy and enters QoS
	Example:	policy-map configuration mode.
	Device(config)# policy-map def	
Step 4	class class-default	Assigns the traffic class you specify to the policy map
	Example:	enters QoS policy-map class configuration mode.
	Device(config-pmap)# class class-default	
Step 5	shape-average shape-value	Configures a shape entity with a Comitted Information Ra of 200 Mb/s.
	Example:	
	Device(config-pmap-c)#shape average 200000000	
Step 6	service-policy policy-map-name	Applies the child policy to the parent class-default class.
	Example:	 child-llq is the name of the child policy map configured in Configuring Class-default Port-Shaper Policy Maps,
	Device(config-pmap-c)# service-policy child-llq	on page 4.

Configuring an LLQ Policy Map

- 1. enable
- 2. configure terminal
- 3. policy-map policy-map-name
- 4. class class-map-name
- 5. priority
- 6. exit
- 7. class class-map-name
- 8. shape average value
- 9. exit

- 10. class class-map-name
- 11. bandwidth percent
- **12**. exit

Enables privileged EXEC mode. • Enter your password if prompted.
• Enter your password if prompted
Enter your password it prompted.
Enters global configuration mode.
Creates a policy and enters QoS policy-map configuration
mode.
Assigns the traffic class you specify to the policy map and
enters policy-map class configuration mode.
Configures LLQ, providing strict priority queueing (PQ)
for class-based weighted fair queueing (CBWFQ).
Exits QoS policy-map class configuration mode.
Assigns the traffic class you specify to the policy map and
enters QoS policy-map class configuration mode.
Configures a shape entity with a Comitted Information
Rate of 200 Mb/s.
200000000

	Command or Action	Purpose
Step 9	exit	Exits QoS policy-map class configuration mode.
	Example:	
	Device(config-pmap-c)# exit	
Step 10	class class-map-name	Assigns the traffic class you specify to the policy map and
	Example:	enters QoS policy-map class configuration mode.
	Device(config-pmap)# class dscp-af3	
Step 11	bandwidth percent	(Optional) Specifies a bandwidth percent for class-leve
	Example:	queues to be used during congestion to determine the amount of excess bandwidth (unused by priority traffic)
	Device(config-pmap-c)# bandwidth 4000000	to allocate to non-priority queues.
Step 12	exit	Exits QoS policy-map class configuration mode.
	Example:	
	Device(config-pmap-c)# exit	

Configuring Port Level Shaping on the Main Interface with Ethernet Flow Points

To configure port level shaping on the main interface with EFPS, first you enable the autonegotiation protocol on the interface, then you attach a policy map to the interface and finally you configure the Ethernet service instance.

- 1. enable
- 2. configure terminal
- **3. interface** *type number*
- 4. no ip address
- 5. negotiation auto
- **6. service-policy output** *policy-map-name*
- **7.** service instance *id* ethernet
- 8. encapsulation dot1q vlan-id
- **9. bridge-domain** *bridge-domain-id*
- 10. exit
- 11. service instance id ethernet
- 12. encapsulation dot1q vlan-id
- 13. bridge-domain bridge-domain-id
- 14. exit
- **15**. end

	Command or Action	Purpose	
Step 1	enable	Enables privileged EXEC mode.	
	Example:	• Enter your password if prompted.	
	Device> enable		
Step 2	configure terminal	Enters global configuration mode.	
	Example:		
	Device# configure terminal		
Step 3	interface type number	Configures an interface type and enters interface	
	Example:	configuration mode.	
	Device(config)# interface GigabitEthernet 0/0/1	Enter the interface type number.	
Step 4	no ip address	Disables IP routing on the interface.	
	Example:		
	Device(config-if)# no ip address		
Step 5	negotiation auto	Enables the autonegotiation protocol to configure the	
	Example:	speed, duplex, and automatic flow control of the Gigabit Ethernet interface.	
	Device(config-if)# negotiation auto		
Step 6	service-policy output policy-map-name	Specifies the name of the policy map to be attached to the input or output direction of the interface.	
	Example:	You can enter the name of a hierarchical or a flat	
	Device(config-if)# service-policy output parent-llq	policy map.	
Step 7	service instance id ethernet	Configures an Ethernet service instance on an interfact and enters service instance configuration mode.	
	Example:		
	Device(config-if)# service instance 1 ethernet		
Step 8	encapsulation dot1q vlan-id	Defines the matching criteria to map 802.1Q frames'	
	Example:	ingress on an interface to the service instance.	
	Device(config-if-srv)# encapsulation dot1q 100		
Step 9	bridge-domain bridge-domain-id	Binds the bridge domain to the service instance.	
	Example:		
	Device(config-if-srv)# bridge-domain 100		

	Command or Action	Purpose
Step 10	exit	Exits service instance configuration mode.
	Example:	
	Device(config-if-serv)# exit	
Step 11	service instance id ethernet	Configures an Ethernet service instance on an interface
	Example:	and enters service instance configuration mode.
	Device(config-if)# service instance 2 ethernet	
Step 12	encapsulation dot1q vlan-id	Defines the matching criteria to map 802.1Q frames'
	Example:	ingress on an interface to the service instance.
	Device(config-if-srv)# encapsulation dot1q 101	
Step 13	bridge-domain bridge-domain-id	Binds the bridge domain to the service instance.
	Example:	
	Device(config-if-srv)# bridge-domain 101	
Step 14	exit	Exits QoS policy-map class configuration mode.
	Example:	
	Device(config-if-srv)# exit	
Step 15	end	(Optional) Exits interface configuration mode.
	Example:	
	Device(config-if)# end	

Configuration Examples for Port-Shaper and LLQ in the Presence of EFPs

Example: Configuring Hierarchical QoS Port Level Shaping on the Main Interface with EFPs

The following example shows how to configure hierarchical QoS port level shaping on a main physical interface to support traffic prioritization and Low Level Queueing across all EFPs configured on the interface:

policy-map parent-llq
 class class-default
 service-policy child-llq

```
policy-map child-llq
class precedenc-1
 set cos 5
 bandwidth percent 20
 class precedenc-2
 bandwidth percent 80
interface GigabitEthernet 0/0/1
no ip address
negotiation auto
 service-policy output parent-llq
 service instance 1 ethernet
 encapsulation dot1q 100
 bridge-domain 100
 service instance 2 ethernet
  encapsulation dot1q 101
 bridge-domain 101
```



Note

Only match EFP and match qos-group is supported on RSP3 in egress policy map.

Configuration Example: Class-default Port-Shaper and EFP policy

The following example shows how to configure class-default port-shaper and EFP policy, where the main interface can have the class-default shaper policy and EFP can have the HQOS policies.

```
policy-map co12
class class-default
shape average 50m
policy-map def
class class-default
shape average 500m
service-policy co12
```

Example: Configuring Port Level Shaping on the Main Interface with EFPs

The following example shows how to configure port level shaping on a main physical interface to support traffic prioritization and Low Level Queueing across all Ethernet Flow Points (EFPs) configured on the interface:

```
policy-map llq_flat
  class dscp-af1
  priority
  class dscp-af2
  shape average 200000000
  class dscp-af3
  bandwidth 400000

interface GigabitEthernet 0/0/1
```

```
no ip address
negotiation auto
service-policy output llq_flat
service instance 1 ethernet
encapsulation dotlq 100
bridge-domain 100
!
service instance 2 ethernet
encapsulation dotlq 101
bridge-domain 101
```

Additional References

Related Documents

Related Topic	Document Title
Cisco IOS commands	Cisco IOS Master Commands List, All Releases
QoS commands: complete command syntax, command modes, command history, defaults, usage guidelines, and examples	Cisco IOS QoS Command Reference
Policing and shaping	"Policing and Shaping Overview" module
Class maps	"Applying QoS Features Using the MQC" module
Policy maps	"Applying QoS Features Using the MQC" module
Low Latency Queueing	QoS Congestion Management Configuration Guide

Standards and RFCs

Standard	Title
No new or modified standards are supported, and support for existing standards has not been modified.	

MIBs

MIB	MIBs Link
No new or modified MIBs are supported, and support for existing MIBs has not been modified.	To locate and download MIBs for selected platforms, Cisco IOS XE software releases, and feature sets, use Cisco MIB Locator found at the following URL: http://www.cisco.com/go/mibs

Technical Assistance

Description	Link
The Cisco Support and Documentation website provides online resources to download documentation, software, and tools. Use these resources to install and configure the software and to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password.	

Feature Information for Port-Shaper and LLQ in the Presence of EFPs

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Table 1: Feature Information for Port-Shaper and LLQ in the Presence of EFPs

Feature Name	Releases	Feature Information
Port-Shaper and LLQ in the Presence of EFPs	Cisco IOS Release XE 3.6S	The Port-Shaper and LLQ in the Presence of EFPs feature provides support for LLQ and traffic prioritization across all EFPs on a port. In Cisco IOS XE Release 3.6S, support was added for the Cisco ASR 903 router.

Feature Information for Port-Shaper and LLQ in the Presence of EFPs