



Configuring RTP Media Loopback for SIP Calls

Last Updated: December 20, 2011

RTP packets are looped back toward the source device when the RTP Media Loopback for SIP Calls feature is configured on a dial peer. The SIP RTP media loopback can be used during Cisco UBE deployments to make test calls to verify the media path between the endpoints and Cisco UBE. In a voice loopback call, an echo is heard at the device originating the call. In a video loopback call, the locally captured video and the audio echo must be rendered at the source device.

Media packets must be enabled to pass through the gateway. Use the **media flow-through** command in dial peer voice or voice service configuration mode to enable the media packets.

Cisco Unified Border Element

- Cisco IOS Release 15.1(4)M or a later release must be installed and running on your Cisco Unified Border Element.

Cisco Unified Border Element (Enterprise)

- Cisco IOS XE Release 3.3S or a later release must be installed and running on your Cisco ASR 1000 Series Router.



Note

- SRTP, DTLS, and STUN are not supported in loopback mode.
- Fax (midcall transmit function change) is not supported.
- RSVP is not supported.
- Call transfer is not supported.

>



Americas Headquarters:
Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **dial-peer voice *tag* voip**
4. **destination-pattern *string***
5. **session protocol sipv2**
6. **session target loopback:rtp**
7. **incoming called-number *string***
8. **exit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	dial-peer voice <i>tag</i> voip Example: Router(config)# dial-peer voice 77 voip	Specifies that the dial peer is a VoIP peer and enters dial peer voice configuration mode.
Step 4	destination-pattern <i>string</i> Example: Router(config-dial-peer)# destination-pattern 77	Specifies the prefix or the full E.164 number for the dial peer.
Step 5	session protocol sipv2 Example: Router(config-dial-peer)# session protocol sipv2	Specifies the session protocol for calls with the SIP option.

	Command or Action	Purpose
Step 6	session target loopback:rtp Example: <pre>Router(config-dial-peer)# session target loopback:rtp</pre>	Designates a network-specific address to receive calls from a VoIP dial peer and configures all voice data to loop back to the source.
Step 7	incoming called-number <i>string</i> Example: <pre>Router(config-dial-peer)# incoming called-number 77</pre>	Specifies a digit string that can be matched by an incoming call to associate the call with the dial peer.
Step 8	exit Example: <pre>Router(config-dial-peer)# exit</pre>	Exits dial peer voice configuration mode and enters global configuration mode.

- [Finding Feature Information, page 3](#)
- [Configuration Examples for RTP Media Loopback, page 3](#)
- [Feature Information for RTP Media Loopback for SIP Calls, page 4](#)

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest feature information and caveats, see the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the Feature Information Table at the end of this document.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Configuration Examples for RTP Media Loopback

- [Example Configuring Video Loopback with Cisco Telepresence System, page 3](#)
- [Example Configuring Video Loopback with Cisco Unified Video Advantage, page 4](#)

Example Configuring Video Loopback with Cisco Telepresence System

The following sample output shows Media Loopback for SIP Calls configured on a Cisco Telepresence System (CTS).

!

```

codec profile 1 aacld
  fmp "fmp:96 profile-level-
id=16;streamtype=5;mode=AACHbr;config=B98C00;sizeLength=13;indexLength=3;indexDeltaLength=
3;constantDura
tion=480"
!
codec profile 2 h264
  fmp "fmp:112 profile-level-id=4D0028;sprop-parametersets=
R00AKAmWUgDwBDyA,SGE7jyA=;packetization-mode=1"
!
voice class codec 4
  codec preference 1 aacld profile 1
  video codec h264 profile 2
!
dial-peer voice 2000 voip
  destination-pattern 2000
  rtp payload-type cisco-codec-fax-ind 110
  rtp payload-type cisco-codec-aacld 96
  rtp payload-type cisco-codec-video-h264 112
  session protocol sipv2
  session target loopback:rtp
  incoming called-number 2000
  voice-class codec 4
  voice-class sip bandwidth audio tias-modifier 64000
  voice-class sip bandwidth video tias-modifier 4500000
!

```

Example Configuring Video Loopback with Cisco Unified Video Advantage

The following sample output shows Media Loopback for SIP Calls configured on a Cisco Unified Video Advantage (CUVA).

```

!
codec profile 3 h264
  fmp "fmp:98 profile-level-id=420015"
!
voice class codec 6
  codec preference 1 g711ulaw
  video codec h264 profile 3
!
dial-peer voice 5000 voip
  description CUVA
  destination-pattern 5000
  rtp payload-type cisco-codec-video-h264 98
  session protocol sipv2
  session target loopback:rtp
  incoming called-number 5000
  voice-class codec 6
  voice-class sip bandwidth video tias-modifier 384000
!

```

Feature Information for RTP Media Loopback for SIP Calls

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Feature History Table entry for the Cisco Unified Border Element.

Table 1 *Feature Information for RTP Media Loopback for SIP Calls*

Feature Name	Releases	Feature Information
RTP Media Loopback for SIP Calls	15.1(4)M	<p>RTP packets are looped back toward the source when the RTP Media Loopback for SIP Calls feature is configured on a dial peer. SIP RTP media loopback helps in verifying the media path between the device originating the call and the intermediate device.</p> <p>The following commands were introduced or modified: None.</p>

Feature History Table entry for the Cisco Unified Border Element (Enterprise).

Table 2 *Feature Information for RTP Media Loopback for SIP Calls*

Feature Name	Releases	Feature Information
RTP Media Loopback for SIP Calls	Cisco IOS XE Release 3.3S	<p>RTP packets are looped back toward the source when the RTP Media Loopback for SIP Calls feature is configured on a dial peer. SIP RTP media loopback helps in verifying the media path between the device originating the call and the intermediate device.</p> <p>The following commands were introduced or modified: None.</p>

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2011 Cisco Systems, Inc. All rights reserved.