

# **DOCSIS** Provisioning

This chapter describes the provisioning flow in a Prime Cable Provisioning DOCSIS deployment. It also provides information required before configuration and describes the available tools.

This chapter contains the following sections:

- DOCSIS Workflow, on page 1
- Prime Cable Provisioning Features for DOCSIS Configurations, on page 13

## **DOCSIS Workflow**

This section describes the provisioning workflow contained in the DOCSIS Provisioning Specification for DHCPv4 and DHCPv6.

- DOCSIS DHCPv4 Workflow, on page 1
- DOCSIS DHCPv6 Workflow, on page 6

### **DOCSIS DHCPv4 Workflow**

The following figure shows the provisioning workflow contained in the DOCSIS Provisioning Specification for DHCPv4. Each step is described subsequently.

Flow	CM/MTA	CMTS	DOCSIS DHCP	DOCSIS TFTP	DOCSIS ToD	Prov Server	PKT DHCP	PKT DNS	PKT TFTP	MSO KDC	SYSLOG
Start with	DOCSIS	1.1 Initializ	ation/Regi	stration							
CM-1		DHCP Br	oadcast Di	scover							
CM-2	-	DHCP O	ffer								
CM-3		DHCP R	equest								
CM-4	-	DHCP Ad	sk								
CM-5		DOCSIS	OCSIS 1.1 CM config file request								
CM-6	-	DOCSIS 1.1 config file									
CM-7		ToD Req	uest								
CM-8	-	ToD Res	ponse								
CM-9		CM regis	tration with	CMTS							D.
CM-10	<	CMTS R	egistration	ACK							12953

#### Figure 1: DOCSIS DHCPv4 Provisioning Flow

The following table describes the potential problems that can exist at various DOCSIS provisioning steps illustrated in Figure 1: DOCSIS DHCPv4 Provisioning Flow, on page 2.

### Table 1: DOCSIS DHCPv4 Workflow Description

Step	DOCSIS DHCPv4 Workflow	Potential Problems
CM <sup>1</sup> -1	DHCP Discover	

Step	DOCSIS DHCPv4 Workflow	Potential Problems
		• init(d) state
		• No addresses available
		Incorrect Prime Cable     Provisioning shared secret
		• Incorrectly configured Class of Service
		• DOCSIS template parsing errors (invalid option, include file - not found, and so on)
		Cisco Prime Network Registrar DHCP
		Incorrect DHCP configuration
		• DHCP server not there in provisioning group
		• No appropriate scopes defined (or do not match configuration in RDU)
		Prime Cable Provisioning Network Registrar Extension
		Network Registrar extension cannot contact DPEs
		• Network Registrar extension fails to find any DPEs in provisioning group
		Network Registrar extension cannot contact RDU
		• Network Registrar extension gets DPE cache miss, sends request to RDU
		RDU
		• Incorrect IP address of RDU
		Incorrect RDU port
		• RDU cannot be pinged from DPE
		• Configuration generation failing at RDU
		• RDU licenses exceeded, not

Step	DOCSIS DHCPv4 Workflow	Potential Problems
		configured
		• Device detection failing at RDU
		DPE
		• DPEs not assigned to provisioning group
		• DPEs cannot be pinged from the DHCP server
		• DPE interfaces not enabled for provisioning
CM-2	DHCP Offer	Routing issues between DHCP and the cable modem termination system (CMTS)
CM-3	DHCP Request	• init(i) state
		• DHCP server did not provide all required parameters
CM-4	DHCP Ack	
CM-5	TFTP Request	• Init(o) state
		Routing issues between CMTS     and DPE
		• No route from TFTP server (DPE) to modem
		• DPE cache miss (static file, and RDU down or does not have file)
		• File not found at TFTP server (DPE)
		• DPE cache miss (dynamic file)
		• DPE IP validation failure (for example, the IP address of the device is not what was expected, the Dynamic Shared Secret is enabled on CMTS, or a hacker is spoofing as a DOCSIS modem)

Step	DOCSIS DHCPv4 Workflow	Potential Problems
CM-6	TFTP Response	Routing issues between DPE and CMTS
CM-7	ToD Request	init(t) state - No route from time server (DPE) to modem
CM-8	ToD Response	
CM-9	CM registration with CMTS	<ul> <li>reject(m) - * CMTS shared secret mismatch with Prime Cable Provisioning or DPE DOCSIS shared secret</li> <li>reject(c) - * delivered incorrect DOCSIS configuration file (1.1 file to 1.0 cable modem)</li> </ul>
CM-10	CMTS registration Ack	Acceptable states are: • online • online(d) • online(pk) • online(pt)

<sup>1</sup> CM = cable modem

### **DOCSIS DHCPv6 Workflow**

The following figure shows the provisioning workflow contained in the DOCSIS Provisioning Specification for DHCPv6. Each step is described subsequently.



#### Figure 2: DOCSIS DHCPv6 Provisioning Flow

The DOCSIS provisioning workflow for DHCPv6 involves the cable modem establishing IPv6 connectivity, which includes assigning:

- Link-local address
- Default router
- IPv6 management address
- Other IPv6 configuration

The following table describes the potential problems that can exist at various DOCSIS provisioning steps illustrated in Figure 2: DOCSIS DHCPv6 Provisioning Flow, on page 7.

#### Table 2: DOCSIS DHCPv6 Workflow Description

Workflow	Description	Potential Problems		
Provisioning Phase: Link-local address assignment				

Workflow	Description	Potential Problems
The cable modem constructs an IPv (64-bit Extended Unique Identifier address of the interface.		
NS (DAD) The cable modem uses an NS (Neighbor Solicitation) message to perform duplicate address detection (DAD). DAD verifies if the constructed link-local address is already in use. If there is no response to the NS, the cable modem determines that the link-local address is not in use. If a response is returned, it implies that the link-local address, and the cable modem stops the provisioning process.		
Provisioning Phase: Router Disco	overy	
The cable modem uses router disco identify prefixes on a HFC link.	overy to find a default router and	
RS	The cable modem sends an RS (Router Solicitation) to the CMTS to trigger transmission of the periodic Router Advertisement message (RA).	
RA	<ul> <li>The CMTS router sends periodic RAs, each of which contains the:</li> <li>List of IPv6 prefixes assigned to the link</li> <li>Directive to use DHCPv6</li> <li>Availability of the CMTS router as the default router</li> </ul>	
Provisioning Phase: DHCPv6		

Workflow	Description	Potential Problems
Solicit	The cable modem sends a Solicit	• init6(s) state
	message to locate DHCP servers.	• No IPv6 addresses available
		Incorrect Prime Cable     Provisioning shared secret
		• Incorrectly configured Class of Service
		• DOCSIS template parsing errors (invalid option, include file - not found, and so on)
		Network Registrar DHCP
		Incorrect DHCPv6     configuration
		• DHCP server not there in provisioning group
		• No appropriate prefixes defined (or do not match Prime Cable Provisioning RDU configuration)

I

Workflow	Description	Potential Problems
Solicit	The cable modem sends a Solicit message to locate DHCP servers.	Prime Cable Provisioning Network Registrar Extension
(commuta)		Network Registrar extension cannot contact DPEs
		<ul> <li>Network Registrar extension fails to find IPv6 DPEs in provisioning group</li> </ul>
		• Network Registrar extension cannot contact RDU
		• Network Registrar extension gets DPE cache miss, sends request to RDU
		RDU
		• Incorrect IP address of RDU
		• Incorrect RDU port
		• RDU cannot be pinged from DPE
		• Configuration generation failing at RDU
		• RDU licenses exceeded, not configured
		• Device detection failing at RDU
		DPE
		• DPEs not assigned to provisioning group
		• DPEs cannot be pinged from DHCP server
		• DPE interfaces not enabled for IPv6 provisioning
		Provisioning group not enabled for IPv6 provisioning

Workflow	Description	Potential Problems
Relay-Forw	The relay agent forwards the complete DHCPv6 message received from the cable modem to the DHCPv6 server.	
	The relay agent adds relay agent message fields and options, such as:	
	Peer-address	
	• Link-address	
	• Interface ID	
Relay-Repl	The relay agent extracts the server response and forwards it to the cable modem, via the CMTS.	
Advertise	The DHCP server, in response to the Solicit message that it received from the cable modem, returns an Advertise message to indicate that it is available for DHCP service.	<ul> <li>init6(a) state</li> <li>Routing issues between DHCP and CMTS</li> </ul>
Request	On receiving the Advertise message, the cable modem sends a Request message to request configuration parameters, including IP addresses, from a specific server.	<ul> <li>init6(r) state</li> <li>DHCP server did not provide all required parameters</li> </ul>
Relay-Forw	The relay agent forwards the message to the DHCPv6 server.	
Relay-Repl	The relay agent extracts the server response and forwards it to the cable modem, via the CMTS.	
Reply	The CMTS forwards the REPLY message received from the DHCP server, containing assigned addresses and configuration parameters.	init6(i) state
Note DHCPv6 clients can be p two-message exchange, i involves a Solicit and a F Solicit–Advertise–Reque message if they go throu to a Solicit (that is wrapp Relay-Repl message). If (that is wrapped in a Rela	provisioned in the Rapid Commit mo instead of the usual four-message exce Reply, while the four-message exchans st-Reply. All these messages are wran gh a relay agent. If rapid commit is e bed in a Relay-Forw message) with a you disable rapid commit, the DHCP ay-Reply) message.	de. Rapid commit features a hange. The two-message exchange nge involves the oped in a Relay-Forw or Relay-Repl nabled, the DHCP server responds Reply (that is wrapped in a server responds with an Advertise

I

Workflow	Description	Potential Problems		
NS (DAD)	Once the DHCPv6 message exchange is complete, the cable modem confirms if the link-local address is not already in use via DAD. If it does not receive a response, then it deems the IP address acquisition to be successful.			
Provisioning Phase: ToD				
Request	After obtaining an IPv6 address, the cable modem requests the time of day from the REC 868 time	init6(t) state - No route from time server (DPE) to modem		
Response	server. The IPv6 addresses for servers are supplied through DHCPv6 options.			
<b>Provisioning Phase: TFTP</b>				
TFTP-Get TFTP RSP (config file)	The cable modem, using TFTP, downloads the configuration file. The IPv6 addresses for servers and the name of the configuration file are made available via DHCPv6.	<ul> <li>init6(o) state</li> <li>Routing issues between CMTS and DPE</li> <li>No route from TFTP server (DPE) to modem</li> <li>DPE cache miss (static file, and RDU down or does not have file)</li> <li>File not found at TFTP server (DPE)</li> <li>DPE cache miss (dynamic file)</li> <li>DPE lP validation failure (for example, the IP address of the device is not what was expected, the Dynamic Shared Secret is enabled on CMTS, or a hacker is spoofing as a DOCSIS modem)</li> <li>Routing issues between DPE and CMTS</li> </ul>		
	ad for IDr.( or another a			
The cable modem is now provisioned for IPv6 operations.				

## **Prime Cable Provisioning Features for DOCSIS Configurations**

This section describes Prime Cable Provisioning value-added features as they relate to the DOCSIS technology.

### **Dynamic Configuration TLVs**

The DPE adds the following TLVs (Type Length Value) when it receives a TFTP request for dynamic DOCSIS configuration:

- TLV 19: TFTP Server Timestamp (optional)—Displays in the Configure DOCSIS Defaults page as the TFTP Time Stamp Option. See Table 1 for more information. This TLV requires NTP synchronization on CMTS and DPE.
- TLV 20 and TLV 59: TFTP Server Provisioned Modem Address for IPv4 and IPv6 (optional)—Displays in the Configure DOCSIS Defaults page as the TFTP Modem Address Option. See Table 1 for more information.



**Note** The TFTP IP validation feature on the DPE is incompatible with the Cisco CMTS DSS feature. See DPE TFTP IP Validation, on page 14. If DSS is set on the Cisco CMTS, you must ensure that the TFTP Server Provisioned Modem Address is disabled.

In some cases, the CM might not accept the configuration and might stay in reject(IP) state. If it is the CMTS that acts as TFTP proxy, the DPE TLV 19/20 features must be disabled. This can be configured from the Admin UI.

The CMTS DSS feature is more effective at theft prevention than the CableLabs standard CabeLabs TLV 19/20 features.

- TLV 6: CM MIC Configuration Setting (required)
- TLV 7: CMTS MIC Configuration Setting (required)—Displays in the Configure DOCSIS Defaults page as the CMTS Shared Secret. See Table 1 for more information.
- TLV 43.6.x: Extended CMTS MIC Configuration Setting (required)—Displays in the Configure DOCSIS Defaults page as the CMTS Shared Secret. See Table 1 for more information.

**Note** When configuring CMTS MIC, note the following CMTS IOS release dependencies:

- DOCSIS 2.0 CMTS MIC requires CMTS IOS 12.3BC when including TLV 39 or TLV 40.
- Certain CMTS IOS commands are assumed to be configured by Prime Cable Provisioning:
  - ip dhcp relay information option
  - no ip dhcp relay information check
  - cable helper-address x.x.x.x. x.x.x.x is the IP address of the Network Registrar DHCP server.

In an IPv6 environment, you must use the following command instead of **cable helper-address**: **ipv6 dhcp relay destination** *ipv6-address* [*interface-type interface-number*]

• cable dhcp-giaddr primary

### **DPE TFTP IP Validation**

For dynamic configuration files, the DPE TFTP server verifies if the IP address of the TFTP client matches the expected DOCSIS cable modem IP address. If it does not match, the request is dropped. This feature is incompatible with the Cisco CMTS DMIC feature.

Use the **no service tftp** *1..1* **ipv6 verify-ip** command to disable the verification of requestor IP addresses on dynamic configuration TFTP requests. For detailed information, see the Cisco Prime Cable Provisioning 6.1.3 DPE CLI Reference Guide.

### Support for DOCSIS 1.0, 1.1, 2.0, 3.0, and 3.1

Prime Cable Provisioning supports DOCSIS 1.0, 1.1, 2.0, 3.0, and 3.1. For information describing the TLVs, see Template Grammar, and for a list of options that this Prime Cable Provisioning release supports in each DOCSIS version, see Technology Option Support.

### **Dynamic DOCSIS Version Selection**

Prime Cable Provisioning can detect a cable modem's DOCSIS version from an incoming DHCP request. It can also detect the DOCSIS version of the CMTS in one of two ways:

- By using the CMTS as a relay agent that transmits its DOCSIS version, using DHCPv4 Option 82 and DHCPv6 Option 17.
- From a customer-supplied source that provides a mapping of GIADDR to the CMTS DOCSIS version.

Using this DOCSIS version, Prime Cable Provisioning, if so configured, determines the optimum DOCSIS configuration file for the device. This is the lowest common DOCSIS version between the device and the CMTS. For example, if the device supports DOCSIS 2.0 and the CMTS supports DOCSIS 1.1, the DOCSIS 1.1 file is used.

### Determining the DOCSIS Version of the Modem

Prime Cable Provisioning can detect a cable modem's DOCSIS version from an incoming DHCP request, in which a string included in the Vendor Class Identifier field (Option 60) identifies the modem capabilities. For example, as in "docsis1.1:xxxxx" where xxxxx is an ASCII representation of the modem capabilities. The service-level selection extension uses the characters between "docsis" and the ":xxxxxx" hex string as the DOCSIS version for the modem.

### Determining the DOCSIS Version of the CMTS

Prime Cable Provisioning enables the CMTS to serve as a relay agent to provide the DOCSIS version of the CMTS. This feature is enabled via:

- DHCPv4 Relay Agent Option 82, which allows the CMTS to transmit (or advertise) specific capabilities of the CMTS. This option is a DOCSIS DHCP vendor-identifying option and carries the DOCSIS version of the CMTS.
- DHCPv6 Vendor-specific Information Option 17, which allows you to specify vendor-specific information. This option is carried in the Relay-forward and Relay-reply messages and transmits information between the DHCPv6 relay agent and the DHCPv6 server.

As in earlier versions, this Prime Cable Provisioning version also determines the DOCSIS version of the CMTS via the DHCP GIADDR field, which specifies the IP address of the CMTS interface. In this method, the service-level selection extension for DOCSIS modems looks for the //docsis/cmts/version/giaddrToVersionMap property. The value of this property is the name of an external file containing a mapping of the GIADDR to the DOCSIS version.

You must name this mapping file *giaddr-docsis-map.txt* and add it to the RDU. You can add the *giaddr-docsis-map.txt* file to the RDU from the:

- API via the Configuration.addFile() call.
- Administrator user interface via Configuration > Files. See Adding Files.

The giaddr-docsis-map.txt file must include the necessary information in the following format:

IPv4 dotted decimal address string, DOCSIS version string

- IPv4 dotted decimal address string—Specifies the IP address of the CMTS interface.
- docsis\_version\_string—Identifies the DOCSIS version that the cable modem supports.

For example, if the CMTS interface has IP address 10.30.0.1 with DOCSIS version 1.0, the file would includes the following:

### 10.30.0.1 1.0

The service-level extension uses the GIADDR address contained in the DHCP packet to look up the DOCSIS version of the CMTS. If the GIADDR is not found in the mapping file, the extension uses the value of the //docsis/cmts/version/default property for the DOCSIS version of the cable modem. The default value of this property is **1.0**.

To dynamically update the *giaddr-docsis-map.txt* file, edit it and replace it in the RDU via the *replaceExternalFile* API or via the administrator user interface.

Note

If the properties for the DOCSIS version selection are not specified on the Class of Service, the original file is used, allowing for systematic upgrades across the network.

### Selecting Service Level Based on DOCSIS Version

After the DOCSIS version of the modem and the CMTS are determined, the service-level selection extension determines the minimum DOCSIS version supported and configures the */docsis/version* property in the service level. The value of this property is set to the DOCSIS version string, such as 1.1.

Note

You can specify the DOCSIS version using the Configuration File Utility. For more information, see Using Configuration File Utility for Template. This function that the file utility performs is different from RDU verification, during which the RDU DOCSIS Version Selector feature determines the latest DOCSIS version supported by a CMTS.

#### **DOCSIS Configuration File Based on DOCSIS Version**

Prime Cable Provisioning determines the filename of the DOCSIS configuration file that is to be sent to the modem using the DOCSIS version.

The following Class of Service properties are supported by the Prime Cable Provisioning administrator user interface and the API:

```
/cos/docsis/file/1.0
/cos/docsis/file/1.1
/cos/docsis/file/2.0
/cos/docsis/file/3.0/IPv4
/cos/docsis/file/3.0/IPv6
```

Optionally, you can add these properties to a DOCSIS Class of Service to associate a DOCSIS configuration filename with a particular DOCSIS version. Each of these properties, when set, causes the RDU to establish a database relationship between the Class of Service and the file named by the property value, as is done for the existing DOCSIS configuration filename property.

If the DOCSIS version property is present, Prime Cable Provisioning forms a property name by appending the DOCSIS version string that is given by that property value to the name of the property that provides the DOCSIS configuration filename:

#### /cos/docsis/file/docsis version string

The service-level extension looks for this property name in the property hierarchy for the modem. When the DOCSIS version property is found, it uses the property value as the DOCSIS configuration filename. If the DOCSIS version property is not found, Prime Cable Provisioning uses the DOCSIS configuration filename property without the DOCSIS version suffix and supplies the filename to specify in the device configuration.