

Console Port, Telnet, and SSH Handling

This chapter covers the following topics:

- Console Port Overview, page 1
- Connecting Console Cables, page 1
- Installing USB Device Drivers, page 2
- Console Port Handling Overview, page 2
- Telnet and SSH Overview, page 2
- Persistent Telnet and Persistent SSH Overview, page 2
- Configuring a Console Port Transport Map, page 3
- Configuring Persistent Telnet, page 5
- Configuring Persistent SSH, page 8
- Viewing Console Port, SSH, and Telnet Handling Configurations, page 11
- Important Notes and Restrictions, page 14

Console Port Overview

The console port on the chassis is an EIA/TIA-232 asynchronous, serial connection with no flow control and an RJ-45 connector. The console port is used to access the chassis and is located on the front panel of the Route Switch Processor (RSP).

For information on accessing the chassis using the console port, see the "Accessing the CLI Using a Console" section on page 1-4.

Connecting Console Cables

For information about connecting console cables to the chassis, see the ASR 900 Series Hardware Installation Guides .

Installing USB Device Drivers

For instructions on how to install device drivers in order to use the USB console port, see the ASR 900 Series Hardware Installation Guides .

Console Port Handling Overview

Users using the console port to access the chassis are automatically directed to the IOS command-line interface, by default.

If a user is trying to access the router through the console port and sends a break signal (a break signal can be sent by entering **Ctrl-C** or **Ctrl-Shift-6**, or by entering the **send break** command at the Telnet prompt) before connecting to the IOS command-line interface, the user is directed into diagnostic mode by default if the non-RPIOS sub-packages can be accessed.

These settings can be changed by configuring a transport map for the console port and applying that transport map to the console interface.

Telnet and SSH Overview

Telnet and Secure Shell (SSH) can be configured and handled like Telnet and SSH on other Cisco platforms. For information on traditional Telnet, see the **line** command in the *Cisco IOS Terminal Services Command Reference guide* located at

http://www.cisco.com/en/US/docs/ios/12 2/termserv/command/reference/trflosho.html#wp1029818.

For information on configuring traditional SSH, see the Secure Shell Configuration Guide, Cisco IOS XE Release 3S

The chassis also supports persistent Telnet and persistent SSH. Persistent Telnet and persistent SSH allow network administrators to more clearly define the treatment of incoming traffic when users access the router through the Management Ethernet port using Telnet or SSH. Notably, persistent Telnet and persistent SSH provide more robust network access by allowing the router to be configured to be accessible through the Ethernet Management port using Telnet or SSH even when the IOS process has failed.

Persistent Telnet and Persistent SSH Overview

In traditional Cisco routers, accessing the router using Telnet or SSH is not possible in the event of an IOS failure. When Cisco IOS fails on a traditional Cisco router, the only method of accessing the router is through the console port. Similarly, if all active IOS processes have failed on a chassis that is not using persistent Telnet or persistent SSH, the only method of accessing the router is through the console port.

With persistent Telnet and persistent SSH, however, users can configure a transport map that defines the treatment of incoming Telnet or SSH traffic on the Management Ethernet interface. Among the many configuration options, a transport map can be configured to direct all traffic to the IOS command-line interface, diagnostic mode, or to wait for an IOS vty line to become available and then direct users into diagnostic mode when the user sends a break signal while waiting for the IOS vty line to become available. If a user uses Telnet or SSH to access diagnostic mode, that Telnet or SSH connection will be usable even in scenarios when no IOS process is active. Therefore, persistent Telnet and persistent SSH introduce the ability to access the router

via diagnostic mode when the IOS process is not active. For information on diagnostic mode, see the "Understanding Diagnostic Mode" section on page 1-3 .

For more information on the various other options that are configurable using persistent Telnet or persistent SSH transport map see the Configuring Persistent Telnet, on page 5 and the Configuring Persistent SSH, on page 8.

Configuring a Console Port Transport Map

This task describes how to configure a transport map for a console port interface.

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- 3. transport-map type console transport-map-name
- 4. connection wait [allow interruptible | none]
- 5. banner [diagnostic | wait] banner-message
- 6. exit
- 7. transport type console console-line-number input transport-map-name

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Router> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Router# configure terminal	
Step 3	transport-map type console transport-map-name	Creates and names a transport map for handling console connections, and enter transport map configuration mode.
	Example:	
	Router(config)# transport-map type console consolehandler	
Step 4	connection wait [allow interruptible none]	Specifies how a console connection will be handled using this transport map:
	<pre>Example: Router(config-tmap)# connection wait none</pre>	• allow interruptible—The console connection waits for an IOS

	Command or Action	Purpose
	Example:	Note Users can interrupt a waiting connection by entering Ctrl-C or Ctrl-Shift-6. • none—The console connection immediately enters diagnostic mode.
Step 5	<pre>banner [diagnostic wait] banner-message Example: Router(config-tmap) # banner diagnostic X</pre>	(Optional) Creates a banner message that will be seen by users entering diagnostic mode or waiting for the IOS vty line as a result of the console transport map configuration. • diagnostic—Creates a banner message seen by users directed into
	Example: Enter TEXT message. End with the character 'X'.	diagnostic mode as a result of the console transport map configuration. • wait—Creates a banner message seen by users waiting for the IOS vty to become available.
	Example:Welcome to Diagnostic Mode	• banner-message—The banner message, which begins and ends with the same delimiting character.
	Example:	
	<pre>Example: Router(config-tmap)#</pre>	
	Example:	
Step 6	exit	Exits transport map configuration mode to re-enter global configuration mode.
	Example:	
	Router(config-tmap)# exit	
Step 7	transport type console console-line-number input transport-map-name	Applies the settings defined in the transport map to the console interface. The <i>transport-map-name</i> for this command must match the
	Example:	transport-map-name defined in the transport-map type console comm and.
	Router(config)# transport type console 0 input consolehandler	

Examples

In the following example, a transport map to set console port access policies is created and attached to console port 0:

```
Router(config) # transport-map type console consolehandler
Router(config-tmap) # connection wait allow interruptible
Router(config-tmap) # banner diagnostic X
Enter TEXT message. End with the character 'X'.
Welcome to diagnostic mode
X
Router(config-tmap) # banner wait X
Enter TEXT message. End with the character 'X'.
Waiting for IOS vty line
X
Router(config-tmap) # exit
Router(config) # transport type console 0 input consolehandler
```

Configuring Persistent Telnet

Before You Begin

For a persistent Telnet connection to access an IOS vty line on the chassis, local login authentication must be configured for the vty line (the **login** command in line configuration mode). If local login authentication is not configured, users will not be able to access IOS using a Telnet connection into the Management Ethernet interface with an applied transport map. Diagnostic mode will still be accessible in this scenario.

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- 3. transport-map type persistent telnet transport-map-name
- 4. connection wait [allow {interruptible}| none {disconnect}]
- 5. banner [diagnostic | wait] banner-message
- 6. transport interface type num
- 7. exit
- 8. transport type persistent telnet input transport-map-name

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Router> enable	

	Command or Action	Purpose
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Router# configure terminal	
Step 3	transport-map type persistent telnet transport-map-name	Creates and names a transport map for handling persistent Telnet connections, and enters transport map configuration mode.
	Example:	
	Router(config) # transport-map type persistent telnet telnethandler	
Step 4	<pre>connection wait [allow {interruptible} none {disconnect}]</pre>	Specifies how a persistent Telnet connection will be handled using this transport map:
	Example:	• allow—The Telnet connection waits for an IOS vty line to become available, and exits the router if interrupted.
	Router(config-tmap)# connection wait none	• allow interruptible—The Telnet connection waits for the IOS vty line to become available, and also allows user to enter diagnostic
	Example:	mode by interrupting a Telnet connection waiting for the IOS vty line to become available. This is the default setting.
		Note Users can interrupt a waiting connection by entering Ctrl-C or Ctrl-Shift-6.
		• none—The Telnet connection immediately enters diagnostic mode.
		• none disconnect—The Telnet connection does not wait for the IOS vty line and does not enter diagnostic mode, so all Telnet connections are rejected if no vty line is immediately available in IOS.
Step 5	banner [diagnostic wait] banner-message	(Optional) Creates a banner message that will be seen by users entering diagnostic mode or waiting for the IOS vty line as a result of the persistent Telnet configuration.
	Example:	
	Router(config-tmap)# banner diagnostic X	 diagnostic—creates a banner message seen by users directed into diagnostic mode as a result of the persistent Telnet configuration.
	Example:	 wait—creates a banner message seen by users waiting for the vty line to become available. banner-message—the banner message, which begins and ends with the same delimiting character.
	Enter TEXT message. End with the character 'X'.	
	Example:	
	Welcome to Diagnostic Mode	
	Example:	
	x	

	Command or Action	Purpose
	<pre>Example: Router(config-tmap)#</pre>	
	Example:	
Step 6	transport interface type num	Applies the transport map settings to the Management Ethernet interface (interface gigabitethernet 0).
	Example:	Persistent Telnet can only be applied to the Management Ethernet interface
	Router(config-tmap) # transport interface gigabitethernet 0	on the chassis. This step must be taken before applying the transport material to the Management Ethernet interface.
Step 7	exit	Exits transport map configuration mode to re-enter global configuration mode.
	Example:	
	Router(config-tmap)# exit	
Step 8	transport type persistent telnet input transport-map-name	Applies the settings defined in the transport map to the Management Ethernet interface.
	Example:	The <i>transport-map-name</i> for this command must match the <i>transport-map-name</i> defined in the transport-map type persistent telnet command.
	Router(config)# transport type persistent telnet input telnethandler	comm and.

Examples

In the following example, a transport map that will make all Telnet connections wait for an IOS vty line to become available before connecting to the router, while also allowing the user to interrupt the process and enter diagnostic mode, is configured and applied to the Management Ethernet interface (interface gigabitethernet 0).

A diagnostic and a wait banner are also configured.

The transport map is then applied to the interface when the **transport type persistent telnet input** command is entered to enable persistent Telnet.

```
Router(config) # transport-map type persistent telnet telnethandler Router(config-tmap) # connection wait allow interruptible Router(config-tmap) # banner diagnostic X Enter TEXT message. End with the character 'X'. --Welcome to Diagnostic Mode-- X Router(config-tmap) # banner wait X Enter TEXT message. End with the character 'X'. --Waiting for IOS Process-- X Router(config-tmap) # transport interface gigabitethernet 0
```

Router(config-tmap)# exit
Router(config)# transport type persistent telnet input telnethandler

Configuring Persistent SSH

This task describes how to configure persistent SSH.

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- 3. transport-map type persistent ssh transport-map-name
- 4. connection wait [allow {interruptible}| none {disconnect}]
- 5. rsa keypair-name rsa-keypair-name
- 6. authentication-retriesnumber-of-retries
- 7. banner [diagnostic | wait] banner-message
- 8. time-outtimeout-interval
- 9. transport interface type num
- 10. exit
- 11. transport type persistent ssh input transport-map-name

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Router> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Router# configure terminal	
Step 3	transport-map type persistent ssh transport-map-name	Creates and names a transport map for handling persistent SSH connections, and enters transport map configuration mode.
	Example:	
	Router(config)# transport-map type persistent ssh sshhandler	
Step 4	connection wait [allow {interruptible} none {disconnect}]	Specifies how a persistent SSH connection will be handled using this transport map:

	Command or Action	Purpose
	Example:	• allow—The SSH connection waits for the vty line to become available, and exits the router if interrupted.
	Router(config-tmap)# connection wait allow interruptible Example:	• allow interruptible—The SSH connection waits for the vty line to become available, and also allows users to enter diagnostic mode by interrupting a SSH connection waiting for the vty line to become available. This is the default setting.
		Note Users can interrupt a waiting connection by entering Ctrl-C or Ctrl-Shift-6.
		• none—The SSH connection immediately enters diagnostic mode.
		• none disconnect—The SSH connection does not wait for the vty line from IOS and does not enter diagnostic mode, so all SSH connections are rejected if no vty line is immediately available.
Step 5	rsa keypair-name rsa-keypair-name	Names the RSA keypair to be used for persistent SSH connections.
·	<pre>Example: Router(config-tmap)# rsa keypair-name sshkeys</pre>	For persistent SSH connections, the RSA keypair name must be defined using this command in transport map configuration mode. The RSA keypair definitions defined elsewhere on the router, such as through the use of the ip ssh rsa keypair-name command, do not apply to persistent SSH connections.
		No rsa-keypair-name is defined by default.
Step 6	authentication-retriesnumber-of-retries	(Optional) Specifies the number of authentication retries before dropping the connection.
	Example:	The default <i>number-of-retries</i> is 3.
	Router(config-tmap)# authentication-retries 4	
Step 7	banner [diagnostic wait] banner-message	(Optional) Creates a banner message that will be seen by users entering diagnostic mode or waiting for the vty line as a result of the persistent
	Example:	SSH configuration.
	Router(config-tmap) # banner diagnostic X	• diagnostic—Creates a banner message seen by users directed into diagnostic mode as a result of the persistent SSH configuration.
	Example:	• wait—Creates a banner message seen by users waiting for the vty line to become active.
	Enter TEXT message. End with the character 'X'.	• <i>banner-message</i> —The banner message, which begins and ends with the same delimiting character.
	Example:	
	Welcome to Diagnostic Mode	
	Example:	
	х	

	Command or Action	Purpose
	Example:	
	Router(config-tmap)#	
Step 8	time-out/imeout-interval	(Optional) Specifies the SSH time-out interval in seconds.
	Example:	The default <i>timeout-interval</i> is 120 seconds.
	Router(config-tmap)# time-out 30	
Step 9	transport interface type num	Applies the transport map settings to the Management Ethernet interface (interface gigabitethernet 0).
	Example:	Persistent SSH can only be applied to the Management Ethernet interface
	Router(config-tmap)# transport interface gigabitethernet 0	on the chassis.
Step 10	exit	Exits transport map configuration mode to re-enter global configuration mode.
	Example:	
	Router(config-tmap)# exit	
Step 11	transport type persistent ssh input transport-map-name	Applies the settings defined in the transport map to the Management Ethernet interface.
	Example:	The <i>transport-map-name</i> for this command must match the <i>transport-map-name</i> defined in the transport-map type persistent ssh
	Router(config)# transport type persistent ssh input sshhandler	command .

Examples

In the following example, a transport map that will make all SSH connections wait for the vty line to become active before connecting to the router is configured and applied to the Management Ethernet interface (interface gigabitethernet 0). The RSA keypair is named sshkeys.

This example only uses the commands required to configure persistent SSH.

```
Router(config) # transport-map type persistent ssh sshhandler
Router(config-tmap) # connection wait allow
Router(config-tmap) # rsa keypair-name sshkeys
Router(config-tmap) # transport interface gigabitethernet 0
```

In the following example, a transport map is configured that will apply the following settings to any users attempting to access the Management Ethernet port via SSH:

- Users using SSH will wait for the vty line to become active, but will enter diagnostic mode if the attempt to access IOS through the vty line is interrupted.
- The RSA keypair name is "sshkeys"
- The connection allows one authentication retry.

- The banner "--Welcome to Diagnostic Mode--" will appear if diagnostic mode is entered as a result of SSH handling through this transport map.
- The banner "--Waiting for vty line--" will appear if the connection is waiting for the vty line to become
 active.

The transport map is then applied to the interface when the **transport type persistent ssh input** command is entered to enable persistent SSH.

```
Router(config) # transport-map type persistent ssh sshhandler
Router(config-tmap) # connection wait allow interruptible
Router(config-tmap) # rsa keypair-name sshkeys
Router(config-tmap) # authentication-retries 1

Router(config-tmap) # banner diagnostic X

Enter TEXT message. End with the character 'X'.

--Welcome to Diagnostic Mode--

X

Router(config-tmap) #banner wait X
Enter TEXT message. End with the character 'X'.

--Waiting for vty line--
X
Router(config-tmap) #
time-out 30
Router(config-tmap) # transport interface gigabitethernet 0
Router(config-tmap) # exit
Router(config) # transport type persistent ssh input sshhandler
```

Viewing Console Port, SSH, and Telnet Handling Configurations

Use the **show transport-map all name** *transport-map-name* | **type console persistent ssh telnet**]]] EXEC or privileged EXEC command to view the transport map configurations.

In the following example, a console port, persistent SSH, and persistent Telnet transport are configured on the router and various forms of the **show transport-map** command are entered to illustrate the various ways the **show transport-map** command can be entered to gather transport map configuration information.

```
Router# show transport-map all
Transport Map:
  Name: consolehandler
  Type: Console Transport
Connection:
  Wait option: Wait Allow Interruptable
  Wait banner:
Waiting for the IOS CLI
 bshell banner:
Welcome to Diagnostic Mode
Transport Map:
  Name: sshhandler
  Type: Persistent SSH Transport
Interface:
  GigabitEthernet0
Connection:
  Wait option: Wait Allow Interruptable
  Wait banner:
Waiting for IOS prompt
  Bshell banner:
Welcome to Diagnostic Mode
SSH:
```

```
Timeout: 120
  Authentication retries: 5
  RSA keypair: sshkeys
Transport Map:
  Name: telnethandler
  Type: Persistent Telnet Transport
Interface:
 GigabitEthernet0
Connection:
  Wait option: Wait Allow Interruptable
  Wait banner:
Waiting for IOS process
 Bshell banner:
Welcome to Diagnostic Mode
Transport Map:
  Name: telnethandling1
  Type: Persistent Telnet Transport
Connection:
 Wait option: Wait Allow
Router# show transport-map type console
Transport Map:
  Name: consolehandler
  Type: Console Transport
Connection:
  Wait option: Wait Allow Interruptable
  Wait banner:
Waiting for the IOS CLI
 Bshell banner:
Welcome to Diagnostic Mode
Router# show transport-map type persistent ssh
Transport Map:
  Name: sshhandler
  Type: Persistent SSH Transport
Interface:
 GigabitEthernet0
Connection:
  Wait option: Wait Allow Interruptable
 Wait banner:
Waiting for IOS prompt
 Bshell banner:
Welcome to Diagnostic Mode
SSH:
  Timeout: 120
  Authentication retries: 5
 RSA keypair: sshkeys
Router# show transport-map type persistent telnet
Transport Map:
  Name: telnethandler
  Type: Persistent Telnet Transport
Interface:
  GigabitEthernet0
Connection:
  Wait option: Wait Allow Interruptable
  Wait banner:
Waiting for IOS process
  Bshell banner:
Welcome to Diagnostic Mode
Transport Map:
  Name: telnethandling1
  Type: Persistent Telnet Transport
Connection:
  Wait option: Wait Allow
Router# show transport-map name telnethandler
Transport Map:
  Name: telnethandler
  Type: Persistent Telnet Transport
Interface:
  GigabitEthernet0
Connection:
  Wait option: Wait Allow Interruptable
  Wait banner:
Waiting for IOS process
```

```
Bshell banner:
Welcome to Diagnostic Mode
Router# show transport-map name consolehandler
Transport Map:
  Name: consolehandler
  Type: Console Transport
Connection:
  Wait option: Wait Allow Interruptable
  Wait banner:
Waiting for the IOS CLI
  Bshell banner:
Welcome to Diagnostic Mode
Router# show transport-map name sshhandler
Transport Map:
  Name: sshhandler
  Type: Persistent SSH Transport
Interface:
  GigabitEthernet0
Connection:
  Wait option: Wait Allow Interruptable
  Wait banner:
Waiting for IOS prompt
 Bshell banner:
Welcome to Diagnostic Mode
  Timeout: 120
  Authentication retries: 5
  RSA keypair: sshkeys
Router#
```

The **show platform software configuration access policy** command can be used to view the current configurations for the handling of incoming console port, SSH, and Telnet connections. The output of this command provides the current wait policy for each type of connection, as well as any information on the currently configured banners. Unlike **show transport-map**, this command is available in diagnostic mode so it can be entered in cases when you need transport map configuration information but cannot access the IOS CLI.

Router# show platform software configuration access policy

```
The current access-policies
Met.hod
            : telnet
Rule
            : wait
Shell banner:
Wait banner:
Method
            : wait
Shell banner:
Wait banner:
        : console
: wait with interrupt
Method
Rule
Shell banner:
Wait banner:
```

In the following example, the connection policy and banners are set for a persistent SSH transport map, and the transport map is enabled.

The **show platform software configuration access policy** output is given both before the new transport map is enabled and after the transport map is enabled so the changes to the SSH configuration are illustrated in the output.

Router# show platform software configuration access policy

```
The current access-policies
Method : telnet
Rule : wait with interrupt
Shell banner:
Welcome to Diagnostic Mode
Wait banner :
Waiting for IOS Process
Method : ssh
```

```
Rule
           : wait
Shell banner:
Wait banner :
Method : console
           : wait with interrupt
Rule
Shell banner:
Wait banner :
Router# configure terminal
Enter configuration commands, one per line. End with {\tt CNTL/Z.}
Router(config)# transport-map type persistent ssh sshhandler
Router(config-tmap) # connection wait allow interruptible
Router(config-tmap) # banner diagnostic X
Enter TEXT message. End with the character 'X'.
Welcome to Diag Mode
Router(config-tmap) # banner wait X
Enter TEXT message. End with the character 'X'.
Waiting for IOS
Router(config-tmap)# rsa keypair-name sshkeys
Router(config-tmap) # transport interface gigabitethernet 0
Router(config-tmap)# exit
Router(config) # transport type persistent ssh input sshhandler
Router(config) # exit
Router# show platform software configuration access policy
The current access-policies
          : telnet
Method
Rule
           : wait with interrupt
Shell banner:
Welcome to Diagnostic Mode
Wait banner :
Waiting for IOS process
          : ssh
Method
           : wait with interrupt
Rule
Shell banner:
Welcome to Diag Mode
Wait banner :
Waiting for IOS
Method
        : console
: wait with interrupt
Rule
Shell banner:
Wait banner :
```

Important Notes and Restrictions

- The Telnet and SSH settings made in the transport map override any other Telnet or SSH settings when the transport map is applied to the Management Ethernet interface.
- Only local usernames and passwords can be used to authenticate users entering a Management Ethernet interface. AAA authentication is not available for users accessing the router through a Management Ethernet interface using persistent Telnet or persistent SSH.
- Applying a transport map to a Management Ethernet interface with active Telnet or SSH sessions can disconnect the active sessions. Removing a transport map from an interface, however, does not disconnect any active Telnet or SSH sessions.
- Configuring the diagnostic and wait banners is optional but recommended. The banners are especially useful as indicators to users of the status of their Telnet or SSH attempts.