



## **Cisco IOS XR Virtual Private Network Command Reference for the Cisco XR 12000 Series Router, Release 4.3.x**

**First Published:** 2012-12-01

**Last Modified:** 2013-05-01

### **Americas Headquarters**

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
<http://www.cisco.com>  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 527-0883

Text Part Number: OL-28460-01

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <http://www.cisco.com/go/trademarks>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <http://www.cisco.com/go/trademarks>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)



## CONTENTS

---

### Preface

### Preface vii

Changes to This Document vii

Obtaining Documentation and Submitting a Service Request vii

---

### CHAPTER 1

### Virtual Private Network Commands 1

authentication (L2TP) 4

backup (L2VPN) 6

backup disable (L2VPN) 8

clear l2tp counters control session 10

clear l2tp counters control tunnel 12

clear l2tp tunnel 14

clear l2vpn collaborators 16

clear l2vpn counters l2tp 17

clear l2vpn counters bridge mac-withdrawal 19

clear l2vpn forwarding counters 20

clear l2vpn forwarding mac-address-table 21

clear l2vpn forwarding message counters 23

clear l2vpn forwarding table 24

description (GLOBAL) 25

description (XCONNECT) 26

digest (L2TP) 27

hello-interval (L2TP) 29

hidden (L2TP) 31

hostname (L2TP) 33

interface (p2p) 35

interworking ipv4 37

interworking ethernet 38

l2tp-class	40
l2tp-class configuration	41
l2transport	43
l2transport cell-packing	45
l2transport propagate	47
l2vpn	49
l2vpn switchover	51
logging (l2vpn)	53
logging nsr	55
mpls static label (L2VPN)	57
neighbor (L2VPN)	59
nsr (L2VPN)	61
password (L2TP)	63
pw-class (L2VPN)	65
pw-class encapsulation l2tpv3	67
pw-class encapsulation mpls	69
pw-ether	71
pw-grouping	73
p2p	74
receive-window (L2TP)	76
retransmit (L2TP)	78
rollover (L3VPN)	80
sequencing (L2VPN)	82
show generic-interface-list	84
show l2tp class	86
show l2tp counters forwarding session	88
show l2tp session	90
show l2tp tunnel	93
show l2vpn	95
show l2vpn atom-db	97
show l2vpn collaborators	100
show l2vpn database	102
show l2vpn forwarding	105
show l2vpn forwarding l2tp	112
show l2vpn generic-interface-list	114

show l2vpn index 116  
show l2vpn nsr 118  
show l2vpn provision queue 120  
show l2vpn pw-class 122  
show l2vpn pwhe 124  
show l2vpn resource 126  
show l2vpn trace 127  
show l2vpn xconnect 129  
show tunnel-template 138  
switching-tlv (L2VPN) 140  
tag-impose 142  
tag-rewrite 144  
timeout setup (L2TP) 146  
transport mode (L2VPN) 148  
tunnel-template 150  
xconnect group 151

---

**CHAPTER 2****Virtual Private LAN Services Commands 153**

action (VPLS) 155  
aging (VPLS) 157  
bridge-domain (VPLS) 159  
bridge group (VPLS) 161  
clear l2vpn bridge-domain (VPLS) 163  
flooding disable 165  
flooding unknown-unicast disable (VPLS) 167  
interface (VPLS) 169  
learning disable (VPLS) 171  
limit (VPLS) 173  
mac (VPLS) 175  
maximum (VPLS) 177  
mpls static label (VPLS) 179  
mtu (VPLS) 181  
neighbor (VPLS) 183  
notification (VPLS) 185  
port-down flush disable (VPLS) 187

pw-class (VFI)	189
pw-status (L2VPN)	191
show l2vpn bridge-domain (VPLS)	193
show l2vpn forwarding bridge-domain (VPLS)	201
show l2vpn forwarding bridge-domain mac-address (VPLS)	206
shutdown (Bridge Domain)	210
shutdown (VFI)	212
static-address (VPLS)	214
static-mac-address (VPLS)	216
time (VPLS)	218
type (VPLS)	220
vfi (VPLS)	222
withdraw (VPLS)	224



## Preface

---

The *Cisco IOS XR Virtual Private Network Command Reference for the Cisco XR 12000 Series Router* preface contains these sections:

- [Changes to This Document](#), page vii
- [Obtaining Documentation and Submitting a Service Request](#), page vii

## Changes to This Document

This table lists the changes made to this document since it was first printed.

**Table 1: Changes to This Document**

Revision	Date	Change Summary
OL-28460-01	December 2012	Initial release of this document.

## Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see [What's New in Cisco Product Documentation](#).

To receive new and revised Cisco technical content directly to your desktop, you can subscribe to the [What's New in Cisco Product Documentation RSS feed](#). RSS feeds are a free service.





# Virtual Private Network Commands

---

For detailed information about virtual private network concepts, configuration tasks, and examples, refer to the *Cisco IOS XR Virtual Private Network Configuration Guide for the Cisco XR 12000 Series Router*

- [authentication \(L2TP\), page 4](#)
- [backup \(L2VPN\), page 6](#)
- [backup disable \(L2VPN\), page 8](#)
- [clear l2tp counters control session, page 10](#)
- [clear l2tp counters control tunnel, page 12](#)
- [clear l2tp tunnel, page 14](#)
- [clear l2vpn collaborators, page 16](#)
- [clear l2vpn counters l2tp, page 17](#)
- [clear l2vpn counters bridge mac-withdrawal, page 19](#)
- [clear l2vpn forwarding counters, page 20](#)
- [clear l2vpn forwarding mac-address-table, page 21](#)
- [clear l2vpn forwarding message counters, page 23](#)
- [clear l2vpn forwarding table, page 24](#)
- [description \(GLOBAL\), page 25](#)
- [description \(XCONNECT\), page 26](#)
- [digest \(L2TP\), page 27](#)
- [hello-interval \(L2TP\), page 29](#)
- [hidden \(L2TP\), page 31](#)
- [hostname \(L2TP\), page 33](#)
- [interface \(p2p\), page 35](#)
- [interworking ipv4, page 37](#)
- [interworking ethernet, page 38](#)

- [l2tp-class](#), page 40
- [l2tp-class configuration](#), page 41
- [l2transport](#), page 43
- [l2transport cell-packing](#), page 45
- [l2transport propagate](#), page 47
- [l2vpn](#), page 49
- [l2vpn switchover](#), page 51
- [logging \(l2vpn\)](#), page 53
- [logging nsr](#), page 55
- [mpls static label \(L2VPN\)](#), page 57
- [neighbor \(L2VPN\)](#), page 59
- [nsr \(L2VPN\)](#), page 61
- [password \(L2TP\)](#), page 63
- [pw-class \(L2VPN\)](#), page 65
- [pw-class encapsulation l2tpv3](#), page 67
- [pw-class encapsulation mpls](#), page 69
- [pw-ether](#), page 71
- [pw-grouping](#), page 73
- [p2p](#), page 74
- [receive-window \(L2TP\)](#), page 76
- [retransmit \(L2TP\)](#), page 78
- [rollover \(L3VPN\)](#), page 80
- [sequencing \(L2VPN\)](#), page 82
- [show generic-interface-list](#) , page 84
- [show l2tp class](#), page 86
- [show l2tp counters forwarding session](#), page 88
- [show l2tp session](#), page 90
- [show l2tp tunnel](#), page 93
- [show l2vpn](#), page 95
- [show l2vpn atom-db](#), page 97
- [show l2vpn collaborators](#), page 100
- [show l2vpn database](#), page 102
- [show l2vpn forwarding](#), page 105

- [show l2vpn forwarding l2tp](#), page 112
- [show l2vpn generic-interface-list](#), page 114
- [show l2vpn index](#), page 116
- [show l2vpn nsr](#) , page 118
- [show l2vpn provision queue](#), page 120
- [show l2vpn pw-class](#), page 122
- [show l2vpn pwhe](#), page 124
- [show l2vpn resource](#), page 126
- [show l2vpn trace](#), page 127
- [show l2vpn xconnect](#), page 129
- [show tunnel-template](#), page 138
- [switching-tlv \(L2VPN\)](#), page 140
- [tag-impose](#), page 142
- [tag-rewrite](#), page 144
- [timeout setup \(L2TP\)](#), page 146
- [transport mode \(L2VPN\)](#), page 148
- [tunnel-template](#), page 150
- [xconnect group](#), page 151

# authentication (L2TP)

To enable L2TP authentication for a specified L2TP class name, use the **authentication** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

**authentication**

**no authentication**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** L2TP class configuration

Command History	Release	Modification
	Release 3.7.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



**Note**

You can also enable L2TP authentication for a specified class name from L2TP class configuration submode. To enter this submode, enter the **l2tp-class** command followed by the class name.

Task ID	Task ID	Operations
	l2vpn	read, write

**Examples** The following example shows how to configure L2TP authentication for the specified L2TP class name "cisco":

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2tp-class cisco
RP/0/0/CPU0:router(config-l2tp-class)# authentication
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">hello-interval (L2TP), on page 29</a>	Configures the hello-interval value for L2TP (duration between control channel hello packets).
<a href="#">hidden (L2TP), on page 31</a>	Enables hidden attribute-value pairs (AVPs).
<a href="#">hostname (L2TP), on page 33</a>	Defines the name used in the L2TP hostname AVP.
<a href="#">l2tp-class, on page 40</a>	Enters L2TP class configuration mode where you can define an L2TP signaling template.
<a href="#">password (L2TP), on page 63</a>	Defines the password and password encryption type for control channel authentication.
<a href="#">receive-window (L2TP), on page 76</a>	Configures the receive window size for the L2TP server.
<a href="#">retransmit (L2TP), on page 78</a>	Configures retransmit retry and timeout values.

## backup (L2VPN)

To configure the backup pseudowire for the cross-connect, use the **backup** command in L2VPN xconnect p2p pseudowire configuration mode. To disable this feature, use the **no** form of this command.

**backup neighbor** *IP-address* **pw-id** *value*

**no backup neighbor** *IP-address* **pw-id** *value*

### Syntax Description

<b>neighbor</b> <i>IP-address</i>	Specifies the peer to cross connect. The <i>IP-address</i> argument is the IPv4 address of the peer.
<b>pw-id</b> <i>value</i>	Configures the pseudowire ID. The range is from 1 to 4294967295.

### Command Default

None

### Command Modes

L2VPN xconnect p2p pseudowire configuration

### Command History

Release	Modification
Release 3.8.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **backup** command to enter L2VPN xconnect p2p pseudowire backup configuration mode.

### Task ID

Task ID	Operations
l2vpn	read, write

### Examples

The following example shows how to configure backup pseudowires:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# xconnect group gr1
RP/0/0/CPU0:router(config-l2vpn-xc)# p2p p001
RP/0/0/CPU0:router(config-l2vpn-xc-p2p)# neighbor 10.1.1.1 pw-id 2
RP/0/0/CPU0:router(config-l2vpn-xc-p2p-pw)# backup neighbor 10.2.2.2 pw-id 5
RP/0/0/CPU0:router(config-l2vpn-xc-p2p-pw-backup)#
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">backup disable (L2VPN), on page 8</a>	Specifies how long a backup pseudowire should wait before resuming operation after the primary pseudowire goes down.
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.
<a href="#">neighbor (L2VPN), on page 59</a>	Configures a pseudowire for a cross-connect.
<a href="#">p2p, on page 74</a>	Enters p2p configuration submode to configure point-to-point cross-connects.
<a href="#">xconnect group, on page 151</a>	Configures cross-connect groups.

## backup disable (L2VPN)

To specify how long a backup pseudowire should wait before resuming primary pseudowire operation after the failure with primary pseudowire has been cleared, use the **backup disable** command in L2VPN pseudowire class configuration mode. To disable this feature, use the **no** form of this command.

**backup disable** {*delay value*| **never**}

**no backup disable** {*delay value*| **never**}

### Syntax Description

<b>delay</b> <i>value</i>	Specifies the number of seconds that elapse after the failure with primary pseudowire has been cleared before the Cisco IOS XR software attempts to activate the primary pseudowire.  The range, in seconds, is from 0 to 180. The default is 0.
<b>never</b>	Specifies that the secondary pseudowire does not fall back to the primary pseudowire if the primary pseudowire becomes available again, unless the secondary pseudowire fails.

### Command Default

The default disable delay is the value of 0, which means that the primary pseudowire is activated immediately when it comes back up.

### Command Modes

L2VPN pseudowire class configuration

### Command History

Release	Modification
Release 3.8.0	This command was introduced.
Release 5.2.1	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

### Task ID

Task ID	Operations
l2vpn	read, write

**Examples**

The following example shows how a backup delay is configured for point-to-point pseudowire in which the backup disable delay is set to 50 seconds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# pw-class class1
RP/0/0/CPU0:router(config-l2vpn-pwc)# backup disable delay 50
RP/0/0/CPU0:router(config-l2vpn-pwc)# exit
RP/0/0/CPU0:router(config-l2vpn)# xconnect group A
RP/0/0/CPU0:router(config-l2vpn-xc)# p2p rtrx
RP/0/0/CPU0:router(config-l2vpn-xc-p2p)# neighbor 10.1.1.1 pw-id 2
RP/0/0/CPU0:router(config-l2vpn-xc-p2p-pw)# pw-class class1
RP/0/0/CPU0:router(config-l2vpn-xc-p2p-pw)# backup neighbor 10.2.2.2 pw-id 5
RP/0/0/CPU0:router(config-l2vpn-xc-p2p-pw-backup)#
```

**Related Commands**

Command	Description
<a href="#">l2vpn</a> , on page 49	Enters L2VPN configuration mode.
<a href="#">neighbor (L2VPN)</a> , on page 59	Configures a pseudowire for a cross-connect.
<a href="#">p2p</a> , on page 74	Enters p2p configuration submode to configure point-to-point cross-connects.
<a href="#">pw-class (L2VPN)</a> , on page 65	Enters pseudowire class submode to define a pseudowire class template.
<a href="#">xconnect group</a> , on page 151	Configures cross-connect groups.

# clear l2tp counters control session

To clear L2TP control counters for a session, use the **clear l2tp counters control session** command in EXEC mode.

**clear l2tp counters control session fsm [event| state transition]**

## Syntax Description

<b>fsm</b>	(Optional) Clears finite state machine counters.
<b>event</b>	(Optional) Clears state machine event counters.
<b>state</b>	(Optional) Clears state machine state counters.
<b>transition</b>	(Optional) Clears state machine transition counters.

## Command Default

None

## Command Modes

EXEC

## Command History

Release	Modification
Release 3.7.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operations
l2vpn	read, write

## Examples

The following example shows how to clear all L2TP state machine transition counters:

```
RP/0/0/CPU0:router(config-l2vpn-xc-p2p-pw-backup)## clear l2tp counters control session fsm
state transition
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">clear l2tp counters control tunnel, on page 12</a>	Clears L2TP control counters for a tunnel.
<a href="#">clear l2vpn counters l2tp, on page 17</a>	Clears L2VPN statistical information, such as, packets dropped.

# clear l2tp counters control tunnel

To clear L2TP control counters for a tunnel, use the **clear l2tp counters control tunnel** command in EXEC mode.

**clear l2tp counters control tunnel** {all| authentication| id *tunnel id*}

## Syntax Description

<b>all</b>	Clears all L2TP counters, except authentication counters
<b>authentication</b>	Clears tunnel authentication counters.
<b>id <i>tunnel id</i></b>	Clears a specified counter. Range is 1 to 4294967295.

## Command Default

None

## Command Modes

EXEC

## Command History

Release	Modification
Release 3.7.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operations
l2vpn	read, write

## Examples

The following example shows how to clear all L2TP control tunnel counters:

```
RP/0/0/CPU0:router# clear l2tp counters control tunnel all
```

## Related Commands

Command	Description
<a href="#">clear l2tp counters control session</a> , <a href="#">on page 10</a>	Clears L2TP control counters for a session.

Command	Description
<a href="#">clear l2vpn counters l2tp, on page 17</a>	Clears L2VPN statistical information, such as, packets dropped.

# clear l2tp tunnel

To clear L2TP tunnels, use the **clear l2tp tunnel** command in EXEC mode.

```
clear l2tp tunnel {all| id tunnel id| l2tp-class class name| local ipv4 ipv4 address| remote ipv4 ipv4 address}
```

## Syntax Description

<b>all</b>	Clears all L2TP tunnels.
<b>id</b> <i>tunnel id</i>	Clears a specified tunnel.
<b>l2tp-class</b> <i>class name</i>	Clears all L2TP tunnels based on L2TP class name.
<b>local ipv4</b> <i>ipv4 address</i>	Clears all local tunnels based on the specified local IPv4 address.
<b>remote ipv4</b> <i>ipv4 address</i>	Clears all remote tunnels based on the specified local IPv4 address.

## Command Default

None

## Command Modes

EXEC

## Command History

Release	Modification
Release 3.7.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operations
l2vpn	read, write

## Examples

The following example shows how to clear all L2TP tunnels:

```
RP/0/0/CPU0:router# clear l2tp tunnel all
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">clear l2tp counters control session, on page 10</a>	Clears L2TP control counters for a session.
<a href="#">clear l2tp counters control tunnel, on page 12</a>	Clears L2TP control counters for a tunnel.

# clear l2vpn collaborators

To clear the state change counters for L2VPN collaborators, use the **clear l2vpn collaborators** command in EXEC mode.

**clear l2vpn collaborators**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.4.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

**Examples** The following example shows how to clear change counters for L2VPN collaborators:

```
RP/0/0/CPU0:router# clear l2vpn collaborators
```

Related Commands	Command	Description
	<a href="#">show l2vpn collaborators</a> , on page 100	Displays information about the state of the interprocess communications connections between l2vpn_mgr and other processes.

# clear l2vpn counters l2tp

To clear L2VPN statistical information, such as, packets dropped, use the **clear l2vpn counters l2tp** command in EXEC mode.

**clear l2vpn counters l2tp** [**neighbor** *ip-address* [**pw-id** *value*]]

Syntax Description		
<b>l2tp</b>		Clears all L2TP counters.
<b>neighbor</b> <i>ip-address</i>		(Optional) Clears all L2TP counters for the specified neighbor.
<b>pw-id</b> <i>value</i>		(Optional) Configures the pseudowire ID. The range is from 1 to 4294967295.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.4.0	This command was introduced.
	Release 3.7.0	The <b>pw-id</b> keyword was added.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

**Examples** The following example shows how to clear all L2TP counters:

```
RP/0/0/CPU0:router# clear l2vpn counters l2tp
```

**Related Commands**

Command	Description
<a href="#">show l2vpn collaborators, on page 100</a>	Displays information about the state of the interprocess communications connections between l2vpn_mgr and other processes.

# clear l2vpn counters bridge mac-withdrawal

To clear the MAC withdrawal statistics for the counters of the bridge domain, use the **clear l2vpn counters bridge mac-withdrawal** command in EXEC mode.

**clear l2vpn counters bridge mac-withdrawal** {**all**| **group** *group-name* **bd-name** *bd-name*| **neighbor** *ip-address* **pw-id** *value*}

## Syntax Description

<b>all</b>	Clears the MAC withdrawal statistics over all the bridges.
<b>group</b> <i>group-name</i>	Clears the MAC withdrawal statistics over the specified group.
<b>bd-name</b> <i>bd-name</i>	Clears the MAC withdrawal statistics over the specified bridge.
<b>neighbor</b> <i>ip-address</i>	Clears the MAC withdrawal statistics over the specified neighbor.
<b>pw-id</b> <i>value</i>	Clears the MAC withdrawal statistics over the specified pseudowire. The range is from 1 to 4294967295.

## Command Default

None

## Command Modes

EXEC

## Command History

Release	Modification
Release 3.7.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operations
l2vpn	read, write

## Examples

The following example shows how to clear the MAC withdrawal statistics over all the bridges:

```
RP/0/0/CPU0:router# clear l2vpn counters bridge mac-withdrawal all
```

# clear l2vpn forwarding counters

To clear L2VPN forwarding counters, use the **clear l2vpn forwarding counters** command in EXEC mode.

**clear l2vpn forwarding counters**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** EXEC

## Command History

Release	Modification
Release 3.4.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operations
l2vpn	read, write

## Examples

The following example shows how to clear L2VPN forwarding counters:

```
RP/0/0/CPU0:router# clear l2vpn forwarding counters
```

## Related Commands

Command	Description
<a href="#">show l2vpn forwarding</a> , <a href="#">on page 105</a>	Displays forwarding information from the layer2_fib manager on the line card.

# clear l2vpn forwarding mac-address-table

To clear L2VPN forwarding MAC address tables, use the **clear l2vpn forwarding mac-address-table** command in EXEC mode.

```
clear l2vpn forwarding mac-address-table {address address| bridge-domain name| interface type
interface-path-id| location node-id}
```

## Syntax Description

<i>address</i>	Clears a specified MAC address.
<b>bridge-domain</b> <i>name</i>	Clears bridge domains learned from a MAC address table.
<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. <b>Note</b> Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
<b>location</b> <i>node-id</i>	Clears L2VPN forwarding message counters for the specified location. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

## Command Default

None

## Command Modes

EXEC

## Command History

Release	Modification
Release 3.5.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operations
l2vpn	read, write, execute

**Examples**

The following example shows how to clear L2VPN forwarding MAC address tables on a specified node:

```
RP/0/0/CPU0:router# clear l2vpn forwarding mac-address location 1/1/1
```

**Related Commands**

Command	Description
<a href="#">show l2vpn forwarding, on page 105</a>	Displays forwarding information from the layer2_fib manager on the line card.

# clear l2vpn forwarding message counters

To clear L2VPN forwarding message counters, use the **clear l2vpn forwarding message counters** command in EXEC mode.

**clear l2vpn forwarding message counters location** *node-id*

<b>Syntax Description</b>	<b>location</b> <i>node-id</i>	Clears L2VPN forwarding message counters for the specified location.
---------------------------	--------------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC
----------------------	------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.5.0	This command was introduced.

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	l2vpn	read, write

**Examples**

The following example shows how to clear L2VPN forwarding message counters on a specified node:

```
RP/0/0/CPU0:router# clear l2vpn forwarding message counters location 0/6/CPU0
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">show l2vpn forwarding</a> , on page 105	Displays forwarding information from the layer2_fib manager on the line card.

# clear l2vpn forwarding table

To clear an L2VPN forwarding table at a specified location, use the **clear l2vpn forwarding table** command in EXEC mode.

**clear l2vpn forwarding table location** *node-id*

## Syntax Description

<b>location</b> <i>node-id</i>	Clears L2VPN forwarding tables for the specified location.
--------------------------------	--

## Command Default

None

## Command Modes

EXEC

## Command History

Release	Modification
Release 3.4.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operations
l2vpn	read, write

## Examples

The following example shows how to clear an L2VPN forwarding table from a specified location:

```
RP/0/0/CPU0:router# clear l2vpn forwarding table location 1/2/3/5
```

## Related Commands

Command	Description
<a href="#">show l2vpn forwarding</a> , on page 105	Displays forwarding information from the layer2_fib manager on the line card.

## description (GLOBAL)

To specify the description of a multisegment pseudowire globally, use the **description** command in l2vpn configuration mode. To revert, use the **no** form of the command.

**description** *description-name*

**no description**

<b>Syntax Description</b>	<i>description-name</i>	Name of the description of the multisegment pseudowire.				
<b>Command Default</b>	None					
<b>Command Modes</b>	l2vpn					
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 4.1.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 4.1.1	This command was introduced.	
Release	Modification					
Release 4.1.1	This command was introduced.					
<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.					
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>l2vpn</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operation	l2vpn	read, write	
Task ID	Operation					
l2vpn	read, write					
<b>Examples</b>	<p>The example shows how to specify the description of a multisegment pseudowire:</p> <pre>RP/0/0/CPU0:router# configure RP/0/0/CPU0:router(config)# l2vpn RP/0/0/CPU0:router(config-l2vpn)# description S-PE1</pre>					
<b>Related Commands</b>	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td><a href="#">description (XCONNECT)</a>, on page 26</td> <td>Specifies the description of an l2vpn cross connect.</td> </tr> </tbody> </table>	Command	Description	<a href="#">description (XCONNECT)</a> , on page 26	Specifies the description of an l2vpn cross connect.	
Command	Description					
<a href="#">description (XCONNECT)</a> , on page 26	Specifies the description of an l2vpn cross connect.					

## description (XCONNECT)

To specify the description of an l2vpn xconnect such as attachment circuit (AC) AC-AC, AC-PW, and multisegment pseudowire (MS-PW), use the **description** command in L2VPN xconnect mode. To revert, use the **no** form of the command.

**description** *description-name*

**no description**

Syntax Description	<i>description-name</i>	Name of the description of the cross connect.
--------------------	-------------------------	---

Command Default	None
-----------------	------

Command Modes	L2VPN xconnect
---------------	----------------

Command History	Release	Modification
	Release 4.1.1	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
------------------	---

Task ID	Task ID	Operation
	l2vpn	read, write

**Examples** The example shows how to specify the description of a cross connect:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# xconnect group MS-PW1
RP/0/0/CPU0:router(config-l2vpn-xc)# p2p ms-pw1
RP/0/0/CPU0:router(config-l2vpn-xc-p2p)# description MS-PW from T-PE1 to T-PE2
```

Related Commands	Command	Description
	<a href="#">description (GLOBAL)</a> , on page 25	Specifies multisegment pseudowire global description.

## digest (L2TP)

To configure digest options, use the **digest** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

```
digest {check disable| hash {MD5| SHA1}| secret {0| 7| word}}
```

```
no digest {check disable| hash {MD5| SHA1}| secret {0| 7| word}}
```

### Syntax Description

check disable	Disables digest checking.
hash {MD5   SHA1}	Configures the digest hash method (MD5 or SHA1). Default is MD5.
secret {0   7   word}	Configures a shared secret for message digest.

### Command Default

**check disable:** Digest checking is enabled by default.

**hash:** Default is MD5 if the **digest** command is issued without the secret keyword option and L2TPv3 integrity checking is enabled.

### Command Modes

L2TP class configuration

### Command History

Release	Modification
Release 3.7.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The digest secret and hash algorithm can be configured in the l2tp-class configuration for authentication of the control channel. For control channel authentication to work correctly, however, both sides of the L2TP control channel connection must share a common secret and hash algorithm.

To update of digest secret without network disruption, Cisco supports a maximum to two digest secrets. You can configure a new secret while keeping the old secret valid. You can safely remove the old secret after you update all affected peer nodes with a new secret,

### Task ID

Task ID	Operations
l2vpn	read, write

**Examples**

The following example shows how to configure digest options for L2TP:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2tp-class cisco
RP/0/0/CPU0:router(config-l2tp-class)# digest check disable
RP/0/0/CPU0:router(config-l2tp-class)# digest secret cisco hash md5
```

**Related Commands**

Command	Description
<a href="#">authentication (L2TP), on page 4</a>	Enables L2TP authentication for a specified L2TP class name.
<a href="#">hello-interval (L2TP), on page 29</a>	Configures the hello-interval value for L2TP (duration between control channel hello packets).
<a href="#">hidden (L2TP), on page 31</a>	Enables hidden attribute-value pairs (AVPs).
<a href="#">hostname (L2TP), on page 33</a>	Defines the name used in the L2TP hostname AVP.
<a href="#">l2tp-class, on page 40</a>	Enters L2TP class configuration mode where you can define an L2TP signaling template.
<a href="#">password (L2TP), on page 63</a>	Defines the password and password encryption type for control channel authentication.
<a href="#">receive-window (L2TP), on page 76</a>	Configures the receive window size for the L2TP server.
<a href="#">retransmit (L2TP), on page 78</a>	Configures retransmit retry and timeout values.

## hello-interval (L2TP)

To configure the hello-interval value for L2TP (duration between control channel hello packets), use the **hello interval (L2TP)** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

**hello-interval** *interval*

**no hello-interval** *interval*

<b>Syntax Description</b>	<i>interval</i>	Interval (in seconds) between control channel hello packets. The range is from 0 to 1000. Default is 60 seconds.
---------------------------	-----------------	--

<b>Command Default</b>	<i>interval</i> : 60 seconds
------------------------	------------------------------

<b>Command Modes</b>	L2TP class configuration
----------------------	--------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	l2vpn	read, write

**Examples** The following example shows how to configure the hello-interval value for L2TP to 22 seconds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2tp-class cisco
RP/0/0/CPU0:router(config-l2tp-class)# hello-interval 22
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">authentication (L2TP)</a> , <a href="#">on page 4</a>	Enables L2TP authentication for a specified L2TP class name.

Command	Description
<a href="#">hidden (L2TP), on page 31</a>	Enables hidden attribute-value pairs (AVPs).
<a href="#">hostname (L2TP), on page 33</a>	Defines the name used in the L2TP hostname AVP.
<a href="#">l2tp-class, on page 40</a>	Enters L2TP class configuration mode where you can define an L2TP signaling template.
<a href="#">password (L2TP), on page 63</a>	Defines the password and password encryption type for control channel authentication.
<a href="#">receive-window (L2TP), on page 76</a>	Configures the receive window size for the L2TP server.
<a href="#">retransmit (L2TP), on page 78</a>	Configures retransmit retry and timeout values.

# hidden (L2TP)

To enable hidden attribute-value pairs (AVPs), use the **hidden** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

**hidden**

**no hidden**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** L2TP class configuration

Command History	Release	Modification
	Release 3.7.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

**Examples** The following example shows how to enable hidden AVPs:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2tp-class cisco
RP/0/0/CPU0:router(config-l2tp-class)# hidden
```

Related Commands	Command	Description
	<a href="#">authentication (L2TP)</a> , on page 4	Enables L2TP authentication for a specified L2TP class name.
	<a href="#">hello-interval (L2TP)</a> , on page 29	Configures the hello-interval value for L2TP (duration between control channel hello packets).
	<a href="#">hostname (L2TP)</a> , on page 33	Defines the name used in the L2TP hostname AVP.

Command	Description
<a href="#">l2tp-class</a> , on page 40	Enters L2TP class configuration mode where you can define an L2TP signaling template.
<a href="#">password (L2TP)</a> , on page 63	Defines the password and password encryption type for control channel authentication.
<a href="#">receive-window (L2TP)</a> , on page 76	Configures the receive window size for the L2TP server.
<a href="#">retransmit (L2TP)</a> , on page 78	Configures retransmit retry and timeout values.

## hostname (L2TP)

To define the name used in the L2TP hostname AVP, use the **hostname** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

**hostname** *name*

**no hostname** *name*

<b>Syntax Description</b>	<i>name</i>	Hostname used to identify the router during L2TP control channel authentication.
---------------------------	-------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	L2TP class configuration
----------------------	--------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	l2vpn	read, write

<b>Examples</b>	The following example shows how to configure a hostname using the word "cisco":
-----------------	---

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2tp-class cisco
RP/0/0/CPU0:router(config-l2tp-class)# hostname cisco
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">authentication (L2TP)</a> , <a href="#">on page 4</a>	Enables L2TP authentication for a specified L2TP class name.

Command	Description
<a href="#">hello-interval (L2TP), on page 29</a>	Configures the hello-interval value for L2TP (duration between control channel hello packets).
<a href="#">hidden (L2TP), on page 31</a>	Enables hidden attribute-value pairs (AVPs).
<a href="#">l2tp-class, on page 40</a>	Enters L2TP class configuration mode where you can define an L2TP signaling template.
<a href="#">password (L2TP), on page 63</a>	Defines the password and password encryption type for control channel authentication.
<a href="#">receive-window (L2TP), on page 76</a>	Configures the receive window size for the L2TP server.
<a href="#">retransmit (L2TP), on page 78</a>	Configures retransmit retry and timeout values.

## interface (p2p)

To configure an attachment circuit, use the **interface** command in p2p configuration submode. To return to the default behavior, use the **no** form of this command.

```
interface type interface-path-id [PW-Ether | PW-IW]
```

```
no interface type interface-path-id [PW-Ether | PW-IW]
```

### Syntax Description

<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. <b>Note</b> Use the <b>show interfaces</b> command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
<b>PW-Ether</b>	(Optional) Configures an Ethernet Interface.
<b>PW-IW</b>	(Optional) Configures an IP Interworking Interface.

### Command Default

None

### Command Modes

p2p configuration submode

### Command History

Release	Modification
Release 3.4.0	This command was introduced.
Release 4.2.1	The following keywords were added: <ul style="list-style-type: none"> <li>• <b>PW-Ether</b></li> <li>• <b>PW-IW</b></li> </ul>

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

**Task ID**

Task ID	Operations
l2vpn	read, write

**Examples**

The following example shows how to configure an attachment circuit on a TenGigE interface:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# xconnect group gr1
RP/0/0/CPU0:router(config-l2vpn-xc)# p2p p001
RP/0/0/CPU0:router(config-l2vpn-xc-p2p)# interface TenGigE 1/1/1/1
```

**Related Commands**

Command	Description
<a href="#">p2p, on page 74</a>	Enters p2p configuration submode to configure point-to-point cross-connects.

# interworking ipv4

To configure IPv4 interworking, use the **interworking ipv4** command in the p2p configuration submode. To return to the default behavior, use the **no** form of this command.

**interworking ipv4**  
**no interworking ipv4**

<b>Syntax Description</b>	<b>ipv4</b>	Sets IPv4 interworking.
---------------------------	-------------	-------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	p2p configuration submode
----------------------	---------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.0	This command was introduced.

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	l2vpn	read, write

**Examples**

The following example shows how to configure an attachment circuit on a TenGigE interface:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# xconnect group gr1
RP/0/0/CPU0:router(config-l2vpn-xc)# p2p gr1
RP/0/0/CPU0:router(config-l2vpn-xc-p2p)# interworking ipv4
RP/0/0/CPU0:router(config-l2vpn-xc-p2p)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">p2p</a> , <a href="#">on page 74</a>	Enters p2p configuration submode to configure point-to-point cross-connects.

# interworking ethernet

To configure ethernet interworking across a pseudowire that enables delivery of Ethernet frames, use the **interworking ethernet** command in p2p configuration submode. To undo the configuration, use the **no** form of this command.

**interworking ethernet**

**no interworking ethernet**

## Syntax Description

<b>ethernet</b>	Specifies the type of pseudowire and the type of traffic that can flow across it.
-----------------	---

## Command Default

None

## Command Modes

p2p configuration submode

## Command History

Release	Modification
Release 4.2.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operation
l2vpn	read, write

## Examples

This example shows how to configure an ethernet interface:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# Xconnect group grp1
RP/0/0/CPU0:router(config-l2vpn-xc)# p2p AC1_to_PW1
RP/0/0/CPU0:router(config-l2vpn-xc-p2p)# interworking ethernet
RP/0/0/CPU0:router(config-l2vpn-xc-p2p)#
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">p2p, on page 74</a>	Enters p2p configuration submode to configure point-to-point cross-connects.
<a href="#">interworking ipv4, on page 37</a>	Configures IPv4 interworking.

# l2tp-class

To enter L2TP class configuration mode where you can define an L2TP signaling template, use the **l2tp-class** command in global configuration mode. To delete the L2TP class, use the **no** form of this command.

**l2tp-class** *l2tp-class-name*

**no l2tp-class** *l2tp-class-name*

## Syntax Description

l2tp-class-name	L2TP class name.
-----------------	------------------

## Command Default

No L2TP classes are defined.

## Command Modes

Global configuration

## Command History

Release	Modification
Release 3.7.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



### Note

An L2TP class name must be defined before configuring L2TP control plane configuration settings.

## Task ID

Task ID	Operations
l2vpn	read, write

## Examples

The following example shows how to enter L2TP configuration mode to create a template of L2TP control plane configuration settings that can be inherited by different pseudowire classes (in this case, the word “cisco” is used):

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2tp-class cisco
RP/0/0/CPU0:router(config-l2tp-class)#
```

# l2tp-class configuration

To enter L2TP class configuration mode in which an L2TP signaling template is not defined, use the **l2tp-class configuration** command in global configuration mode. To delete the L2TP class configuration, use the **no** form of this command.

**l2tp-class configuration**

**no l2tp-class configuration**

**Syntax Description** This command has no arguments or keywords.

**Command Default** No L2TP classes are defined.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.8.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

**Examples** The following example shows how to enter L2TP configuration mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2tp-class configuration
RP/0/0/CPU0:router(config-l2tp-class)#
```

Related Commands	Command	Description
	<a href="#">authentication (L2TP)</a> , <a href="#">on page 4</a>	Enables L2TP authentication for a specified L2TP class name.
	<a href="#">hello-interval (L2TP)</a> , <a href="#">on page 29</a>	Configures the hello-interval value for L2TP (duration between control channel hello packets).

Command	Description
<a href="#">hidden (L2TP), on page 31</a>	Enables hidden attribute-value pairs (AVPs).
<a href="#">hostname (L2TP), on page 33</a>	Defines the name used in the L2TP hostname AVP.
<a href="#">password (L2TP), on page 63</a>	Defines the password and password encryption type for control channel authentication.
<a href="#">receive-window (L2TP), on page 76</a>	Configures the receive window size for the L2TP server.
<a href="#">retransmit (L2TP), on page 78</a>	Configures retransmit retry and timeout values.

# l2transport

To configure a physical interface to operate in Layer 2 transport mode, use the **l2transport** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

## l2transport

### no l2transport

This command has no arguments or keywords.

#### Command Default

None

#### Command Modes

Interface configuration

#### Command History

Release	Modification
Release 3.4.0	This command was introduced.

#### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The l2transport command and these configuration items are mutually exclusive:

- IPv4 address and feature (for example, ACL) configuration
- IPv4 enable, address and feature (for example, ACL) configuration
- Bundle-enabling configuration
- L3 subinterfaces
- Layer 3 QoS Policy



#### Note

After an interface or connection is set to Layer 2 switched, commands such as **ipv4 address** are not usable. If you configure routing commands on the interface, **l2transport** is rejected.

#### Task ID

Task ID	Operations
l2vpn	read, write

**Examples**

The following example shows how to configure an interface or connection as Layer 2 switched under several different modes:

**Ethernet Port Mode:**

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface GigabitEthernet 0/0/0/0
RP/0/0/CPU0:router(config-if)# l2transport
```

**Ethernet VLAN Mode:**

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface GigabitEthernet 0/0/0/0.900 l2transport
RP/0/0/CPU0:router(config-if)# encapsulation dot1q 100dot1q vlan 999
```

**Ethernet VLAN Mode (QinQ):**

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface GigabitEthernet 0/0/0/0.900 l2transport
RP/0/0/CPU0:router(config-if)# encapsulation dot1q 20 second-dot1q 10vlan 999 888
```

**Ethernet VLAN Mode (QinAny):**

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface GigabitEthernet 0/0/0/0.900 l2transport
RP/0/0/CPU0:router(config-if)# encapsulation dot1q 30 second-dot1q dot1q vlan 999 any
```

**Related Commands**

Command	Description
<a href="#">show l2vpn forwarding</a> , <a href="#">on page 105</a>	Displays forwarding information from the layer2_fib manager on the line card.

# l2transport cell-packing

To configure L2VPN cell packing parameters, use the **l2transport cell-packing** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

**l2transport cell-packing** *maximum timer*

**no l2transport cell-packing** *maximum timer*

## Syntax Description

<i>maximum</i>	Maximum number of cells to be packed in a packet. Range is 2 to 86.
<i>timer</i>	Cell packing timer (1, 2, or 3).

## Command Default

No default behavior or values

## Command Modes

Interface configuration

## Command History

Release	Modification
Release 3.5.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operations
l2vpn	read, write
atm	read, write

## Examples

The following example shows how to configure L2VPN cell packing parameters:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface GigabitEthernet 0/0/0/0
RP/0/0/CPU0:router(config-if)# l2transport cell-packing 33 2
```

**Related Commands**

Command	Description
<a href="#">show l2vpn forwarding, on page 105</a>	Displays forwarding information from the layer2_fib manager on the line card.

# l2transport propagate

To propagate Layer 2 transport events, use the **l2transport propagate** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

**l2transport propagate remote-status**

**no l2transport propagate remote-status**

Syntax Description	remote-status	Propagates remote link status changes.
--------------------	---------------	--

Command Default	None
-----------------	------

Command Modes	Interface configuration
---------------	-------------------------

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **l2transport propagate** command provides a mechanism for the detection and propagation of remote link failure for port mode EoMPLS.

To display the state of l2transport events, use the **show controller internal** command in *Cisco IOS XR Interface and Hardware Component Configuration Guide for the Cisco XR 12000 Series Router*

For more information about the Ethernet remote port shutdown feature, see *Cisco IOS XR MPLS Configuration Guide for the Cisco XR 12000 Series Router*.

Task ID	Task ID	Operations
	l2vpn	read, write

## Examples

The following example shows how to propagate remote link status changes:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface GigabitEthernet 0/0/0/0
RP/0/0/CPU0:router(config-if)# l2transport propagate remote remote-status
```

**Related Commands**

Command	Description
<a href="#">show l2vpn forwarding, on page 105</a>	Displays forwarding information from the layer2_fib manager on the line card.

# l2vpn

To enter L2VPN configuration mode, use the **l2vpn** command in global configuration mode. To return to the default behavior, use the **no** form of this command.

**l2vpn**  
**no l2vpn**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.4.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



**Note**

All L2VPN configuration can be deleted using the **no l2vpn** command.

Task ID	Task ID	Operations
	l2vpn	read, write

**Examples** The following example shows how to enter L2VPN configuration mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)#
```

**Related Commands**

Command	Description
<a href="#">show l2vpn forwarding, on page 105</a>	Displays forwarding information from the layer2_fib manager on the line card.

# l2vpn switchover

To force a manual pseudowire switchover, use the **l2vpn switchover** command in EXEC mode.

**l2vpn switchover xconnect neighbor *IP-address* pw-id *value***

## Syntax Description

<b>xconnect</b>	Configures the switchover for the cross-connect.
<b>neighbor <i>IP-address</i></b>	Configures the peer for the cross-connect.
<b>pw-id <i>value</i></b>	Configures the pseudowire ID. The range is from 1 to 4294967295.

## Command Default

None

## Command Modes

EXEC

## Command History

Release	Modification
Release 4.1.1	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If the backup exists, you can switch a primary router over to the backup router. You can use the **l2vpn switchover** command to reactivate the primary router.

## Task ID

Task ID	Operations
l2vpn	read, write, execute

## Examples

The following example shows how to switch a primary pseudowire to a backup pseudowire:

```
RP/0/0/CPU0:router# l2vpn switchover xconnect neighbor 10.1.1.1 pw-id 2
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">backup disable (L2VPN), on page 8</a>	Specifies how long a backup pseudowire should wait before resuming operation after the primary pseudowire goes down.

## logging (l2vpn)

To enable cross-connect logging, use the **logging** command in L2VPN configuration submode. To return to the default behavior, use the **no** form of this command.

**logging pseudowire status**

**no logging pseudowire status**

### Syntax Description

pseudowire status	Enables pseudowire state change logging.
-------------------	--

### Command Default

None

### Command Modes

L2VPN configuration submode

### Command History

Release	Modification
Release 3.5.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



#### Note

All L2VPN configuration can be deleted using the **no l2vpn** command.

### Task ID

Task ID	Operations
l2vpn	read, write

### Examples

The following example shows how to enable cross-connect logging:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# logging pseudowire status
```

**Related Commands**

Command	Description
<a href="#">l2vpn</a> , on page 49	Enters L2VPN configuration mode.

# logging nsr

To enable non-stop routing logging, use the **logging nsr** command in L2VPN configuration submode. To return to the default behavior, use the **no** form of this command.

**logging nsr**

**no logging nsr**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** L2VPN configuration submode

Command History	Release	Modification
	Release 4.3.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



**Note**

All L2VPN configuration can be deleted using the **no l2vpn** command.

Task ID	Task ID	Operations
	l2vpn	read, write

## Examples

The following example shows how to enable non-stop routing logging:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# logging nsr
```

**Related Commands**

Command	Description
<a href="#">l2vpn</a> , on page 49	Enters L2VPN configuration mode.

## mpls static label (L2VPN)

To configure static labels for MPLS L2VPN, use the **mpls static label** command in L2VPN cross-connect P2P pseudowire configuration mode. To have MPLS assign a label dynamically, use the **no** form of this command.

**mpls static label local** *label* **remote** *value*

**no mpls static label local** *label* **remote** *value*

### Syntax Description

**local** *label* Configures a local pseudowire label. Range is 16 to 15999.

**remote** *value* Configures a remote pseudowire label. Range is 16 to 15999.

### Command Default

The default behavior is a dynamic label assignment.

### Command Modes

L2VPN cross-connect P2P pseudowire configuration

### Command History

Release	Modification
Release 3.7.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

### Task ID

Task ID	Operations
l2vpn	read, write

### Examples

The following example shows how to configure static labels for MPLS L2VPN:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn xconnect group l2vpn
RP/0/0/CPU0:router(config-l2vpn-xc)# p2p rtrA_to_rtrB
RP/0/0/CPU0:router(config-xc-p2p)# neighbor 10.1.1.2 pw-id 1000
RP/0/0/CPU0:router(config-l2vpn-xc-p2p-pw)# mpls static label local 800 remote 500
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.
<a href="#">neighbor (L2VPN), on page 59</a>	Configures a pseudowire for a cross-connect.
<a href="#">p2p, on page 74</a>	Enters p2p configuration submode to configure point-to-point cross-connects.
<a href="#">xconnect group, on page 151</a>	Configures cross-connect groups.

## neighbor (L2VPN)

To configure a pseudowire for a cross-connect, use the **neighbor** command in p2p configuration submode. To return to the default behavior, use the **no** form of this command.

**neighbor** *A.B.C.D* **pw-id** *value* [**backup**| **mpls** || **pw-class** | **tag-impose**]

**no neighbor** *A.B.C.D* **pw-id** *value* [**backup**| **mpls** || **pw-class** | **tag-impose**]

### Syntax Description

<i>A.B.C.D</i>	IP address of the cross-connect peer.
<b>pw-id</b> <i>value</i>	Configures the pseudowire ID and ID value. Range is 1 to 4294967295.
<b>tag-impose</b>	Optional Specifies a tag during a VLAN ID configuration.

### Command Default

None

### Command Modes

p2p configuration submode

### Command History

Release	Modification
Release 3.4.0	This command was introduced.
Release 3.4.1	The <b>vccv disable</b> keyword was added.
Release 3.7.0	These keywords were removed: <ul style="list-style-type: none"> <li>• <b>control-word</b></li> <li>• <b>pw-static-label local</b></li> <li>• <b>remote</b></li> <li>• <b>vccv</b></li> <li>• <b>transport-mode</b></li> </ul>
Release 4.2.1	The keyword <b>tag-impose</b> was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

A cross-connect may have two segments:

- 1 An Attachment Circuit (AC)
- 2 An second AC or a pseudowire

**Note**

The pseudowire is identified by two keys: neighbor and pseudowire ID. There may be multiple pseudowires going to the same neighbor. It is not possible to configure only a neighbor.

All L2VPN configurations can be deleted using the **no l2vpn** command.

**Task ID**

Task ID	Operations
l2vpn	read, write

**Examples**

This example shows a point-to-point cross-connect configuration (including pseudowire configuration):

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn xconnect group l2vpn
RP/0/0/CPU0:router(config-l2vpn-xc)# p2p rtrA_to_rtrB
RP/0/0/CPU0:router(config-xc-p2p)# neighbor 10.1.1.2 pw-id 1000 pw-class class12
RP/0/0/CPU0:router(config-xc-p2p)# neighbor 10.1.1.3 pw-id 1001 pw-class class13
RP/0/0/CPU0:router(config-xc)# p2p rtrC_to_rtrD
RP/0/0/CPU0:router(config-xc-p2p)# neighbor 10.2.2.3 pw-id 200 pw-class class23
RP/0/0/CPU0:router(config-xc-p2p)# neighbor 10.2.2.4 pw-id 201 pw-class class24
```

This example shows a point-to-point cross-connect configuration (including pseudowire configuration):

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn xconnect group l2vpn
RP/0/0/CPU0:router(config-l2vpn-xc)# p2p rtrA_to_rtrB
RP/0/0/CPU0:router(config-xc-p2p)# neighbor 10.1.1.2 pw-id 1000 pw-class foo
RP/0/0/CPU0:router(config-xc)# p2p rtrC_to_rtrD
RP/0/0/CPU0:router(config-xc-p2p)# neighbor 20.2.2.3 pw-id 200 pw-class bar1
```

**Related Commands**

Command	Description
<a href="#">l2vpn</a> , on page 49	Enters L2VPN configuration mode.
<a href="#">p2p</a> , on page 74	Enters p2p configuration submode to configure point-to-point cross-connects.
<a href="#">pw-class (L2VPN)</a> , on page 65	Enters pseudowire class submode to define a pseudowire class template.
<a href="#">xconnect group</a> , on page 151	Configures cross-connect groups.

## nsr (L2VPN)

To configure non-stop routing, use the **nsr** command in L2VPN configuration submode. To return to the default behavior, use the **no** form of this command.

**nsr**

**no nsr**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** L2VPN configuration submode

Command History	Release	Modification
	Release 4.3.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



**Note**

All L2VPN configuration can be deleted using the **no l2vpn** command.

Task ID	Task ID	Operation
	l2vpn	read, write

**Examples** The following example shows how to configure non-stop routing:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# nsr
```

**Related Commands**

Command	Description
<a href="#">l2vpn</a> , on page 49	Enters L2VPN configuration mode.

## password (L2TP)

To define the password and password encryption type for control channel authentication, use the **password** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

**password** [**0**| **7**] *password*

**no password**

Syntax Description		
	<b>0</b>	(Optional) Specifies that an unencrypted password will follow.
	<b>7</b>	(Optional) Specifies that an encrypted password will follow.
	<i>password</i>	Unencrypted or clear text user password.

**Command Default** None

**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.7.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

**Examples** The following example shows how to define an unencrypted password using the word "cisco" for control channel authentication:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2tp-class sanjose
RP/0/0/CPU0:router(config-l2tp-class)# password 0 cisco
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">authentication (L2TP)</a> , on page 4	Enables L2TP authentication for a specified L2TP class name.
<a href="#">hello-interval (L2TP)</a> , on page 29	Configures the hello-interval value for L2TP (duration between control channel hello packets).
<a href="#">hidden (L2TP)</a> , on page 31	Enables hidden attribute-value pairs (AVPs).
<a href="#">hostname (L2TP)</a> , on page 33	Defines the name used in the L2TP hostname AVP.
<a href="#">l2tp-class</a> , on page 40	Enters L2TP class configuration mode where you can define an L2TP signaling template.
<a href="#">receive-window (L2TP)</a> , on page 76	Configures the receive window size for the L2TP server.
<a href="#">retransmit (L2TP)</a> , on page 78	Configures retransmit retry and timeout values.

## pw-class (L2VPN)

To enter pseudowire class submode to define a pseudowire class template, use the **pw-class** command in L2VPN configuration submode. To delete the pseudowire class, use the **no** form of this command.

**pw-class** *class-name*

**no pw-class** *class-name*

### Syntax Description

<i>class-name</i>	Pseudowire class name.
-------------------	------------------------

### Command Default

None

### Command Modes

L2VPN configuration submode

### Command History

Release	Modification
Release 3.5.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



#### Note

All L2VPN configurations can be deleted using the **no l2vpn** command.

### Task ID

Task ID	Operations
l2vpn	read, write

### Examples

The following example shows how to define a simple pseudowire class template:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# xconnect group l1vpn
RP/0/0/CPU0:router(config-l2vpn-xc)# p2p rtrA_to_rtrB
RP/0/0/CPU0:router(config-l2vpn-xc-p2p)# neighbor 10.1.1.2 pw-id 1000
RP/0/0/CPU0:router(config-l2vpn-xc-p2p-pw)# pw-class kanata01
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">p2p, on page 74</a>	Enters p2p configuration submode to configure point-to-point cross-connects.

## pw-class encapsulation l2tpv3

To configure L2TPv3 pseudowire encapsulation, use the **pw-class encapsulation l2tpv3** command in L2VPN pseudowire class configuration mode. To return to the default behavior, use the **no** form of this command.

```
pw-class class name encapsulation l2tpv3 [cookie size {0|4|8}| ipv4 source address| pmtu max 68-65535|
protocol l2tpv3 class name| tos {reflect value 0-255| value 0-255}| ttl value]
```

```
no pw-class class name encapsulation l2tpv3 [cookie size {0|4|8}| ipv4 source address| pmtu max
68-65535| protocol l2tpv3 class name| tos {reflect value 0-255| value 0-255}| ttl value]
```

### Syntax Description

<b>class name</b>	Configures an encapsulation class name.
<b>cookie size {0   4   8}</b>	(Optional) Configures the L2TPv3 cookie size setting: <ul style="list-style-type: none"> <li>• 0—Cookie size is 0 bytes.</li> <li>• 4—Cookie size is 4 bytes.</li> <li>• 8—Cookie size is 8 bytes.</li> </ul>
<b>ipv4 source <i>address</i></b>	(Optional) Configures the local source IPv4 address.
<b>pmtu max 68-65535</b>	(Optional) Configures the value of the maximum allowable session MTU.
<b>protocol l2tpv3 class <i>name</i></b>	(Optional) Configures L2TPv3 as the signaling protocol for the pseudowire class.
<b>tos {reflect value 0-255   value 0-255}</b>	(Optional) Configures TOS and the TOS value. Range is 0 to 255.
<b>ttl <i>value</i></b>	Configures the Time-to-live (TTL) value. Range is 1 to 255.

### Command Default

None

### Command Modes

L2VPN pseudowire class configuration

### Command History

Release	Modification
Release 3.7.0	This command was introduced.

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

**Note**

All L2VPN configurations can be deleted using the **no l2vpn** command.

**Task ID**

Task ID	Operations
l2vpn	read, write

**Examples**

The following example shows how to define L2TPV3 pseudowire encapsulation:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# pw-class kanata01
RP/0/0/CPU0:router(config-l2vpn-pwc)# encapsulation l2tpv3
```

The following example shows how to set the encapsulation and protocol to L2TPV3:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# pw-class kanata01
RP/0/0/CPU0:router(config-l2vpn-pwc)# encapsulation l2tpv3
RP/0/0/CPU0:router(config-l2vpn-pwc-l2tpv3)# protocol l2tpv3
```

**Related Commands**

Command	Description
<a href="#">pw-class (L2VPN), on page 65</a>	Enters pseudowire class submode to define a pseudowire class template.
<a href="#">pw-class encapsulation mpls, on page 69</a>	Configures MPLS pseudowire encapsulation.

## pw-class encapsulation mpls

To configure MPLS pseudowire encapsulation, use the **pw-class encapsulation mpls** command in L2VPN pseudowire class configuration mode. To undo the configuration, use the **no** form of this command.

**pw-class** *class-name* **encapsulation mpls** {**control word**| **ipv4**| **load-balancing**| **preferred-path**| **protocol ldp**| **redundancy one-way**| **sequencing**| **tag-rewrite**| **transport-mode**| **vccv verification-type none**}

**no pw-class** *class-name* **encapsulation mpls** {**control word**| **ipv4**| **load-balancing**| **preferred-path**| **protocol ldp**| **redundancy one-way**| **sequencing**| **tag-rewrite**| **transport-mode**| **vccv verification-type none**}

### Syntax Description

<i>class-name</i>	Encapsulation class name.
<b>control word</b>	Disables control word for MPLS encapsulation. Disabled by default.
<b>ipv4</b>	Sets the local source IPv4 address.
<b>load-balancing</b>	Sets flow label-based load balancing.
<b>preferred-path</b>	Configures the preferred path tunnel settings.
<b>protocol ldp</b>	Configures LDP as the signaling protocol for this pseudowire class.
<b>redundancy one-way</b>	Configures one-way PW redundancy behavior in the Redundancy Group.
<b>sequencing</b>	Configures sequencing on receive or transmit.
<b>tag-rewrite</b>	Configures VLAN tag rewrite.
<b>transport-mode</b>	Configures transport mode to be either Ethernet or VLAN.
<b>vccv none</b>	Enables or disables the VCCV verification type.

**Command Default** None

**Command Modes** L2VPN pseudowire class configuration

**Command History**

Release	Modification
Release 3.5.0	This command was introduced.
Release 3.8.0	The keywords <b>control word disable</b> and <b>vccv none</b> were replaced by the keywords <b>control word</b> and <b>vccv verification-type none</b> .
Release 3.9.0	The following keywords were added: <ul style="list-style-type: none"> <li>• <b>preferred-path</b></li> <li>• <b>sequencing</b></li> <li>• <b>tag-rewrite</b></li> <li>• <b>transport-mode</b></li> </ul>
Release 4.2.0	The keyword <b>redundancy one-way</b> was introduced.

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

**Note**

All L2VPN configurations can be deleted using the **no l2vpn** command.

**Task ID**

Task ID	Operations
l2vpn	read, write

**Examples**

This example shows how to define MPLS pseudowire encapsulation:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# pw-class kanata01
RP/0/0/CPU0:router(config-l2vpn-pwc)# encapsulation mpls
```

**Related Commands**

Command	Description
<a href="#">pw-class (L2VPN), on page 65</a>	Enters pseudowire class submode to define a pseudowire class template.
<a href="#">pw-class encapsulation l2tpv3, on page 67</a>	Configures L2TPv3 pseudowire encapsulation.

# pw-ether

To configure a PWHE Ethernet interface, use the **pw-ether** command in global configuration mode or in p2p configuration submenu. To return to the default behavior, use the **no** form of this command.

**pw-ether** *value*

**no pw-ether** *value*

## Syntax Description

<i>value</i>	Value of the PWHE Ethernet interface. The range is from 1 to 32768.
--------------	---

## Command Default

None

## Command Modes

Global configuration  
p2p configuration

## Command History

Release	Modification
Release 4.2.1	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operation
interface (global configuration)	read, write
l2vpn (p2p configuration)	read, write

## Examples

This example shows the sample output of a PWHE Ethernet interface configuration in global configuration mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface pw-ether 78
RP/0/0/CPU0:router(config-if)# attach generic-interface-list interfacelist1
```

This example shows the sample output of a PWHE Ethernet interface configuration in p2p configuration submode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# xconnect group xc1
RP/0/0/CPU0:router(config-l2vpn-xc)# p2p grp1
RP/0/0/CPU0:router(config-l2vpn-xc-p2p)# interface pw-ether 78
```

This example shows the sample output of L2 overhead configuration for the PW-HE interface:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface pw-ether 78
RP/0/0/CPU0:router(config-if)# l2overhead 32
```

This example shows the sample output of Load-interval configuration for the PW-HE interface:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface pw-ether 78
RP/0/0/CPU0:router(config-if)# load-interval 60
```

This example shows the sample output of how to set logging of interface state change for the PW-HE interface:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface pw-ether 78
RP/0/0/CPU0:router(config-if)# logging events link-status
```

This example shows the sample output of MAC address configuration for the PW-HE interface:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface pw-ether 78
RP/0/0/CPU0:router(config-if)# mac-address 44-37-E6-89-C3-93
```

This example shows the sample output of MTU configuration for the PW-HE interface:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface pw-ether 78
RP/0/0/CPU0:router(config-if)# mtu 128
```

This example shows the sample output of bandwidth configuration for the PW-HE interface:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# interface pw-ether 78
RP/0/0/CPU0:router(config-if)# bandwidth 256
```

## Related Commands

Command	Description
<a href="#">p2p</a> , <a href="#">on page 74</a>	Enters p2p configuration submode to configure point-to-point cross-connects.

# pw-grouping

To enable Pseudowire Grouping, use the **pw-grouping** command in L2vpn configuration submode. To return to the default behavior, use the **no** form of this command.

**pw-grouping**

**no pw-grouping**

## Syntax Description

<b>pw-grouping</b>	Enables Pseudowire Grouping.
--------------------	------------------------------

## Command Default

PW-grouping is disabled by default.

## Command Modes

L2VPN configuration submode

## Command History

Release	Modification
Release 4.3.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operation
l2vpn	read, write

## Examples

This example shows the sample output of pw-grouping configuration in L2VPN configuration submode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# pw-grouping
```

## Related Commands

Command	Description
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.
<a href="#">show l2vpn, on page 95</a>	Displays L2VPN information

## p2p

To enter p2p configuration submode to configure point-to-point cross-connects, use the **p2p** command in L2VPN xconnect mode. To return to the default behavior, use the **no** form of this command.

**p2p** *xconnect-name*

**no p2p** *xconnect-name*

### Syntax Description

<i>xconnect-name</i>	(Optional) Configures the name of the point-to-point cross- connect.
----------------------	--

### Command Default

None

### Command Modes

L2VPN xconnect

### Command History

Release	Modification
Release 3.4.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The name of the point-to-point cross-connect string is a free format description string.

### Task ID

Task ID	Operations
l2vpn	read, write

### Examples

The following example shows a point-to-point cross-connect configuration (including pseudowire configuration):

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# xconnect group group 1
RP/0/0/CPU0:router(config-l2vpn-xc)# p2p xc1
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">interface (p2p), on page 35</a>	Configures an attachment circuit.

## receive-window (L2TP)

To configure the receive window size for the L2TP server, use the **receive-window** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

**receive-window** *size*

**no receive-window** *size*

### Syntax Description

<i>size</i>	Maximum number of packets that are received from a peer before back-off is applied. Default is 512.
-------------	---

### Command Default

*size*: 512

### Command Modes

L2TP class configuration

### Command History

Release	Modification
Release 3.7.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

### Task ID

Task ID	Operations
l2vpn	read, write

### Examples

The following example shows how to configure the receive window size for the L2TP server to 10 packets:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2tp-class cisco
RP/0/0/CPU0:router(config-l2tp-class)# receive-window 10
```

### Related Commands

Command	Description
<a href="#">authentication (L2TP)</a> , <a href="#">on page 4</a>	Enables L2TP authentication for a specified L2TP class name.

Command	Description
<a href="#">hello-interval (L2TP), on page 29</a>	Configures the hello-interval value for L2TP (duration between control channel hello packets).
<a href="#">hidden (L2TP), on page 31</a>	Enables hidden attribute-value pairs (AVPs).
<a href="#">hostname (L2TP), on page 33</a>	Defines the name used in the L2TP hostname AVP.
<a href="#">l2tp-class, on page 40</a>	Enters L2TP class configuration mode where you can define an L2TP signaling template.
<a href="#">password (L2TP), on page 63</a>	Defines the password and password encryption type for control channel authentication.
<a href="#">retransmit (L2TP), on page 78</a>	Configures retransmit retry and timeout values.

## retransmit (L2TP)

To configure retransmit retry and timeout values, use the **retransmit** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

**retransmit** {**initial** *initial-retries*| **retries** *retries*| **timeout** {**max**| **min**} *timeout*}

**no retransmit** {**initial** *initial-retries*| **retries** *retries*| **timeout** {**max**| **min**} *timeout*}

### Syntax Description

<b>initial</b> <i>initial-retries</i>	Configures the number of SCCRQ messages resent before giving up on a particular control channel. Range is 1 to 1000. Default is 2.
<b>retries</b> <i>retries</i>	Configures the maximum number of retransmissions before determining that peer router does not respond. Range is 5 to 1000. Default is 15.
<b>timeout</b> { <b>max</b>   <b>min</b> } <i>timeout</i>	Configures the maximum and minimum retransmission interval in seconds for control packets. Range is 1 to 8. Maximum timeout default is 8 seconds. Minimum timeout default is 1 second.

### Command Default

*initial retries: 2*

*retries: 15*

*min timeout: 1*

*max timeout: 8*

### Command Modes

L2TP class configuration

### Command History

Release	Modification
Release 3.7.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

### Task ID

Task ID	Operations
l2vpn	read, write

**Examples**

The following example shows how to configure a retransmit retry value to 1:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2tp-class cisco
RP/0/0/CPU0:router(config-l2tp-class)# retransmit initial retries 1
```

**Related Commands**

Command	Description
<a href="#">authentication (L2TP), on page 4</a>	Enables L2TP authentication for a specified L2TP class name.
<a href="#">hello-interval (L2TP), on page 29</a>	Configures the hello-interval value for L2TP (duration between control channel hello packets).
<a href="#">hidden (L2TP), on page 31</a>	Enables hidden attribute-value pairs (AVPs).
<a href="#">hostname (L2TP), on page 33</a>	Defines the name used in the L2TP hostname AVP.
<a href="#">l2tp-class, on page 40</a>	Enters L2TP class configuration mode where you can define an L2TP signaling template.
<a href="#">password (L2TP), on page 63</a>	Defines the password and password encryption type for control channel authentication.
<a href="#">receive-window (L2TP), on page 76</a>	Configures the receive window size for the L2TP server.

## rollover (L3VPN)

To configure rollover times for a tunnel-template, use the **rollover** command in tunnel encapsulation l2tp configuration mode. To return to the default behavior, use the **no** form of this command.

**rollover** *periodic time holdown time*

**no rollover** *periodic time holdown time*

### Syntax Description

<b>periodic</b> <i>time</i>	Configures the periodic rollover time in seconds. Range is 60 to 31536000.
<b>holddown</b> <i>time</i>	Configures the holddown time for old session cookie values.

### Command Default

None

### Command Modes

tunnel encapsulation l2tp configuration

### Command History

Release	Modification
Release 3.5.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The name of the point-to-point cross-connect string is a free format description string.

### Task ID

Task ID	Operations
l2vpn	read, write

### Examples

The following example shows how to configure rollover times for a tunnel-template:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# tunnel-template kanata_9
RP/0/0/CPU0:router(config-tuntem) encapsulation l2tp
RP/0/0/CPU0:router(config-tunencap-l2tp)# rollover
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">interface (p2p), on page 35</a>	Configures an attachment circuit.

## sequencing (L2VPN)

To configure L2VPN pseudowire class sequencing, use the **pw-class sequencing** command in L2VPN pseudowire class encapsulation mode. To return to the default behavior, use the **no** form of this command.

**sequencing** {both| receive| transmit {resynch 5-65535}}

**no sequencing** {both| receive| transmit {resynch 5-65535}}

### Syntax Description

<b>both</b>	Configures transmit and receive side sequencing.
<b>receive</b>	Configures receive side sequencing.
<b>transmit</b>	Configures transmit side sequencing.
<b>resynch 5-65535</b>	Configures the threshold for out-of-sequence packets before resynchronization. Range is 5 to 65535.

### Command Default

None

### Command Modes

L2VPN pseudowire class encapsulation mode

### Command History

Release	Modification
Release 3.5.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Do not configure **sequence resynch** on high speed circuits. On low speed circuits, do not configure a threshold lower than 10 to 20 seconds of traffic.



#### Note

All L2VPN configurations can be deleted using the **no l2vpn** command.

### Task ID

Task ID	Operations
l2vpn	read, write

## Examples

The following example shows how to configure L2VPN pseudowire class sequencing:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# pw-class kanata01
RP/0/0/CPU0:router(config-l2vpn-pw)# encapsulation mpls
RP/0/0/CPU0:router(config-l2vpn-encap-mpls)# sequencing both
```

## Related Commands

Command	Description
<a href="#">pw-class (L2VPN)</a> , on page 65	Enters pseudowire class submode to define a pseudowire class template.

# show generic-interface-list

To display information about interface-lists, use the **show generic-interface-list** in EXEC mode.

**show generic-interface-list** [ **location** | **name** | **retry** | **standby** ]

## Syntax Description

<b>location</b>	(Optional) Displays information about interface-lists for the specified location.
<b>name</b>	(Optional) Displays information about interface-lists for the specified interface list name.
<b>retry</b>	(Optional) Displays retry-list information.
<b>standby</b>	(Optional) Displays Standby node specific information.

## Command Default

None

## Command Modes

EXEC

## Command History

Release	Modification
Release 4.3.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operation
l2vpn	read

## Examples

The following example displays output for the **show generic-interface-list** command:

```
RP/0/0/CPU0:router# show generic-interface-list
Thu Aug  2 13:48:57.462 CDT
generic-interface-list: nsrIL (ID: 1, interfaces: 2)
  Bundle-Ether2 - items pending 0, downloaded to FIB
  GigabitEthernet0/0/0/1 - items pending 0, downloaded to FIB
Number of items: 400
List is downloaded to FIB
```

The following example displays output for the **show generic-interface-list retry private** command:

```
RP/0/0/CPU0:router# show generic-interface-list retry private
Thu Aug 2 14:20:42.883 CDT
total: 0 items
```

The following example displays output for the **show generic-interface-list standby** command:

```
RP/0/0/CPU0:router# show generic-interface-list standby
Thu Aug 2 14:25:01.749 CDT
generic-interface-list: nsrIL (ID: 0, interfaces: 2)
Bundle-Ether2 - items pending 0, NOT downloaded to FIB
GigabitEthernet0/0/0/1 - items pending 0, NOT downloaded to FIB
Number of items: 0
List is not downloaded to FIB
```

### Related Commands

Command	Description
<a href="#">l2vpn</a> , on page 49	Enters L2VPN configuration mode.

# show l2tp class

To display information about an L2TP class, use the **show l2tp class** command in EXEC mode.

**show l2tp class** *name name*

## Syntax Description

<b>name</b> <i>name</i>	Configures an L2TP class name.
-------------------------	--------------------------------

## Command Default

None

## Command Modes

EXEC

## Command History

Release	Modification
Release 3.7.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operations
l2vpn	read, write

## Examples

The following example shows sample output for the **show l2vtp session class** command:

```
RP/0/0/CPU0:router# show l2tp class name kanata_02
```

```
l2tp-class kanata_02
  manually configured class
  configuration parameters:
    (not) hidden
    (no) authentication
    (no) digest
    digest check enable
    hello 60
    (no) hostname
    (no) password
    (no) accounting
    (no) security crypto-profile
    (no) ip vrf
    receive-window 888
    retransmit retries 15
```

```

retransmit timeout max 8
retransmit timeout min 1
retransmit initial retries 2
retransmit initial timeout max 8
retransmit initial timeout min 1
timeout setup 300

```

This table describes the significant fields shown in the display.

**Table 2: show l2tp class brief Field Descriptions**

Field	Description
l2tp-class	Shows the L2TP class name and the manner of its creation. For example, manually configured class.
configuration parameters	Displays a complete list and state of all configuration parameters.

### Related Commands

Command	Description
<a href="#">l2tp-class</a> , <a href="#">on page 40</a>	Enters L2TP class configuration mode where you can define an L2TP signaling template.

# show l2tp counters forwarding session

To display L2TP forward session counters, use the **show l2tp counter forwarding session** command in EXEC mode.

**show l2tp counters forwarding session** [*id identifier*] **name** *local-name remote-name*]

## Syntax Description

<b>id</b> <i>identifier</i>	(Optional) Configures the session counter identifier.
<b>name</b> <i>local-name remote name</i>	(Optional) Configures the local and remote names for a session counter.

## Command Default

None

## Command Modes

EXEC

## Command History

Release	Modification
Release 3.7.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operations
l2vpn	read, write

## Examples

The following example shows sample output for the **show l2tp counters forwarding session** command:

```
RP/0/RP00/CPU0:router(config-l2vpn)# pw-class kanata01show l2tp counters forwarding session
```

```
LocID      RemID      TunID      Pkts-In    Pkts-Out   Bytes-In   Bytes-Out
22112     15584     14332         0          0           0           0
```

This table describes the significant fields shown in the display.

**Table 3: show l2tp counters forwarding session Field Descriptions**

Field	Description
LocID	Local session ID.
RemID	Remote session ID.
TunID	Local Tunnel ID for this session.
Pkts-In	Number of packets input in the session.
Pkts-Out	Number of packets output in the session.
Bytes-In	Number of bytes input in the session.
Bytes-Out	Number of bytes output in the session.

**Related Commands**

Command	Description
<a href="#">#unique_79</a>	

# show l2tp session

To display information about L2TP sessions, use the **show l2tp session** command in EXEC mode.

**show l2tp session** [**detail**|**brief**|**interworking**|**circuit**|**sequence**|**state**] {**id** *id*|**name** *name*}

## Syntax Description

<b>brief</b>	(Optional) Displays summary output for a session.
<b>circuit</b>	(Optional) Displays attachment circuit information for a session.
<b>detail</b>	(Optional) Displays detailed output for a session.
<b>interworking</b>	(Optional) Displays interworking information for a session.
<b>sequence</b>	(Optional) Displays data packet sequencing information for a session.
<b>state</b>	(Optional) Displays control plane state information for a session.
<b>id</b> <i>id</i>	Configures the local tunnel ID. Range is 0 to 4294967295.
<b>name</b> <i>name</i>	Configures the tunnel name.

## Command Default

None

## Command Modes

EXEC

## Command History

Release	Modification
Release 3.7.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operations
l2vpn	read, write

**Examples**

The following sample output is from the **show l2tp session brief** command:

```
RP/0/RP00/CPU0:router(config-l2vpn-pw)# show l2tp session brief
Tue Jun 10 12:51:30.901 UTC
LocID      TunID      Peer-address  State      Username, Intf/sess/cir  Vcid, Circuit
1606803058 1487464659 26.26.26.26   est,UP     101, Gi0/2/0/1.101
3663696887 1487464659 26.26.26.26   est,UP     100, Gi0/2/0/1.100
```

This table describes the significant fields shown in the display.

**Table 4: show l2tp session brief Field Descriptions**

Field	Description
LocID	Local session ID.
TunID	Local tunnel ID for this session.
Peer-address	The IP address of the other end of the session.
State	The state of the session.
Vcid	The Virtual Circuit ID of the session. This is the same value of the pseudowire ID for l2vpn.

The following sample output is from the **show l2tp session detail** command:

```
RP/0/RP00/CPU0:router(config-l2vpn-pw)# show l2tp session detail
Tue Jun 10 12:53:19.842 UTC
Session id 1606803058 is up, tunnel id 1487464659, logical session id 131097
  Remote session id is 2602674409, remote tunnel id 2064960537
  Remotely initiated session
  Call serial number is 4117500017
  Remote tunnel name is ASR9K-PE2
  Internet address is 26.26.26.26:1248
  Local tunnel name is PRABHRAM-PE1
  Internet address is 25.25.25.25:4272
IP protocol 115
  Session is L2TP signaled
  Session state is established, time since change 00:07:28
  UDP checksums are disabled
  Session cookie information:
    local cookie, size 4 bytes, value 6d 3e 03 67
    remote cookie, size 4 bytes, value 0d ac 7a 3b
  Tie breaker is 0xfee65781a2fa2cfd, enabled TRUE.
  Sequencing is off
  Conditional debugging is disabled
  Unique ID is 101
Session Layer 2 circuit
  Payload type is Ethernet, Name is GigabitEthernet0_2_0_1.101
  Session vcid is 101
  Circuit state is UP
    Local circuit state is UP
    Remote circuit state is UP
```

 show l2tp session**Related Commands**

Command	Description
<a href="#">#unique_79</a>	

# show l2tp tunnel

To display information about L2TP tunnels, use the **show l2tp tunnel** command in EXEC mode.

**show l2tp tunnel** {**detail**|**brief**|**state**|**transport**} {**id** *identifier*|**name** *local-name remote-name*}

Syntax Description		
<b>detail</b>		Displays detailed output for L2TP tunnels.
<b>brief</b>		Displays summary information for the tunnel.
<b>state</b>		Displays control plane state information.
<b>transport</b>		Displays transport information (IP) for each selected control channel.
<b>id</b> <i>identifier</i>		Displays local control channel identifiers.
<b>name</b> <i>local-name remote-name</i>		Displays the local and remote names of a control channel.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.7.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

## Examples

The following sample output is from the **show l2tp tunnel brief** command:

```
RP/0/0/CPU0:router(config-l2vpn-encap-mp1s)# show l2tp tunnel brief
Tue Jun 10 12:46:04.421 UTC
LocTunID  RemTunID  Remote Name  State  Vrf Name  Remote Address  Sessn L2TP Class/Count
  VPDN Group
```

```
1487464659 2064960537 ASR9K-PE2      est                26.26.26.26      2      L2TPV3_CLASS
```

This table describes the significant fields shown in the display.

**Table 5: show l2tp tunnel Field Descriptions**

Field	Description
LocTunID	Local session ID.
RemTunID	Remote session ID.
Remote Name	Remote name of the session.
State	State of the session.
Remote Address	Remote address of the session.
Port	Session port.
Sessions	Number of sessions.
L2TP	L2TP class name.

The following sample output is from the **show l2tp tunnel detail** command:

```
RP/0/0/CPU0:router(config-l2vpn-encap-mpls)# show l2tp tunnel detail
Tue Jun 10 12:47:36.638 UTC
Tunnel id 1487464659 is up, remote id is 2064960537, 2 active sessions
  Remotely initiated tunnel
  Tunnel state is established, time since change 4d19h
  Tunnel transport is IP (115)
  Remote tunnel name is ASR9K-PE2
    Internet Address 26.26.26.26, port 0
  Local tunnel name is PRABHRAM-PE1
    Internet Address 25.25.25.25, port 0
  VRF table id is 0xe0000000
  Tunnel group id
  L2TP class for tunnel is L2TPV3_CLASS
  Control Ns 4178, Nr 4181
  Local RWS 512 (default), Remote RWS 512
  Control channel Congestion Control is disabled
  Tunnel PMTU checking disabled
  Retransmission time 1, max 1 seconds
  Unsent queuesize 0, max 0
  Resend queuesize 0, max 1
  Total resends 0, ZLE ACKs sent 4177
  Total out-of-order dropped pkts 0
  Total out-of-order reorder pkts 0
  Total peer authentication failures 0
  Current no session pak queue check 0 of 5
  Retransmit time distribution: 0 0 0 0 0 0 0 0
  Control message authentication is disabled
```

## Related Commands

Command	Description
<a href="#">show l2tp session</a> , on page 90	Displays information about L2TP sessions.

# show l2vpn

To display L2VPN information, use the **show l2vpn** command in EXEC mode.

```
show l2vpn
```

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 4.3.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	l2vpn	read

**Examples** The following example displays output for the **show l2vpn** command. The output provides an overview of the state of the globally configured features.

```
RP/0/0/CPU0:router# show l2vpn
Mon May 7 15:01:17.963 BST
PW-Status: disabled
PW-Grouping: disabled
Logging PW: disabled
Logging BD state changes: disabled
Logging VFI state changes: disabled
Logging NSR state changes: disabled
TCN propagation: disabled
PWOAMRefreshTX: 30s
```

Related Commands	Command	Description
	<a href="#">l2vpn</a> , <a href="#">on page 49</a>	Enters L2VPN configuration mode.

Command	Description
<a href="#">pw-grouping</a> , on page 73	Enables Pseudowire Grouping

## show l2vpn atom-db

To display AToM database information, use the **show l2vpn atom-db** command in EXEC mode.

```
show l2vpn atom-db [detail| l2-rid| ldp-rid| local-gid| neighbor| preferred-path| remote-gid| source]
```

### Syntax Description

<b>detail</b>	Specifies the details of the database.
<b>l2-rid</b>	Specifies the AToM database walking the L2 RID thread.
<b>ldp-rid</b>	Specifies the AToM database walking the LDP RID thread.
<b>local-gid</b>	Specifies the AToM database walking the Local GID thread.
<b>neighbor</b>	Specifies the details of the neighbor database.
<b>preferred-path</b>	Specifies the preferred path (tunnel) of the database
<b>remote-gid</b>	Specifies the AToM database walking the Remote GID thread.
<b>source</b>	Specifies the details of the source database.

### Command Default

None

### Command Modes

EXEC

### Command History

Release	Modification
Release 4.2.1	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

### Task ID

Task ID	Operations
l2vpn	read

**Examples**

This example shows the sample output of the **show l2vpn atom-db source 1.1.1.1** command:

```
RP/0/0/CPU0:router# show l2vpn atom-db source 1.1.1.1
Peer ID      Source      VC ID      Encap      Signaling   FEC      Discovery
2.2.2.2      1.1.1.1     1          MPLS       LDP         128     none
```

This example shows the sample output of the **show l2vpn atom-db source 1.1.1.1 detail** command:

```
RP/0/0/CPU0:router# show l2vpn atom-db source 1.1.1.1 detail
PW: neighbor 2.2.2.2, PW ID 1, state is down ( provisioned )
  PW class class1, XC ID 0x1
  Encapsulation MPLS, protocol LDP
  Source address 1.1.1.1
  PW type Ethernet, control word disabled, interworking none
  PW backup disable delay 0 sec
  Sequencing not set

      MPLS              Local              Remote
-----
Label              16000              unknown
Group ID           0x200000060        0x0
Interface          GigabitEthernet0/0/0/1.1
MTU                1504              unknown
Control word       disabled           unknown
PW type            Ethernet           unknown
VCCV CV type       0x2               0x0
                  (LSP ping verification)
                  (TTL expiry)
VCCV CC type       0x6               0x0
                  (router alert label)
                  (TTL expiry)
-----
MIB cpwVcIndex: 4278194081
Create time: 13/12/2010 15:28:26 (20:32:27 ago)
Last time status changed: 13/12/2010 15:28:26 (20:32:27 ago)
Configuration info:
  PW class: class1
  Peer ID = 2.2.2.2, pseudowire ID = 1
  Control word is not set
  Transport mode: not set
  Configured (Static) Encapsulation: not set
  Provisioned Encapsulation: MPLS
  Static tag rewrite: not set
  MTU: 1504
  Tunnel interface: None
  IW type: 0
  PW type: Dynamic
  Pref path configured: No
  Bridge port: No
  BP learning disabled: No
  BP ucast flooding disabled: No
  BP bcast flooding disabled: No
  CW is mandatory: No
  Label: local unassigned, remote unassigned
  L2 Router-ID: 0.0.0.0
  LDP Router-ID: 0.0.0.0
  GR stale: No
  LDP Status: local established, remote unknown
  LDP tag rewrite: not set
  Force switchover: inactive
  MAC trigger: inactive
  VC sane: Yes
  Use PW Status: No
  Local PW Status: Up(0x0); Remote PW Status: Up(0x0)
  Peer FEC Failed: No
  LSP: Down
  Operational state:
    LDP session state: down
    TE tunnel transport: No
    VC in gr mode: No
```

```
Peer state: up
Transport LSP down: Yes
Advertised label to LDP: No
Received a label from LSD: Yes
Need to send standby bit: No
VC created from rbinding: No
PW redundancy dampening on : No
Notified up : No
Detailed segment state: down
PW event trace history [Total events: 8]
-----
Time          Event          Value
====          =====
12/13/2010 15:28:26 LSP Down      0
12/13/2010 15:28:26 Provision    0
12/13/2010 15:28:26 LSP Down      0
12/13/2010 15:28:26 Connect Req   0
12/13/2010 15:28:26 Rewrite create 0x100000
12/13/2010 15:28:26 Got label     0x3e80
12/13/2010 15:28:26 Local Mt     0x5e0
12/13/2010 15:28:26 Peer Up      0
```

# show l2vpn collaborators

To display information about the state of the interprocess communications connections between l2vpn\_mgr and other processes, use the **show l2vpn collaborators** command in EXEC mode.

**show l2vpn collaborators**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** EXEC

Release	Modification
Release 3.4.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Operations
l2vpn	read, write

**Examples** The following example shows sample output for the **show l2vpn collaborators** command:

```
RP/0/0/CPU0:router# show l2vpn collaborators
L2VPN Collaborator stats:
Name                State      Up Cnts    Down Cnts
-----
IMC                  Down      0          0
LSD                  Up        1          0
```

This table describes the significant fields shown in the display.

**Table 6: show l2vpn collaborators Field Descriptions**

Field	Description
Name	Abbreviated name of the task interacting with l2vpn_mgr.

Field	Description
State	Indicates if l2vpn_mgr has a working connection with the other process.
Up Cnts	Number of times the connection between l2vpn_mgr and the other process has been successfully established.
Down Cnts	Number of times that the connection between l2vpn_mgr and the other process has failed or been terminated.

**Related Commands**

Command	Description
<a href="#">clear l2vpn collaborators</a> , on page 16	Clears the state change counters for L2VPN collaborators.

# show l2vpn database

To display L2VPN database, use the **show l2vpn database** command in EXEC mode.

**show l2vpn database {ac| node}**

Syntax Description	
<b>ac</b>	Displays L2VPN Attachment Circuit (AC) database
<b>node</b>	Displays L2VPN node database.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 4.3.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	l2vpn	read

**Examples** The following example displays output for the **show l2vpn database ac** command:

```
RP/0/0/CPU0:router# show l2vpn database ac
  Bundle-Ether1.1:
    Other-Segment MTU: 0
    Other-Segment status flags: 0x0
    Signaled capability valid: No
    Signaled capability flags: 0x0
    Configured capability flags: 0x0
    XCID: 0xffffffff
    PSN Type: Undefined
    ETH data:
      Xconnect tags: 0
      Vlan rewrite tag: 0
    AC defn:
      ac-ifname: Bundle-Ether1.1
```

```

capabilities: 0x00368079
extra-capabilities: 0x00000000
parent-ifh: 0x020000e0
ac-type: 0x15
interworking: 0x00
AC info:
  seg-status-flags: 0x00000000
  segment mtu/l2-mtu: 1504/1518

GigabitEthernet0/0/0/0.4096:
  Other-Segment MTU: 0
  Other-Segment status flags: 0x0
  Signaled capability valid: No
  Signaled capability flags: 0x0
  Configured capability flags: 0x0
  XCID: 0x0
  PSN Type: Undefined
  ETH data:
    Xconnect tags: 0
    Vlan rewrite tag: 0
AC defn:
  ac-ifname: GigabitEthernet0_0_0_0.4096
  capabilities: 0x00368079
  extra-capabilities: 0x00000000
  parent-ifh: 0x040000c0
  ac-type: 0x15
  interworking: 0x00
AC info:
  seg-status-flags: 0x00000003
  segment mtu/l2-mtu: 1504/1518

```

The following example displays output for the **show l2vpn database node** command:

```

RP/0/0/CPU0:router# show l2vpn database node
0/RSP0/CPU0
  MA: vlan_ma

  AC event trace history [Total events: 4]
  -----
  Time                Event                                Num Rcvd    Num Sent
  ====                =====                                =
  07/27/2012 15:00:31 Process joined                                0            0
  07/27/2012 15:00:31 Process init success                       0            0
  07/27/2012 15:00:31 Replay start rcvd                          0            0
  07/27/2012 15:00:31 Replay end rcvd                            2            0

  MA: ether_ma

  AC event trace history [Total events: 4]
  -----
  Time                Event                                Num Rcvd    Num Sent
  ====                =====                                =
  07/27/2012 15:00:31 Process joined                                0            0
  07/27/2012 15:00:31 Process init success                       0            0
  07/27/2012 15:00:31 Replay start rcvd                          0            0
  07/27/2012 15:00:31 Replay end rcvd                            0            0

0/0/CPU0
  MA: vlan_ma

  AC event trace history [Total events: 4]
  -----
  Time                Event                                Num Rcvd    Num Sent
  ====                =====                                =
  07/27/2012 15:00:31 Process joined                                0            0
  07/27/2012 15:00:31 Process init success                       0            0
  07/27/2012 15:00:31 Replay start rcvd                          0            0
  07/27/2012 15:00:40 Replay end rcvd                          6006         6001

```

MA: ether\_ma

AC event trace history [Total events: 4]

Time	Event	Num Rcvd	Num Sent
====	=====	=====	=====
07/27/2012 15:00:31	Process joined	0	0
07/27/2012 15:00:31	Process init success	0	0
07/27/2012 15:00:31	Replay start rcvd	0	0
07/27/2012 15:00:31	Replay end rcvd	1	0

# show l2vpn forwarding

To display forwarding information from the layer2\_fib manager on the line card, use the **show l2vpn forwarding** command in EXEC mode.

```
show l2vpn forwarding {xconnect| bridge-domain| counter| detail| hardware| inconsistent| interface|
l2tp| location [ node-id ]| message| mstp| resource| retry-list| summary| unresolved}
```

## Syntax Description

<b>xconnect</b>	Displays the cross-connect related information.
<b>bridge-domain</b>	Displays bridge domain related forwarding information.
<b>counter</b>	Displays the cross-connect counters.
<b>detail</b>	Displays detailed information from the layer2_fib manager.
<b>hardware</b>	Displays hardware-related layer2_fib manager information.
<b>inconsistent</b>	Displays inconsistent entries only.
<b>interface</b>	Displays the match AC subinterface.
<b>l2tp</b>	Displays L2TPv3 related forwarding information.
<b>location</b> <i>node-id</i>	Displays layer2_fib manager information for the specified location. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>message</b>	Displays messages exchanged with collaborators.
<b>mstp</b>	Displays multi-spanning tree related forwarding information.
<b>resource</b>	Displays resource availability information in the layer2_fib manager.
<b>retry-list</b>	Displays retry list related information.

<b>summary</b>	Displays summary information about cross-connects in the layer2_fib manager.
<b>unresolved</b>	Displays unresolved entries only.

**Command Default** None

**Command Modes** EXEC

<b>Release</b>	<b>Modification</b>
Release 3.4.0	This command was introduced.
Release 3.7.0	Sample output was updated to add MAC information for the layer2_fib manager summary.

**Usage Guidelines** To use commands of this module, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using any command, contact your AAA administrator for assistance.

<b>Task ID</b>	<b>Operations</b>
l2vpn	read

**Examples** The following sample output is from the **show l2vpn forwarding bridge detail location** command for IOS-XR releases 5.3.1 and earlier:

```
RP/0/0/CPU0:router# show l2vpn forwarding bridge detail location 0/2/cpu0
Bridge-domain name: bgl:bd1, id: 0, state: up
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: no
Security: disabled
DHCPv4 snooping: profile not known on this node
IGMP snooping: disabled, flooding: disabled
Bridge MTU: 1500 bytes
Number of bridge ports: 1
Number of MAC addresses: 0
Multi-spanning tree instance: 0

GigabitEthernet0/1/0/1.2, state: oper up
```

```

Number of MAC: 0
Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0
Storm control drop counters:
  packets: broadcast 0, multicast 0, unknown unicast 0
  bytes: broadcast 0, multicast 0, unknown unicast 0

Bridge-domain name: bgl:bd2, id: 1, state: up
  Type: pbb-edge, I-SID: 1234
  Core-bridge: pbb-bd2
  MAC learning: enabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: no
  Security: disabled
  DHCPv4 snooping: profile not known on this node
  IGMP snooping: disabled, flooding: disabled
  Bridge MTU: 1500 bytes
  Number of bridge ports: 0
  Number of MAC addresses: 0
  Multi-spanning tree instance: 0

PBB Edge, state: up
  Number of MAC: 0
GigabitEthernet0/1/0/1.3, state: oper up
  Number of MAC: 0
  Storm control drop counters:
    packets: broadcast 0, multicast 0, unknown unicast 0
    bytes: broadcast 0, multicast 0, unknown unicast 0

Bridge-domain name: bgl:bd3, id: 2, state: up
  Type: pbb-core
  Number of associated pbb-edge BDs: 1

MAC learning: enabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: no
  Security: disabled
  DHCPv4 snooping: profile not known on this node
  IGMP snooping: disabled, flooding: disabled
  Bridge MTU: 1500 bytes
  Number of bridge ports: 0
  Number of MAC addresses: 0
  Multi-spanning tree instance: 0

PBB Core, state: up
  Vlan-id: 1

GigabitEthernet0/1/0/1.4, state: oper up
  Number of MAC: 0
  Storm control drop counters:
    packets: broadcast 0, multicast 0, unknown unicast 0
    bytes: broadcast 0, multicast 0, unknown unicast 0

```

The following sample output is from the **show l2vpn forwarding bridge detail location** command for IOS-XR 5.3.2 release:

```

RP/0/0/CPU0:router# show l2vpn forwarding bridge detail location 0/0/CPU0

Bridge-domain name: pbb:pbb_core1, id: 10, state: up
  Type: pbb-core
  Number of associated pbb-edge BDs: 1
  MAC learning: enabled

```

```

MAC port down flush: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: no
MAC Secure: disabled, Logging: disabled
DHCPv4 snooping: profile not known on this node
Dynamic ARP Inspection: disabled, Logging: disabled
IP Source Guard: disabled, Logging: disabled
IGMP snooping: disabled, flooding: enabled
MLD snooping: disabled, flooding: disabled
MMRP Flood Optimization: disabled
Storm control: disabled
P2MP PW: disabled
Bridge MTU: 1500 bytes
Number of bridge ports: 1
Number of MAC addresses: 5
Multi-spanning tree instance: 0
PBB-EVPN: enabled
Statistics:
  packets: received 0, sent 963770
  bytes: received 0, sent 263433178

PBB Core, state: Up
Vlan-id: 1
XC ID: 0x80000010
Number of MAC: 0
Statistics:
  packets: received 0 (unicast 0), sent 0
  bytes: received 0 (unicast 0), sent 0
  MAC move: 0
Storm control drop counters:
  packets: broadcast 0, multicast 0, unknown unicast 0
  bytes: broadcast 0, multicast 0, unknown unicast 0

```

The following sample outputs shows the backup pseudowire information:

```

RP/0/0/CPU0:router#show l2vpn forwarding detail location 0/2/CPU0
Local interface: GigabitEthernet0/2/0/0.1, Xconnect id: 0x3000001, Status: up
Segment 1
  AC, GigabitEthernet0/2/0/0.1, Ethernet VLAN mode, status: Bound
  RG-ID 1, active
  Statistics:
    packets: received 0, sent 0
    bytes: received 0, sent 0
Segment 2
  MPLS, Destination address: 101.101.101.101, pw-id: 1000, status: Bound
  Pseudowire label: 16000
  Statistics:
    packets: received 0, sent 0
    bytes: received 0, sent 0
Backup PW
  MPLS, Destination address: 102.102.102.102, pw-id: 1000, status: Bound
  Pseudowire label: 16001
  Statistics:
    packets: received 0, sent 0
    bytes: received 0, sent 0

RP/0/0/CPU0:router#show l2vpn forwarding bridge-domain detail location 0/2/CPU0
Bridge-domain name: bg1:bd1, id: 0, state: up
....
GigabitEthernet0/2/0/0.4, state: oper up
  RG-ID 1, active
  Number of MAC: 0
  ....

Nbor 101.101.101.101 pw-id 5000
Backup Nbor 101.101.101.101 pw-id 5000

```

```

    Number of MAC: 0
    ....
RP/0/0/CPU0:router#show l2vpn forwarding bridge-domain detail location 0/2/CPU0
Bridge-domain name: bgl:bd1, id: 0, state: up
....
GigabitEthernet0/2/0/0.4, state: oper up
XC ID: 0x1880002
Number of MAC: 0
Statistics:
packets: received 0 (multicast 0, broadcast 0, unknown unicast 0, unicast 0), sent 963770
bytes: received 0 (multicast 0, broadcast 0, unknown unicast 0, unicast 0), sent 263433178
MAC move: 0
Storm control drop counters:
packets: broadcast 0, multicast 0, unknown unicast 0
bytes: broadcast 0, multicast 0, unknown unicast 0
Dynamic arp inspection drop counters:
packets: 0, bytes: 0
IP source guard drop counters:
packets: 0, bytes: 0

```

....  
The following sample outputs displays the SPAN segment information of the xconnect:

```

RP/0/0/CPU0:router# show l2vpn forwarding counter location 0/7/CPU0
Legend: ST = State, DN = Down

Segment 1                               Segment 2           ST      Byte           Switched
-----
pw-span-test (Monitor-Session) mpls 2.2.2.2 UP      0

```

```

RP/0/0/CPU0:router #Show l2vpn forwarding monitor-session location 0/7/CPU0
Segment 1                               Segment 2           State
-----
pw-span-test (monitor-session) mpls 2.2.2.2 UP
pw-span-sess (monitor-session) mpls 3.3.3.3 UP

```

```

RP/0/0/CPU0:router #Show l2vpn forwarding monitor-session pw-span-test location 0/7/CPU0
Segment 1                               Segment 2           State
-----
pw-span-test (Monitor-Session) mpls 2.2.2.2 UP

```

Example 4:

```

RP/0/0/CPU0:router #show l2vpn forwarding detail location 0/7/CPU0
Xconnect id: 0xc000001, Status: up
Segment 1
  Monitor-Session, pw-span-test, status: Bound
Segment 2
  MPLS, Destination address: 2.2.2.2, pw-id: 1, status: Bound
  Pseudowire label: 16001
Statistics:
  packets: received 0, sent 11799730
  bytes: received 0, sent 707983800

```

Example 5:

```

show l2vpn forwarding private location 0/11/CPU0
Xconnect ID 0xc000001
Xconnect info:
  Base info: version=0xaabbcc13, flags=0x0, type=2, reserved=0
  xcon_bound=TRUE, switching_type=0, data_type=3

AC info:
  Base info: version=0xaabbcc11, flags=0x0, type=3, reserved=0
  xcon_id=0xc000001, ifh= none, subifh= none, ac_id=0, ac_type=SPAN,
  ac_mtu=1500, iw_mode=none, adj_valid=FALSE, adj_addr none

```

```

PW info:
Base info: version=0xaabbcc12, flags=0x0, type=4, reserved=0
pw id=1, nh_valid=TRUE, sig_cap_flags=0x20, context=0x0,
MFLS, pw_label=16001
Statistics:
  packets: received 0, sent 11799730
  bytes: received 0, sent 707983800

Object: NHOP
Event Trace History [Total events: 5]
-----
Time          Event          Flags
=====
-----

Nexthop info:
Base info: version=0xaabbcc14, flags=0x10000, type=5, reserved=0
nh_addr=2.2.2.2, plat_data_valid=TRUE, plat_data_len=128, child_count=1

Object: XCON
Event Trace History [Total events: 16]
-----
Time          Event          Flags
=====
-----

```

```

RP/0/0/CPU0:router #show l2vpn forwarding summary location 0/7/CPU0
Major version num:1, minor version num:0
Shared memory timestamp:0x31333944cf
Number of forwarding xconnect entries:2
Up:2 Down:0
AC-PW:1 (1 mpls) AC-AC:0 AC-BP:0 AC-Unknown:0
PW-BP:0 PW-Unknown:0 Monitor-Session-PW:1
Number of xconnects down due to:
AIB:0 L2VPN:0 L3FIB:0
Number of p2p xconnects: 2
Number of bridge-port xconnects: 0
Number of nexthops:1
MPLS: Bound:1 Unbound:0 Pending Registration:0
Number of bridge-domains: 0
Number of static macs: 0
Number of locally learned macs: 0
Number of remotely learned macs: 0
Number of total macs: 0

```

The following sample output is from the **show l2vpn forwarding** command:

```
RP/0/0/CPU0:router# show l2vpn forwarding location 0/2/cpu0
```

```

ID  Segment 1          Segment 2
-----
1   Gi0/2/0/0 1       1.1.1.1  9)

```

The following sample output shows the MAC information in the layer2\_fib manager summary:

```
RP/0/0/CPU0:router# show l2vpn forwarding summary location 0/3/CPU0
```

```

Major version num:1, minor version num:0
Shared memory timestamp:0x66ff58e894
Number of forwarding xconnect entries:2
Up:1 Down:0
AC-PW:0 AC-AC:0 AC-BP:1 PW-BP:1
Number of xconnects down due to:
AIB:0 L2VPN:0 L3FIB:0
Number of nexthops:1
Number of static macs: 5
Number of locally learned macs: 5
Number of remotely learned macs: 0
Number of total macs: 10

```

**Related Commands**

Command	Description
<a href="#">clear l2vpn forwarding counters, on page 20</a>	Clears L2VPN forwarding counters.

# show l2vpn forwarding l2tp

To display L2VPN forwarding information, use the **show l2vpn forwarding l2tp** command in EXEC mode.

**show l2vpn forwarding l2tp disposition** {local session id *session-ID*| hardware| location *node-id*} location *node-id*

## Syntax Description

<b>disposition</b>	Displays forwarding disposition information.
<i>session-ID</i>	Displays L2TPv3-related forwarding information for the specified local session ID. Range is 1-4294967295.
<b>hardware</b>	Displays L2TPv3-related forwarding information read from hardware.
<b>location</b>	Displays L2TPv3-related forwarding information for the specified location.

## Command Default

None

## Command Modes

EXEC

## Command History

Release	Modification
Release 3.7.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operations
l2vpn	read

## Examples

The following example shows sample output for the **show l2vpn forwarding l2tp** command:

```
RP/0/0/CPU0:router# show l2vpn forwarding l2tp disposition hardware location 0/3/1
ID  Segment 1          Segment 2
-----
1   Gi0/2/0/0 1       1.1.1.1  9)
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">clear l2vpn forwarding counters, on page 20</a>	Clears L2VPN forwarding counters.

# show l2vpn generic-interface-list

To display all the L2VPN virtual interfaces, use the **show l2vpn generic-interface-list** command in EXEC mode.

**show l2vpn generic-interface-list** {**detail**| **name**| **private**| **summary**}

## Syntax Description

<b>detail</b>	Specifies the details of the interface.
<b>name</b>	Specifies the name of the interface.
<b>private</b>	Specifies the private details of the interface.
<b>summary</b>	Specifies the summary information of the interface.

## Command Default

None

## Command Modes

EXEC

## Command History

Release	Modification
Release 4.2.1	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operations
l2vpn	read

## Examples

This example shows the sample output of the **show l2vpn generic-interface-list** command:

```
RP/0/0/CPU0:router# show l2vpn generic-interface-list
generic-interface-list: l1 (ID: 2, interfaces: 2) Number of items: 20
generic-interface-list: l2 (ID: 3, interfaces: 4) Number of items: 15
```

This example shows the sample output of the **show l2vpn generic-interface-list detail** command:

```
RP/0/0/CPU0:router# show l2vpn generic-interface-list detail
generic-interface-list: l1 (ID: 2, interfaces: 2)
```

```
GigabitEthernet0/1/0/0 - items pending 2
GigabitEthernet0/1/0/1 - items pending 4
Number of items: 27
  PW-Ether: 1-10, 12-21
  PW-IW: 1-7

generic-interface-list: 12 (ID: 3, interfaces: 4)
GigabitEthernet0/1/0/0 - items pending 2
GigabitEthernet0/1/0/1 - items pending 4
GigabitEthernet0/1/0/2 - items pending 1
GigabitEthernet0/1/0/3 - items pending 0
Number of items: 20
  PW-Ether: 1-15
  PW-IW: 1-7
```

This example shows the sample output of the **show l2vpn generic-interface-list name | detail** command:

```
RP/0/0/CPU0:router# show l2vpn generic-interface-list name 11 detail
generic-interface-list: 11 (ID: 2, interfaces: 2)
GigabitEthernet0/1/0/0 - items pending 2
GigabitEthernet0/1/0/1 - items pending 4
Number of items: 20
  PW-Ether 1-10, 12-21
```

# show l2vpn index

To display statistics about the index manager, use the **show l2vpn index** command in EXEC mode.

**show l2vpn index** [**location**] **private** | **standby**]

## Syntax Description

<b>location</b>	(Optional) Displays index manager statistics for the specified location.
<b>private</b>	(Optional) Detailed information about all indexes allocated for each pool.
<b>standby</b>	(Optional) Displays Standby node specific information.

## Command Default

None

## Command Modes

EXEC

## Command History

Release	Modification
Release 4.2.1	This command was introduced.
Release 4.3.0	The following keywords are introduced: <ul style="list-style-type: none"> <li>• location</li> <li>• standby</li> </ul>

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operations
l2vpn	read

**Examples**

This example shows the sample output of the **show l2vpn index** command:

```
RP/0/0/CPU0:router# show l2vpn index
Pool id: 0x4, App: RD
Pool size: 32767
zombied IDs: 0
allocated IDs: 0

Pool id: 0x5, App: IFLIST
Pool size: 65535
zombied IDs: 0
allocated IDs: 2

Pool id: 0xff000001, App: PW/PBB/Virtual AC
Pool size: 40960
zombied IDs: 0
allocated IDs: 1

Pool id: 0xff000002, App: BD
Pool size: 4095
zombied IDs: 0
allocated IDs: 2

Pool id: 0xff000003, App: MP2MP
Pool size: 65535
zombied IDs: 0
allocated IDs: 1
```

This example shows the sample output of the **show l2vpn index standby** command:

```
RP/0/0/CPU0:router# show l2vpn index standby
Pool id: 0xfffc0000, App: Global
Max number of ID mgr instances: 1
ID mgr instances in use: 1
Pool size: 98304
zombied IDs: 0
allocated IDs: 0

Pool id: 0xfffc0002, App: BD
Max number of ID mgr instances: 1
ID mgr instances in use: 1
Pool size: 8192
zombied IDs: 0
allocated IDs: 0

Pool id: 0xfffc0003, App: MP2MP
Max number of ID mgr instances: 1
ID mgr instances in use: 1
Pool size: 65535
zombied IDs: 0
allocated IDs: 0
```

# show l2vpn nsr

To display the status of l2vpn non-stop routing, use the **show l2vpn nsr** command in EXEC mode.

**show l2vpn nsr** [**location**| **standby**]

Syntax Description	
<b>location</b>	(Optional) Displays non-stop routing information for the specified location.
<b>standby</b>	(Optional) Displays Standby node specific information.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 4.3.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	l2vpn	read

**Examples** The following example displays output for the **show l2vpn nsr** command:

```
RP/0/0/CPU0:router# show l2vpn nsr

Mon May 30 19:32:01.045 UTC
L2VPN NSR information
NSR Status:
NSR Ready           : Fri May 27 10:50:59 UTC 2016 (3d08h ago)
Last NSR Withdraw Time : Fri May 27 10:50:59 UTC 2016 (3d08h ago)
Standby Connected     : Fri May 27 10:50:59 UTC 2016 (3d08h ago)
IDT Done              : Fri May 27 10:50:59 UTC 2016 (3d08h ago)
Number of XIDs sent   : Virtual AC: 0
                       AC          : 1
                       PW          : 1
                       BD          : 0
                       MP2MP       : 0
```

```
RD          : 0
PBB        : 0
IFLIST     : 0
ATOM       : 1
Global     : 0
PWGroup    : 0
EVPN       : 0
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.
<a href="#">nsr (L2VPN), on page 61</a>	Configures non-stop routing.
<a href="#">show l2vpn index, on page 116</a>	Displays statistics about the index manager.

# show l2vpn provision queue

To display L2VPN configuration provisioning queue information, use the **show l2vpn provision queue** command in EXEC mode.

**show l2vpn provision queue** [*location*] *standby*]

Syntax Description	location	(Optional) Displays L2VPN configuration provisioning queue information for the specified location.
	standby	(Optional) Displays Standby node specific information.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 4.3.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	l2vpn	read

**Examples** The following example displays output for the **show l2vpn provision queue** command:

```
RP/0/0/CPU0:router# show l2vpn provision queue

Legend: P/P/R = Priority/Provisioned/Require Provisioning.
Configuration Item      Object Type      Class      P/P/R Object
Key
-----
BD_NAME                 bd_t             vpls_bd_class  0/0/0 BD
VPLS01
BD_NAME                 bd_t             vpls_bd_class  0/0/0 BD
VPLS02
```

```

      BD_NAME          bd_t          vpls_bd_class          0/0/0 BD
VPLS03

```

The following example displays output for the **show l2vpn provision queue standby** command:

```

RP/0/0/CPU0:router# show l2vpn provision queue standby
Legend: P/P/R = Priority/Provisioned/Require Provisioning.
Configuration Item      Object Type      Class      P/P/R Object
Key
-----
      BD_NAME          bd_t          vpls_bd_class          0/0/0 BD
VPLS01
      BD_NAME          bd_t          vpls_bd_class          0/0/0 BD
VPLS02
      BD_NAME          bd_t          vpls_bd_class          0/0/0 BD
VPLS03
      BD_NAME          bd_t          vpls_bd_class          0/0/0 BD
VPLS04
      BD_NAME          bd_t          vpls_bd_class          0/0/0 BD
VPLS05
      BD_NAME          bd_t          vpls_bd_class          0/0/0 BD
VPLS06
      BD_NAME          bd_t          vpls_bd_class          0/0/0 BD
VPLS07
      BD_NAME          bd_t          vpls_bd_class          0/0/0 BD
VPLS08
      BD_NAME          bd_t          vpls_bd_class          0/0/0 BD
VPLS09
      BD_NAME          bd_t          vpls_bd_class          0/0/0 BD
VPLS010

```

#### Related Commands

Command	Description
<a href="#">l2vpn</a> , <a href="#">on page 49</a>	Enters L2VPN configuration mode.

# show l2vpn pw-class

To display L2VPN pseudowire class information, use the **show l2vpn pw-class** command in EXEC mode.

**show l2vpn pw-class** [**detail**] **location** | **name** *class name* | **standby**]

## Syntax Description

<b>detail</b>	(Optional) Displays detailed information.
<b>location</b>	(Optional) Displays location specific information.
<b>name</b> <i>class-name</i>	(Optional) Displays information about a specific pseudowire class name.
<b>standby</b>	(Optional) Displays standby node specific information.

## Command Default

None

## Command Modes

EXEC

## Command History

Release	Modification
Release 3.5.0	This command was introduced.
Release 4.3.0	The keywords <b>location</b> and <b>standby</b> were introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operations
l2vpn	read

## Examples

The following example shows sample output for the **show l2vpn pw-class** command:

```
RP/0/0/CPU0:router# show l2vpn pw-class
Name                               Encapsulation  Protocol
-----
mplsclass_75                       MPLS           LDP
l2tp-dynamic                       L2TPv3        L2TPv3
```

This example shows sample output for the **show l2vpn pw-class detail** command:

```
RP/0/0/CPU0:router# show l2vpn pw-class detail
  Encapsulation MPLS, protocol LDP
  Transport mode not set, control word unset (default)
  Sequencing not set
  Static tag rewrite not set
  PW Backup disable delay: 0 sec
  MAC withdraw message is sent over PW: no
  IPv4 source address 1.1.1.1
```

This table describes the significant fields shown in the display.

**Table 7: show l2vpn pw-class Command Field Descriptions**

Field	Description
Name	Displays the name of the pseudowire class.
Encapsulation	Displays the encapsulation type.
Protocol	Displays the protocol type.

#### Related Commands

Command	Description
<a href="#">clear l2vpn forwarding counters</a> , <a href="#">on page 20</a>	Clears L2VPN forwarding counters.

# show l2vpn pwhe

To display the pseudowire headend (PWHE) information, use the **show l2vpn pwhe** command in EXEC mode.

**show l2vpn pwhe** {**detail**| **interface**| **summary**}

## Syntax Description

<b>detail</b>	Specifies the details of the interface.
<b>interface</b>	Specifies the name of the interface.
<b>summary</b>	Specifies the summary information of the interface.

## Command Default

None

## Command Modes

EXEC

## Command History

Release	Modification
Release 4.2.1	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operations
l2vpn	read

## Examples

This example show the sample output for **show l2vpn pwhe detail** command:

```
RP/0/0/CPU0:router# show l2vpn pwhe detail
Interface: PW-Ether1   Interface State: Down, Admin state: Up
Interface handle 0x20000070
MTU: 1514
BW: 10000 Kbit
Interface MAC addresses: 0279.96e9.8205
Label: 16000
L2-overhead: 0
VC-type: 5
CW: N
```

```
Generic-interface-list: ifl1 (id: 1)
  Gi0/2/0/1, in bundle BE3, state: Up, replication: success
  Gi0/2/0/0, in bundle BE5, state: Up, replication: success
  Gi0/2/0/2, in bundle BE5, state: Up, replication: success
  Gi0/2/0/3, state: Up, replication: success

Interface: PW-IW1   Interface State: Up, Admin state: Up
  Interface handle 0x20000070
  MTU: 1514
  BW: 10000 Kbit
  VC-type: 11
  CW: N
Generic-interface-list: ifl2 (id: 2)
  Gi0/3/0/1, in bundle BE6, state: Up, replication: success
  Gi0/3/0/0, in bundle BE6, state: Up, replication: success
  Gi0/3/0/2, state: Up, replication: success
  Gi0/3/0/3, state: Up, replication: success
```

This example show the sample output for **show l2vpn pwhe summary** command:

```
RP/0/0/CPU0:router# show l2vpn pwhe summary
Number of PW-HE interface: 1600
Up: 1300 Down: 300 Admindown: 0
Number of PW-Ether interfaces: 900
Up: 700 Down: 200 Admindown: 0
Number of PW-IW interfaces: 700
Up: 600 Down: 100 Admindown: 0
```

# show l2vpn resource

To display the memory state in the L2VPN process, use the **show l2vpn resource** command in EXEC mode.

**show l2vpn resource**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** EXEC

## Command History

Release	Modification
Release 3.4.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operations
l2vpn	read

## Examples

The following example shows sample output for the **show l2vpn resource** command:

```
RP/0/0/CPU0:router# show l2vpn resource
```

```
Memory: Normal
```

describes the significant fields shown in the display. [Table 8: show l2vpn resource Command Field Descriptions, on page 126](#)

**Table 8: show l2vpn resource Command Field Descriptions**

Field	Description
Memory	Displays memory status.

# show l2vpn trace

To display trace data for L2VPN, use the **show l2vpn trace** command in EXEC mode.

**show l2vpn trace** [**checker**| **file**| **hexdump**| **last**| **location**| **reverse**| **stats**| **tailf**| **unique**| **usec**| **verbose**| **wide**| **wrapping**]

## Syntax Description

<b>checker</b>	Displays trace data for the L2VPN Uberverifier.
<b>file</b>	Displays trace data for the specified file.
<b>hexdump</b>	Display traces data in hexadecimal format.
<b>last</b>	Display last <n> entries
<b>location</b>	Displays trace data for the specified location.
<b>reverse</b>	Display latest traces first
<b>stats</b>	Display trace statistics
<b>tailf</b>	Display new traces as they are added
<b>unique</b>	Display unique entries with counts
<b>usec</b>	Display usec details with timestamp
<b>verbose</b>	Display internal debugging information
<b>wide</b>	Display trace data excluding buffer name, node name, tid
<b>wrapping</b>	Display wrapping entries

## Command Default

None

## Command Modes

EXEC

## Command History

Release	Modification
Release 4.3.0	This command was introduced.

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

**Task ID**

Task ID	Operation
l2vpn	read

**Examples**

This example displays output for the **show l2vpn trace** command:

```
RP/0/0/CPU0:router# show l2vpn trace
 310 unique entries (1775 possible, 0 filtered)
 Jul 27 14:39:51.786 l2vpn/fwd-detail 0/RSP0/CPU0 2# t1 FWD_DETAIL:415: l2tp session
table rebuilt
 Jul 27 14:39:52.106 l2vpn/issu 0/RSP0/CPU0 1# t1 ISSU:788: ISSU - imdr init called;
'infra/imdr' detected the 'informational' condition 'the service is not supported in the
node'
 Jul 27 14:39:52.107 l2vpn/issu 0/RSP0/CPU0 1# t1 ISSU:428: ISSU - attempt to start
COLLABORATOR wait timer while not in ISSU mode
 Jul 27 14:39:54.286 l2vpn/fwd-common 0/RSP0/CPU0 1# t1 FWD_COMMON:3257: show edm thread
initialized
 Jul 27 14:39:55.270 l2vpn/fwd-mac 0/RSP0/CPU0 1# t1 FWD_MAC|ERR:783: Mac aging init
 Jul 27 14:39:55.286 l2vpn/fwd-mac 0/RSP0/CPU0 1# t1 FWD_MAC:1765: l2vpn_gsp_cons_init
returned No error
 Jul 27 14:39:55.340 l2vpn/fwd-mac 0/RSP0/CPU0 1# t1 FWD_MAC:1792: Client successfully
joined gsp group
 Jul 27 14:39:55.340 l2vpn/fwd-mac 0/RSP0/CPU0 1# t1 FWD_MAC:779: Initializing the
txlist IPC thread
 Jul 27 14:39:55.341 l2vpn/fwd-mac 0/RSP0/CPU0 1# t1 FWD_MAC:2971: gsp_optimal_msg_size
= 4832 (real: True)
 Jul 27 14:39:55.351 l2vpn/fwd-mac 0/RSP0/CPU0 1# t1 FWD_MAC:626: Entering mac aging
timer init
```

## show l2vpn xconnect

To display brief information on configured cross-connects, use the **show l2vpn xconnect** command in EXEC mode.

```
show l2vpn xconnect [brief| detail| encapsulation| group| groups| interface| location| mp2mp| mspw|
neighbor| pw-class| standby| state| summary| type| state unresolved]
```

### Syntax Description

<b>brief</b>	(Optional) Displays encapsulation brief information.
<b>detail</b>	(Optional) Displays detailed information.
<i>encapsulation</i>	(Optional) Filters on encapsulation type.
<b>group</b>	(Optional) Displays all cross-connects in a specified group.
<b>groups</b>	(Optional) Displays all groups information.
<b>interface</b>	(Optional) Filters the interface and subinterface.
<b>location</b>	(Optional) Displays location specific information.
<b>mp2mp</b>	(Optional) Displays MP2MP information.
<b>mspw</b>	(Optional) Displays ms_pw information.
<b>neighbor</b>	(Optional) Filters the neighbor.
<b>pw-class</b>	(Optional) Filters on pseudowire class
<b>standby</b>	(Optional) Displays standby node specific information.
<b>state</b>	(Optional) Filters the following xconnect state types: <ul style="list-style-type: none"> <li>• up</li> <li>• down</li> </ul>
<b>summary</b>	(Optional) Displays AC information from the AC Manager database.
<b>type</b>	(Optional) Filters the following xconnect types: <ul style="list-style-type: none"> <li>• ac-pw</li> <li>• locally switched</li> </ul>

---

<b>state unresolved</b>	(Optional) Displays information about unresolved cross-connects.
-------------------------	--

---

**Command Default** None

**Command Modes** EXEC

**Command History**

Release	Modification
Release 3.4.0	This command was introduced.
Release 3.4.1	VCCV-related show command output was added.
Release 3.6.0	Preferred-path-related show command output was added.
Release 3.7.0	Sample output was updated to display the backup pseudowire information.
Release 4.3.0	The following keywords were introduced: <ul style="list-style-type: none"> <li>• brief</li> <li>• encapsulation</li> <li>• groups</li> <li>• location</li> <li>• mp2mp</li> <li>• mspw</li> <li>• pw-class</li> <li>• standby</li> </ul>

---

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If a specific cross-connect is specified in the command (for instance, AC\_to\_PW1) then only that cross-connect will be displayed; otherwise, all cross-connects are displayed.

When configuring Ethernet Connectivity Fault Management (CFM) over l2vpn cross-connect, the CFM Continuity Check Messages (CCM) packets are not accounted for in the cross-connect pseudowire packet counters displayed in this show command output.

**Task ID**

Task ID	Operations
l2vpn	read, write

**Examples**

The following example shows sample output for the **show l2vpn xconnect** command:

```
RP/0/0/CPU0:router# show l2vpn xconnect
Wed May 21 09:06:47.944 UTC
Legend: ST = State, UP = Up, DN = Down, AD = Admin Down, UR = Unresolved,
        SB = Standby, SR = Standby Ready, (PP) = Partially Programmed
```

XConnect Group	Name	ST	Segment 1 Description	ST	Segment 2 Description	ST
L2TPV3_V4_XC_GRP	L2TPV3_P2P_1	UP	Gi0/2/0/1.2	UP	26.26.26.26 100	UP
L2TPV3_V4_XC_GRP	L2TPV3_P2P_2	UP	Gi0/2/0/1.3	UP	26.26.26.26 200	UP

The following sample output shows that the backup is in standby mode for the **show l2vpn xconnect detail** command:

```
RP/0/0/CPU0:router# show l2vpn xconnect detail

Group siva_xc, XC siva_p2p, state is up; Interworking none
Monitor-Session: pw-span-test, state is configured
AC: GigabitEthernet0/4/0/1, state is up
  Type Ethernet
  MTU 1500; XC ID 0x5000001; interworking none; MSTi 0
  Statistics:
    packet totals: send 90
    byte totals: send 19056
PW: neighbor 10.1.1.1, PW ID 1, state is up ( established )
PW class not set, XC ID 0x5000001
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
PW backup disable delay 0 sec
Sequencing not set
  MPLS
  -----
  Label          30005                               16003
  Group ID       0x5000300                          0x5000400
  Interface      GigabitEthernet0/4/0/1              GigabitEthernet0/4/0/2
Interface pw-span-test          GigabitEthernet0/3/0/1
  MTU          1500                               1500
  Control word enabled
  PW type      Ethernet                            Ethernet
  VCCV CV type 0x2                               0x2
                (LSP ping verification)          (LSP ping verification)
  VCCV CC type 0x3                               0x3
                (control word)                    (control word)
                (router alert label)              (router alert label)
  -----
Create time: 20/11/2007 21:45:07 (00:49:18 ago)
Last time status changed: 20/11/2007 21:45:11 (00:49:14 ago)
Statistics:
  packet totals: receive 0
  byte totals: receive 0
```

## show l2vpn xconnect

```

Backup PW:
PW: neighbor 2.2.2.2, PW ID 2, state is up ( established )
Backup for neighbor 1.1.1.1 PW ID 1 ( standby )
PW class not set, XC ID 0x0
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
PW backup disable delay 0 sec
Sequencing not set
-----
MPLS          Local                               Remote
-----
Label          30006                               16003
Group ID       unassigned                            0x5000400
Interface      unknown                               GigabitEthernet0/4/0/2
MTU            1500                                  1500
Control word   enabled                               enabled
PW type        Ethernet                             Ethernet
VCCV CV type   0x2                                  0x2
                (LSP ping verification)             (LSP ping verification)
VCCV CC type   0x3                                  0x3
                (control word)                     (control word)
                (router alert label)           (router alert label)
-----
Backup PW for neighbor 10.1.1.1 PW ID 1
Create time: 20/11/2007 21:45:45 (00:48:40 ago)
Last time status changed: 20/11/2007 21:45:49 (00:48:36 ago)
Statistics:
  packet totals: receive 0
  byte totals: receive 0

```

The following sample output shows that the backup is active for the **show l2vpn xconnect detail** command:

```
RP/0/0/CPU0:router# show l2vpn xconnect detail
```

```

Group siva_xc, XC siva_p2p, state is down; Interworking none
Monitor-Session: pw-span-test, state is configured
AC: GigabitEthernet0/4/0/1, state is up
  Type Ethernet
  MTU 1500; XC ID 0x5000001; interworking none; MSTi 0
  Statistics:
    packet totals: send 98
    byte totals: send 20798
PW: neighbor 10.1.1.1, PW ID 1, state is down ( local ready )
PW class not set, XC ID 0x5000001
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
PW backup disable delay 0 sec
Sequencing not set
-----
MPLS          Local                               Remote
-----
Label          30005                               unknown
Group ID       0x5000300                            0x0
Interface      GigabitEthernet0/4/0/1              unknown
Interface      pw-span-test                        GigabitEthernet0/3/0/1
MTU            1500                                  unknown
Control word   enabled                               unknown
PW type        Ethernet                             unknown
VCCV CV type   0x2                                  0x0
                (LSP ping verification)             (none)
VCCV CC type   0x3                                  0x0
                (control word)                     (none)
                (router alert label)
-----
Create time: 20/11/2007 21:45:06 (00:53:31 ago)
Last time status changed: 20/11/2007 22:38:14 (00:00:23 ago)
Statistics:
  packet totals: receive 0
  byte totals: receive 0

```

```
Backup PW:
```

```

PW: neighbor 10.2.2.2, PW ID 2, state is up ( established )
Backup for neighbor 10.1.1.1 PW ID 1 ( active )
PW class not set, XC ID 0x0
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
PW backup disable delay 0 sec
Sequencing not set
-----
MPLS          Local                               Remote
-----
Label         30006                                       16003
Group ID      unassigned                                  0x5000400
Interface     unknown                                    GigabitEthernet0/4/0/2
MTU           1500                                        1500
Control word  enabled                                    enabled
PW type       Ethernet                                    Ethernet
VCCV CV type  0x2                                         0x2
              (LSP ping verification)                  (LSP ping verification)
VCCV CC type  0x3                                         0x3
              (control word)                        (control word)
              (router alert label)                (router alert label)
-----
Backup PW for neighbor 10.1.1.1 PW ID 1
Create time: 20/11/2007 21:45:44 (00:52:54 ago)
Last time status changed: 20/11/2007 21:45:48 (00:52:49 ago)
Statistics:
  packet totals: receive 0
  byte totals: receive 0

```

The following sample output displays the xconnects with switch port analyzer (SPAN) as one of the segments:

```

Show l2vpn xconnect type minotor-session-pw
Legend: ST = State, UP = Up, DN = Down, AD = Admin Down, UR = Unresolved,
        LU = Local Up, RU = Remote Up, CO = Connected

```

XConnect	Name	ST	Segment 1 Description	ST	Segment 2 Description	ST
g1	x1	UP	pw-span-test	UP	2.2.2.2	1 UP

The following sample output shows that one-way redundancy is enabled:

```

Group g1, XC x2, state is up; Interworking none
AC: GigabitEthernet0/2/0/0.2, state is up, active in RG-ID 1
Type VLAN; Num Ranges: 1
VLAN ranges: [2, 2]
MTU 1500; XC ID 0x3000002; interworking none
Statistics:
  packets: received 103, sent 103
  bytes: received 7348, sent 7348
  drops: illegal VLAN 0, illegal length 0
PW: neighbor 101.101.101.101, PW ID 2000, state is up ( established )
PW class class1, XC ID 0x3000002
Encapsulation MPLS, protocol LDP
PW type Ethernet VLAN, control word disabled, interworking none
PW backup disable delay 0 sec
One-way PW redundancy mode is enabled
Sequencing not set
.....
Incoming Status (PW Status TLV):
  Status code: 0x0 (Up) in Notification message
Outgoing Status (PW Status TLV):
  Status code: 0x0 (Up) in Notification message
.....
Backup PW:
PW: neighbor 102.102.102.102, PW ID 3000, state is standby ( all ready )
Backup for neighbor 101.101.101.101 PW ID 2000 ( inactive )
PW class class1, XC ID 0x3000002
Encapsulation MPLS, protocol LDP
PW type Ethernet VLAN, control word disabled, interworking none
Sequencing not set
.....

```

```
Incoming Status (PW Status TLV):
  Status code: 0x26 (Standby, AC Down) in Notification message
Outgoing Status (PW Status TLV):
  Status code: 0x0 (Up) in Notification message
```

The following example shows sample output for the **show l2vpn xconnect** command:

```
RP/0/0/CPU0:router# show l2vpn xconnect
```

```
Legend: ST = State, UP = Up, DN = Down, AD = Admin Down, UR = Unresolved,
        LU = Local Up, RU = Remote Up, CO = Connected
```

XConnect Group	Name	ST	Segment 1 Description	ST	Segment 2 Description	ST
siva_xc	siva_p2p	UP	Gi0/4/0/1	UP	1.1.1.1 1	UP
					Backup 2.2.2.2 2	UP

The following sample output shows that the backup is in standby mode for the **show l2vpn xconnect detail** command:

```
RP/0/0/CPU0:router# show l2vpn xconnect detail
```

```
Group siva_xc, XC siva_p2p, state is up; Interworking none
AC: GigabitEthernet0/4/0/1, state is up
```

```
Type Ethernet
MTU 1500; XC ID 0x5000001; interworking none; MSTi 0
Statistics:
```

```
packet totals: received 90, sent 90
byte totals: received 19056, sent 19056
```

```
PW: neighbor 1.1.1.1, PW ID 1, state is up ( established )
```

```
PW class not set, XC ID 0x5000001
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
PW backup disable delay 0 sec
Sequencing not set
```

MPLS	Local	Remote
Label	30005	16003
Group ID	0x5000300	0x5000400
Interface	GigabitEthernet0/4/0/1	GigabitEthernet0/4/0/2
MTU	1500	1500
Control word	enabled	enabled
PW type	Ethernet	Ethernet
VCCV CV type	0x2	0x2
	(LSP ping verification)	(LSP ping verification)
VCCV CC type	0x3	0x3
	(control word)	(control word)
	(router alert label)	(router alert label)

```
Create time: 20/11/2007 21:45:07 (00:49:18 ago)
```

```
Last time status changed: 20/11/2007 21:45:11 (00:49:14 ago)
```

```
Statistics:
packet totals: received 0, sent 0
byte totals: received 0, sent 0
```

```
Backup PW:
```

```
PW: neighbor 2.2.2.2, PW ID 2, state is up ( established )
```

```
Backup for neighbor 1.1.1.1 PW ID 1 ( standby )
```

```
PW class not set, XC ID 0x0
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
PW backup disable delay 0 sec
Sequencing not set
```

MPLS	Local	Remote
Label	30006	16003
Group ID	unassigned	0x5000400
Interface	unknown	GigabitEthernet0/4/0/2
MTU	1500	1500

```

Control word enabled          enabled
PW type Ethernet             Ethernet
VCCV CV type 0x2              0x2
(LSP ping verification)      (LSP ping verification)
VCCV CC type 0x3              0x3
(control word)                (control word)
(router alert label)          (router alert label)
-----

```

```

Backup PW for neighbor 1.1.1.1 PW ID 1
Create time: 20/11/2007 21:45:45 (00:48:40 ago)
Last time status changed: 20/11/2007 21:45:49 (00:48:36 ago)
Statistics:
  packet totals: received 0, sent 0
  byte totals: received 0, sent 0

```

The following sample output shows that the backup is active for the **show l2vpn xconnect detail** command:

```
RP/0/0/CPU0:router# show l2vpn xconnect detail
```

```
Group siva_xc, XC siva_p2p, state is down; Interworking none
```

```
AC: GigabitEthernet0/4/0/1, state is up
Type Ethernet
MTU 1500; XC ID 0x5000001; interworking none; MSTi 0
Statistics:
```

```
  packet totals: send 98
  byte totals: send 20798
```

```
PW: neighbor 1.1.1.1, PW ID 1, state is down ( local ready )
```

```
PW class not set, XC ID 0x5000001
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
PW backup disable delay 0 sec
Sequencing not set
```

MPLS	Local	Remote
Label	30005	unknown
Group ID	0x5000300	0x0
Interface	GigabitEthernet0/4/0/1	unknown
MTU	1500	unknown
Control word	enabled	unknown
PW type	Ethernet	unknown
VCCV CV type	0x2	0x0
		(none)
	(LSP ping verification)	
VCCV CC type	0x3	0x0
		(none)
	(control word)	
	(router alert label)	

```

Create time: 20/11/2007 21:45:06 (00:53:31 ago)
Last time status changed: 20/11/2007 22:38:14 (00:00:23 ago)
Statistics:
  packet totals: received 0, sent 0
  byte totals: received 0, sent 0

```

```
Backup PW:
```

```
PW: neighbor 2.2.2.2, PW ID 2, state is up ( established )
```

```
Backup for neighbor 1.1.1.1 PW ID 1 ( active )
PW class not set, XC ID 0x0
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
PW backup disable delay 0 sec
Sequencing not set
```

MPLS	Local	Remote
Label	30006	16003
Group ID	unassigned	0x5000400
Interface	unknown	GigabitEthernet0/4/0/2
MTU	1500	1500
Control word	enabled	enabled
PW type	Ethernet	Ethernet
VCCV CV type	0x2	0x2

```

                (LSP ping verification)          (LSP ping verification)
VCCV CC type 0x3                                0x3
                (control word)                  (control word)
                (router alert label)            (router alert label)
-----
Backup PW for neighbor 1.1.1.1 PW ID 1
Create time: 20/11/2007 21:45:44 (00:52:54 ago)
Last time status changed: 20/11/2007 21:45:48 (00:52:49 ago)
Statistics:
  packet totals: received 0, sent 0
  byte totals: received 0, sent 0

```

This example shows that the PW type changes to Ethernet, which is Virtual Circuit (VC) type 5, on the interface when a double tag rewrite option is used.

```
RP/0/0/CPU0:router# show l2vpn xconnect pw-class pw-class1 detail
```

```

Group VPWS, XC ac3, state is up; Interworking none
AC: GigabitEthernet0/7/0/5.3, state is up
Type VLAN; Num Ranges: 1
VLAN ranges: [12, 12]
MTU 1508; XC ID 0x2440096; interworking none
Statistics:
  packets: received 26392092, sent 1336
  bytes: received 1583525520, sent 297928
  drops: illegal VLAN 0, illegal length 0
PW: neighbor 3.3.3.3, PW ID 3, state is up ( established )
PW class VPWS1, XC ID 0x2440096
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word disabled, interworking none
PW backup disable delay 0 sec
Sequencing not set

```

```
Preferred path tunnel TE 3, fallback disabled
```

```

PW Status TLV in use
  MPLS          Local          Remote
-----
Label          16147          21355
Group ID       0x120001c0     0x120001c0
Interface      GigabitEthernet0/7/0/5.3  GigabitEthernet0/7/0/5.3
MTU            1508           1508
Control word   disabled       disabled
PW type        Ethernet      Ethernet
VCCV CV type   0x2            0x2
                (LSP ping verification)  (LSP ping verification)
VCCV CC type   0x6            0x6
                (router alert label)  (router alert label)
                (TTL expiry)          (TTL expiry)
-----

```

```

Incoming Status (PW Status TLV):
Status code: 0x0 (Up) in Notification message
Outgoing Status (PW Status TLV):
Status code: 0x0 (Up) in Notification message
MIB cpwVcIndex: 4294705365
Create time: 21/09/2011 08:05:01 (00:14:01 ago)
Last time status changed: 21/09/2011 08:07:01 (00:12:01 ago)
Statistics:
  packets: received 1336, sent 26392092
  bytes: received 297928, sent 1583525520

```

This example shows the sample output of a pseudowire headend (PWHE) cross connect:

```

RP/0/0/CPU0:router# show l2vpn xconnect interface pw-ether 67 detail
Group g1, XC xcl, state is down; Interworking none
AC:PW-Ether1, state is up
Type PW-Ether
Interface-list: interfacelist1
Replicate status:
  Gi0/2/0/1: success
  Gi0/3/0/1: pending
  Gi0/4/0/1: failed
MTU 1500; interworking none

```

```

Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0
PW: neighbor 130.130.130.130, PW ID 1234, state is down ( provisioned )
PW class not set
Encapsulation MPLS, protocol LDP
PW type Ethernet VLAN, control word disabled, interworking none
Sequencing not set
Internal label: 16008
VLAN id imposed: 101

```

MPLS	Local	Remote
Label	16001	unknown
Group ID	0x2000600	0x0
Interface	PW-Ether1	unknown
MTU	1500	unknown
Control word	disabled	unknown
PW type	Ethernet VLAN	unknown
VCCV CV type	0x2	0x0 (none)
	(LSP ping verification)	
VCCV CC type	0x6	0x0 (none)
	(router alert label)	
	(TTL expiry)	

```

MIB cpwVcIndex: 2
Create time: 19/02/2010 23:13:01 (1w2d ago)
Last time status changed: 19/02/2010 23:13:16 (1w2d ago)
Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0

```

This table describes the significant fields shown in the display.

**Table 9: show l2vpn xconnect Command Field Descriptions**

Field	Description
XConnect Group	Displays a list of all configured cross-connect groups.
Group	Displays the cross-connect group number.
Name	Displays the cross-connect group name.
Description	Displays the cross-connect group description. If no description is configured, the interface type is displayed.
ST	State of the cross-connect group: up (UP) or down (DN).

#### Related Commands

Command	Description
<a href="#">xconnect group</a> , on page 151	Configures cross-connect groups.

# show tunnel-template

To display tunnel template information, use the **show tunnel-template** command in the EXEC mode.

**show tunnel-template** *template-name*

## Syntax Description

<i>template-name</i>	Name of the tunnel template.
----------------------	------------------------------

## Command Default

None

## Command Modes

EXEC

## Command History

Release	Modification
Release 3.5.0	This command was introduced.

## Usage Guidelines

### Task ID

Task ID	Operation
tunnel	read

## Examples

The following example shows the output of the **show tunnel-template test** command for Local PE Tunnel:

```
RP/0/0/CPU0:router# show tunnel-template test
Fri Jan 30 06:22:46.428 UTC

Tunnel template
-----
Name:      test (ifhandle: 0x00080030)
MTU:      1464
TTL:      255
TOS:      0
Tunnel ID: 1
Source:   25.25.25.25
Session ID: 0x1D174108 Cookie: 8 bytes [0x24FD3ADAA4485333] being rolled into
           Session ID: 0x15A86E93 Cookie: 8 bytes [0xF486195660CCD522]
Next Session-id/Cookie rollover happens in 1 minute 49 seconds
Transmit:      14213298 pkts  1250770344 bytes
Cookie Mismatch: 0 pkts
MTU Violation: 0 pkts
```

The following example shows the output of the **show tunnel-template test** command for Remote PE Tunnel:

```
RP/0/0/CPU0:router# show tunnel-template test
```

Fri Jan 30 06:04:29.800 UTC

Tunnel template

```
-----  
Name:      test (ifhandle: 0x00080030)  
MTU:      600  
TTL:      255  
TOS:      0  
Tunnel ID: 1  
Source:    35.35.35.35   Address Pool: 36.36.36.0/28  
Session ID: 0x111F4312 Cookie: 8 bytes [0xB95A806145BE9BE7]  
Transmit:  122168722 pkts 10750845295 bytes  
Cookie Mismatch: 0 pkts  
MTU Violation: 0 pkts
```

## Related Commands

Command	Description
<a href="#">tunnel-template, on page 150</a>	Enters tunnel-template configuration submenu.

## switching-tlv (L2VPN)

To advertise the switching point type-length variable (TLV) in the label binding, use the **switching-tlv** command in the pseudowire class configuration mode. To disable the display of the TLV, use the **no** form of this command.

**switching tlv hide**

**no switching tlv**

Syntax Description	hide	Hides TLV.
--------------------	------	------------

**Command Default** Switching point TLV data is advertised to peers.

**Command Modes** L2VPN pseudowire class encapsulation mode

Command History	Release	Modification
	Release 4.1.1	This command was introduced.

**Usage Guidelines** The pseudowire switching point TLV information includes the following information:

- Pseudowire ID of the last pseudowire segment traversed
- Pseudowire switching point description
- Local IP address of the pseudowire switching point
- Remote IP address of the last pseudowire switching point that was crossed or the T-PE router

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

**Examples**

The following example shows how to configure a timeout value for L2TP session setup of 400 seconds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# pw-class cisco
RP/0/0/CPU0:router(config-l2vpn-pwc)# encapsulation mpls
RP/0/0/CPU0:router(config-l2vpn-pwc-mpls)# switching-tlv hide
RP/0/0/CPU0:router(config-l2vpn-pwc-mpls)#
```

**Related Commands**

Command	Description
<a href="#">pw-class (L2VPN), on page 65</a>	Enters pseudowire class submode to define a pseudowire class template.

# tag-impose

To specify a tag for a VLAN ID configuration, use the **tag-impose** command in l2vpn configuration submode. To remove the tag, use the **no** form of this command.

**tag-impose** *vlan value*

**no tag-impose** *vlan value*

## Syntax Description

<b>vlan</b>	VLAN in tagged mode.
<b>value</b>	Tag value. The range is from 1 to 4094. The default value is 0.

## Command Default

None

## Command Modes

L2VPN configuration

## Command History

Release	Modification
Release 4.2.1	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operations
l2vpn	read, write

## Examples

This example shows how to specify a tag for a VLAN:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# xconnect group xc1
RP/0/0/CPU0:router(config-l2vpn-xc)#p2p grp1
RP/0/0/CPU0:router(config-l2vpn-xc-p2p)#neighbor 10.1.1.2 pw-id 78
RP/0/0/CPU0:router(config-l2vpn-xc-p2p-pw)#tag-impose vlan 8
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">pw-class (L2VPN), on page 65</a>	Enters pseudowire class submode to define a pseudowire class template.

## tag-rewrite

To configure VLAN tag rewrite, use the **tag-rewrite** command in Encapsulation MPLS configuration mode. To disable VLAN tag rewrite, use the **no** form of this command.

**tag-rewrite ingress vlan** *vlan-id*

**no tag-rewrite ingress vlan** *vlan-id*

### Syntax Description

<b>ingress</b>	Configures ingress mode.
<b>vlan</b>	Configures VLAN tagged mode
<i>vlan-id</i>	Specifies the value of the ID of the VLAN.

### Command Default

None

### Command Modes

Encapsulation MPLS configuration

### Command History

Release	Modification
Release 3.7.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **tag-rewrite** command is applicable only to pseudowires with MPLS encapsulation.

### Task ID

Task ID	Operations
l2vpn	read, write

### Examples

The following example shows how to configure preferred-path tunnel settings:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# pw-class kanata01
RP/0/0/CPU0:router(config-l2vpn-pwc)# encapsulation mpls
RP/0/0/CPU0:router(config-l2vpn-pwc-encap-mpls)# tag-rewrite vlan 2000
RP/0/0/CPU0:router(config-l2vpn-pwc-encap-mpls)#
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">show l2vpn xconnect, on page 129</a>	Displays brief information on configured cross-connects.

## timeout setup (L2TP)

To configure timeout definitions for L2TP session setup, use the **timeout setup** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

**timeout setup** *seconds*

**no timeout setup** *seconds*

<b>Syntax Description</b>	<i>seconds</i>	Time, in seconds, to setup a control channel. Range is 60 to 6000 seconds. Default is 300 seconds.
---------------------------	----------------	--

<b>Command Default</b>	<i>seconds</i> : 300
------------------------	----------------------

<b>Command Modes</b>	L2TP class configuration
----------------------	--------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	l2vpn	read, write

**Examples** The following example shows how to configure a timeout value for L2TP session setup of 400 seconds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2tp-class cisco
RP/0/0/CPU0:router(config-l2tp-class)# timeout setup 400
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">authentication (L2TP)</a> , <a href="#">on page 4</a>	Enables L2TP authentication for a specified L2TP class name.

Command	Description
<a href="#">hello-interval (L2TP), on page 29</a>	Configures the hello-interval value for L2TP (duration between control channel hello packets).
<a href="#">hidden (L2TP), on page 31</a>	Enables hidden attribute-value pairs (AVPs).
<a href="#">hostname (L2TP), on page 33</a>	Defines the name used in the L2TP hostname AVP.
<a href="#">l2tp-class, on page 40</a>	Enters L2TP class configuration mode where you can define an L2TP signaling template.
<a href="#">password (L2TP), on page 63</a>	Defines the password and password encryption type for control channel authentication.
<a href="#">receive-window (L2TP), on page 76</a>	Configures the receive window size for the L2TP server.
<a href="#">retransmit (L2TP), on page 78</a>	Configures retransmit retry and timeout values.
<a href="#">show l2tp session, on page 90</a>	Displays information about L2TP sessions.
<a href="#">show l2tp tunnel, on page 93</a>	Displays information about L2TP tunnels.

## transport mode (L2VPN)

To configure L2VPN pseudowire class transport mode, use the **transport mode** command in L2VPN pseudowire class MPLS encapsulation mode. To disable the L@VPN pseudowire class transport mode configuration, use the **no** form of this command.

**transport mode** {ethernet| vlan }

**no transport mode** {ethernet| vlan }

### Syntax Description

<b>ethernet</b>	Configures Ethernet port mode.
<b>vlan</b>	Configures VLAN tagged mode.

### Command Default

None

### Command Modes

L2VPN pseudowire class MPLS encapsulation

### Command History

Release	Modification
Release 3.7.2	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



#### Note

All L2VPN configurations can be deleted using the **no l2vpn** command.

### Task ID

Task ID	Operations
l2vpn	read, write

### Examples

This example shows how to configure Ethernet transport mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# pw-class kanata01
```

```
RP/0/0/CPU0:router(config-l2vpn-pw)# encapsulation mpls  
RP/0/0/CPU0:router(config-l2vpn-encap-mpls)# transport-mode ethernet
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">pw-class (L2VPN), on page 65</a>	Enters pseudowire class submode to define a pseudowire class template.

# tunnel-template

To enter tunnel-template configuration submode, use the **tunnel-template** command in global configuration mode.

**tunnel-template** *template name*

**no tunnel-template** *template-name*

## Syntax Description

<i>template-name</i>	Configures a name for the tunnel template.
----------------------	--

## Command Default

None

## Command Modes

Global configuration

## Command History

Release	Modification
Release 3.5.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operations
tunnel	read, write

## Examples

The following example shows how to enter tunnel-template configuration submode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# tunnel-template template_01
```

## Related Commands

Command	Description
<a href="#">xconnect group</a> , on page 151	Configures cross-connect groups.

## xconnect group

To configure cross-connect groups, use the **xconnect group** command in L2VPN configuration mode. To return to the default behavior, use the **no** form of this command.

**xconnect group** *group-name*

**no xconnect group** *group-name*

### Syntax Description

<i>group-name</i>	Configures a cross-connect group name using a free-format 32-character string.
-------------------	--

### Command Default

None

### Command Modes

L2VPN configuration

### Command History

Release	Modification
Release 3.4.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



#### Note

You can configure up to a maximum of 16K cross-connects per box.

### Task ID

Task ID	Operations
l2vpn	read, write

### Examples

The following example shows how to group all cross -connects for customer\_atlantic:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# xconnect group customer_atlantic
```

**Related Commands**

Command	Description
<a href="#">show l2vpn xconnect</a> , <a href="#">on page 129</a>	Displays brief information on configured cross-connects.



## Virtual Private LAN Services Commands

---

This module describes the commands used to configure, monitor, and troubleshoot Virtual Private LAN Services (VPLS).

For detailed information about virtual private network concepts, configuration tasks, and examples, refer to the *Virtual Private Configuration Guide*.

- [action \(VPLS\), page 155](#)
- [aging \(VPLS\), page 157](#)
- [bridge-domain \(VPLS\), page 159](#)
- [bridge group \(VPLS\), page 161](#)
- [clear l2vpn bridge-domain \(VPLS\), page 163](#)
- [flooding disable, page 165](#)
- [flooding unknown-unicast disable \(VPLS\), page 167](#)
- [interface \(VPLS\), page 169](#)
- [learning disable \(VPLS\), page 171](#)
- [limit \(VPLS\), page 173](#)
- [mac \(VPLS\), page 175](#)
- [maximum \(VPLS\), page 177](#)
- [mpls static label \(VPLS\), page 179](#)
- [mtu \(VPLS\), page 181](#)
- [neighbor \(VPLS\), page 183](#)
- [notification \(VPLS\), page 185](#)
- [port-down flush disable \(VPLS\), page 187](#)
- [pw-class \(VFI\), page 189](#)
- [pw-status \(L2VPN\), page 191](#)
- [show l2vpn bridge-domain \(VPLS\), page 193](#)
- [show l2vpn forwarding bridge-domain \(VPLS\), page 201](#)

- [show l2vpn forwarding bridge-domain mac-address \(VPLS\)](#), page 206
- [shutdown \(Bridge Domain\)](#), page 210
- [shutdown \(VFI\)](#), page 212
- [static-address \(VPLS\)](#), page 214
- [static-mac-address \(VPLS\)](#), page 216
- [time \(VPLS\)](#), page 218
- [type \(VPLS\)](#), page 220
- [vfi \(VPLS\)](#), page 222
- [withdraw \(VPLS\)](#), page 224

## action (VPLS)

To configure the bridge behavior when the number of learned MAC addresses reaches the MAC limit configured, use the **action** command in L2VPN bridge group bridge domain MAC limit configuration mode. To disable this feature, use the **no** form of this command.

**action** {**flood**| **no-flood**| **shutdown**}

**no action** {**flood**| **no-flood**| **shutdown**}

### Syntax Description

<b>flood</b>	Configures the action to flood all unknown unicast packets when the MAC limit is reached. If the action is set to flood, all unknown unicast packets, with unknown destinations addresses, are flooded over the bridge.
<b>no-flood</b>	Configures the action to no-flood so all unknown unicast packets are dropped when the MAC limit is reached. If the action is set to no-flood, all unknown unicast packets, with unknown destination addresses, are dropped.
<b>shutdown</b>	Stops forwarding when the MAC limit is reached. If the action is set to shutdown, all packets are dropped.

### Command Default

No action is taken when the MAC address limit is reached.

### Command Modes

L2VPN bridge group bridge domain MAC limit configuration

### Command History

Release	Modification
Release 3.7.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **action** command to specify the type of action to be taken when the action is violated.

The configured action has no impact if the MAC limit has not been reached.

### Task ID

Task ID	Operations
l2vpn	read, write

**Examples**

The following example shows how to configure the bridge bar to flood all unknown unicast packets when the number of MAC addresses learned by the bridge reaches 10:

```
RP/0/0/CPU0:router#configure
RP/0/0/CPU0:router (config) #l2vpn
RP/0/0/CPU0:router (config-l2vpn) #bridge group 1
RP/0/0/CPU0:router (config-l2vpn-bg) #bridge-domain bar
RP/0/0/CPU0:router (config-l2vpn-bg-bd) #mac
RP/0/0/CPU0:router (config-l2vpn-bg-bd-mac) #limit
RP/0/0/CPU0:router (config-l2vpn-bg-bd-mac-limit) #action flood
RP/0/0/CPU0:router (config-l2vpn-bg-bd-mac-limit) #maximum 10
```

**Related Commands**

Command	Description
<a href="#">bridge-domain (VPLS), on page 159</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS), on page 161</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">limit (VPLS), on page 173</a>	Sets the MAC address limit for action, maximum, and notification and enters L2VPN bridge group bridge domain MAC limit configuration mode.
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.
<a href="#">mac (VPLS), on page 175</a>	Enters L2VPN bridge group bridge domain MAC configuration mode.
<a href="#">maximum (VPLS), on page 177</a>	Configures the specified action when the number of MAC addresses learned on a bridge is reached.
<a href="#">notification (VPLS), on page 185</a>	Specifies the type of notification that is sent when the number of learned MAC addresses exceeds the configured limit.

## aging (VPLS)

To enter the MAC aging configuration submode to set the aging parameters such as time and type, use the **aging** command in L2VPN bridge group bridge domain configuration mode. To return to the default value for all parameters that are attached to this configuration submode, use the **no** form of this command.

**aging**

**no aging**

**Syntax Description** This command has no keywords or arguments.

**Command Default** No defaults are attached to this parameter since it is used as a configuration submode. See defaults that are assigned to the [time \(VPLS\)](#), on page 218 and the [type \(VPLS\)](#), on page 220 parameters.

**Command Modes** L2VPN bridge group bridge domain MAC configuration

Command History	Release	Modification
	Release 3.7.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **aging** command to enter L2VPN bridge group bridge domain MAC aging configuration mode.

Task ID	Task ID	Operations
	l2vpn	read, write

**Examples** The following example shows how to enter MAC aging configuration submode and to set the MAC aging time to 120 seconds:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac)# aging
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac-aging)# time 120
```

**Related Commands**

Commands	Description
<a href="#">bridge-domain (VPLS)</a> , on page 159	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS)</a> , on page 161	Creates a bridge group so that it can contain bridge domains and then assigns network interfaces to the bridge domain.
<a href="#">l2vpn</a> , on page 49	Enters L2VPN configuration mode.
<a href="#">mac (VPLS)</a> , on page 175	Enters L2VPN bridge group bridge domain MAC configuration mode.
<a href="#">time (VPLS)</a> , on page 218	Configures the maximum aging time.
<a href="#">type (VPLS)</a> , on page 220	Configures the type for MAC address aging.

## bridge-domain (VPLS)

To establish a bridge domain and to enter L2VPN bridge group bridge domain configuration mode, use the **bridge-domain** command in L2VPN bridge group configuration mode. To return to a single bridge domain, use the **no** form of this command.

**bridge-domain** *bridge-domain-name*

**no bridge-domain** *bridge-domain-name*

### Syntax Description

*bridge-domain-name*

Name of the bridge domain.

**Note** The maximum number of characters that can be specified in the bridge domain name is 27.

### Command Default

The default value is a single bridge domain.

### Command Modes

L2VPN bridge group configuration

### Command History

#### Release

#### Modification

Release 3.7.0

This command was introduced.

### Usage Guidelines

Use the **bridge-domain** command to enter L2VPN bridge group bridge domain configuration mode.

### Task ID

#### Task ID

#### Operations

l2vpn

read, write

### Examples

The following example shows how to configure a bridge domain:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router (config)# l2vpn
RP/0/0/CPU0:router (config-l2vpn)# bridge group 1
RP/0/0/CPU0:router (config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router (config-l2vpn-bg-bd)#
```

**Related Commands**

Command	Description
<a href="#">bridge group (VPLS), on page 161</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.

## bridge group (VPLS)

To create a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain, use the **bridge group** command in L2VPN configuration mode. To remove all the bridge domains that are created under this bridge group and to remove all network interfaces that are assigned under this bridge group, use the **no** form of this command.

**bridge group** *bridge-group-name*

**no bridge-group** *bridge-group-name*

Syntax Description	
	<i>bridge-group-name</i>
	Number of the bridge group to which the interface belongs.

**Command Default** No bridge group is created.

**Command Modes** L2VPN configuration

Command History	Release	Modification
	Release 3.7.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **bridge group** command to enter L2VPN bridge group configuration mode.

Task ID	Task ID	Operations
	l2vpn	read, write

**Examples** The following example shows that bridge group 1 is assigned:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)#
```

**Related Commands**

Command	Description
<a href="#">bridge-domain (VPLS), on page 159</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.

## clear l2vpn bridge-domain (VPLS)

To clear the MAC addresses and to restart the bridge domains on the router, use the **clear l2vpn bridge-domain** command in EXEC mode.

```
clear l2vpn bridge-domain {all| bd-name name| group group}
```

### Syntax Description

<b>all</b>	Clears and restarts all the bridge domains on the router.
<b>bd-name</b> <i>name</i>	Clears and restarts the specified bridge domain. The <i>name</i> argument specifies the name of the bridge-domain.
<b>group</b> <i>group</i>	Clears and restarts all the bridge domains that are part of the bridge group.

### Command Default

None

### Command Modes

EXEC

### Command History

Release	Modification
Release 3.7.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

This is the method that allows a bridge to forward again after it was put in Shutdown state as a result of exceeding the configured MAC limit.

### Task ID

Task ID	Operations
l2vpn	read, write

### Examples

The following example shows how to clear all the MAC addresses and to restart all the bridge domains on the router:

```
RP/0/0/CPU0:router# clear l2vpn bridge-domain all
```

**clear l2vpn bridge-domain (VPLS)****Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">show l2vpn bridge-domain (VPLS), on page 193</a>	Display information for the bridge ports such as attachment circuits and pseudowires for the specific bridge domains.

# flooding disable

To configure flooding for traffic at the bridge domain level or at the bridge port level, use the **flooding disable** command in L2VPN bridge group bridge domain configuration mode. To return the bridge to normal flooding behavior when all unknown unicast packets, all broadcast packets, and all multicast packets are flooded over all other bridge domain network interfaces, use the **no** form of this command.

**flooding disable**

**no flooding disable**

This command has no keywords or arguments.

## Command Default

The default behavior is that packets are flooded when their destination MAC address is not found.

## Command Modes

L2VPN bridge group bridge domain configuration

## Command History

Release	Modification
Release 3.7.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **flooding disable** command to override the parent bridge configuration.

By default, bridge ports inherit the flooding behavior of the bridge domain.

When flooding is disabled, all unknown unicast packets, all broadcast packets, and all multicast packets are discarded.

## Task ID

Task ID	Operations
l2vpn	read, write

## Examples

The following example shows how to disable flooding on the bridge domain called bar:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# flooding disable
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">bridge-domain (VPLS), on page 159</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS), on page 161</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.
<a href="#">mtu (VPLS), on page 181</a>	Adjusts the maximum packet size or maximum transmission unit (MTU) size for the bridge domain.

# flooding unknown-unicast disable (VPLS)

To disable flooding of unknown unicast traffic at the bridge domain level or at the bridge port level, use the **flooding unknown-unicast disable** command in L2VPN bridge group bridge domain configuration mode. To return the bridge to normal flooding behavior, use the **no** form of this command.

**flooding unknown-unicast disable**

**no flooding unknown-unicast disable**

**Syntax Description** This command has no keywords or arguments.

**Command Default** The default behavior is that packets are flooded when their destination MAC address is not found.

**Command Modes** L2VPN bridge group bridge domain configuration

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **flooding unknown-unicast disable** command to override the parent bridge configuration.

By default, bridge ports inherit the flooding behavior of the bridge domain.

When flooding is disabled, all unknown unicast packets are discarded.

Use this command on Layer 2 interfaces. This command is not applicable on BVI interfaces.

Task ID	Task ID	Operations
	l2vpn	read, write

**Examples** The following example shows how to disable flooding on the bridge domain called bar:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# flooding unknown-unicast disable
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">bridge-domain (VPLS), on page 159</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS), on page 161</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.
<a href="#">mtu (VPLS), on page 181</a>	Adjusts the maximum packet size or maximum transmission unit (MTU) size for the bridge domain.

## interface (VPLS)

To add an interface to a bridge domain that allows packets to be forwarded and received from other interfaces that are part of the same bridge domain, use the **interface** command in L2VPN bridge group bridge domain configuration mode. To remove an interface from a bridge domain, use the **no** form of this command.

**interface** *type interface-path-id*

**no interface** *type interface-path-id*

### Syntax Description

<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface.
	<b>Note</b> Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

### Command Default

None

### Command Modes

L2VPN bridge group bridge domain configuration

### Command History

Release	Modification
Release 3.7.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **interface** command to enter L2VPN bridge group bridge domain attachment circuit configuration mode. In addition, the **interface** command enters the interface configuration submode to configure parameters specific to the interface.

By default, an interface is not part of a bridge.

### Task ID

Task ID	Operations
l2vpn	read, write

**Examples**

The following example shows how to configure the bundle Ethernet interface as an attachment circuit:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# interface gigabitethernet 0/1/0/9
RP/0/0/CPU0:router(config-l2vpn-bg-bd-ac)#
```

**Related Commands**

Command	Description
<a href="#">bridge-domain (VPLS), on page 159</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS), on page 161</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.

## learning disable (VPLS)

To override the MAC learning configuration of a parent bridge or to set the MAC learning configuration of a bridge, use the **learning disable** command in L2VPN bridge group bridge domain MAC configuration mode. To disable this feature, use the **no** form of this command.

**learning disable**

**no learning disable**

**Syntax Description** This command has no keywords or arguments.

**Command Default** By default, learning is enabled on all bridge domains and all interfaces on that bridge inherits this behavior.

**Command Modes** L2VPN bridge group bridge domain MAC configuration

Command History	Release	Modification
	Release 3.7.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

When set, the **learning disable** command stops all MAC learning either on the specified interface or the bridge domain.

Task ID	Task ID	Operations
	l2vpn	read, write

**Examples** In the following example, MAC learning is disabled on all ports in the bridge domain called bar, which is applied to all interfaces in the bridge unless the interface has its own MAC learning enable command.

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac)# learning disable
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">bridge-domain (VPLS), on page 159</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS), on page 161</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.
<a href="#">mac (VPLS), on page 175</a>	Enters L2VPN bridge group bridge domain MAC configuration mode.

## limit (VPLS)

To set the MAC address limit for action, maximum, and notification and to enter L2VPN bridge group bridge domain MAC limit configuration mode, use the **limit** command in L2VPN bridge group bridge domain MAC configuration mode. To remove all limits that were previously configured under the MAC configuration submodes, use the **no** form of this command.

**limit**

**no limit**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** L2VPN bridge group bridge domain MAC configuration

Command History	Release	Modification
	Release 3.7.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **limit** command to enter L2VPN bridge group bridge domain MAC limit configuration mode. The **limit** command specifies that one syslog message is sent or a corresponding trap is generated with the MAC limit when the action is violated.

Task ID	Task ID	Operations
	l2vpn	read, write

**Examples** The following example shows how the MAC limit for the bridge bar is set to 100 with an action of shutdown. After the configuration, the bridge stops all forwarding after 100 MAC addresses are learned. When this happens, a syslog message and an SNMP trap are created.

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# mac
```

```

RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac)# limit
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac-limit)# maximum 100
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac-limit)# action shutdown
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac-limit)# notification both

```

**Related Commands**

Command	Description
<a href="#">action (VPLS), on page 155</a>	Configures bridge behavior when the number of learned MAC addresses reaches the MAC limit configured.
<a href="#">bridge-domain (VPLS), on page 159</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS), on page 161</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.
<a href="#">mac (VPLS), on page 175</a>	Enters L2VPN bridge group bridge domain MAC configuration mode.
<a href="#">maximum (VPLS), on page 177</a>	Configures the specified action when the number of MAC addresses learned on a bridge is reached.
<a href="#">notification (VPLS), on page 185</a>	Specifies the type of notification that is sent when the number of learned MAC addresses exceeds the configured limit.

## mac (VPLS)

To enter L2VPN bridge group bridge domain MAC configuration mode, use the **mac** command in L2VPN bridge group bridge domain configuration mode. To disable all configurations added under the MAC configuration submodes, use the **no** form of this command.

**mac**

**no mac**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** L2VPN bridge group bridge domain configuration

Command History	Release	Modification
	Release 3.7.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **mac** command to enter L2VPN bridge group bridge domain MAC configuration mode.

Task ID	Task ID	Operations
	l2vpn	read, write

**Examples** The following example shows how to enter L2VPN bridge group bridge domain MAC configuration mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router (config)# l2vpn
RP/0/0/CPU0:router (config-l2vpn)# bridge group 1
RP/0/0/CPU0:router (config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router (config-l2vpn-bg-bd)# mac
RP/0/0/CPU0:router (config-l2vpn-bg-bd-mac)#
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">aging (VPLS), on page 157</a>	Enters the MAC aging configuration submode to set the aging parameters such as time and type.
<a href="#">bridge-domain (VPLS), on page 159</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS), on page 161</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.
<a href="#">learning disable (VPLS), on page 171</a>	Overrides the MAC learning configuration of a parent bridge or sets the MAC learning configuration of a bridge.
<a href="#">limit (VPLS), on page 173</a>	Sets the MAC address limit for action, maximum, and notification and enters L2VPN bridge group bridge domain MAC limit configuration mode.
<a href="#">static-address (VPLS), on page 214</a>	Adds static entries to the MAC address for filtering.
<a href="#">withdraw (VPLS), on page 224</a>	Disables MAC address withdrawal for a specified bridge domain

## maximum (VPLS)

To configure the specified action when the number of MAC addresses learned on a bridge is reached, use the **maximum** command in L2VPN bridge group bridge domain MAC limit configuration mode. To disable this feature, use the **no** form of this command.

**maximum** *value*

**no maximum** *value*

### Syntax Description

<i>value</i>	Maximum number of learned MAC addresses. The range is from 5 to 512000.
--------------	--

### Command Default

The default maximum value is 4000.

### Command Modes

L2VPN bridge group bridge domain MAC limit configuration

### Command History

Release	Modification
Release 3.7.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The action can either be flood, no flood, or shutdown. Depending on the configuration, a syslog, an SNMP trap notification, or both are issued.

### Task ID

Task ID	Operations
l2vpn	read, write

### Examples

The following example shows when the number of MAC address learned on the bridge reaches 5000 and the bridge stops learning but continues flooding:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# mac
```

```

RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac)# limit
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac-limit)# maximum 5000
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac-limit)# action no-flood

```

**Related Commands**

Command	Description
<a href="#">action (VPLS), on page 155</a>	Configures bridge behavior when the number of learned MAC addresses reaches the MAC limit configured.
<a href="#">bridge-domain (VPLS), on page 159</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS), on page 161</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.
<a href="#">limit (VPLS), on page 173</a>	Sets the MAC address limit for action, maximum, and notification and enters L2VPN bridge group bridge domain MAC limit configuration mode.
<a href="#">mac (VPLS), on page 175</a>	Enters L2VPN bridge group bridge domain MAC configuration mode.
<a href="#">notification (VPLS), on page 185</a>	Specifies the type of notification that is sent when the number of learned MAC addresses exceeds the configured limit.

## mpls static label (VPLS)

To configure the MPLS static labels and the static labels for the access pseudowire configuration, use the **mpls static label** command in L2VPN bridge group bridge domain VFI pseudowire configuration mode. To assign the dynamic MPLS labels to either the virtual forwarding interface (VFI) pseudowire or the access pseudowire, use the **no** form of this command.

**mpls static label local** *value value* **remote** *value*

**no mpls static label local** *value value* **remote** *value*

### Syntax Description

<b>local</b> <i>value</i>	Configures the local pseudowire label. <b>Note</b> Use the <b>show mpls label range</b> command to obtain the range for the local labels.
<b>remote</b> <i>value</i>	Configures the remote pseudowire label. <b>Note</b> The range of values for the remote labels depends on the label allocator of the remote router.

### Command Default

By default, the router attempts to assign dynamic labels to the pseudowire.

### Command Modes

L2VPN bridge group bridge domain Access/VFI pseudowire configuration

### Command History

Release	Modification
Release 3.7.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Ensure that both ends of the pseudowire have matching static labels.

### Task ID

Task ID	Operations
l2vpn	read, write

**Examples**

The following example shows how to configure the VFI pseudowire 10.1.1.2 with pseudowire ID of 1000 to use MPLS label 800 and remote MPLS label 500:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# vfi model
RP/0/0/CPU0:router(config-l2vpn-bg-bd-vfi)# neighbor 10.1.1.2 pw-id 1000
RP/0/0/CPU0:router(config-l2vpn-bg-bd-vfi-pw)# mpls static label local 800 remote 500
```

**Related Commands**

Command	Description
<a href="#">bridge-domain (VPLS), on page 159</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS), on page 161</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.
<a href="#">neighbor (VPLS), on page 183</a>	Adds an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI).
<a href="#">pw-class (VFI), on page 189</a>	Configures the pseudowire class template name to use for the pseudowire.
<a href="#">vfi (VPLS), on page 222</a>	Configures virtual forwarding interface (VFI) parameters.

## mtu (VPLS)

To adjust the maximum packet size or maximum transmission unit (MTU) size for the bridge domain, use the **mtu** command in L2VPN bridge group bridge domain configuration mode. To disable this feature, use the **no** form of this command.

**mtu** *bytes*

**no mtu**

### Syntax Description

*bytes* MTU size, in bytes. The range is from 46 to 65535.

### Command Default

The default MTU value is 1500.

### Command Modes

L2VPN bridge group bridge domain configuration

### Command History

Release	Modification
Release 3.7.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Each interface has a default maximum packet size or MTU size. This number generally defaults to the largest size possible for that interface type. On serial interfaces, the MTU size varies, but cannot be set smaller than 64 bytes.

The MTU for the bridge domain includes only the payload of the packet. For example, a configured bridge MTU of 1500 allows tagged packets of 1518 bytes (6 bytes DA, 6 bytes SA, 2 bytes ethertype, or 4 bytes qtag).

### Task ID

Task ID	Operations
l2vpn	read, write

### Examples

The following example specifies an MTU of 1000 bytes:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
```

```
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# mtu 1000
```

**Related Commands**

Command	Description
<a href="#">bridge-domain (VPLS), on page 159</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS), on page 161</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">flooding disable, on page 165</a>	Configures flooding for traffic at the bridge domain level or at the bridge port level.
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.

## neighbor (VPLS)

To add an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI), use the **neighbor** command in the appropriate L2VPN bridge group bridge domain configuration submode. To remove the pseudowire either from the bridge or from the VFI, use the **no** form of this command.

**neighbor** *A.B.C.D* **pw-id** *value*

**no neighbor** *A.B.C.D* **pw-id** *value*

### Syntax Description

<i>A.B.C.D</i>	IP address of the cross-connect peer.
<b>pw-id</b> <i>value</i>	Configures the pseudowire ID and ID value. Range is 1 to 4294967295.

### Command Default

None

### Command Modes

L2VPN bridge group bridge domain configuration  
L2VPN bridge group bridge domain VFI configuration

### Command History

Release	Modification
Release 3.7.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **neighbor** command to enter L2VPN bridge group bridge domain VFI pseudowire configuration mode. Alternatively, use the **neighbor** command to enter L2VPN bridge group bridge domain access pseudowire configuration mode.

### Task ID

Task ID	Operations
l2vpn	read, write

### Examples

The following example shows how to configure an access pseudowire directly under a bridge domain in L2VPN bridge group bridge domain configuration mode:

```
RP/0/0/CPU0:router# configure
```

```
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# neighbor 10.1.1.2 pw-id 1000
RP/0/0/CPU0:router(config-l2vpn-bg-bd-pw)#
```

The following example shows how to configure the parameters for any pseudowire in L2VPN bridge group bridge domain VFI configuration mode:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# vfi v1
RP/0/0/CPU0:router(config-l2vpn-bg-bd-vfi)# neighbor 10.1.1.2 pw-id 1000
RP/0/0/CPU0:router(config-l2vpn-bg-bd-vfi-pw)#
```

## Related Commands

Command	Description
<a href="#">bridge-domain (VPLS), on page 159</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS), on page 161</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.
<a href="#">mpls static label (VPLS), on page 179</a>	Configures the MPLS static labels and the static labels for the access pseudowire configuration.
<a href="#">pw-class (VFI), on page 189</a>	Configures the pseudowire class template name to use for the pseudowire.
<a href="#">static-mac-address (VPLS), on page 216</a>	Configures the static MAC address to associate a remote MAC address with a pseudowire or any other bridge interface.
<a href="#">vfi (VPLS), on page 222</a>	Configures virtual forwarding interface (VFI) parameters.

## notification (VPLS)

To specify the type of notification that is sent when the number of learned MAC addresses exceeds the configured limit, use the **notification** command in L2VPN bridge group bridge domain MAC limit configuration mode. To use the notification as only a syslog entry, use the **no** form of this command.

**notification** {both| none| trap}

**no notification** {both| none| trap}

### Syntax Description

<b>both</b>	Sends syslog and trap notifications when the action is violated.
<b>none</b>	Specifies no notification.
<b>trap</b>	Sends trap notifications when the action is violated.

### Command Default

By default, only a syslog message is sent when the number of learned MAC addresses reaches the maximum configured.

### Command Modes

L2VPN bridge group bridge domain MAC limit configuration

### Command History

Release	Modification
Release 3.7.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

A syslog message and an SNMP trap is generated. Alternatively, an SNMP trap is generated. Finally, no notification is generated.

### Task ID

Task ID	Operations
l2vpn	read, write

**Examples**

The following example shows how both a syslog message and an SNMP trap are generated with the bridge bar and learns more MAC addresses than the configured limit:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac)# limit
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac-limit)# notification both
```

**Related Commands**

Command	Description
<a href="#">action (VPLS), on page 155</a>	Configures bridge behavior when the number of learned MAC addresses reaches the MAC limit configured.
<a href="#">bridge-domain (VPLS), on page 159</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS), on page 161</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.
<a href="#">mac (VPLS), on page 175</a>	Enters L2VPN bridge group bridge domain MAC configuration mode.
<a href="#">maximum (VPLS), on page 177</a>	Configures the specified action when the number of MAC addresses learned on a bridge is reached.

## port-down flush disable (VPLS)

To disable MAC flush when the bridge port is nonfunctional, use the **port-down flush disable** command in the L2VPN bridge group bridge domain MAC configuration mode. Use the **no** form of this command to enable the MAC flush when the bridge port is nonfunctional.

**port-down flush disable**

**no port-down flush disable**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** L2VPN bridge group bridge domain MAC configuration

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **port-down flush disable** command disables the MAC flush when the bridge port is nonfunctional.

Task ID	Task ID	Operations
	l2vpn	read, write

**Examples** The following example shows how to disable MAC flush when the bridge port is nonfunctional:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac)# port-down flush disable
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">action (VPLS), on page 155</a>	Configures bridge behavior when the number of learned MAC addresses reaches the MAC limit configured.
<a href="#">bridge-domain (VPLS), on page 159</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS), on page 161</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.
<a href="#">mac (VPLS), on page 175</a>	Enters L2VPN bridge group bridge domain MAC configuration mode.
<a href="#">maximum (VPLS), on page 177</a>	Configures the specified action when the number of MAC addresses learned on a bridge is reached.
<a href="#">notification (VPLS), on page 185</a>	Specifies the type of notification that is sent when the number of learned MAC addresses exceeds the configured limit.

## pw-class (VFI)

To configure the pseudowire class template name to use for the pseudowire, use the **pw-class** command in L2VPN bridge group bridge domain VFI pseudowire configuration mode. To delete the pseudowire class, use the **no** form of this command.

**pw-class** *class-name*

**no pw-class** *class-name*

Syntax Description	<i>class-name</i>	Pseudowire class name.
--------------------	-------------------	------------------------

Command Default	None
-----------------	------

Command Modes	L2VPN bridge group bridge domain VFI pseudowire configuration
---------------	---

Command History	Release	Modification
	Release 3.7.0	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
------------------	---

Task ID	Task ID	Operations
	l2vpn	read, write

**Examples** The following example shows how to attach the pseudowire class to the pseudowire:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# vfi v1
RP/0/0/CPU0:router(config-l2vpn-bg-bd-vfi)# neighbor 10.1.1.2 pw-id 1000
RP/0/0/CPU0:router(config-l2vpn-bg-bd-vfi-pw)# pw-class canada
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">bridge-domain (VPLS), on page 159</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS), on page 161</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.
<a href="#">mpls static label (VPLS), on page 179</a>	Configures the MPLS static labels and the static labels for the access pseudowire configuration.
<a href="#">neighbor (VPLS), on page 183</a>	Adds an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI).
<a href="#">vfi (VPLS), on page 222</a>	Configures virtual forwarding interface (VFI) parameters.

## pw-status (L2VPN)

To enable status signaling on a pseudowire, use the **pw-status** command in L2VPN configuration submode. To disable the pseudowire status signaling, use the **no** form of this command.

**pw-status**

**no pw-status**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** L2VPN configuration submode

Command History	Release	Modification
	Release 4.1.1	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Cisco IOS XR software provides two methods for signaling pseudowires (PW) status:

- Using Label Withdraw Message  
The provider edge routers (PEs) send Label Mapping Message to their peers as soon as the pseudowire is configured and administratively enabled. The pseudowire label should not be withdrawn unless the pseudowire is administratively disabled or deleted.
- Using PW status TLV  
The PEs use LDP pseudowire status TLV to indicate pseudowire status to their peers. The LDP pseudowire status TLV contains additional information compared to the Label Withdraw Message.



**Note** Unless pseudowire status TLV is explicitly enabled under L2VPN configuration, the default signaling method is Label Withdrawal.

Task ID	Task ID	Operations
	l2vpn	read, write

**Examples**

The following example shows how to enable pseudowire status signaling on configured pseudowires:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# pw-status
RP/0/0/CPU0:router(config-l2vpn)#
```

**Related Commands**

Command	Description
<a href="#">l2vpn</a> , <a href="#">on page 49</a>	Enters L2VPN configuration mode.

## show l2vpn bridge-domain (VPLS)

To display information for the bridge ports such as attachment circuits and pseudowires for the specific bridge domains, use the **show l2vpn bridge-domain** command in EXEC mode.

**show l2vpn bridge-domain** [**bd-name** *bridge-domain-name* | **brief** | **detail** | **group** *bridge-domain-group-name* | **interface** *type interface-path-id*] **neighbor** **IP-address** [**pw-id** *value* | **summary**]

### Syntax Description

<b>bd-name</b> <i>bridge-domain-name</i>	(Optional) Displays the bridges by the bridge ID. The <i>bridge-domain-name</i> argument is used to name a bridge domain.
<b>brief</b>	(Optional) Displays brief information about the bridges.
<b>detail</b>	(Optional) Displays the output for the Layer 2 VPN (L2VPN) to indicate whether or not the MAC withdrawal feature is enabled and the number of MAC withdrawal messages that are sent or received from the pseudowire.
<b>group</b> <i>bridge-domain-group-name</i>	(Optional) Displays filter information on the bridge-domain group name. The <i>bridge-domain-group-name</i> argument is used to name the bridge domain group.
<b>interface</b> <i>type</i>	(Optional) Displays the filter information for the interface on the bridge domain. Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface. <b>Note</b> Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
<b>neighbor</b> <i>IP-address</i>	(Optional) Displays only the bridge domain that contains the pseudowires to match the filter for the neighbor. The <i>IP-address</i> argument is used to configure IP address of the neighbor.
<b>pw-id</b> <i>value</i>	(Optional) Displays the filter for the pseudowire ID. The range is from 1 to 4294967295.
<b>summary</b>	(Optional) Displays the summary information for the bridge domain.

**Command Default** None

**Command Modes** EXEC mode

**Command History**

Release	Modification
Release 3.7.0	This command was introduced.

**Usage Guidelines**

To use commands of this module, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using any command, contact your AAA administrator for assistance.

Use the **interface** keyword to display only the bridge domain that contains the specified interface as an attachment circuit. In the sample output, only the attachment circuit matches the filter that is displayed. No pseudowires are displayed.

**Task ID**

Task ID	Operations
l2vpn	read

**Examples**

This is the sample output for **show l2vpn bridge-domain** command with VxLAN parameters configured:

```
RP/0/0/CPU0:router# show l2vpn bridge-domain bd-name bg1_bd1 detail
Legend: pp = Partially Programmed.
Bridge group: bg1, bridge-domain: bg1_bd1, id: 0, state: up, ShgId: 0, MSTi: 0
  Coupled state: disabled
  MAC learning: enabled
  MAC withdraw: enabled
    MAC withdraw for Access PW: enabled
    MAC withdraw sent on: bridge port up
    MAC withdraw relaying (access to access): disabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: no
  MAC port down flush: enabled
  MAC Secure: disabled, Logging: disabled
  Split Horizon Group: none
  Dynamic ARP Inspection: disabled, Logging: disabled
  IP Source Guard: disabled, Logging: disabled
  DHCPv4 snooping: disabled
  IGMP Snooping: enabled
  IGMP Snooping profile: none
  MLD Snooping profile: none
  Storm Control: disabled
  Bridge MTU: 1500
  MIB cvplsConfigIndex: 1
  Filter MAC addresses:
  P2MP PW: disabled
  Create time: 30/03/2015 22:25:38 (00:26:08 ago)
  No status change since creation
  ACs: 2 (2 up), VFIs: 1, PWs: 0 (0 up), PBBs: 0 (0 up)
  List of ACs:
    AC: BV11, state is up
      Type Routed-Interface
      MTU 1514; XC ID 0x80000001; interworking none
      BVI MAC address:
```

```

    1000.4444.0001
AC: GigabitEthernet0/8/0/0.1, state is up
  Type VLAN; Num Ranges: 1
  Outer Tag: 1
  VLAN ranges: [1001, 1001]
  MTU 1508; XC ID 0x508000a; interworking none
  MAC learning: enabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: no
  MAC port down flush: enabled
  MAC Secure: disabled, Logging: disabled
  Split Horizon Group: none
  Dynamic ARP Inspection: disabled, Logging: disabled
  IP Source Guard: disabled, Logging: disabled
  DHCPv4 snooping: disabled
  IGMP Snooping: enabled
  IGMP Snooping profile: none
  MLD Snooping profile: none
  Storm Control: bridge-domain policer
  Static MAC addresses:

  Storm control drop counters:
    packets: broadcast 0, multicast 0, unknown unicast 0
    bytes: broadcast 0, multicast 0, unknown unicast 0
  Dynamic ARP inspection drop counters:
    packets: 0, bytes: 0
  IP source guard drop counters:
    packets: 0, bytes: 0
List of VNIs:
  VNI 1, state is up
  XC ID 0x80000014
  Encap type VXLAN
  Overlay nve100, Source 1.1.1.1, Multicast Group 225.1.1.1, UDP Port 4789
  Anycast VTEP 100.1.1.1, Anycast Multicast Group 224.10.10.1
  MAC learning: enabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: no
  MAC port down flush: enabled
  MAC Secure: disabled, Logging: disabled
  Split Horizon Group: none
  Dynamic ARP Inspection: disabled, Logging: disabled
  IP Source Guard: disabled, Logging: disabled
  DHCPv4 snooping: disabled
  IGMP Snooping: enabled
  IGMP Snooping profile: none
  MLD Snooping profile: none
  Storm Control: bridge-domain policer

List of Access PWs:
List of VFIs:
  VFI bg1_bd1_vfi (up)
  VFI Statistics:
    drops: illegal VLAN 0, illegal length 0

```

This table describes the significant fields shown in the display.

The following sample output shows information for the bridge ports such as attachment circuits and pseudowires for the specific bridge domains:

```

RP/0/0/CPU0:router# show l2vpn bridge-domain

Bridge group: g1, bridge-domain: bd1, id: 0, state: up, ShgId: 0, MSTi: 0
  Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog

```

```

Filter MAC addresses: 0
ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
List of ACs:
  Gi0/1/0/0, state: up, Static MAC addresses: 2, MSTi: 0 (unprotected)
List of Access PWs:
List of VFIs:
  VFI 1
    Neighbor 10.1.1.1 pw-id 1, state: up, Static MAC addresses: 0

```

This table describes the significant fields shown in the display.

**Table 10: show l2vpn bridge-domain Command Field Descriptions**

Field	Description
Bridge group	Name of bridge domain group is displayed.
bridge-domain	Name of bridge domain is displayed.
id	ID assigned to this bridge domain is displayed.
state	Current state of the bridge domain is displayed.

The following example shows sample output for a bridge named bd1:

```

RP/0/0/CPU0:router# show l2vpn bridge-domain bd-name bd1

Bridge group: g1, bridge-domain: bd1, id: 0, state: up, ShgId: 0, MSTi: 0
Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
Filter MAC addresses: 0
ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
List of ACs:
  Gi0/1/0/0, state: up, Static MAC addresses: 2, MSTi: 0 (unprotected)
List of Access PWs:
List of VFIs:
  VFI 1
    Neighbor 10.1.1.1 pw-id 1, state: up, Static MAC addresses: 0

```

The following sample output shows brief information about the bridges:

```

RP/0/0/CPU0:router# show l2vpn bridge-domain brief

Bridge Group/Bridge-Domain Name  ID      State      Num ACs/up      Num PWs/up
-----
g1/bd1                          0       up         1/1              1/1

```

This table describes the significant fields shown in the display.

**Table 11: show l2vpn bridge-domain brief Command Field Descriptions**

Field	Description
Bridge Group/Bridge-Domain Name	Bridge domain group name followed by the bridge domain name are displayed.
ID	ID assigned to this bridge domain is displayed.
State	Current state of the bridge domain is displayed.

Field	Description
Num ACs/up	Total number of attachment circuits that are up in this bridge domain is displayed.
Num PWs/up	Total number of pseudowires that are up in this bridge domain is displayed. The count includes both VFI pseudowires and access pseudowires.

The following sample output shows detailed information:

```
RP/0/0/CPU0:router# show l2vpn bridge-domain detail

Bridge group: g1, bridge-domain: bd1, id: 0, state: up, ShgId: 0, MSTi: 0
MAC learning: enabled
MAC withdraw: disabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: yes
Security: disabled
DHCPv4 snooping: disabled
MTU: 1500
Filter MAC addresses:
ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
List of ACs:
  AC: GigabitEthernet0/1/0/0, state is up
    Type Ethernet
    MTU 1500; XC ID 0x2000001; interworking none; MSTi 0 (unprotected)
    MAC learning: enabled
    Flooding:
      Broadcast & Multicast: enabled
      Unknown unicast: enabled
    MAC aging time: 300 s, Type: inactivity
    MAC limit: 4000, Action: none, Notification: syslog
    MAC limit reached: yes
    Security: disabled
    DHCPv4 snooping: disabled
    Static MAC addresses:
      0000.0000.0000
      0001.0002.0003
    Statistics:
      packet totals: receive 3919680,send 9328
      byte totals: receive 305735040,send 15022146
List of Access PWs:
List of VFIs:
  VFI 1
    PW: neighbor 1.1.1.1, PW ID 1, state is up ( established )
    PW class mpls, XC ID 0xff000001
    Encapsulation MPLS, protocol LDP
    PW type Ethernet, control word disabled, interworking none
    PW backup disable delay 0 sec
    Sequencing not set
      MPLS          Local          Remote
      -----
Label             16003             16003
Group ID          0x0               0x0
Interface         1                 1
MTU               1500              1500
Control word      disabled           disabled
PW type           Ethernet           Ethernet
VCCV CV type     0x2                0x2
                  (LSP ping verification)
VCCV CC type     0x2                0x2
```

```

----- (router alert label) (router alert label) -----
Create time: 12/03/2008 14:03:00 (17:17:30 ago)
Last time status changed: 13/03/2008 05:57:58 (01:22:31 ago)
MAC withdraw message: send 0 receive 0
Static MAC addresses:
Statistics:
  packet totals: receive 3918814, send 3918024
  byte totals: receive 305667492, send 321277968
VFI Statistics:
  drops: illegal VLAN 0, illegal length 0

```

The following sample output shows that when a bridge operates in VPWS mode, the irrelevant information for MAC learning is suppressed:

```

RP/0/0/CPU0:router# show l2vpn bridge-domain detail

Bridge group: foo_group, bridge-domain: foo_bd, id: 0, state: up, ShgId: 0
  VPWS Mode
  MTU: 1500
  ACs: 1 (0 up), VFIs: 1, PWs: 2 (2 up)
  List of ACs:
    AC: GigabitEthernet0/5/1/4, state is admin down
      Type Ethernet      MTU 1500; XC ID 1; interworking none
      Static MAC addresses:
      Statistics:
        packet totals: receive 0, send 0
        byte totals: receive 0, send 0
  List of VFIs:
    VFI foo vfi
      PW: neighbor 1.1.1.1, PW ID 1, state is up ( established )
      PW class not set
      Encapsulation MPLS, protocol LDP
      PW type Ethernet, control word enabled, interworking none
      Sequencing not set
      MPLS
      -----
      Label          16001
      Group ID      unassigned
      Interface     siva/vfi
      MTU           1500
      Control word  enabled
      PW type       Ethernet
      VCCV CV type  0x2
                    (LSP ping verification)
      VCCV CC type  0x3
                    (control word)
                    (router alert label)
      -----
      Remote
      Label          16001
      Group ID      unknown
      Interface     siva/vfi
      MTU           1500
      Control word  enabled
      PW type       Ethernet
      VCCV CV type  0x2
                    (LSP ping verification)
      VCCV CC type  0x3
                    (control word)
                    (router alert label)
      -----
      Create time: 25/06/2007 05:29:42 (2w0d ago)
      Last time status changed: 27/06/2007 06:50:35 (1w5d ago)
      Static MAC addresses:
      PW: neighbor 1.1.1.1, PW ID 2, state is up ( established )
      PW class not set
      Encapsulation MPLS, protocol LDP
      PW type Ethernet, control word enabled, interworking none
      Sequencing not set
      MPLS
      -----
      Label          16002
      Group ID      unassigned
      Interface     siva/vfi
      MTU           1500
      Control word  enabled
      PW type       Ethernet
      VCCV CV type  0x2
                    (LSP ping verification)
      VCCV CC type  0x3
                    (control word)
                    (router alert label)
      -----
      Remote
      Label          16002
      Group ID      unknown
      Interface     siva/vfi
      MTU           1500
      Control word  enabled
      PW type       Ethernet
      VCCV CV type  0x2
                    (LSP ping verification)
      VCCV CC type  0x3
                    (control word)
                    (router alert label)
      -----
      Create time: 25/06/2007 05:29:42 (2w0d ago)

```

```

Last time status changed: 27/06/2007 06:50:35 (1w5d ago)
Static MAC addresses:
Statistics:
drops: illegal VLAN 0, illegal length 0

```

This table describes the significant fields shown in the display.

**Table 12: show l2vpn bridge-domain detail Command Field Descriptions**

Field	Description
Bridge group	Name of bridge domain group is displayed.
bridge-domain	Name of bridge domain is displayed.
ID	ID assigned to this bridge domain is displayed.
state	Current state of the bridge domain is displayed.
MSTi	ID for the Multiple Spanning Tree.

The following sample output shows filter information about the bridge-domain group named g1:

```

RP/0/0/CPU0:router# show l2vpn bridge-domain group g1

Bridge group: g1, bridge-domain: bd1, id: 0, state: up, ShgId: 0, MSTi: 0
Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
Filter MAC addresses: 0
ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
List of ACs:
  Gi0/1/0/0, state: up, Static MAC addresses: 2, MSTi: 0 (unprotected)
List of Access PWs:
List of VFIs:
  VFI 1
    Neighbor 1.1.1.1 pw-id 1, state: up, Static MAC addresses: 0

```

The following sample output shows display the filter information for the interface on the bridge domain:

```

RP/0/0/CPU0:router# show l2vpn bridge-domain interface gigabitEthernet 0/1/0/0

Bridge group: g1, bridge-domain: bd1, id: 0, state: up, ShgId: 0, MSTi: 0
Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
Filter MAC addresses: 0
ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
List of ACs:
  Gi0/1/0/0, state: up, Static MAC addresses: 2, MSTi: 0 (unprotected)

```

The following sample output shows that the bridge domain contains the pseudowires to match the filter for the neighbor:

```

RP/0/0/CPU0:router# show l2vpn bridge-domain neighbor 1.1.1.1

Bridge group: g1, bridge-domain: bd1, id: 0, state: up, ShgId: 0, MSTi: 0
Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
Filter MAC addresses: 0
ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
List of Access PWs:
List of VFIs:
  VFI 1
    Neighbor 1.1.1.1 pw-id 1, state: up, Static MAC addresses: 0

```

The following sample output shows the summary information for the bridge domain:

```

RP/0/0/CPU0:router# show l2vpn bridge-domain summary

```

**show l2vpn bridge-domain (VPLS)**

Number of groups: 1, bridge-domains: 1, Up: 1, Shutdown: 0  
 Number of ACs: 1 Up: 1, Down: 0  
 Number of PWs: 1 Up: 1, Down: 0

This table describes the significant fields shown in the display.

**Table 13: show l2vpn bridge-domain summary Command Field Descriptions**

Field	Description
Number of groups	Number of configured bridge domain groups is displayed.
bridge-domains	Number of configured bridge domains is displayed.
Shutdown	Number of bridge domains that are in Shutdown state is displayed.
Number of ACs	Number of attachment circuits that are in Up state and Down state are displayed.
Number of PWs	Number of pseudowires that are in Up state and Down state are displayed. This includes the VFI pseudowire and the access pseudowire.

**Related Commands**

Command	Description
<a href="#">clear l2vpn bridge-domain (VPLS), on page 163</a>	Clears the MAC addresses and restarts the bridge domains on the router.

## show l2vpn forwarding bridge-domain (VPLS)

To display information on the bridge that is used by the forwarding layer, use the **show l2vpn forwarding bridge-domain** command in EXEC mode.

```
show l2vpn forwarding bridge-domain [ bridge-domain-name ] {detail|hardware {egress|ingress}}
location node-id
```

### Syntax Description

<i>bridge-domain-name</i>	(Optional) Name of a bridge domain.
<b>detail</b>	Displays all the detailed information on the attachment circuits and pseudowires.
<b>hardware</b>	Displays the hardware location entry.
<b>egress</b>	Reads information from the egress PSE.
<b>ingress</b>	Reads information from the ingress PSE.
<b>location</b> <i>node-id</i>	Displays the bridge-domain information for the specified location. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

### Command Default

None

### Command Modes

EXEC

### Command History

Release	Modification
Release 3.7.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

For each bridge, you can display summary information about the number of bridge ports, number of MAC addresses, configured VXLANs and so forth.

The **detail** keyword displays detailed information on the attachment circuits and pseudowires, and is meant for field investigation by a specialized Cisco engineer.

**Note**

All bridge ports in the bridge domain on that line card are displayed. Therefore, if the bridge domain contains non-local bridge ports, those are displayed as well.

**Task ID**

Task ID	Operations
l2vpn	read

**Examples**

The following sample output shows bridge-domain information for location 0/1/CPU0:

```
RP/0/0/CPU0:router# show l2vpn forwarding bridge-domain location 0/1/CPU0
Bridge-Domain Name          ID      Ports addr  Flooding Learning State
-----
g1:bd1

Bridge-domain name: g1:bd1, id: 0, state: up
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: yes
Security: disabled
DHCPv4 snooping: profile not known on this node
Bridge MTU: 1500 bytes
Number of bridge ports: 2
Number of MAC addresses: 65536
Multi-spanning tree instance: 0

GigabitEthernet0/1/0/0, state: oper up
Number of MAC: 32770
Sent(Packets/Bytes): 0/21838568
Received(Packets/Bytes): 5704781/444972918

Nbor 1.1.1.1 pw-id 1
Number of MAC: 32766
Sent(Packets/Bytes): 0/0
Received(Packets/Bytes): 5703987/444910986
0          2          65536 Enabled Enabled UP
```

The following sample output shows detailed information for hardware location 0/1/CPU0 from the egress pse:

```
RP/0/0/CPU0:router

Bridge-domain name: g1:bd1, id: 0, state: up
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: yes
Security: disabled
DHCPv4 snooping: profile not known on this node
Bridge MTU: 1500 bytes
Number of bridge ports: 2
Number of MAC addresses: 65536
Multi-spanning tree instance: 0
```

```

===== GSR HW Information =====
-----
SHG-TX rewrite details
-----
HW Rewrite 0 Detail :
-----
Rewrite HW Address : 0x00060000
packets 0 bytes 0
Raw data:
[ 0x04018180 04018190 040181a0 040181b0 ]
[ 0x04018170 00000000 80360000 000bfff4 ]
[ 0x00000000 00000000 00000000 00000000 ]
-----
SHG-TX encap details
-----
outer_etype:          0
outer_vlan_id:        0
gather_profile:       0
inner_vlan_id:        0
so_l2_len_adjust:    0
-----
SHG-TX mgid details
-----
Base MGIDs for default mgid
base_mgid[0]:         0x0003ffff
base_mgid[1]:         0x0003ffff
base_mgid[2]:         0x0003ffff
base_mgid[3]:         0x0003ffff
base_mgid[4]:         0x0003ffff
base_mgid[5]:         0x0003ffff
base_mgid[6]:         0x0003ffff
base_mgid[7]:         0x0003ffff
MGID Entries for default mgid
oi[0]:                0
oq[0]:                16384
xc_id[0]:              1
mgid_idx[0]:          0x00000000
next_mgid[0]:         0x00000000
-----
VMR 0 Details
-----
vmrid: 0x5f002010
Value: 0xc0 0x00 0x1f 0xff 0xff 0xff 0xff 0xff 0xff 0xff
Mask : 0x00 0x00 0x1f 0xff 0xff 0xff 0xff 0xff 0xff 0xe0
Result 0x32003000
=====

GigabitEthernet0/1/0/0, state: oper up
Number of MAC: 32770
Sent(Packets/Bytes): 749/22989834
Received(Packets/Bytes): 5732104/447104112

===== GSR HW Information =====
-----
BP-TX-AC rewrite details
-----
BP is local

-----
BP L2 Uidb Details
-----
l2fwd_enabled:        true
plim_enabled:         true
l2fwd_type:           4
l2_ac_type:           0
xconn_id:             0

```

## show l2vpn forwarding bridge-domain (VPLS)

```

bridge_id:                0
shg_id:                   0
unicast flooding enabled:  0
multicast flooding enabled: 0
broadcast flooding enabled: 0
mac learning enabled:     0
Is AC Port mode?:        0
-----
HW Rewrite 0 Detail :
-----
Rewrite HW Address : 0x59eff314
packets 0 bytes 0
HFA Bits 0x0 gp 0 mtu 1580 (REW)
OI 0x3fffc OutputQ 0 Output-port 0x36 local_outputq 0x0
Raw data:
[ 0x00000000 0036062c 0003fffc 00000000 ]
[ 0x00000000 00000000 0d103600 00000010 ]
[ 0x00000000 00000000 00000000 00000000 ]
-----
BP OI/OQ Details
-----
oi[0]:          0x00000000      oq[0]          16384
oi[1]:          0x00000000      oq[1]          65535
oi[2]:          0x00000000      oq[2]          65535
oi[3]:          0x00000000      oq[3]          65535
oi[4]:          0x00000000      oq[4]          65535
oi[5]:          0x00000000      oq[5]          65535
oi[6]:          0x00000000      oq[6]          65535
oi[7]:          0x00000000      oq[7]          65535
-----
Sram table entry details
-----
sram_data: 0xa000400c
=====

Nbor 1.1.1.1 pw-id 1
Number of MAC: 32766
Sent(Packets/Bytes): 0/0
Received(Packets/Bytes): 5731250/447037500
===== GSR HW Information =====

-----
BP-TX-AC rewrite details
-----
BP OI/OQ Details
-----
oi[0]:          0x00000000      oq[0]          65535
oi[1]:          0x00000000      oq[1]          65535
oi[2]:          0x00000000      oq[2]          65535
oi[3]:          0x00000000      oq[3]          65535
oi[4]:          0x00000000      oq[4]          65535
oi[5]:          0x00000000      oq[5]          65535
oi[6]:          0x00000000      oq[6]          65535
oi[7]:          0x00000000      oq[7]          65535
-----
BP Encap Info
-----
mac_length:      0
mac_string:
egress_slot:    2
num_tags:       1
tags:           {16001, }
if_handle:      0x03000500
=====

```

The following sample output shows the bridge-domain information for the specified location:

```

RP/0/0/CPU0:router# show l2vpn forwarding bridge-domain g1:bd1 location 0/1/CPU0
Bridge-Domain Name          ID      Ports addr  Flooding Learning State

```

```
-----
g1:bd1                                0      2      65536  Enabled  Enabled  UP
```

This table describes the significant fields shown in the display.

**Table 14: show l2vpn forwarding bridge-domain Command Field Descriptions**

Field	Description
Bridge-Domain Name	Name of bridge domain is displayed.
Bridge ID	ID assigned to this bridge domain is displayed.
Ports	Number of ports that are part of this bridge domain is displayed.
MAC Addr	Number of MAC addresses that are learned on this bridge domain is displayed.
Flooding	Flooding of packets are displayed if they are enabled on this bridge domain.
Learning	Learning of MAC addresses are displayed if they are enabled on this bridge domain.
State	Current state of the bridge domain is displayed.

#### Related Commands

Command	Description
<a href="#">clear l2vpn bridge-domain (VPLS)</a> , on page 163	Clears the MAC addresses and restarts the bridge domains on the router.

## show l2vpn forwarding bridge-domain mac-address (VPLS)

To display the summary information for the MAC address, use the **show l2vpn forwarding bridge-domain mac-address** command in EXEC mode.

```
show l2vpn forwarding bridge-domain [ bridge-domain-name ] mac-address {MAC-address| detail|
hardware {egress| ingress}| interface type interface-path-id| neighbor address pw-id pw-id} location
node-id
```

### Syntax Description

<i>bridge-domain-name</i>	(Optional) Name of a bridge domain.
<i>MAC-address</i>	MAC address.
<b>detail</b>	Displays detailed information for the MAC address.
<b>hardware</b>	Reads information from the hardware.
<b>egress</b>	Reads information from the egress PSE.
<b>ingress</b>	Reads information from the ingress PSE.
<b>interface</b>	Displays the match for the attachment circuit subinterface.
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface. <b>Note</b> Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
<b>neighbor address</b>	Displays the match for the neighbor IP address.
<b>pw-id pw-id</b>	Displays the match for the pseudowire ID.
<b>location node-id</b>	Displays the bridge-domain information for the MAC address of the specified location. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

### Command Default

None

### Command Modes

EXEC

**Command History**

Release	Modification
Release 3.7.0	This command was introduced.
Release 3.7.2	This command was introduced.
Release 3.8.0	This command was introduced.

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

**Task ID**

Task ID	Operations
l2vpn	read

**Examples**

The following sample output shows the specified location of the bridge-domain name g1:bd1 for the MAC address:

```
RP/0/0/CPU0:router# show l2vpn forwarding bridge-domain g1:bd1 location 0/1/CPU0
          Bridge      MAC
Bridge-Domain Name  ID    Ports addr  Flooding Learning State
-----
g1:bd1              0     2    65536  Enabled  Enabled  UP
```

The following sample output shows the list of MAC addresses that are learned on a specified bridge and summary information for the addresses:

```
RP/0/0/CPU0:router# show l2vpn forwarding bridge-domain mac-address location 0/1/CPU0
Mac Address      Type      Learned from/Filtered on      LC learned Age
-----
0000.0000.0000  static   Gi0/1/0/0                     N/A           N/A
0000.0001.0101  dynamic  Gi0/1/0/0                     0/1/CPU0     0d 0h 2m 22s
0000.0001.0102  dynamic  Gi0/1/0/0                     0/1/CPU0     0d 0h 2m 22s
0000.0001.0103  dynamic  Gi0/1/0/0                     0/1/CPU0     0d 0h 2m 22s
0000.0001.0104  dynamic  Gi0/1/0/0                     0/1/CPU0     0d 0h 2m 22s
0000.0001.0105  dynamic  Gi0/1/0/0                     0/1/CPU0     0d 0h 2m 22s
0000.0001.0106  dynamic  Gi0/1/0/0                     0/1/CPU0     0d 0h 2m 22s
0000.0001.0107  dynamic  Gi0/1/0/0                     0/1/CPU0     0d 0h 2m 22s
0000.0001.0108  dynamic  Gi0/1/0/0                     0/1/CPU0     0d 0h 2m 22s
0000.0001.0109  dynamic  Gi0/1/0/0                     0/1/CPU0     0d 0h 2m 22s
0000.0001.010a  dynamic  Gi0/1/0/0                     0/1/CPU0     0d 0h 2m 22s
0000.0001.010b  dynamic  Gi0/1/0/0                     0/1/CPU0     0d 0h 2m 22s
0000.0001.010c  dynamic  Gi0/1/0/0                     0/1/CPU0     0d 0h 2m 22s
0000.0001.010d  dynamic  Gi0/1/0/0                     0/1/CPU0     0d 0h 2m 22s
0000.0001.010e  dynamic  Gi0/1/0/0                     0/1/CPU0     0d 0h 2m 22s
0000.0001.010f  dynamic  Gi0/1/0/0                     0/1/CPU0     0d 0h 2m 22s
0000.0001.0110  dynamic  Gi0/1/0/0                     0/1/CPU0     0d 0h 2m 22s
0000.0001.0111  dynamic  Gi0/1/0/0                     0/1/CPU0     0d 0h 2m 22s
0000.0001.0112  dynamic  Gi0/1/0/0                     0/1/CPU0     0d 0h 2m 22s
....
```

**show l2vpn forwarding bridge-domain mac-address (VPLS)**

The following sample output shows the MAC address on a specified interface on a specified bridge:

```
RP/0/0/CPU0:router# show l2vpn forwarding bridge-domain g1:bd1 mac-address 1.2.3 location 0/1/CPU0
```

Mac Address	Type	Learned from/Filtered on	LC learned	Age
0001.0002.0003	static	Gi0/1/0/0	N/A	N/A

The following sample output shows the hardware information from the egress pse:

```
RP/0/0/CPU0:router# show l2vpn forwarding bridge-domain g1:bd1 mac-address hardware egress location 0/1/CPU0
```

Mac Address	Type	Learned from/Filtered on	LC learned	Age
0000.0000.0000	static	Gi0/1/0/0	N/A	N/A
0000.0001.0101	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0102	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0103	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0104	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0105	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0106	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0107	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0108	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0109	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.010a	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.010b	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.010c	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.010d	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.010e	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.010f	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0110	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0111	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0112	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0113	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0114	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
...				

The following sample output shows the MAC addresses that are learned on a specified pseudowire on a specified bridge:

```
RP/0/0/CPU0:router# show l2vpn forwarding bridge-domain mac-address neighbor 1.1.1.1 pw-id 1 location 0/1/CPU0
```

Mac Address	Type	Learned from/Filtered on	LC learned	Age
0000.0003.0101	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0102	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0103	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0104	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0105	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0106	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0107	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0108	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0109	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.010a	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.010b	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.010c	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.010d	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.010e	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.010f	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0110	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0111	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0112	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0113	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0114	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0115	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
...				

The following sample output shows the detailed information for MAC addresses that are learned on a specified interface and on specified bridge of a specified interface card. The sample output lists all the MAC addresses, the learned location, and the current age.

```
RP/0/0/CPU0:router# show l2vpn forwarding bridge-domain g1:bd1 mac-address interface
gigabitEthernet 0/1/0/0 location 0/1/CPU0
```

Mac Address	Type	Learned from/Filtered on	LC learned	Age
0000.0000.0000	static	Gi0/1/0/0	N/A	N/A
0000.0001.0101	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0102	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0103	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0104	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0105	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0106	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0107	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0108	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0109	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.010a	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.010b	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.010c	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.010d	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.010e	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.010f	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0110	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0111	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0112	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0113	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0114	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s

## Related Commands

Command	Description
<a href="#">show l2vpn forwarding bridge-domain (VPLS)</a> , on <a href="#">page 201</a>	Displays information on the bridge that is used by the forwarding layer.

## shutdown (Bridge Domain)

To shut down a bridge domain to bring the bridge and all attachment circuits and pseudowires under it to admin down state, use the **shutdown** command in L2VPN bridge group bridge domain configuration mode. To re-enable the bridge domain, use the **no** form of this command.

**shutdown**

**no shutdown**

**Syntax Description** This command has no keywords or arguments.

**Command Default** By default, the bridge is not shutdown.

**Command Modes** L2VPN bridge group bridge domain configuration

Command History	Release	Modification
	Release 3.7.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

When a bridge domain is disabled, all VFIs associated with the bridge domain are disabled. You can still attach or detach members to or from the bridge domain as well as the VFIs associated with the bridge domain.

Task ID	Task ID	Operations
	l2vpn	read, write

**Examples** The following example shows how to disable the bridge domain named bar:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# shutdown
```

**Related Commands**

Command	Description
<a href="#">bridge-domain (VPLS), on page 159</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS), on page 161</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.

## shutdown (VFI)

To disable virtual forwarding interface (VFI), use the **shutdown** command in L2VPN bridge group bridge domain VFI configuration mode. To re-enable VFI, use the **no** form of this command.

**shutdown**

**no shutdown**

**Syntax Description** This command has no keywords or arguments.

**Command Default** By default, the VFI is not shutdown.

**Command Modes** L2VPN bridge group bridge domain VFI configuration

Command History	Release	Modification
	Release 3.7.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

**Examples** The following example shows how to disable VFI:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# vfi v1
RP/0/0/CPU0:router(config-l2vpn-bg-bd-vfi)# shutdown
```

Related Commands	Command	Description
	<a href="#">bridge-domain (VPLS)</a> , <a href="#">on page 159</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.

Command	Description
<a href="#">bridge group (VPLS), on page 161</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.
<a href="#">mpls static label (VPLS), on page 179</a>	Configures the MPLS static labels and the static labels for the access pseudowire configuration.
<a href="#">neighbor (VPLS), on page 183</a>	Adds an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI).

## static-address (VPLS)

To add static entries to the MAC address for filtering, use the **static-address** command in L2VPN bridge group bridge domain MAC configuration mode. To remove entries profiled by the combination of a specified entry information, use the **no** form of this command.

**static-address** *MAC-address* **drop**

**no static-address** *MAC-address* **drop**

### Syntax Description

<i>MAC-address</i>	Static MAC address that is used to filter on the bridge domain.
<b>drop</b>	Drops all traffic that is going to the configured MAC address.

### Command Default

No static MAC address is configured.

### Command Modes

L2VPN bridge group bridge domain MAC configuration

### Command History

Release	Modification
Release 3.7.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

### Task ID

Task ID	Operations
l2vpn	read, write

### Examples

The following example shows how to add static MAC entries in L2VPN bridge group bridge domain MAC configuration mode. This entry causes all packets with destination MAC address 1.1.1 to be dropped.

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac)# static-address 1.1.1 drop
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">bridge-domain (VPLS), on page 159</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS), on page 161</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.
<a href="#">mac (VPLS), on page 175</a>	Enters L2VPN bridge group bridge domain MAC configuration mode.

## static-mac-address (VPLS)

To configure the static MAC address to associate a remote MAC address with a pseudowire or any other bridge interface, use the **static-mac-address** command in the appropriate L2VPN bridge group bridge domain configuration submode. To disable this feature, use the **no** form of this command.

**static-mac-address** *MAC-address*

**no static-mac-address** *MAC-address*

<b>Syntax Description</b>	<i>MAC-address</i>	Static address to add to the MAC address.
<b>Command Default</b>	None	
<b>Command Modes</b>	L2VPN bridge group bridge domain VFI pseudowire configuration L2VPN bridge group bridge domain attachment circuit configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.0	This command was introduced.
<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	l2vpn	read, write

### Examples

The following example shows how to associate a remote MAC address with a pseudowire:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# vfi model
RP/0/0/CPU0:router(config-l2vpn-bg-bd-vfi)# neighbor 10.1.1.2 pw-id 1000
RP/0/0/CPU0:router(config-l2vpn-bg-bd-vfi-pw)# static-mac-address 1.1.1
```

The following example shows how to associate a GigabitEthernet interface from a bridge domain to static MAC address 1.1.1:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# interface GigabitEthernet 0/1/0/0
RP/0/0/CPU0:router(config-l2vpn-bg-bd-ac)# static-mac-address 1.1.1
```

The following example shows how to associate an access pseudowire to static MAC address 2.2.2:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# neighbor 10.1.1.2 pw-id 2000
RP/0/0/CPU0:router(config-l2vpn-bg-bd-pw)# static-mac-address 2.2.2
```

### Related Commands

Command	Description
<a href="#">bridge-domain (VPLS), on page 159</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS), on page 161</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.
<a href="#">mpls static label (VPLS), on page 179</a>	Configures the MPLS static labels and the static labels for the access pseudowire configuration.
<a href="#">neighbor (VPLS), on page 183</a>	Adds an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI).
<a href="#">vfi (VPLS), on page 222</a>	Configures virtual forwarding interface (VFI) parameters.

## time (VPLS)

To configure the maximum aging time, use the **time** command in L2VPN bridge group bridge domain MAC aging configuration mode. To disable this feature, use the **no** form of this command.

**time** *seconds*

**no time** *seconds*

### Syntax Description

<i>seconds</i>	MAC address table entry maximum age. The range is from 300 to 30000 seconds. Aging time is counted from the last time that the switch saw the MAC address. The default value is 300 seconds.
----------------	--

### Command Default

*seconds*: 300

### Command Modes

L2VPN bridge group bridge domain MAC aging configuration

### Command History

Release	Modification
Release 3.7.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If no packets are received from the MAC address for the duration of the maximum aging time, the dynamic MAC entry previously learned is removed from the forwarding table.

### Task ID

Task ID	Operations
l2vpn	read, write

### Examples

The following example shows how to increase the maximum aging time to 600 seconds. After 600 seconds of inactivity from a MAC address, the MAC address is removed from the forwarding table.

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# mac
```

```
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac)# aging
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac-aging)# time 600
```

**Related Commands**

Command	Description
<a href="#">aging (VPLS), on page 157</a>	Enters the MAC aging configuration submode to set the aging parameters such as time and type.
<a href="#">bridge-domain (VPLS), on page 159</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS), on page 161</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.
<a href="#">mac (VPLS), on page 175</a>	Enters L2VPN bridge group bridge domain MAC configuration mode.
<a href="#">type (VPLS), on page 220</a>	Configures the type for MAC address aging.

## type (VPLS)

To configure the type for MAC address aging, use the **type** command in L2VPN bridge group bridge domain MAC aging configuration mode. To disable this feature, use the **no** form of this command.

**type** {absolute| inactivity}

**no type** {absolute| inactivity}

### Syntax Description

<b>absolute</b>	Configures the absolute aging type.
<b>inactivity</b>	Configures the inactivity aging type.

### Command Default

By default, the inactivity type is configured.

### Command Modes

L2VPN bridge group bridge domain MAC aging configuration

### Command History

Release	Modification
Release 3.7.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

In general, the type is set to inactivity. With an inactivity type configuration, a MAC address is removed from the forwarding table after the MAC address is inactive for the configured aging time.

With an absolute type configuration, a MAC address is always removed from the forwarding table after the aging time has elapsed once it is initially learned.

### Task ID

Task ID	Operations
l2vpn	read, write

### Examples

The following example shows how to configure the MAC address aging type to absolute for every member of the bridge domain named bar:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
```

```
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac)# aging
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac-aging)# type absolute
```

**Related Commands**

Command	Description
<a href="#">aging (VPLS), on page 157</a>	Enters the MAC aging configuration submode to set the aging parameters such as time and type.
<a href="#">bridge-domain (VPLS), on page 159</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS), on page 161</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.
<a href="#">mac (VPLS), on page 175</a>	Enters L2VPN bridge group bridge domain MAC configuration mode.
<a href="#">time (VPLS), on page 218</a>	Configures the maximum aging time.

## vfi (VPLS)

To configure virtual forwarding interface (VFI) parameters and to enter L2VPN bridge group bridge domain VFI configuration mode, use the **vfi** command in L2VPN bridge group bridge domain configuration mode. To remove all configurations that are made under the specified VFI, use the **no** form of this command.

**vfi** *vfi-name*

**no vfi** *vfi-name*

### Syntax Description

<i>vfi-name</i>	Name of the specified virtual forwarding interface.
-----------------	---

### Command Default

None

### Command Modes

L2VPN bridge group bridge domain configuration

### Command History

Release	Modification
Release 3.7.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **vfi** command to enter L2VPN bridge group bridge domain VFI configuration mode.

You cannot configure a pseudowire directly under a bridge domain. Therefore, a pseudowire must be configured under a VFI, which is configured under a bridge domain.

### Task ID

Task ID	Operations
l2vpn	read, write

### Examples

The following example shows how to create a VFI:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# vfi vl
RP/0/0/CPU0:router(config-l2vpn-bg-bd-vfi)#
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">bridge-domain (VPLS), on page 159</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS), on page 161</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.
<a href="#">mpls static label (VPLS), on page 179</a>	Configures the MPLS static labels and the static labels for the access pseudowire configuration.
<a href="#">neighbor (VPLS), on page 183</a>	Adds an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI).

## withdraw (VPLS)

To enable MAC address withdrawal for a specified bridge domain, use the **withdraw** command in L2VPN bridge group bridge domain MAC configuration mode. To disable this feature, use the **no** form of this command

**withdraw** { **disable** }

**no withdraw** { **disable** }

### Syntax Description

<b>disable</b>	Disables MAC address withdrawal.
----------------	----------------------------------

### Command Default

By default, MAC address withdrawal is enabled.

### Command Modes

L2VPN bridge group bridge domain MAC configuration

### Command History

Release	Modification
Release 3.7.0	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

### Task ID

Task ID	Operations
l2vpn	read, write

### Examples

The following example shows how to enable disable MAC withdrawal:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac)# withdraw disable
```

The following example shows how to disable sending MAC withdrawal messages to access pseudowires:

```
RP/0/0/CPU0:router# configure
RP/0/0/CPU0:router(config)# l2vpn
RP/0/0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
```

```
RP/0/0/CPU0:router(config-l2vpn-bg-bd)# mac  
RP/0/0/CPU0:router(config-l2vpn-bg-bd-mac)# withdraw access-pw disable
```

**Related Commands**

Command	Description
<a href="#">bridge-domain (VPLS), on page 159</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS), on page 161</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn, on page 49</a>	Enters L2VPN configuration mode.
<a href="#">mac (VPLS), on page 175</a>	Enters L2VPN bridge group bridge domain MAC configuration mode.

