



Cisco Cyber Vision Sensor Application for Cisco Switches Installation Guide, Release 4.2.0

First Published: 2021-01-01

Last Modified: 2023-06-06

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883



CONTENTS

CHAPTER 1	About this documentation	1
	Document purpose	1
	Warnings and notices	1

CHAPTER 2	Overview	3
------------------	-----------------	----------

CHAPTER 3	Requirements	7
------------------	---------------------	----------

CHAPTER 4	Additional remarks	9
------------------	---------------------------	----------

CHAPTER 5	Known issues	11
------------------	---------------------	-----------

CHAPTER 6	Initial configuration	13
	Configure the switch access	13
	Check the software version	13
	SD Card (IE3x00/IE9x00)	14
	SSD Disk (Catalyst 9x00)	15
	Check date and time	15
	Enable IOx	16
	Add the necessary configuration parameters (IE3x00)	17
	Add the necessary configuration parameters (Catalyst 9x00/IE9x00)	19
	Configure with ERSPAN	19
	Configure with RSPAN (Catalyst 9x00 only)	21

CHAPTER 7	Installation	23
	Procedure with the Cisco Cyber Vision sensor management extension	23

- Install the sensor management extension 23
 - Management jobs 24
 - Create a sensor in the sensor management extension 25
 - Configure a sensor in the sensor management extension 27
 - Configure Active Discovery 31
- Procedure with the Local Manager 33
 - Access the Local manager 33
 - Install the sensor virtual application 35
 - Configure the sensor virtual application (IE3x00/IE9x00) 36
 - Configure the sensor virtual application (Catalyst 9x00) 40
 - Generate the provisioning package 45
 - Import the provisioning package 48
- Procedure with the CLI 50
 - Configure the sensor application 50
 - Install the sensor application 52
 - Generate the provisioning package 53
 - Copy the sensor application provisioning package 55
 - Final step 55

CHAPTER 8

Maintenance 57

- Upgrade procedures 57
 - Upgrade through the Cisco Cyber Vision sensor management extension 57
 - Update the sensor management extension 57
 - Update the sensors 58
 - Upgrade through the IOx Local Manager 60
- Replace SD card 64
- Reconfigure/Redeploy a sensor 65



CHAPTER 1

About this documentation

- [Document purpose, on page 1](#)
- [Warnings and notices, on page 1](#)

Document purpose

This installation guide describes how to perform a clean installation of Cisco Cyber Vision on the following devices:

- Cisco Catalyst IE3300 10G Rugged Series Switch
- Cisco Catalyst IE3400 Rugged Series Switch
- Cisco Catalyst IE3400 Heavy Duty Series Switch
- Cisco Catalyst IE9300 Rugged Series Switch
- Cisco Catalyst 9300 Series Switch
- Cisco Catalyst 9400 Series Switch

Moreover, this document describes how to upgrade sensors through different methods.

This documentation is applicable to **system version 4.2.0**.

Warnings and notices

This manual contains notices you have to observe to ensure your personal safety as well as to prevent damage to property.

The notices referring to your personal safety and to your property damage are highlighted in the manual by a safety alert symbol described below. These notices are graded according to the degree of danger.



Warning

Indicates risks that involve industrial network safety or production failure that could possibly result in personal injury or severe property damage if proper precautions are not taken.



Important Indicates risks that could involve property or Cisco equipment damage and minor personal injury if proper precautions are not taken.



Note Indicates important information on the product described in the documentation to which attention should be paid.



CHAPTER 2

Overview

- [Overview, on page 3](#)

Overview

Proposed architecture:

The architecture proposed and described in this document is for demonstration. The local network engineer should be consulted before applying the parameters used in this document. IP addresses, port numbers and VLAN IDs used should be verified beforehand as wrong configurations could stop normal exchanges and stop the process.

The schema below explains the architecture virtually deployed in the switch to embed the sensor application. VLAN and physical ports configuration will allow OT traffic to be copied and communication with the Cisco Cyber Vision Center to be established.

The communication between the Cisco Cyber Vision Center and the sensor is represented in blue on the schema. Mirrored OT traffic is represented in yellow.

The architecture in this document is meant for a switch with an embedded sensor directly connected to the Cisco Cyber Vision Center. The schema presents two types of architecture:

- one with a direct connection to the Center (link="switchport access vlan 507").
- the other with a trunk to another switch or router which is connected to the Center (link="switch mode trunk").

Several types of installation are explained. One of them is the installation with the Sensor Management extension. This method requires an access for the Cisco Cyber Vision Center to the switch's Local Manager. Several solutions exist:

having the Center on the same subnet than the switch's Local Manager (<admin_VLAN> and <collection_VLAN> are the same).


having a route path from the Center to an <admin_VLAN> that is different from <collection_VLAN>.

Any port of the switch can be used for the communication with the Center or for OT traffic.

Architecture diagram for:


- **Cisco Catalyst IE3300 10G Rugged Series Switch**
- **Cisco Catalyst IE3400 Rugged Series Switch**

- Cisco Catalyst IE3400 Heavy Duty Series Switch



Architecture diagram for:

- Cisco Catalyst 9300 Series Switch
- Cisco Catalyst 9400 Series Switch
- Cisco Catalyst IE9300 Rugged Series Switch





CHAPTER 3

Requirements

- [Requirements, on page 7](#)

Requirements

The hardware must have an access set to the Local Manager and to the CLI (ssh or console port).

Elements to collect

- The Cisco Cyber Vision Sensor application to collect from Cisco.com, i.e.
 - CiscoCyberVision-IOx-aarch64-<version>.tar (Cisco IE3300 10G, Cisco IE3400, Cisco IE9300)
 - CiscoCyberVision-IOx-x86-64-<version>.tar (Cisco Catalyst 9300)
 - CiscoCyberVision-IOx-Active-Discovery-aarch64-<version>.tar (Cisco IE3300 10G, Cisco IE3400, Cisco IE9300 with Active Discovery)
 - CiscoCyberVision-IOx-Active-Discovery-x86-64-<version>.tar (Cisco Catalyst 9300 with Active Discovery)
- A console cable, for the connection to the hardware's console port.
OR
- An Ethernet cable, for the connection to one of the hardware's port.



CHAPTER 4

Additional remarks

- [Additional remarks, on page 9](#)

Additional remarks

About the IE3400 and IE3300 10G platforms:

Cisco Cyber Vision Sensor application will receive ERSPAN traffic. Due to ERSPAN overhead it is recommended to not update the MTU of the platform (switch IE3x00) above 1940 bytes. Otherwise, large packets above 1940 will not be received by the sensor application.

About the initial configuration:

Configurations described in the initial configuration are given as examples to use a Cisco Cyber Vision sensor embedded in a switch.

However, in case a more complex installation is required, a trained user will have to configure the switch with all the necessary VLAN and port settings.



CHAPTER 5

Known issues

- [Known issues, on page 11](#)

Known issues

- The deployment procedure with the Local Manager is not supported by firmware version 17.3.x. Perform the [Procedure with the Cisco Cyber Vision sensor management extension, on page 23](#) instead.
- Cisco Catalyst 9300: deployments will be possible for sensors on firmware version 17.6.x as of Cisco Cyber Vision version 4.0.1.
- IOx redundancy is not supported: sensors will not persist after a failover. This applies in particular to stacks of Cisco Catalyst 9300, stacks of Cisco IE9300 and Cisco Catalyst 9400 with redundant processor boards.
- The sensor application supports RSPAN on Catalyst 9300 and Catalyst 9400 in addition to ERSPAN in Cisco Cyber Vision version 4.1.3. In case of RSPAN usage, multicast packets and packet VLAN information are not transferred to the sensor application.



CHAPTER 6

Initial configuration

in body: To install Cisco Cyber Vision on a Cisco switch, you must perform the Initial configuration which steps are described in this section.

- [Configure the switch access, on page 13](#)
- [Check the software version, on page 13](#)
- [SD Card \(IE3x00/IE9x00\), on page 14](#)
- [SSD Disk \(Catalyst 9x00\), on page 15](#)
- [Check date and time, on page 15](#)
- [Enable IOx, on page 16](#)
- [Add the necessary configuration parameters \(IE3x00\), on page 17](#)
- [Add the necessary configuration parameters \(Catalyst 9x00/IE9x00\), on page 19](#)

Configure the switch access

To configure each Cisco switch access refer to its corresponding installation guide available through the following links:

- Cisco Catalyst IE3x00:
 - <https://www.cisco.com/c/en/us/support/switches/catalyst-ie3300-rugged-series/series.html#~tab-documents>
 - <https://www.cisco.com/c/en/us/support/switches/catalyst-ie3400-rugged-series/series.html#~tab-documents>
 - <https://www.cisco.com/c/en/us/support/switches/catalyst-ie3400-heavy-duty-series/series.html>
- Cisco Catalyst IE9x00:
 - <https://www.cisco.com/c/en/us/support/switches/catalyst-ie9300-rugged-series/series.html>
- Cisco Catalyst 9x00:
 - <https://www.cisco.com/c/en/us/support/switches/catalyst-9300-series-switches/series.html#~tab-documents>
 - <https://www.cisco.com/c/en/us/support/switches/catalyst-9400-series-switches/series.html#~tab-documents>

Check the software version

- Check the software version using the following command in the switch's CLI:

```
Show version
```

To be compatible with the Cisco Cyber Vision Sensor Application:

- the displayed version for Cisco IE3x00 and Cisco Catalyst 9x00 must be 17.02.01 or higher.
- the displayed version for Cisco IE9x00 must be 17.09.01 or higher.

For example: Cisco IE3400

```
IE340CCV#
IE340CCV#show version
Cisco IOS XE Software, Version 17.02.01
Cisco IOS Software [Amsterdam], IE3x00 Switch Software (IE3x00-UNIVERSALK9-M), Version 17.2.1, RELEASE SOFTWARE (fc4)
Technical Support: http://www.cisco.com/techsupport
Copyright (c) 1986-2020 by Cisco Systems, Inc.
Compiled Thu 26-Mar-20 01:42 by mcpre
```

If the version is lower, you must update the switch firmware. To do so, follow the links to the products page in [Configure the switch access](#).

SD Card (IE3x00/IE9x00)

If not already done, insert a 4GB Cisco SD card into the switch SD card slot.

- You can format the SD card using the following command:

```
format sdflash: ext4
```

```
IE340CCV#format sdflash: ext4
Format operation may take a while. Continue? [confirm]
Format operation will destroy all data in "sdflash:". Continue? [confirm]
format completed with no errors

Format of sdflash: complete
IE340CCV#
```

- You can partition the SD card using the following command:

```
partition sdflash: iox
```

```
IE3400PERF#partition sdflash: iox
Partitioning IOS:IOX(34%:66%) Default
Partition command reloads the switch, Continue?[confirm]
Please make sure to back-up "sdflash:" contents
Partition operation will destroy all data in "sdflash:". Continue?[confirm]
```

Partition is intended for SD swap drive usage. For more information, refer to the corresponding switch user manual.

- You can check the file system using the following command (check for ext4 and Read/Write):

```
show sdflash: fileys
```

```
IE340CCV#show sdflash: fileys
Filesystem: sdflash
Filesystem Path: /flash11
Filesystem Type: ext4
Mounted: Read/Write
```

SSD Disk (Catalyst 9x00)

If not already done, insert a 120GB Cisco SSD disk in the SSD slot.

- You can format the SSD disk using the following command:

```
format usbflash1: ext4
```

```
CAT9KCCV#  
CAT9KCCV#format usbflash1: ext4  
Format operation may take a while. Continue? [confirm]  
Format operation will destroy all data in "usbflash1:". Continue? [confirm]  
Format of usbflash1: complete  
CAT9KCCV#
```

- You can check the file system using the following command (check for ext4 and Read/Write):

```
show usbflash1: fileys
```

```
CAT9KCCV#show usbflash1: fileys  
Filesystem: usbflash1  
Filesystem Path: /vol/usb1  
Filesystem Type: ext4  
Mounted: Read/Write  
CAT9KCCV#
```

Check date and time

The internal clock of the switch must be synchronized and configured properly.



Note Unlike hardware sensors (i.e. Cisco IC3000) that fetch their time from the Center, the Cyber Vision IOX application sensor gets the time from the host (switch platform). Therefore, it is critical that the host synchronizes its time with the Center or a valid NTP server if it's synchronized with the Center. If the time difference is large (hours or more), the user should adjust the Cisco IE3400 time using the Local Manager so it is close to the reference time. If not, the synchronization may take many update cycles.

1. Check the date and time using the following command:

```
Show clock
```

For examples:

Cisco IE3400:

```
IE340CCV#  
IE340CCV#show clock  
*13:48:03.650 UTC Wed Apr 8 2020  
IE340CCV#
```

Cisco Catalyst 9300:


```
CAT9KCCV#
CAT9KCCV#show clock
*16:02:57.900 UTC Thu Apr 30 2020
CAT9KCCV#
```

- If needed, adjust to the UTC time using the following command:

```
clock set [hh:mm:ss] [month] [day] [year]
```

Or go to the Local Manager:

For example: Cisco IE3400



Enable IOx

Before installing the Cisco Cyber Vision sensor on the hardware, you must enable IOx.

- Enable IOx using the following command:

```
configure terminal
iox
```

For examples:

Cisco IE3400:

```
IE340CCV#
IE340CCV#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
IE340CCV(config)#iox
Warning: Do not remove SD flash card when IOx is enabled or errors on SD device could occur.
IE340CCV(config)#
```

Cisco Catalyst 9300:


```
CAT9KCCV#
CAT9KCCV#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
CAT9KCCV(config)#iox
CAT9KCCV(config)#
```

2. Check the IOx service status using the following command:

```
exit
show iox
```

For examples:

Cisco IE3400:

```
IE340CCV#show iox

IOx Infrastructure Summary:
-----
IOx service (CAF) 1.10.0.1 : Running
IOx service (HA)           : Not Supported
IOx service (IOxman)       : Running
IOx service (Sec storage)  : Not Supported
Libvirtd 1.3.4              : Running
Dockerd 18.03.0            : Running
```

Cisco Catalyst 9300:

```
CAT9KCCV#
CAT9KCCV#show iox

IOx Infrastructure Summary:
-----
IOx service (CAF) 1.10.0.1 : Running
IOx service (HA)           : Running
IOx service (IOxman)       : Running
IOx service (Sec storage)  : Not Running
Libvirtd 1.3.4              : Running
Dockerd 18.03.0            : Running
Application DB Sync Info  : Available
Sync Status : Disabled

CAT9KCCV#
```

Add the necessary configuration parameters (IE3x00)

The example of configuration given below is a simple one. This configuration is only valid if a direct link exists between the Center and the switch with the embedded sensor. In this case, the dedicated port is configured with the Collection VLAN (for example, 507). In many other cases, the port used for communication between the Center and the sensor will have to be configured as trunk.

1. Open the Cisco IE3300 10G/IE3400 CLI through ssh or via the console terminal.

2. Configure a VLAN for traffic mirroring using the following commands:

```
configure terminal
vtp mode off
vlan 2508
remote-span
exit
```

```
IE34ERIC(config)#vtp mode off
Setting device to VTP Off mode for VLANs.
IE34ERIC(config)#vlan 2508
IE34ERIC(config-vlan)#remote-span
IE34ERIC(config-vlan)#exit
IE34ERIC(config)#
```

The VTP off command is performed here since VTP is enabled by default and is not compatible with a high VLAN number.

If needed, select another VLAN number and use the VTP configuration requested by the network.

3. Configure the AppGigabitEthernet port for communications to reach the IOx virtual application using the following commands:

```
interface AppGigabitEthernet 1/1
switchport mode trunk
exit
```

```
IE340CCV(config)#
IE340CCV(config)#interface AppGigabitEthernet 1/1
IE340CCV(config-if)#switchport mode trunk
IE340CCV(config-if)#exit
IE340CCV(config)#
```

4. Configure the SPAN session and add to the session the interfaces to monitor:

```
monitor session 1 source interface Gi1/10 both
monitor session 1 destination remote vlan 2508
monitor session 1 destination format-erspan 169.254.1.2
```

```
IE340CCV(config)#monitor session 1 source interface Gi1/10 both
IE340CCV(config)#monitor session 1 destination remote vlan 508
IE340CCV(config)#monitor session 1 destination format-erspan 169.254.1.2
```

5. Configure one of the switch's ports to enable the communication between the virtual sensor and the Center:

```
int gi1/3
switchport access vlan 507
no shutdown
```

```
IE340CCV(config)#
IE340CCV(config)#int gi1/3
IE340CCV(config-if)#switchport access vlan 507
% Access VLAN does not exist. Creating vlan 507
IE340CCV(config-if)#no shutdown
IE340CCV(config-if)#exit
```

6. Save the configuration using the following commands:

```
exit
write mem
```

```
IE340CCV(config)#exit
IE340CCV#write mem
Building configuration...
[OK]
IE340CCV#
```

The initial configuration is now complete. Proceed with the application installation and deployment following one of the procedures below:

- [Procedure with the Cisco Cyber Vision sensor management extension, on page 23](#)
- [Procedure with the Local Manager, on page 33](#)
- [Procedure with the CLI, on page 50](#)

Add the necessary configuration parameters (Catalyst 9x00/IE9x00)

The configuration examples given in this section are simple ones. They are only valid if a direct link exists between the Center and the switch with the embedded sensor. In this case, the dedicated port is configured with the Collection VLAN (for example, 507). In many other cases, the port used for communication between the Center and the sensor will have to be configured as trunk.

Configuration with ERSPAN is recommended but requires routing to be enabled on the switch. If this is not possible, RSPAN is available on the Catalyst 9x00. However, note that Multicast and VLAN information will be missing with this configuration.

Configure with ERSPAN

Procedure

- Step 1** Open the switch's CLI through ssh or via the console terminal.
- Step 2** Configure a VLAN for traffic mirroring using the following commands:
- ```
configure terminal
ip routing
vlan 2508
exit
int vlan 2508
ip address 169.254.1.1 255.255.255.252
no shutdown
exit
```
- Step 3** Configure the AppGigabitEthernet port which will enable the communication to the IOx virtual application:
- ```
interface AppGigabitEthernet 1/0/1
switchport mode trunk
exit
```

```
CAT9KCCV(config)#
CAT9KCCV(config)#interface AppGigabitEthernet 1/0/1
CAT9KCCV(config-if)#switchport mode trunk
CAT9KCCV(config-if)#exit
CAT9KCCV(config)#
```

Step 4 Configure the SPAN session and add to the session the interfaces to monitor:

Note Disabling the ip routing command for IPv4 connections and ipv6 unicast-routing command for IPv6 connections stops ERSpan traffic flow to the destination port. [Link to Catalyst 9300 manual](#).

```
monitor session 1 type erspan-source
source interface Gi1/0/2 - 24 both
no shutdown
destination
erspan-id 2
mtu 9000
ip address 169.254.1.2
origin ip address 169.254.1.1
exit
exit
```

```
CAT9KCCV(config)#
CAT9KCCV(config)#monitor session 1 type erspan-source
CAT9KCCV(config-mon-erspan-src)#source interface Gi1/0/2 - 24 both
CAT9KCCV(config-mon-erspan-src)#no shutdown
CAT9KCCV(config-mon-erspan-src)#destination
CAT9KCCV(config-mon-erspan-src-dst)#erspan-id 2
CAT9KCCV(config-mon-erspan-src-dst)#mtu 9000
CAT9KCCV(config-mon-erspan-src-dst)#ip address 169.254.1.2
CAT9KCCV(config-mon-erspan-src-dst)#origin ip address 169.254.1.1
CAT9KCCV(config-mon-erspan-src-dst)#exit
CAT9KCCV(config-mon-erspan-src)#exit
CAT9KCCV(config)#
```

Step 5 Configure one of the switch's ports to enable the communication between the virtual sensor and the Center:

```
interface GigabitEthernet1/0/1
switchport access vlan 507
no shutdown
exit
```

```
CAT9KCCV(config)#interface GigabitEthernet1/0/1
CAT9KCCV(config-if)#switchport access vlan 507
% Access VLAN does not exist. Creating vlan 507
CAT9KCCV(config-if)#no shutdown
CAT9KCCV(config-if)#exit
CAT9KCCV(config)#
```

Step 6 Save the configuration:

```
exit
write mem
```

```
CAT9KCCV(config)#
CAT9KCCV(config)#exit
CAT9KCCV#write mem
Building configuration...
[OK]
CAT9KCCV#
```

What to do next

The initial configuration is now complete. Proceed with the application installation and deployment following one of the procedures below:

- [Procedure with the Cisco Cyber Vision sensor management extension, on page 23](#)
- [Procedure with the Local Manager, on page 33](#)
- [Procedure with the CLI, on page 50](#)

Configure with RSPAN (Catalyst 9x00 only)

Before you begin

The VLAN configured for RSPAN (here 2508) must be filtered on all trunk ports except for the AppGigabitEthernet interface.

Procedure

Step 1 Open the switch's CLI through ssh or via the console terminal.

Step 2 Configure a VLAN for traffic mirroring using the following commands:

```
configure terminal
vlan 2508
exit
int vlan 2508
remote-span
exit
```

Step 3 Configure the AppGigabitEthernet port which will enable the communication to the IOx virtual application:

```
interface AppGigabitEthernet 1/0/1
switchport mode trunk
exit
```

```
CAT9KCCV(config)#
CAT9KCCV(config)#interface AppGigabitEthernet 1/0/1
CAT9KCCV(config-if)#switchport mode trunk
CAT9KCCV(config-if)#exit
CAT9KCCV(config)#
```

Step 4 Configure the SPAN session and add to the session the interfaces to monitor:

```
monitor session 1 source interface Gi1/0/2 - 24 both
monitor session 1 destination remote vlan 2508
```

Step 5 Configure one of the switch's ports to enable the communication between the virtual sensor and the Center:

```
interface GigabitEthernet1/0/1
switchport access vlan 507
no shutdown
exit
```

```
CAT9KCCV(config)#interface GigabitEthernet1/0/1
CAT9KCCV(config-if)#switchport access vlan 507
% Access VLAN does not exist. Creating vlan 507
CAT9KCCV(config-if)#no shutdown
CAT9KCCV(config-if)#exit
CAT9KCCV(config)#
```

Step 6 Save the configuration:

```
exit
write mem
```

```
CAT9KCCV(config)#
CAT9KCCV(config)#exit
CAT9KCCV#write mem
Building configuration...
[OK]
CAT9KCCV#
```

What to do next

The initial configuration is now complete. Proceed with the application installation and deployment following one of the procedures below:

- [Procedure with the Cisco Cyber Vision sensor management extension, on page 23](#)
- [Procedure with the Local Manager, on page 33](#)
- [Procedure with the CLI, on page 50](#)



CHAPTER 7

Installation

- [Procedure with the Cisco Cyber Vision sensor management extension, on page 23](#)
- [Procedure with the Local Manager, on page 33](#)
- [Procedure with the CLI, on page 50](#)

Procedure with the Cisco Cyber Vision sensor management extension

After the [Initial configuration](#), proceed to the steps described in this section. This section also describes the steps to configure Active Discovery.



Note To be able to use the Cisco Cyber Vision sensor management extension, an IP address reachable by the Center Collection interface must be set on the Collection VLAN.

Install the sensor management extension

To install the sensor management extension, you must:

Procedure

- Step 1** Retrieve the extension file (i.e. CiscoCyberVision-sensor-management-<version>.ext) from cisco.com.
- Step 2** Access the Extension administration page in Cisco Cyber Vision.
- Step 3** Import the extension file.

Extensions

From this page, you can manage Cyber Vision Extensions. Extensions are optional add-ons to Cyber Vision Center which provide more features, such as the management of new device types, additional detection engines, or integrations with external services.

Installed extensions

Name	Version	Actions
Cyber Vision sensor management	4.1.0	Update Remove

Install a new extension

[Import extension file](#)

Once the sensor management extension is installed, you will find a new management job under the sensor administration menu ([Management jobs, on page 24](#)), and the **Install via extension** button will be enabled in the Sensor Explorer page.

Management jobs

As some deployment tasks on sensors can take several minutes, this page shows the jobs execution status and advancement for each sensor deployed with the sensor management extension.

This page is only visible when the sensor management extension is installed in Cisco Cyber Vision.

Management jobs

Jobs execution for sensor management tasks.

1 / 20 / page

Jobs	Steps	Duration
Single redeployment (FCW2435P3KW)	✓ — ✓ — ✓ — ✓	1m 11s
Single redeployment (FCW23500HDC)	✓ — ✓ — ✗ —	41s
Single redeployment (FOC2337L0CW)	✓ — ✓ — ✓ — ✓	1m 33s
Single redeployment (FCW23500HDC)	✓ — ✓ — ✗ —	35s
Single redeployment (FCW23500HDC)	✓ — ✓ — ✗ —	39s
Single redeployment (FCW23500HDC)	✓ — ✓ — ✗ —	43s
Single redeployment (FOC2334V045)	✓ — ✓ — ✓ — ✓	6m 52s

You will find the following jobs:

- Single deployment

This job is launched when clicking the Deploy Cisco device button in the sensor administration page, that is when a new IOx sensor is deployed.

- Single redeployment

This job is launched when clicking the Reconfigure Redeploy button in the sensor administration page, that is when deploying on a sensor that has already been deployed. This option is used for example to change the sensor's parameters like enabling active discovery.

- Single removal

This job is launched when clicking the Remove button from the sensor administration page.

- Update all devices

This job is launched when clicking the Update Cisco devices button from the sensor administration page. A unique job is created for all managed sensors that are being updated.

If a job fails, you can click on the error icon to view detailed logs.

Jobs	Steps
Single redeployment (FCW23500HDC)	
Single redeployment (FCW2435P3KW)	
Single redeployment (FCW23500HDC)	
Single redeployment (FOC2337LOCW)	
Single redeployment (FCW23500HDC)	

Enroll - Error

Enroll


Error

```
Fatal error: cannot upload provisioning package: UploadAppData failed: Fog Director API Error Code 0: {"message": "File upload failed. App data upload is not allowed since this app was installed with --rm option and currently app container is cleaned after stopping the app. Consider starting the app and retry."}
```

Create a sensor in the sensor management extension

Procedure

- Step 1** In Cisco Cyber Vision, navigate to Admin > Sensors > Sensor Explorer and click **Install sensor**, then **Install via extension**.



Step 2 Fill the requested fields so Cisco Cyber Vision can reach the device:

- IP address: admin address of the device.
- Port: management port (443).
- Login: user with the admin rights of the device.
- Password: password of the admin user.
- Capture Mode: Optionally, select a capture mode.

Install via extension

Reach Cisco device

Please fill the fields below to enable Cisco Cyber Vision to reach your device.

<p>IP address*</p> <input type="text" value="192.168.49.20"/>	<p>Port*</p> <input type="text" value="443"/> <small>For example 443 or 8443</small>
---	---

Center collection IP

leave blank to use current collection IP

Credentials

Login*

Password*

Capture mode

Optimal (default): analyze the most relevant flows

All: analyze all the flows

Industrial only: analyze industrial flows

Custom: you set your filter using a packet filter in tcpdump-compatible syntax

[Exit](#) **Connect**

Step 3 Click **Connect**.

The Center will join the device and the second parameter list will be displayed. For this step to succeed, the device needs to be reachable by the Center on its eth1 connection.

Configure a sensor in the sensor management extension

If the Center can join the switch, the following form appears:

Form for the Cisco IE3x00 and the Cisco IE9x00:

Install via extension

Configure Cyber Vision IOx sensor app

The device requires additional parameters. Some parameters have been pre-filled. Please complete the remaining fields.

Cisco device: IE-3400-8T2S

Capture IP address*

169.254.1.2

Capture prefix length*

30

Like 24, 16 or 8

Capture VLAN number*

2508

Collection IP address*

192.168.49.21

Collection prefix length*

24

Like 24, 16 or 8

Collection gateway

Collection VLAN number*

507

Exit

Next

Form for the Cisco Catalyst 9x00 with RSPAN configuration available:

Cisco device: C9300L-48T-4X

Monitor session type:

- ERSPAN: recommended choice
- RSPAN: use it only when using ERSPAN is not possible

Capture IP address*

169.254.1.2

Capture prefix length*

30

Like 24, 16 or 8

Capture VLAN number*

2508

Collection IP address*

192.168.0.248

Collection prefix length*

24

Like 24, 16 or 8

Collection gateway

Collection VLAN number*

4

Exit

Next

While some parameters are filled automatically, you can still change them if necessary.

Procedure

Step 1

Fill the following parameters for the Collection interface:

- Capture IP address: IP address destination of the monitor session in the sensor
- Capture prefix length: mask of the capture IP address
- Capture VLAN number: VLAN of the monitor session in the sensor
- Collection IP address: IP address of the sensor in the device
- Collection prefix length: mask of the Collection IP address
- Collection gateway: gateway of the Collection IP address
- Collection VLAN number: VLAN of the sensor

Step 2

Click **Next**.

Step 3

Active Discovery:

If you want to enable Active Discovery on the sensor, select **Passive and Active Discovery**.

You can:

- use the sensor Collection interface by selecting it:

Install via extension

Configure Active Discovery

Please select an application type. If you want to enable Active Discovery on the application, select "Passive and Active Discovery". You will have to add some network interfaces parameters.

Passive only
 Passive and Active Discovery

Add Active Discovery configuration	Network interfaces
<input checked="" type="checkbox"/> Use collection interface + New network interface	<ul style="list-style-type: none"> • 192.168.49.21/24 VLAN#1 (collection interface)

- add new network interfaces filling the following parameters to set dedicated network interfaces and clicking Add:
 - IP address
 - Prefix length
 - VLAN number

Add Active Discovery configuration

Use collection interface

+ New network interface

IP address*

IP address interface used to do Active Discovery

Prefix length*

Like 24, 16 or 8

VLAN number*

Use 1 by default

Add

Cancel

Network interfaces

- 192.168.50.21/24 VLAN#50

delete

Back

Deploy

Step 4 Click **Deploy**.

The Center starts deploying the sensor application on the target equipment. This can take a few minutes. You can go to the Management jobs page to check the deployment advancements.

The screenshot shows the 'Management jobs' page in the Cisco Cyber Vision interface. The left sidebar contains navigation options: System, Data Management, Network Organization, Sensors (expanded), Sensor Explorer, Management jobs (selected), and PCAP Upload. The main content area shows 'Jobs execution for sensor management tasks.' with a table of jobs. A job titled 'Single deployment (FCW2445P6X5)' is shown with a progress bar consisting of three circles: the first is blue with a white checkmark, and the other two are grey with a white power symbol. A page indicator '< 1 >' is visible at the top right of the table.

Once the deployment is finished, a new sensor appears in the sensors list.

The sensor's status will eventually turn to connected.

<input type="checkbox"/>	FCW2445P6X5	192.168.49.21	4.1.0+202202151440	Connected	Pending data	Enabled	4 days
--------------------------	-------------	---------------	--------------------	-----------	--------------	---------	--------

If the Active Discovery has been enabled and set -that is if the option **Passive and Active Discovery** was selected when configuring the sensor in the sensor management extension- the sensor is displayed as below with Active Discovery's status as Enabled.

<input type="checkbox"/>	Label	IP Address	Version	Location	Health status	Processing status	Active Discovery	Uptime
<input type="checkbox"/>	FCW2445P6X5			192.168.49.21	Disconnected	Disconnected		Not
<input type="checkbox"/>	FCW2445P6X5			192.168.49.21	Disconnected	Disconnected		Not
<input type="checkbox"/>	FCW2445P6X5	192.168.49.21	4.1.0+202202151440		Connected	Pending data	Enabled	4 days

Configure Active Discovery

Once the sensor is connected, you can change the Active Discovery's network interface so it uses the Collection network interface instead, and add several network interfaces for the sensor to perform Active Discovery on several subnetworks at the same time.

Procedure

Step 1 Click the sensor to configure and click the **Active Discovery** button on its right side panel.

The screenshot shows the 'Sensor Explorer' interface for sensor FCW2445P6X5. The main panel displays a list of folders and sensors, with the selected sensor FCW2445P6X5 highlighted. The right-hand configuration panel shows the following details:

- Label: FCW2445P6X5
- Serial Number: FCW2445P6X5
- IP address: 192.168.49.21
- Version: 4.1.0+202202151440
- System date: Feb 24, 2022 4:13:06 PM
- Deployment: Sensor Management Extension
- Active Discovery: Enabled
- Capture mode: All
- System Health Status: Connected
- Processing status: Normally processing
- Uptime: a day

At the bottom of the configuration panel, several action buttons are visible: 'Move to', 'Capture mode', 'Redeploy', 'Uninstall', and 'Active Discovery'. The 'Active Discovery' button is highlighted with a red box.

The Active Discovery configuration appears with the interface currently set.

Step 2 Select **Use collection interface** for the Active Discovery to use the Collection network interface.

ACTIVE DISCOVERY CONFIGURATION

From here you can configure Active Discovery

Add Active Discovery configuration

Use collection interface

[+ New network interface](#)

Network interfaces

- 192.168.49.21/24 VLAN#1 (collection interface)

Configure Cancel

To add a network interface to Active Discovery for the sensor to perform active monitoring on another subnetwork:

Step 3 Add a new network interface by clicking the corresponding button.

Step 4 Fill the following parameters to set dedicated network interfaces:

- IP address
- Prefix length
- VLAN number

Step 5 Click **Add**.

ACTIVE DISCOVERY CONFIGURATION

From here you can configure Active Discovery

[+ New network interface](#)

IP address*

192.168.52.24

Prefix length*

24

VLAN number*

52

Add Cancel

Configure Cancel

You can add as many network interfaces as needed.

Step 6 When you are done, click **Configure**.


A message saying that the configuration has been applied successfully appears.

Procedure with the Local Manager


After the [Initial configuration, on page 13](#), proceed to the steps described in this section.

Access the Local manager


1. Open a browser and navigate to the IP address you configured on the interface you are connected to.
2. Log in using the Local Manager user account and password.




For example: Cisco IE3300 10G/IE3400



- Once logged into the Local Manager, navigate to Configuration > Services > IOx.
For example: Cisco IE3300 10G/IE3400




- Log in using the user account and password.




Install the sensor virtual application


Once logged in, the following menu appears:




1. Click **Add New**.
2. Add an Application id name (e.g. CCVSensor).
3. Select the application archive file
 - "CiscoCyberVision-IOx-aarch64-xxx.tar" for the Cisco IE3300/IE3400/IE9300
 - "CiscoCyberVision-IOx-Active-Discovery-aarch64.tar" for the Cisco IE3300/IE3400/IE9300 with Active Discovery
 - "CiscoCyberVision-IOx-x86-64-xxx.tar" for the Cisco Catalyst 9300
 - "CiscoCyberVision-IOx-Active-Discovery-x86-64.tar" for the Cisco Catalyst 9300



The installation takes a few minutes.




When the application is installed, the following message is displayed:




Configure the sensor virtual application (IE3x00/IE9x00)


1. Click **Activate** to launch the configuration of the sensor application.




2. Change the disk size from the default size to 2048 MB. The disk size must not be larger than this.



- Bind the interfaces in the container to an interface on the host in Network Configuration. Start with eth0 by clicking **edit** in the eth0 line.



- Click **Interface Setting**.



- Apply the following configurations:
 - Select **Static**
 - IP/Mask: IP and mask of the sensor
 - Default gateway: IP address of the Center

- Vlan ID, which is defined below, is the VLAN in the Cisco IE3300 10G/IE3400 dedicated to the Collection network interface (link between the Center and the sensors), e.g. 507.

6. IPV6 must be set to Disable.

7. Click **OK** twice.


Network Configuration	
Name	Network Config
eth0	mgmt-bridge300
eth1	Not Configured

eth0 mgmt-bridge300 L2br network [Interface Setting](#)

Description (optional):

OK Cancel

8. Click **OK** again on the popup.



9. Then, apply the following parameters to eth1:
 - Select **Static**.
 - IP/Mask: the IP and mask of the sensor for the mirrored traffic.

- Vlan ID, which is defined below, is the VLAN in the Cisco IE3300 10G/IE3400/IE9300 dedicated to traffic mirroring.


10. IPV6 must be set to **Disable**.

11. If configuring a sensor with **Active Discovery**, you must set an additional interface (eth2 without IP address) dedicated to this feature.


Name	Network Config	Description	Action
eth0	mgmt-bridge300	none	edit
eth1	Not Configured	none	edit
eth2	Not Configured	none	edit

12. Click the **Activate App** button.

The operation takes several minutes.




The application status changes to "RUNNING":




Configure the sensor virtual application (Catalyst 9x00)


1. Click **Activate** to launch the configuration of the sensor application.




2. Change the disk size from the default size to 80,000 MB. The disk size must not be smaller than this.



3. Bind the interfaces in the container to an interface on the host in Network Configuration. Start with eth0 by clicking **edit** in the eth0 line.



4. Select the mgmt-bridge300 entry in the interface list.



5. Click **Interface Setting**.

▼ Network Configuration

Name	Network Config	Description	Action
eth0	mgmt-bridge300	none	edit
eth1	Not Configured	none	edit

eth0 mgmt-bridge300 L2br network ▼ [Interface Setting](#)

Description (optional):

6. Apply the following configurations:

- Select **Static**
- IP/Mask: the IP and mask of the sensor
- Default gateway: the IP address of the Center
- Vlan ID, which is defined below, is the VLAN in the Cisco Catalyst 9300 dedicated to the Collection network interface (link between the Center and the sensors), e.g. 507.

Interface Setting

IPv4 Setting

Static Dynamic Disable

IP/Mask /

DNS

Default Gateway IP

Vlan ID

Vlan ID

7. IPV6 must be set to **Disable**.

IPv6 Setting

Static Dynamic Disable

8. Click **OK** twice.


▼ Network Configuration

Name	Network Config
eth0	mgmt-bridge300
eth1	Not Configured

eth0 L2br network ▼ [Interface Setting](#)

Description (optional):

9. Click **OK** again on the following popup.



10. Apply the following configurations to eth1:
- Set IPv4 as **Static** and the IP and mask of the sensor for mirrored traffic.
 - Disable IPv6.
 - Set the VLAN id.
 - **Set the mirror mode as enabled.**

Interface Setting

IPv4 Setting

Static Dynamic Disable

IP/Mask: /

DNS:

Default Gateway IP:


Vlan ID

Vlan ID:

Mirror Mode


Mirror Mode: Enabled

11. Click **OK** until you come back to the screen below.
12. Click the **Activate App** button.




The screenshot shows a configuration page with two main sections: Network Configuration and Peripheral Configuration. In the top right corner, there is a button labeled "Activate App" with a checkmark icon. Below the "Network Configuration" section, there is a table with columns: Name, Network Config, Description, and Action. The table contains two rows for network interfaces eth0 and eth1, both pointing to "mgmt-bridge300" with a description of "none" and an "edit" link in the action column. Below the table is a button "Add App Network Interface". The "Peripheral Configuration" section has a table with columns: Device Type, Name, Label, Status, and Action, and a button "Add Peripheral" below it.

The operation takes several seconds.




13. Click **Applications** to display the application status:




The screenshot shows the "Applications" page in a web interface. The top navigation bar includes "Applications", "Docker Layers", "System Info", "System Setting", and "System Troubleshoot". Below this, there are sub-tabs: "Resources", "App-info", "App-Config", "App-DataDir", and "Logs". The "Resources" section is expanded, showing a "Resource Profile" configuration. The profile is set to "exclusive". The resource limits are: CPU (7400 cpu-units), Memory (2048 MB), and Disk (80000 MB). At the bottom of the resource profile section, it shows "Avail. CPU (cpu-units) 0", "Avail. Memory (MB) 0", and "Avail. Disk (MB) 40000". There is a link for "Advanced Settings" at the bottom.


14. The application is activated and needs to be started. To do so, click the **Start** button.



The operation takes several seconds.




The application status changes to "RUNNING".




Generate the provisioning package

1. In Cisco Cyber Vision, navigate to Admin > Sensors > Sensor Explorer and click **Install sensor**, then **Manual install**.



The manual install wizard appears.

2. Select **Cisco IOx Application** and click **Next**.



3. Fill the fields to configure the sensor provisioning package:
 - The serial number of the hardware.
 - Center IP: leave blank.
 - Gateway: add if necessary.
 - Optionally, select a capture mode.
 - Optionally, select RSPAN (only with Catalyst 9x00 and if using ERSPAN is not possible).

Configure provisioning package

Please fill in the fields below to add configuration to the provisioning package to install.

Sensor Application

Serial number*

Center collection IP

leave blank to use current collection IP

Gateway


Capture mode

- Optimal (default): analyze the most relevant flows
- All: analyze all the flows
- Industrial only: analyze industrial flows
- Custom: set your filter using a packet filter in tcpdump-compatible syntax

Monitor session type

- ERSPAN: recommended choice for all devices
- RSPAN: use it only with Catalyst 9X00 and when using ERSPAN is not possible

4. Click **Create sensor**.
5. Click the link to download the provisioning package.



This will download the provisioning package which is a zip archive file with the following name structure: sbs-sensor-config-<serialnumber>.zip (e.g. "sbs-sensor-configFCW23500HDC.zip").

6. Click **Finish**.
7. A new entry for the sensor appears in the Sensor Explorer list.


The sensor status will switch from Disconnected to Connected.

<input type="checkbox"/>	Label	IP Address	Version	Location	Health status	Processing status	Active Discovery	Uptime
<input type="checkbox"/>				IC3000	Disconnected	Disconnected		0h
<input type="checkbox"/>				IC3000	Disconnected	Disconnected		0h
<input type="checkbox"/>	FCW2445P6X5	192.168.49.21	4.1.0+202202151440		Connected	Pending data	Enabled	4 days


Import the provisioning package

1. In the Local manager, in the IOx configuration menu, click **Manage**.

Cisco IE3400:




Cisco Catalyst 9300:




2. Navigate to **App_DataDir**.

For example Cisco IE3400:




3. Click **Upload**.



4. Choose the provisioning package downloaded (i.e. "sbs-sensor-config-FOC2334V01X.zip") and add the exact file name in the path field (i.e. "sbs-sensor-config-FOC2334V01X.zip").

5. Click **OK**.



A popup indicating that Cisco Cyber Vision has been deployed successfully appears.

6. Click **OK**.

Procedure with the CLI

After the [Initial configuration, on page 13](#), proceed to the steps described in this section.

Configure the sensor application



Note In this section, "CCVSensor" is used as the appid.

1. Connect to the device through SSH or a console.
2. Configure the application payload by typing the following commands:

Cisco IE3300 10G/IE3400:

```
enable
configure terminal
app-hosting appid CCVSensor
app-vnic AppGigabitEthernet trunk
vlan 507 guest-interface 0
guest-ipaddress 192.168.69.208 netmask 255.255.255.0
vlan 2508 guest-interface 1
guest-ipaddress 169.254.1.2 netmask 255.255.255.0
app-default-gateway 192.168.69.1 guest-interface 0
app-resource profile custom
persist-disk 2048
cpu 1400
memory 2048
vcpu 2
end
```

```
IE340CCV#enable
IE340CCV#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
IE340CCV(config)#app-hosting appid CCVSensor
IE340CCV(config-app-hosting)#app-vnic AppGigabitEthernet trunk
IE340CCV(config-config-app-hosting-trunk)#vlan 507 guest-interface 0
IE340CCV(config-config-app-hosting-vlan-access-ip)#guest-ipaddress 192.168.69.208 netmask 255.255.255.0
IE340CCV(config-config-app-hosting-vlan-access-ip)#vlan 2508 guest-interface 1
IE340CCV(config-config-app-hosting-vlan-access-ip)#guest-ipaddress 169.254.1.2 netmask 255.255.255.0
IE340CCV(config-config-app-hosting-vlan-access-ip)#app-default-gateway 192.168.69.1 guest-interface 0
IE340CCV(config-app-hosting)#app-resource profile custom
IE340CCV(config-app-resource-profile-custom)#persist-disk 2048
IE340CCV(config-app-resource-profile-custom)#cpu 1400
IE340CCV(config-app-resource-profile-custom)#memory 2048
IE340CCV(config-app-resource-profile-custom)#vcpu 2
IE340CCV(config-app-resource-profile-custom)#end
IE340CCV#
```

Cisco IE9300:

```
enable
configure terminal
app-hosting appid CCVSensor
app-vnic AppGigabitEthernet trunk
  vlan 507 guest-interface 0
    guest-ipaddress 192.168.69.90 netmask 255.255.255.0
  vlan 2508 guest-interface 1
    guest-ipaddress 169.254.1.2 netmask 255.255.255.252
app-default-gateway 192.168.69.190 guest-interface 0
app-resource docker
run-opts 1 --rm
```

```

app-resource profile custom
  cpu 1000
  memory 862
  persist-disk 4000
end

```

```

IE9300_1#
IE9300_1#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
IE9300_1(config)#app-hosting appid CCVSensor
IE9300_1(config-app-hosting)#app-vnic AppGigabitEthernet trunk
IE9300_1(config-config-app-hosting-trunk)#vlan 507 guest-interface 0
IE9300_1(config-config-app-hosting-vlan-access-ip)#guest-ipaddress 192.168.69.90 netmask 255.255.255.0
IE9300_1(config-config-app-hosting-vlan-access-ip)#vlan 2508 guest-interface 1
IE9300_1(config-config-app-hosting-vlan-access-ip)#guest-ipaddress 169.254.1.2 netmask 255.255.255.252
IE9300_1(config-config-app-hosting-vlan-access-ip)#app-default-gateway 192.168.69.190 guest-interface 0
IE9300_1(config-app-hosting)#app-resource docker
IE9300_1(config-app-hosting-docker)#run-opts 1 "--rm"
IE9300_1(config-app-hosting-docker)#app-resource profile custom
IE9300_1(config-app-resource-profile-custom)#cpu 1000
IE9300_1(config-app-resource-profile-custom)#memory 862
IE9300_1(config-app-resource-profile-custom)#persist-disk 4000
IE9300_1(config-app-resource-profile-custom)#end
IE9300_1#

```

Cisco Catalyst 9300:

```

enable
configure terminal
app-hosting appid CCVSensor
app-vnic AppGigabitEthernet trunk
vlan 507 guest-interface 0
guest-ipaddress 192.168.69.210 netmask 255.255.255.0
vlan 2508 guest-interface 1
mirroring
guest-ipaddress 169.254.1.2 netmask 255.255.255.0
app-default-gateway 192.168.69.1 guest-interface 0
app-resource profile custom
persist-disk 8192
cpu 7400
memory 2048
vcpu 2
end

```

```

CAT9KCCV#
CAT9KCCV#enable
CAT9KCCV#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
CAT9KCCV(config)#app-hosting appid CCVSensor
CAT9KCCV(config-app-hosting)#app-vnic AppGigabitEthernet trunk
CAT9KCCV(config-config-app-hosting-trunk)#vlan 507 guest-interface 0
CAT9KCCV(config-config-app-hosting-vlan-access-ip)#guest-ipaddress 192.168.69.210 netmask 255.255.255.0
CAT9KCCV(config-config-app-hosting-vlan-access-ip)#vlan 2508 guest-interface 1
CAT9KCCV(config-config-app-hosting-vlan-access-ip)#guest-ipaddress 169.254.1.2 netmask 255.255.255.0
CAT9KCCV(config-config-app-hosting-vlan-access-ip)#app-default-gateway 192.168.69.1 guest-interface 0
CAT9KCCV(config-app-hosting)#app-resource profile custom
CAT9KCCV(config-app-resource-profile-custom)#persist-disk 8192
CAT9KCCV(config-app-resource-profile-custom)#cpu 7400
CAT9KCCV(config-app-resource-profile-custom)#memory 2048
CAT9KCCV(config-app-resource-profile-custom)#vcpu 2
CAT9KCCV(config-app-resource-profile-custom)#end
CAT9KCCV#

```

For the app-resource profile's custom values, refer to the result of the show app-hosting resource command.

In this example, all maximum values are used for:

- the CPU (CPU available units, here 1400 for the Cisco IE3300 10G/IE3400, 1000 for the Cisco IE9300, and 7400 for the Cisco Catalyst 9300)
- the VCPU (here 2), the memory (Memory available, here 2048)

- the disk (only 2048 MB and 8192 MB respectively are used to let space for application updates)

Install the sensor application

The sensor package is to be retrieved on cisco.com. The file has the following name structure:

- CiscoCyberVision-IOx-aarch64-<VERSION>.tar (Cisco IE3300 10G/IE3400/IE9300).
- CiscoCyberVision-IOx-x86-64-<VERSION>.tar (Cisco Catalyst 9300).

1. Copy the package to a USB key or in the flash memory.

2. Type the following commands on the CLI:

```
enable
app-hosting install appid CCVSensor package usbflash0:<FILENAME>.tar
```

Cisco IE3300 10G/IE3400/IE9300:

```
IE340CCV#app-hosting install appid CCVSensor package usbflash0:CiscoCyberVision-IOx-aarch64-3.1.0-RC4.tar
Installing package 'usbflash0:CiscoCyberVision-IOx-aarch64-3.1.0-RC4.tar' for 'CCVSensor'. Use 'show app-hosting list' f
or progress.
IE340CCV#
```

Cisco Catalyst 9300:

```
CAT9KCCV#
CAT9KCCV#enable
CAT9KCCV#app-hosting install appid CCVSensor package usbflash0:CiscoCyberVision-IOx-x86-64-3.1.0-RC4.tar
Installing package 'usbflash0:CiscoCyberVision-IOx-x86-64-3.1.0-RC4.tar' for 'CCVSensor'. Use 'show app-hosting list' fo
r progress.
CAT9KCCV#
```



Note Adjust "usbflash0:" in accordance with the sensor package's localization (USB port or flash memory).



Note Replace "CiscoCyberVision-IOx-aarch64-<VERSION>.tar" with the right filename.

3. Check that the application is in "DEPLOYED" state:

```
show app-hosting list
```

For example: Cisco IE3400

```
IE340CCV#
IE340CCV#show app-hosting list
App id                               State
-----
CCVSensor                             DEPLOYED
IE340CCV#
```

4. Activate the application using the following command:

```
app-hosting activate appid CCVSensor
```

For example: Cisco IE3400

```
IE340CCV#app-hosting activate appid CCVSensor
CCVSensor activated successfully
Current state is: ACTIVATED
IE340CCV#
```

5. Start the application using the following command:


```
app-hosting start appid CCVSensor
```

For example: Cisco IE3400:

```
IE340CCV#
IE340CCV#app-hosting start appid CCVSensor
CCVSensor started successfully
Current state is: RUNNING
IE340CCV#
```

Generate the provisioning package

1. In Cisco Cyber Vision, navigate to Admin > Sensors > Sensor Explorer and click **Install sensor**, then **Manual install**.



The manual install wizard appears.

2. Select **Cisco IOx Application** and click **Next**.

The screenshot shows a web interface titled "Manual install". On the left is a dark sidebar with navigation icons. The main content area has the heading "Select hardware model". Below the heading is a paragraph: "The manual installation is provided to deploy Cisco IOx Sensor, Cisco IC3000 Industrial Compute Gateway and Sentryo sensors. Please select an hardware below to start configuration." There are five radio button options: "Cisco IC3000", "Cisco IOx Application" (which is selected), "Sentryo SENSOR3", "Sentryo SENSOR5", and "Sentryo SENSOR7". At the bottom left is an "Exit" button with a back arrow, and at the bottom right is a "Next" button.

3. Fill the fields to configure the sensor provisioning package:

- The serial number of the hardware.
- Center IP: leave blank.
- Gateway: add if necessary.
- Optionally, select a capture mode.
- Optionally, select RSPAN (only with Catalyst 9x00 and if using ERSPAN is not possible).

Configure provisioning package

Please fill in the fields below to add configuration to the provisioning package to install.

Sensor Application

Serial number*

Center collection IP

leave blank to use current collection IP

Gateway

Capture mode


- Optimal (default): analyze the most relevant flows
- All: analyze all the flows
- Industrial only: analyze industrial flows
- Custom: set your filter using a packet filter in tcpdump-compatible syntax

Monitor session type

- ERSPAN: recommended choice for all devices
- RSPAN: use it only with Catalyst 9X00 and when using ERSPAN is not possible

4. Click **Create sensor**.

- Click the link to download the provisioning package.



This will download the provisioning package which is a zip archive file with the following name structure: sbs-sensor-config-**<serialnumber>**.zip (e.g. "sbs-sensor-configFCW23500HDC.zip").

- Click **Finish**.
- A new entry for the sensor appears in the Sensor Explorer list.

The sensor status will switch from Disconnected to Connected.

<input type="checkbox"/>	Label	IP Address	Version	Location	Health status	Processing status	Active Discovery	Uptime
<input type="checkbox"/>				USB	Disconnected	Disconnected		0h
<input type="checkbox"/>				USB	Disconnected	Disconnected		0h
<input type="checkbox"/>	FCW2445P6X5	192.168.49.21	4.1.0+202202151440		Connected	Pending data	Enabled	4 days

Copy the sensor application provisioning package

- Copy the provisioning package from the USB key to the application using the following command:

```
app-hosting data appid CCVSensor copy usbflash0:sbs-sensor-config-<SERIAL-NUMBER>.zip
sbs-sensor-config-<SERIAL-NUMBER>.zip
```

For example: Cisco IE3400

```
IE340CCV#
IE340CCV#$ data appid CCVSensor copy usbflash0:sbs-sensor-config-FOC2334V01X.zip sbs-sensor-config-FOC2334V01X.zip
Successfully copied file /usbflash0/sbs-sensor-config-FOC2334V01X.zip to CCVSensor as sbs-sensor-config-FOC2334V01X.zip
IE340CCV#
```

Final step

In the sensor's CLI save the product's configuration by typing the following command:

```
write mem
```




CHAPTER 8

Maintenance

- [Upgrade procedures, on page 57](#)
- [Replace SD card, on page 64](#)
- [Reconfigure/Redeploy a sensor, on page 65](#)

Upgrade procedures

Upgrade through the Cisco Cyber Vision sensor management extension

Before updating IOx sensors, the Cisco Cyber Vision sensor management extension must be up-to-date.


It is possible to select which sensors to update. The update status will be visible in the [Management jobs, on page 24](#) page.

Update the sensor management extension

The Cisco Cyber Vision sensor management extension must be up-to-date to update IOx sensors.

Procedure

- Step 1** Retrieve the sensor management extension file (i.e. CiscoCyberVision-sensor-management-<version>.ext) on [cisco.com](#).
- Step 2** In Cisco Cyber Vision, navigate to Admin > Extensions.
- Step 3** Click **Update** to browse the new version of the extension file.



Extensions

From this page, you can manage Cyber Vision Extensions. Extensions are optional add-ons to Cyber Vision Center which provide more features, such as the management of new device types, additional detection engines, or integrations with external services.

Update
Uploading... Please do not quit or refresh the page.

Installed extensions

Name	Version	Actions
Cyber Vision sensor management	4.1.2	Update Remove


Update the sensors

Procedure

Step 1 In Cisco Cyber Vision, navigate to Admin > Sensors > Sensor Explorer.

Sensors that are not up-to-date have their version displayed in red.

Step 2 Click **Install sensor**, then **Update Cisco devices**.



Sensor Explorer

From this page, you can explore and manage sensors and sensors folders. Sensors can be remotely and securely rebo time, you must authorize it so the Center can receive its data.

[Install sensor](#) [Manage Cisco devices](#) [Organize](#)


[Update Cisco devices](#) [Manage credentials](#)

Folders and sensors


Filter 0 Selected MOVE SELECTION TO More Actions

	Label	IP Address	Version	Location	Health status
<input type="checkbox"/>	FOLDER1			Lyon	
<input type="checkbox"/>	FOLDER2			Paris	
<input type="checkbox"/>	IC3000	192.168.49.23	4.1.1+202205161124		Connected
<input type="checkbox"/>	IE3400	192.168.49.21	4.1.2+202207190948		Connected

The update Cisco devices window pops up listing all sensors that have been deployed with the sensor management extension.




Step 3 Select the sensors you want to update.




Step 4 Click **Update**.


The sensors' update status appear in the Management jobs page in batches per sensor type and of maximum ten sensors per batch.



Herebelow the management jobs indicate that the batch of sensors updated successfully.



If the batch update fails, click the red update error icon to see logs.



Upgrade through the IOx Local Manager

The following section explains how to upgrade the sensor through the IOx Local Manager.



Note In the case of Cisco Cyber Vision upgrade for a Catalyst 9x00 from a release 4.1.2 or lower to a release 4.1.3, the update will fail due to the addition of the RSPAN option. The sensor application must be removed and deployed again.

In the example below, the sensor is upgraded from Cisco Cyber Vision version 3.2.2 to version 3.2.3.

Figure 1: The sensor in version 3.2.2 in the Sensors administration page of Cisco Cyber Vision

Sensors

From this page, you can manage sensors in online and offline modes and generate provisioning packages to deploy Cisco Cyber Vision on remote sensors. Sensors can also be remotely and securely rebooted, shut down, and erased. When a sensor connects for the first time, you must authorize it so the Center can receive its data.

Name	IP	Version	Status	Processing status	Active Discovery status	Capture Mode	Uptime
FOC2334V00H	192.168.69.20	3.2.2+202103181619	Connected	Pending data	Unavailable	All	4d 1h 3m 47s
<p>S/N: FOC2334V00H Name: FOC2334V00H IP address: 192.168.69.20 Version: 3.2.2+202103181619 System date (UTC): Monday, May 31, 2021 9:17 AM Status: Connected Processing status: Pending data Active discovery: Unavailable Deployment: Manual Uptime: 4d 1h 32m 47s Capture mode: All Start recording sensor Go to statistics</p>							
FCH2312Y047	192.168.70.20	3.2.2+202103181753	Connected	Pending data	Unavailable	All	3m 27s

[UPDATE CISCO DEVICES](#)
[DEPLOY CISCO DEVICE](#)
[INSTALL SENSOR MANUALLY](#)
[IMPORT OFFLINE FILE](#)

1. Access the IOx Local Manager.
2. Stop the application.

Cisco IE-3400-8T2S 17.3.2a

Configuration > Services > IOx

Cisco Systems
Cisco IOx Local Manager

Applications Remote Docker Workflow Docker Layers System Info System

CyberVisionSensorN... **RUNNING**

Cisco Cyber Vision sensor for aarch64


TYPE: docker VERSION: 3.2.2+202103181622 PROFILE: exclusive

Memory * 100.0%

CPU * 100.0%


Stop Manage

The operation takes a few moments.



The application status switches to STOPPED.


In Cisco Cyber Vision, the sensor status switches to Disconnected.




3. In the IOx Local Manager, click the **Deactivate** button.

The application status moves to DEPLOYED.


4. Click **Upgrade**.




The pop up Upgrade application appears.




5. Select the **Preserve Application Data** option.
6. Select the new version of the application archive file.
e.g. CiscoCyberVision-IOx-aarch64-3.2.3.tar




The operation takes a few moments.



A message indicating that the sensor has been successfully upgraded is displayed.



7. Check the number of the new version.
8. Click **Activate**.



9. Check configurations.

It can happen that network configurations are lost during the upgrade. If they are, refer to Configure the sensor virtual application in the [Procedure with the Local Manager](#) corresponding to the switch used and do as explained.

10. Click the **Activate App** button.

The application status moves to ACTIVATED.

11. Click the **Start** button.

The application status changes to RUNNING.

In Cisco Cyber Vision, the sensor is upgraded from version 3.2.2 to 3.2.3 and its status moves to Connected.

Name	IP	Version	Status	Processing status	Active Discovery status	Capture Mode	Uptime
FOC2334V00H	192.168.69.20	3.2.3+202104292032	Connected	Pending data	Unavailable	All	4d 1h 49m
FCH2312Y047	192.168.70.20	3.2.2+202103181753	Connected	Pending data	Unavailable	All	19m 34s

Replace SD card

This section explains how to replace a SD card on a Cisco IE3x00.

Procedure

Step 1 Connect to the device CLI and use the following commands to disable IoX:

```
configure terminal
no iox
exit
```

Step 2 Replace the SD card.

Step 3 Format the SD card using the following command:

```
format sdflash: ext4
```

```
IE340CCV#format sdflash: ext4
Format operation may take a while. Continue? [confirm]
Format operation will destroy all data in "sdflash:". Continue? [confirm]
format completed with no errors

Format of sdflash: complete
IE340CCV#
```

Step 4 Enable IOx using the following command:

```
configure terminal
iox
```

```
IE340CCV#
IE340CCV#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
IE340CCV(config)#iox
Warning: Do not remove SD flash card when IOx is enabled or errors on SD device could occur.
IE340CCV(config)#
```

Step 5 Follow the instructions described in the following section to redeploy the sensor.

What to do next

[Reconfigure/Redeploy a sensor, on page 65](#)

Reconfigure/Redeploy a sensor

The Redeploy button is used when you need to replace a sensor model with another one keeping the same network configurations (e.g. replacing a Cisco IE3400 with a Cat 9300), change configurations, or if you need to reconfigure the sensor (e.g. to enable Active Discovery).

To do so:

Procedure

Step 1 On the Sensor Explorer page, click the sensor to reconfigure/redeploy. The sensor right side panel appears.

Step 2 Click **Redeploy**.

The screenshot shows the 'Sensor Explorer' interface. On the left is a navigation pane with 'Sensors' selected. The main area displays a table of sensors. The sensor 'FCW2445P6X5' with IP '192.168.49.21' is highlighted. To the right, a details pane shows sensor information and a 'Redeploy' button, which is circled in red.

A pop up asking to confirm the redeployment of the sensor appears.

Step 3 Click **OK** to proceed.

A summary of the sensor configuration is displayed. In this example, we're going to change the Collection VLAN number.

Step 4 Click **Start**.

Redeploy Cisco device

Get Cisco device configuration

The current configuration of your Cisco device enables you to:

- Reconfigure the Cyber Vision IOx sensor app on this device;
- Reconfigure your Cisco device for Cyber Vision (i.e modify the IP address);
- Deploy the Cyber Vision IOx sensor app on a new device using this configuration.

Device IP: 192.168.49.20	Device port: 443
Capture IP address: 169.254.1.2	Capture prefix length: 30
Capture VLAN number: 2508	Collection IP address: 192.168.49.21
Collection prefix length: 24	Collection VLAN number: 507
Use global credentials: No	Disk size: Use as much space as possible
Active Discovery interfaces: 192.168.50.21/24 VLAN#50	

Exit

Start

Step 5 Enter the credentials to reach the sensor to redeploy and click **Connect**.

Redeploy Cisco device

Reach Cisco device

Please fill the fields below to enable Cisco Cyber Vision to reach your device.

IP address*

Port*

For example 443 or 8443

Center collection IP

leave blank to use current collection IP

Credentials

Login*

Password*

[Exit](#)

[Connect](#)

Step 6 Click the blue link to fill the warning fields with the current sensor configuration. We change the Collection VLAN number value to 49.

Redeploy Cisco device

Configure Cyber Vision IOx sensor app

The device requires additional parameters. Some parameters have been pre-filled. Please complete the remaining fields.

 [Click here to fill the warning fields with the current sensor configuration](#)

Cisco device: IE-3400-8T2S

Capture IP address*

Capture prefix length*

Like 24, 16 or 8

Capture VLAN number*

Collection IP address*

Collection prefix length*

Like 24, 16 or 8

Collection gateway

Collection VLAN number*



 Exit

Next

Step 7

Click **Next**.

Step 8

You can enable Active Discovery selecting Passive and Active Discovery.

Step 9

Click **Deploy**.

A message saying that the sensor is being redeployed appears. You can either go the jobs page or go back to the Sensor Explorer page.

Step 10

Click **Go to the jobs page**.

Redeploy Cisco device

Done!

The Cyber Vision IOx sensor application is being redeployed on your device. A job has been created to track deployment progress.

What's next?

[Back to Sensor Explorer](#)

[Go to the jobs page](#)

You are redirected to the [Management jobs](#) to see the redeployment advancement. This can take several minutes.

The screenshot shows the 'Management jobs' page with a sidebar on the left containing navigation options like System, Data Management, Network Organization, Sensors, Sensor Explorer, and Management jobs. The main content area displays a progress bar for a 'Single redeployment (FCW2445P6X5)' job. The progress bar consists of four steps: the first is a green checkmark, the second is a blue checkmark, and the last two are grey circles with a clock icon, indicating they are still in progress. The 'Duration' column shows 'In progress'.

Jobs	Steps	Duration
Single redeployment (FCW2445P6X5)		In progress

If you go back to the Sensor Explorer page, you will see that the sensor is in Redeploying status.

Sensor Explorer

From this page, you can explore and manage sensors and sensors folders. Sensors can be remotely and securely rebooted, shut down, and erased. When a sensor connects for the first time, you must authorize it so the Center can receive its data.

[+ Install sensor](#) [Manage Cisco devices](#) [Organize](#)

Folders and sensors (3)

[Filter](#) 0 Selected Move selection to [More Actions](#) As of: Feb 23, 2022 4:50 PM [Refresh](#)

<input type="checkbox"/>	Label	IP Address	Version	Location	Health status	Processing status	Active Discovery
<input type="checkbox"/>					Disconnected	Disconnected	
<input type="checkbox"/>					Disconnected	Disconnected	
<input type="checkbox"/>	FCW2445P6X5	192.168.49.21			Redeploying	Not enrolled	Unavailable

Once the redeployment is finished, the sensor will switch status to connected and the Active Discovery to Enabled.

<input type="checkbox"/>	FCW2445P6X5	192.168.49.21	4.1.0+202202151440		Connected	Pending data	Enabled	a minute
--------------------------	-------------	---------------	--------------------	--	-----------	--------------	---------	----------

