



# Caching Services Module Commands

---

- [cluster name](#), on page 3
- [cluster config](#), on page 5
- [cluster add](#), on page 6
- [feature enable](#), on page 8
- [flash-copy](#), on page 10
- [host](#), on page 12
- [install module node](#), on page 14
- [interface svc](#), on page 16
- [iogroup](#), on page 18
- [ip](#), on page 19
- [mdisk-grp](#), on page 20
- [migrate vdisk](#), on page 22
- [node](#), on page 23
- [node svc delete](#), on page 24
- [node svc recover](#), on page 25
- [node svc servicemode](#), on page 26
- [node svc upgrade](#), on page 27
- [quorum](#), on page 28
- [remote-copy](#), on page 29
- [show cluster flash-copy](#), on page 31
- [show cluster host](#), on page 32
- [show cluster iogroup](#), on page 33
- [show cluster ip](#), on page 34
- [show cluster mdisk](#), on page 35
- [show cluster mdsik-grp](#), on page 37
- [show cluster nodes](#), on page 38
- [show cluster remote-copy](#), on page 39
- [show cluster remote-copy-cluster](#), on page 40
- [show cluster status](#), on page 41
- [show cluster vdisk](#), on page 42
- [show environment battery](#), on page 43
- [show interface svc](#), on page 45
- [show nodes](#), on page 48

- [show svc](#), on page 50
- [svc-config](#), on page 53
- [svc-ibmcli](#), on page 54
- [svc-purge-wwn module](#), on page 55
- [vdisk](#), on page 56

# cluster name

To perform operations on a previously-configured cluster, use the cluster name command in SVC configuration mode.

```
cluster name cluster-name flash-copy fc-grp-name [prepare | start | stop]
cluster name cluster-name remote-copy rc-grp-name failover|start [aux | clean | force] | stop aux-enable
cluster name cluster-name shutdown [node node-name]
cluster name cluster-name start discovery
cluster name cluster-name upgrade svc-system force
```

Syntax Description		
cluster		Provides access to cluster commands
name cluster-name		Identifies a previously created cluster to perform an operation.
flash-copy fc-grp-name		Specifies a previously-configured FlashCopy relationship.
prepare		Prepares the FlashCopy consistency group.
start		Starts the FlashCopy for the specified cluster. Starts the background copy for the specified remote copy group
stop		Stops the FlashCopy for the specified cluster. Stops the remote copy relationships for the specified remote copy group.
remote-copy rc-grp-name		Specifies the remote copy consistency group name.
failover		Reverses to using the auxiliary VDisks for the specified relationship.
shutdown		Shuts down the entire cluster (gracefully).
node node-name		Specifies a particular node for a graceful shutdown.
start discovery		Starts the background copy for the specified remote copy group.
aux		Makes the auxiliary VDisks as primary.
clean		Marks the intended secondary VDisks as clean.
upgrade svc-system		Upgrades the specified cluster. The new version of the software image is specified to the FTP:, SCP:, SFTP:, TFTP:, bootflash:, or slot0: directories
force		Permits the remote copy operation to start—even if it leads to the loss of data consistency between the primary and secondary.
aux-enable		Enables write access o the secondary (or auxiliary) VDisks.

**Command Default** None.

**Command Modes** SVC configuration mode.

**cluster name****Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).**Usage Guidelines** None.**Examples** The following example enters the SVC configuration mode and displays all options under the cluster name command.

```
switch# svc-config
switch(svc)# cluster name SampleCluster ?
  flash-copy    Flash-copy
  remote-copy   Remote copy
  shutdown      Shutdown
  start         Start discovery
  upgrade       Upgrade uri
switch(svc)# cluster name SampleCluster flash-copy f1 prepare
switch(svc)# cluster name SampleCluster flash-copy f1 start
switch(svc)# cluster name SampleCluster flash-copy f1 stop

switch(svc)# cluster name SampleCluster remote-copy f1 failover
switch(svc)# cluster name SampleCluster remote-copy f1 start
switch(svc)# cluster name SampleCluster remote-copy f1 stop

switch(svc)# cluster name SampleCluster shutdownn
switch(svc)# cluster name SampleCluster shutdown node svc2/1
switch(svc)# cluster name SampleCluster start discovery
switch(svc)# cluster name SampleCluster upgrade svc-system
bootflash:m9000-ek9-csm-svc_mz.1.3.1.bin
```

## cluster config

To manage cluster configurations on a specified cluster, use the `cluster config` configuration submode.

cluster config cluster-name

Syntax Description	cluster	Provides access to cluster commands
	config cluster-name	Places a previously created cluster in the cluster configuration submode (switch(svc-cluster)#).

<b>Command Default</b>	None.				
<b>Command Modes</b>	SVC configuration mode—cluster configuration submode.				
<b>Command History</b>	This command was introduced in Cisco MDS SAN-OS Release 1.3(1).				
<b>Usage Guidelines</b>	None.				
<b>Examples</b>	<p>The following example enters the SVC configuration mode and adds a cluster called SampleCluster.</p> <pre>switch(svc)# cluster config SampleCluster switch(svc-cluster)# </pre>				
<b>Related Commands</b>	<table border="1"> <thead> <tr> <th><b>Command</b></th><th><b>Description</b></th></tr> </thead> <tbody> <tr> <td>show cluster</td><td>Displays configured cluster information.</td></tr> </tbody> </table>	<b>Command</b>	<b>Description</b>	show cluster	Displays configured cluster information.
<b>Command</b>	<b>Description</b>				
show cluster	Displays configured cluster information.				

**cluster add**

# cluster add

To create a cluster with a specified SVC node, use the cluster add command in SVC configuration mode.

```
cluster add cluster-name ip ip-address node svc slot-number/node-number
```

Syntax Description	cluster Provides access to cluster commands
add cluster-name	Specifies a new cluster addition. The cluster name must start with an alphabet and is restricted to 15 alphanumeric characters, including dash (-) and underscore (_). The cluster name cannot be ClusterX, where X is a number.
ip ip-address	Specifies the IP address of the specified cluster. The IP address must be in the same subnet as the switch management IP address.
node svc	Specifies the node's SVC interface
slot-number	Specifies the slot number of the Caching Service Module (CSM).
node-number	Specifies the node number of the SVC instance running on the CSM. This number ranges from 1 to 2 nodes per module.

**Command Default** None.

**Command Modes** SVC configuration mode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** Enter this command while connected to the switch management IP address of a node at which the cluster is being created.

**Examples** The following example enters the SVC configuration mode, verifies the status of previously-configured clusters, and adds a cluster called SampleCluster.

```
switch# svc-config
switch(svc)# show nodes local
-----
Node      cluster      config   cluster      node      sw
          node       status    status     status    version
-----
svc2/1                No        unconfigured free      1.3(1)
svc2/2                No        unconfigured free      1.3(1)
switch(svc)# cluster add SampleCluster ip 10.10.0.1 node svc 2/1
cluster creation going on. Please wait....
```

The status of the newly-added cluster can be verified using the show nodes local command.

```
switch(svc)# show nodes local
-----
Node      cluster      config   cluster      node      sw
          node       status    status     version
```

```
-----  
svc2/1      SampleCluster      Yes  active   active  1.3(1)  
svc2/2      No    unconfigured   free   1.3(1)
```

**Related Commands**

<b>Command</b>	<b>Description</b>
show nodes local	Displays the cluster name and status for all nodes in the switch.

**feature enable**

# feature enable

To enable a specified feature in a cluster, use the feature enable command in the cluster configuration submode.

```
cluster config cluster-name
feature enable capacity number | flash-copy | remote-copy
```

<b>Syntax Description</b>	
cluster	Provides access to cluster commands
config cluster-name	Places a previously created cluster in the cluster configuration submode.
feature enable	Enables a specified feature on this cluster. Three features can be enabled: capacity, flash-copy, or remote-copy
capacity	Configures the virtualization capacity of this cluster.
number	Provides a range from 1- 1677215 Gigabytes.
flash-copy	Enables the flash-copy feature for this cluster.
remote-copy	Enables the remote-copy feature for this cluster.

**Command Default** None.

**Command Modes** SVC configuration mode—cluster configuration submode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** The cluster configuration submode prompt is (switch(svc-cluster)#).

By default, flash-copy and remote-copy are disabled and 0 (zero) GB of virtualization capacity is enabled.

**Examples** The following example enters the cluster configuration submode for the SampleCluster cluster and assigns a size of 4000 Gigabytes. The next two commands enables the flash-copy and remote-copy features for this cluster.

```
switch(svc)# cluster config SampleCluster
switch(svc-cluster)# feature enable ?
    capacity      Cluster enable feature capacity
    flash-copy    Cluster enable feature flash-copy
    remote-copy   Cluster enable feature remote-copy
switch(svc-cluster)# feature enable capacity ?
    <0-2147483647>  Enter the capacity
switch(svc-cluster)# feature enable capacity 4000
switch(svc-cluster)# feature enable flash-copy
switch(svc-cluster)# feature enable remote-copy
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	show cluster name flash-copy	Displays configured flash-copy information for a specified cluster.

Command	Description
show cluster name remote-copy	Displays configured remote copy information for a specified cluster.

**flash-copy**

# flash-copy

To create a snapshot (or point-in-time copy) of a specified VDisk or group of VDisks, use the flash-copy command in the cluster configuration submode.

```
cluster config cluster-name
flash-copy add fcopy-name
flash-copy name fcopy-name map src-vdisk vdisk-name dst-vdisk vdisk-name | [mode copy-on-write
| full rate rate]
flash-copy rename old-name newname new-name
```

Syntax Description	
cluster	Provides access to cluster commands
config cluster-name	Places a previously created cluster in the cluster configuration submode.
flash-copy add fcopy-name	Creates a FlashCopy instance.
flash-copy fcopy-name	Enters the FlashCopy submode for an existing copy name.
map	Creating a mapping between the source and destination VDisks.
src-vdisk vdisk-name	Specifies the source VDisk for the flash copy.
dst-vdisk vdisk-name	Specifies the destination VDisk for the flash copy.
mode	Controls the FlashCopy mode.
copy-on-write	Copies to the source VDisk only if new information is written to it after FlashCopy is initiated (default).
full rate rate	Specifies the background copy rate (ranges from 1 to 100) at which the source VDisk is copied to the destination VDisk even if no new information is written to the source.

**Command Default** None.

**Command Modes** SVC configuration mode—cluster configuration submode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** The cluster configuration submode prompt is (switch(svc-cluster)#).  
The flash-copy submode prompt is switch(svc-cluster-flash-copy)#.

**Examples** The following example enters the cluster configuration mode for the SampleCluster 1 cluster.

```
switch(svc) # cluster config SampleCluster
switch(svc-cluster) # flash-copy f2
switch(svc-cluster-flash-copy) # ?
```

```

Submode Commands:
  exit  Exit from this mode
  map   Flash-copy map
  mode  Flash-copy mode
  no    Negate a command or set its defaults
switch(svc-cluster-flash-copy)# map src-vdisk VDISK1 dst-vdisk DDISK1
switch(svc-cluster-flash-copy)# mode copy-on-write
switch(svc-cluster-flash-copy)# exit
switch(svc-cluster)# flash-copy add FlashC2
switch(svc-cluster)# exit
switch(svc)# show SampleCluster flash-copy
-----
name          status
-----
fccstgrp0     idle_or_copied
f2            idle_or_copied
switch(svc)# show SampleCluster flash-copy f2
Flash-copy mapping 1:
  src vdisk is v2
  dest vdisk is v3
  state is idle_or_copied
  copy rate is 50
  progress 0% done

```

**Related Commands**

<b>Command</b>	<b>Description</b>
show SampleCluster name flash-copy	Displays configured flash-copy information for a specified SampleCluster.

# host

To create or configure hosts, use the host command in the cluster configuration submode.

```
cluster config cluster-name
host add host-name hostport port-wwn
host name host-name hostport port-wwn | map vdisk vdisk-name [SCSI-lun lun-number]
```

<b>Syntax Description</b>	
cluster	Provides access to cluster commands
config cluster-name	Places a previously created cluster in the cluster configuration submode.
host add host-name	Creates a host with one port and assigns the host name.
hostport port-wwn	Specifies a port using the port WWN
host name host-name	Enters the host submode for an existing host name.
map	Maps a previously configured disk to this host.
vdisk vdisk-name	Specifies the VDisk to be mapped to the host.
SCSI-lun lun-number	Specifies a LUN to map the host port. If the LUN number is not specified, the next available number is assigned automatically.

**Command Default** None.

**Command Modes** SVC configuration mode—cluster configuration submode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** The cluster configuration submode prompt is (switch(svc-cluster)#).

The host submode prompt is switch (svc-cluster-host)#+

**Examples** The following example enters the cluster configuration mode for SampleCluster and creates a host called Host1 with one port, adds a second port, and maps the VDisk for Host1, and verifies the configured information for Host1.

```
switch(svc) # cluster config SampleCluster
switch(svc-cluster) # host add Host1 hostport 11:22:33:44:aa:bb:cc:dd
switch(svc-cluster) # host Host1
switch(svc-cluster-host) # ?
Submode Commands:
  exit      Exit from this mode
  hostport  Add pWWN to host
  map       Map vdisk to host
  no        Negate a command or set its defaults
switch(svc-cluster-host) # hostport 22:11:33:55:11:aa:bb:cc
switch(svc-cluster) # host add Host1 hostport 35:66:11:22:aa:bb:22:cc
switch(svc-cluster) # host Host1
```

```
switch(svc-cluster-host) # hostport 35:66:11:22:aa:bb:22:11
switch(svc-cluster-host) # map vdisk Vdisk1
switch(svc-cluster-host) # map vdisk Vdisk1 ssci-lun 10
```

**Related Commands**

Command	Description
show cluster name host	Displays configured host information for a specified cluster.

**install module node**

# install module node

To install the SVC node image, use the install module node command.

```
install module module-number node node-number image svc-system [bootflash: | slot0: | ftp: | sftp: | scp: | svc-image]
```

<b>Syntax Description</b>	install module	Installs the specified image for the CSM.
	module-number	Switching modules:From slot 1 to 4 and 7 to 9 in a Cisco MDS 9500 Series switch.For slot 2 in a Cisco MDS 9200 Series switch.  Supervisor modules:Slot 5 or 6—only on the active supervisor module in a Cisco MDS 9500 Series switch.Slot 1—upgrades both the supervisor and switching parts of the module in a Cisco MDS 9200 Series switch.
	node	Selects the SVC node to install the image.
	node-number	Specifies the node number.
	image svc-system	Specifies the file name of an SVC image.
	bootflash:	Source location for internal bootflash memory
	ftp	URI containing SVC Image.
	scp	URI containing SVC Image.
	sftp	URI containing SVC Image.
	tftp	URI containing SVC Image.
	slot0:	Source location for the CompactFlash memory or PCMCIA card.
	svc-image	The name of the SAN Volume Controller (SVC) image.

---

**Command Default** None.

---

**Command Modes** EXEC mode.

---

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.0(3).

---

**Usage Guidelines** The install module module-number node command installs the new image in the specified node on the CSM module. All previous data in that node is lost.

---

**Examples** The following example shows how to install a new image on an SVC node.

```
switch# install module 2 node 1 image svc-system
scp://root@172.22.93.174/auto/isan-src/MAIN_1_3_0_17t/VegasSW/build/gdb_sb-svc/isan/targetfs/sb-svc.bin
```

```
SVC reimage going on. Please wait
root@172.22.93.174's password:
sb-svc.bin      100% |*****| 45408 KB      00:53
svc 2/1 software reimage succeeded
```

Related Commands	Command	Description
	show version compatibility	Shows the system software that is currently running on the switch

**interface svc**

# interface svc

To configure a SAN Volume Controller (SVC) interface on the Cisco MDS 9000 Family of switches, use the **interface svc** command.

```
interface svc slot_number/node-number
interface svc slot_number/node-number initiator | mgmt | nwwn nwwn-id target vsan vsan-id
interface svc slot_number/node-number [switchport description | shutdown]
```

<b>Syntax Description</b>	interface      Configures a new interface.
svc	Specifies the new interface to be a SVC interface.
slot-number	Specifies the slot number of the Caching Service Module (CSM).
node-number	Specifies the node number of the SVC instance running on the CSM. This number ranges from 1 to 2 nodes per module.
initiator	Configures the initiator or port in the specified VSAN.
mgmt	Configures the management or port in the specified VSAN.
target	Configures the target or port in the specified VSAN.
vsan vsan-id	Specifies the VSAN ID ranging from 1 to 4093.
shutdown	Enables or disables an interface.
nwwn nwwn-id	Configured a non-system allocated nWWN for SVC Node.
switchport description	Assigns a description to the switchport. Restricted to 80 alphanumeric characters.

**Command Default** None.

**Command Modes** Configuration mode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** By default, all three N-port types (initiator, mgmt, and target) are in VSAN 1. Explicitly remove it from VSAN 1 if this is not required by your network.

The VSAN number can be any number from 1 to 4096. Only 64 VSANs for all initiator/mgmt/target are allowed (meaning, you can have initiator in VSANs 1-30, target in VSANs 31-60, and mgmt in VSANs 61-64). If the target, initiator, and mgmt overlap in VSANs, each overlap is also included in the total VSAN count.

A mgmt N-port can only exist in 4 of these 64 VSANs.

You can specify a range of interfaces by issuing a command with the following example format:

```
interface svc 1/1 space , space svc 2/1-2
```

This command configures Slot 1 Node 1 as an SVC interface and simultaneously configures Slot 2, Nodes 1 and 2 as SVC interfaces.

Place the disk, host, and other SVC nodes in the appropriate VSAN for any configuration to be completely established

## Examples

The following example configures the initiator N-port on VSAN 1, the target N-port on VSAN 2, and the management N-port on VSAN 3.

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# interface svc 2/1
switch(config-if)# ?
Interface configuration commands:
  do      EXEC command
  exit   Exit from this submode
  initiator  Configure Initiator traffic for SVC Node
  mgmt    Configure traffic for communication with other SVC Nodes
  no     Negate a command or set its defaults
  nwwn   Configured a non-system allocated nWWN for SVC Node
  shutdown  Enable/disable an interface
  switchport  Configure switchport parameters
  target   Configure Target traffic for SVC Node
switch(config-if)# initiator vsan 1
switch(config-if)# target vsan 2
switch(config-if)# mgmt vsan 3
```

## Related Commands

Command	Description
show interface	Displays an interface configuration for a specified interface.

# iogroup

To assign a name to I/O groups, use the iogroup command in the cluster configuration submode. Use the no form of this command to delete the configured I/O group alias.

```
cluster config cluster-name
iogroup group-id alias alias-name
```

<b>Syntax Description</b>	
cluster	Provides access to cluster commands
config cluster-name	Places a previously created cluster in the cluster configuration submode.
iogroup group-id	Identifies one of four I/O groups in the specified cluster. The ID ranges from 1 to 4.
alias alias-name	Assigns a name to the selected I/O group. The name is restricted to 15 alphanumeric characters.

**Command Default** None.

**Command Modes** SVC configuration mode—cluster configuration submode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** The no iogroup command deletes the alias name, not the I/O group itself.  
The cluster configuration submode prompt is (switch(svc-cluster)#).

**Examples** The following example enters the cluster configuration mode for SampleCluster and configures a new I/O group. The created group is verified using the show cluster name iogroup command

```
switch(svc) # cluster config SampleCluster
switch(svc-cluster) # iogroup 1 alias SampleIOgroup
switch(svc-cluster) # exit
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	show cluster name iogroup	Displays configured I/O group information for a specified cluster.

# ip

To modify the IP address for a cluster, use the ip command in the cluster configuration submode.

```
cluster config cluster-name
  ip ip-address
```

<b>Syntax Description</b>	cluster      Provides access to cluster commands
	config cluster-name      Places a previously created cluster in the cluster configuration submodes.
	ip ip-address      Specifies the IP address of the cluster.

**Command Default** None.

**Command Modes** SVC configuration mode—cluster configuration submode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** The IP address of the cluster can be changed, but not deleted. If you connect using the current cluster IP address, that session is lost when the command completes. You must then reconnect using the new IP address.

The no form of this command is not allowed.

The cluster configuration submode prompt is (switch(svc-cluster)#).

**Examples** The following example enters the cluster configuration mode for SampleCluster, configures the IP address, and verifies by displaying this information

```
switch(svc) # cluster config SampleCluster
switch(svc-cluster) # ip 209.165.200.226
switch(svc) # show cluster SampleCluster ip
cluster ip address is 209.165.200.226
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	show cluster name ip	Displays configured -- information for a specified cluster.

# mdisk-grp

To create and configure a mdisk group, use the mdisk-grp command in the cluster configuration submode.

```
cluster config cluster-name
mdisk-grp add grp-name extent size
mdisk-grp name grp-name --> mdisk id mdisk-id
```

<b>Syntax Description</b>	
cluster	Provides access to cluster commands
config cluster-name	Places a previously created cluster in the cluster configuration submode.
mdisk-grp addgrp-name	Adds a mdisk group.
extent size	Assigns the extent size of the storage allocation for MDisks in this cluster. The extent size can be 16, 32, 64, 128, 256, or 512 MB.
mdisk-grp name grp-name	Enters the mdisk submode of an existing MDisk group.
mdisk id mdisk-id	Assigns the disk ID ranging from 1 to 4096 to the mdisk in the MDisk group submode.

**Command Default** None.

**Command Modes** SVC configuration mode—cluster configuration submode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** The cluster configuration submode prompt is (switch(svc-cluster)#).

The submode prompt for the MDisk group is switch (svc-cluster-mdisk-grp)#+

**Examples** The following example enters the cluster configuration mode for SampleCluster, creates an MDisk group, and adds an MDisk to the group.

```
switch(svc) # cluster config SampleCluster
switch(svc-cluster) # mdisk-grp add Mdisk1 extent 512
switch(svc-cluster) # mdisk-grp name Mdisk1
switch(svc-cluster-mdisk-grp) # mdisk id 3
switch(svc) # show cluster SampleCluster mdisk-grp
-----
name          Capacity      free       extent   number    number    status
              size(MB)      of mdisks of vdisks
-----
finance      7.56 GB     7.56 GB    16        5
            0           online
marketing   6.48 GB     6.48 GB    16        5
            0           online
```

Related Commands	Command	Description
	show cluster name mdisk	Displays configured MDisk group information for a specified cluster.

## **migrate vdisk**

# **migrate vdisk**

To configure data migration from a VDisk, use the `migrate vdisk` command in the cluster configuration submode.

```
cluster config cluster-name  
migrate vdisk vdisk-name new-mdisk-grp grp-name  
migrate vdisk vdisk-name src-mdisk id mdisk-id num-extents number tgt-mdisk id mdisk-id
```

Syntax Description	cluster	Provides access to cluster commands
	config cluster-name	Places a previously created cluster in the cluster configuration submode.
	migrate vdisk vdisk-name	Migrates data from the specified VDisk to a MDisk or MDisk group.
	new-mdisk-grp grp-name	Migrates data to a newly specified MDisk group.
	src-mdisk id mdisk-id	Specifies the source MDisk for data migration.
	num-extents number	Specifies the extents of a VDisk for data migration.
	tgt-mdisk id mdisk-id	Specifies the target MDisk for data migration.

<b>Command Default</b>	None.
<b>Command Modes</b>	SVC configuration mode—cluster configuration submode.
<b>Command History</b>	This command was introduced in Cisco MDS SAN-OS Release 1.3(1).
<b>Usage Guidelines</b>	The cluster configuration submode prompt is (switch(svc-cluster)#).
<b>Examples</b>	The following example enters the cluster configuration mode for SampleCluster, migrates a VDisk to a new MDisk group.

The following example enters the cluster configuration mode for SampleCluster, migrates a VDisk to a new MDisk group.

```
switch(svc)# cluster config SampleCluster
switch(svc-cluster)# migrate vdisk Vdisk2 new-mdisk-grp Group5
switch(svc-cluster)# migrate vdisk Vdisk2 src-mdisk id 3 num-extents 2 tgt-mdisk id 4
```

Related Commands	Command	Description
	show cluster name status migrate	Displays configured MDisk migration status information for a specified cluster.

# node

To add a node to a cluster or to assign a name to a preconfigured node, use the node command in the cluster configuration submode.

```
cluster config cluster-name
node name node-name
node nwwn node-wwn
node iogroup group-id [alias alias-name]
```

<b>Syntax Description</b>	<table border="1"> <tr> <td>cluster config</td><td>Provides access to cluster commands</td></tr> <tr> <td>node</td><td>Adds a specified node to the cluster being configured.</td></tr> <tr> <td>name node-name</td><td>Specifies the node using a 15 alphanumeric characters.</td></tr> <tr> <td>nwwn node-wwn</td><td>Specifies the node using the nWWN with the format hh:hh:hh:hh:hh:hh.</td></tr> <tr> <td>iogroup group-id</td><td>Identifies one of four I/O groups in the specified cluster. The ID ranges from 1 to 4.</td></tr> <tr> <td>alias alias-name</td><td>Assigns a name to the selected node. The name is restricted to 156 alphanumeric characters.</td></tr> </table>	cluster config	Provides access to cluster commands	node	Adds a specified node to the cluster being configured.	name node-name	Specifies the node using a 15 alphanumeric characters.	nwwn node-wwn	Specifies the node using the nWWN with the format hh:hh:hh:hh:hh:hh.	iogroup group-id	Identifies one of four I/O groups in the specified cluster. The ID ranges from 1 to 4.	alias alias-name	Assigns a name to the selected node. The name is restricted to 156 alphanumeric characters.
cluster config	Provides access to cluster commands												
node	Adds a specified node to the cluster being configured.												
name node-name	Specifies the node using a 15 alphanumeric characters.												
nwwn node-wwn	Specifies the node using the nWWN with the format hh:hh:hh:hh:hh:hh.												
iogroup group-id	Identifies one of four I/O groups in the specified cluster. The ID ranges from 1 to 4.												
alias alias-name	Assigns a name to the selected node. The name is restricted to 156 alphanumeric characters.												

**Command Default** None.

**Command Modes** SVC configuration mode—cluster configuration submode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** The cluster configuration submode prompt is (switch(svc-cluster)#).

The node must first be added before assigning an alias name.

The no form of the command deletes the node from the cluster.

**Examples** The following example enters the cluster configuration mode for SampleCluster, adds a node by assigning the nWWN, and associates the node with an alias.

```
switch(svc) # cluster config SampleCluster
switch(svc-cluster) # node nwwn 20:00:00:04:cf:e6:e4:df iogroup 1
switch(svc-cluster) # node nwwn 20:00:00:04:cf:e6:e4:df alias NodeAlias
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	show cluster name nodes	Displays configured node information for a specified cluster.

**node svc delete**

# node svc delete

To delete all cluster configurations from a specific node, use the node svc delete command in SVC configuration mode.

```
node svc slot-number/node-number delete
```

<b>Syntax Description</b>	<table border="1"> <tr> <td>node svc</td><td>Specifies the node's SVC interface</td></tr> <tr> <td>slot-number</td><td>Specifies the slot number of the Caching Service Module (CSM).</td></tr> <tr> <td>node-number</td><td>Specifies the node number of the SVC instance running on the CSM. This number ranges from 1 to 2 nodes per module.</td></tr> <tr> <td>delete</td><td>Deletes a cluster information from the specified node.</td></tr> </table>	node svc	Specifies the node's SVC interface	slot-number	Specifies the slot number of the Caching Service Module (CSM).	node-number	Specifies the node number of the SVC instance running on the CSM. This number ranges from 1 to 2 nodes per module.	delete	Deletes a cluster information from the specified node.
node svc	Specifies the node's SVC interface								
slot-number	Specifies the slot number of the Caching Service Module (CSM).								
node-number	Specifies the node number of the SVC instance running on the CSM. This number ranges from 1 to 2 nodes per module.								
delete	Deletes a cluster information from the specified node.								

**Command Default** None.

**Command Modes** SVC configuration mode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** Use this command if the node has lost communication with a configured cluster.

**Examples** The following example enters the SVC configuration mode and adds a cluster called SampleCluster.

```
switch# svc-config
switch(svc)# node svc 2/1 delete
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	show nodes local	Displays configured node information.

# node svc recover

To initiate cluster recovery on a specified SVC node, use the recover cluster command in SVC configuration mode.

```
node svc slot-number/node-number recover
```

Syntax Description	node svc      Specifies the node's SVC interface
slot-number	Specifies the slot number of the Caching Service Module (CSM).
node-number	Specifies the node number of the SVC instance running on the CSM. This number ranges from 1 to 2 nodes per module.
recover	Initiates recovery for a specified node.

**Command Default** None.

**Command Modes** SVC configuration mode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** Use this command to initiate cluster recovery after a failure. If the output of the show nodes local command displays recovery pause in the node status column.

**Examples** The following example initiates recovery for the SVC node 1 in slot 2.

```
switch# svc-config
switch(svc)# node svc 2/1 recover
```

Related Commands	Command	Description
	show nodes local	Displays configured node information.

**node svc servicemode**

## node svc servicemode

To place a node in service mode, use the servicemode node svc command in SVC configuration mode. Use the no form of the command to remove a node from service mode.

`node svc slot-number/node-number servicemode`

Syntax Description	node svc      Specifies the node's SVC interface
slot-number	Specifies the slot number of the Caching Service Module (CSM).
node-number	Specifies the node number of the SVC instance running on the CSM. This number ranges from 1 to 2 nodes per module.
servicemode	Places a node in service mode.

**Command Default** None.

**Command Modes** SVC configuration mode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** None.

**Examples** The following example enters the SVC configuration mode and places the specified node in service mode.

```
switch# svc-config
switch(svc)# node svc 2/2 servicemode
```

**Related Commands**

Command	Description
show nodes local	Displays configured node information.

# node svc upgrade

To upgrade the software on a specified SVC node, use the upgrade node svc command in SVC configuration mode.

```
node svc slot-number/node-number url upgrade svc-system url
```

Syntax Description	node svc	Specifies the node's SVC interface
	slot-number	Specifies the slot number of the Caching Service Module (CSM).
	node-number	Specifies the node number of the SVC instance running on the CSM. This number ranges from 1 to 2 nodes per module.
	upgrade	Upgrades the image on the specified node.
	svc-system url	Specifies the SVC image to be used. The new version of the software image is specified to the FTP:, SCP:, SFTP:, TFTP:, bootflash:, or slot0: directories

**Command Default** None.

**Command Modes** SVC configuration mode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** This command is valid only if the node is in service mode or the node has been shutdown.

**Examples** The following example enters the SVC configuration mode and displays all options in this mode.

```
switch# svc-config
switch(svc)# node svc 2/1 upgrade svc-system ?
bootflash:  URI containing the system image for SVC
ftp:        URI containing the system image for SVC
scp:        URI containing the system image for SVC
sftp:       URI containing the system image for SVC
slot0:      URI containing the system image for SVC
tftp:       URI containing the system image for SVC
```

## quorum

To set the quorum disk for a cluster, use the `quorum` command in the cluster configuration submode.

```
cluster config cluster-name  
quorum disk [1 | 2 | 3] mdisk disk-id
```

Syntax Description	cluster	Provides access to cluster commands
	config cluster-name	Places a previously created cluster in the cluster configuration submode.
	quorum disk id	Configures one of three quorum disks for the specified cluster. The quorum ID ranges from 1 to 3.
	mdisk mdisk-id	Specifies the MDisk ID (ranges form 1 to 4096).

---

**Command Default** None.

**Command Modes** SVC configuration mode—cluster configuration submode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

<b>Usage Guidelines</b>	The cluster configuration submode prompt is (switch(svc-cluster)#). You can assign one of 3 possible quorum IDs in any desired order.
-------------------------	---

The following example enters the cluster configuration mode for SampleCluster and sets the quorum disk ID.

```
switch(svc) # cluster config SampleCluster  
switch(svc-cluster) # quorum disk 2 mdisk 1
```

# remote-copy

To create a synchronous copy of a specified VDisk or group of VDisks, use the remote-copy command in the cluster configuration submode.

```
cluster config cluster-name
remote-copy add rcopy-name [cluster rcluster-name]
remote-copy rcopy-name map src-vdisk vdisk-name aux-vdisk vdisk-name
```

<b>Syntax Description</b>	cluster	Provides access to cluster commands
	config cluster-name	Places a previously created cluster in the cluster configuration submode.
	remote-copy add rcopy-name	Creates a remote copy instance and assigns a name.
	remote-copy cluster rcluster-name	Specifies the remote cluster name for the consistency group.
	remote-copy rcopy-name	Enters the remote-copy submode for an existing copy object.
	map	Establishes a relationship between the source and destination VDisks.
	src-vdisk vdisk-name	Specifies the source VDisk for the copy creation.
	aux-vdisk vdisk-name	Specifies a VDisk in the remote copy cluster.

**Command Default** None.

**Command Modes** SVC configuration mode—cluster configuration submode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** The cluster configuration submode prompt is (switch(svc-cluster)#).

The remote-copy submode prompt is switch(svc-cluster-remote-copy)#

**Examples** The following example enters the cluster configuration mode for SampleCluster and creates a synchronous copy of a specified disk.

```
switch(svc)# cluster config SampleCluster
switch(svc-cluster)# remote-copy add Rcopy1
switch(svc-cluster)# remote-copy r1
switch(svc-cluster-remote-copy)# ?
Submode Commands:
  exit  Exit from this mode
  map   Remote-copy map
  no    Negate a command or set its defaults
switch(svc-cluster-remote-copy)# map src-vdisk SrcVdisk1 aux-vdisk AuxVdisk1
switch(svc-cluster)# remote-copy add Rcopy1 cluster remote-cluster
switch(svc-cluster)# remote-copy name Rcopy1
```

**remote-copy****Related Commands**

Command	Description
show cluster name remote-copy	Displays configured remote-copy information for a specified cluster.

# show cluster flash-copy

To display configured FlashCopy information for a specified cluster, use the show cluster cluster-name flash-copy command.

```
show cluster cluster-name flash-copy [fcopy-name]
```

<b>Syntax Description</b>	show cluster cluster-name	Specifies a previously created cluster name.
	flash-copy fcopy-name	Displays FlashCopy relationships configured for the specified FlashCopy object.

**Command Default** None.

**Command Modes** SVC configuration mode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** None.

**Examples** The following examples display configured cluster information.

```
switch(svc)# show cluster SampleCluster flash-copy
-----
name          status
-----
fccstgrp0    idle_or_copied
f2           idle_or_copied
switch(svc)# show cluster SampleCluster flash-copy f2
Flash-copy mapping 1:
    src vdisk is v2
    dest vdisk is v3
    state is idle_or_copied
    copy rate is 50
    progress 0% done
```

**show cluster host**

# show cluster host

To display configured host information for a specific cluster, use the show cluster cluster-name host command.

show cluster cluster-name host [host-name | candidate]

<b>Syntax Description</b>	show cluster cluster-name	Specifies a previously created cluster name.
	host	Displays information about hosts and host ports.
	candidate	Lists all candidates that are not part of this entity but are visible to the cluster.
	host-name	Displays information about the specified host.

**Command Default** None.

**Command Modes** SVC configuration mode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** None.

**Examples** The following examples display configured cluster host information.

```
switch(svc)# show SampleCluster host
-----
name          number of ports
-----
oasis15       1
Host1         2
switch(svc)# show SampleCluster host Host1
host Host1:
    Number of port is 2
    Port WWN is 11:22:33:44:aa:bb:cc:dd
    Port WWN is 22:11:33:55:11:aa:bb:cc
    LUN 0: vdisk V1
    LUN 10: vdisk V2
switch(svc)# show cluster SampleCluster host candidate
-----
id      pwwn
-----
1      21:00:00:e0:8b:09:e7:04
```

# show cluster iogroup

To display configured I/O group information for a specified cluster, use the show cluster cluster-name iogroup command.

```
show cluster cluster-name iogroup [group-id]
```

<b>Syntax Description</b>	show cluster cluster-name	Specifies a previously created cluster name.
	iogroup	Identifies one of four I/O groups in the specified cluster.
	group-id	Specifies the iogroup ID (ranges from 1 to 4).

**Command Default** None.

**Command Modes** SVC configuration mode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** None.

**Examples** The following examples display configured cluster iogroup information.

```
switch(svc)# show SampleCluster iogroup
-----
ID      NAME                NODE-COUNT    VLUN_COUNT
-----
1       Sampleio1            2              3
2       io_grp1              0              0
3       io_grp2              0              0
4       io_grp3              0              0
5       recovery_io_grp      0              0
```



**Note** Only four IDs can be used, the fifth I/O group is internally created and is only used for cluster recovery.

```
switch(svc)# show SampleCluster iogroup id 2
Io group id 2:
  Node count is 0
  Host LUN count is 0
  Contains no nodes
```

**show cluster ip**

# show cluster ip

To displays configured ip information for a specified cluster, use the show cluster-name ip command.

```
show cluster cluster-name ip
```

<b>Syntax Description</b>	show cluster cluster-name	Specifies a previously created cluster name.
	ip	Displays the IP address of the specified cluster.

**Command Default** None.

**Command Modes** SVC configuration mode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** None.

**Examples** The following example displays configured cluster ip information.

```
switch(svc)# show SampleCluster ip
cluster ip address is 209.165.200.226
```

# show cluster mdisk

To display configured MDisk information for a specified cluster, use the show cluster cluster-name mdisk command.

```
show cluster cluster-name mdisk candidate | id mdisk-id [extent]
```

<b>Syntax Description</b>	show cluster cluster-name mdisk candidate id mdisk-id extent	Specifies a previously created cluster name. Displays MDisk specific information. Displays all MDisks that are not assigned to a group. Displays details of the specified MDisk ID. Displays information about the specified MDisk's extent.
---------------------------	--	--

**Command Default** None.

**Command Modes** SVC configuration mode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** None.

**Examples** The following examples display configured cluster MDisk information.

```
switch(svc) # show SampleCluster mdisk
-----
id      nwwn                  mdisk-grp    capacity   status
-----
1       20:00:00:04:cf:e6:1b:5b mg1        68.37 GB  online
2       20:00:00:04:cf:e6:e5:32 mg1        68.37 GB  online
3       20:00:00:04:cf:e6:21:a2 mg1        68.37 GB  online
4       20:00:00:04:cf:e6:e1:81 mg1        68.37 GB  online
5       20:00:00:04:cf:e6:e4:df
6       20:00:00:04:cf:e6:1c:fb
7       20:00:00:04:cf:e6:1a:4c
8       20:00:00:04:cf:e6:e4:6b
switch(svc) # show SampleCluster mdisk candidate
-----
id      nwwn                  capacity
-----
5       20:00:00:04:cf:e6:e4:df 68.37 GB
6       20:00:00:04:cf:e6:1c:fb 68.37 GB
7       20:00:00:04:cf:e6:1a:4c 68.37 GB
8       20:00:00:04:cf:e6:e4:6b 68.37 GB
switch(svc) # show cluster SampleCluster mdisk id 1
mdisk id 1 is online
      Is member of mdisk-grp mg1
      Controller node WWN is 20:00:00:04:cf:e6:e4:6b
      Controller port WWN is 22:00:00:04:cf:e6:e4:6b, LUN 00:00:00:00:00:00:00:00
      Controller serial number is 3HZ0KZ8W
```

**show cluster mdisk**

```
Capacity is 68.37 GB
Number of free extents is 2231
switch(svc)# show cluster SampleCluster mdisk id 1 extent
-----
vdisk          number of extents
-----
v1              2144
```

# show cluster mdsik-grp

To display configured MDisk group information for a specified cluster, use the show cluster cluster-name mdisk-grp command.

```
show cluster cluster-name mdisk-grp [grp-name]
```

<b>Syntax Description</b>	show cluster cluster-name	Specifies a previously created cluster name.
	mdisk-grp grp-name	Displays information about a specified MDisk group.

**Command Default** None.

**Command Modes** SVC configuration mode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** None.

**Examples** The following examples display configured cluster information for a MDisk group.

```
switch(svc)# show cluster SampleCluster mdisk-grp
-----
name      Capacity     free     extent      number      number      status
          size(MB)      of mdisks   of vdisks
-----
mg1       410.16 GB   309.16 GB   16        6          1          online
switch(svc)# show cluster SampleCluster mdisk-grp mg1
mdisk-grp mg1 is online
      Total capacity is 410.16 GB
      Free capacity is 309.16 GB
      Extent size is 16 MB
      Number of mdisks is 6
      Number of vdisks using this group is 1
```

**show cluster nodes**

# show cluster nodes

To display configured node information for a specified cluster, use the show cluster cluster-name nodes command.

```
show cluster cluster-name nodes [candidate]
```

<b>Syntax Description</b>	show cluster cluster-name	Specifies a previously created cluster name.
	nodes	Displays information about nodes in this cluster.
	candidate	Lists all candidates that are not part of this entity but are visible to the cluster.

**Command Default** None.

**Command Modes** SVC configuration mode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** None.

**Examples** The following example displays configured cluster information for a specified node.

```
switch(svc)# show cluster SampleCluster nodes
Node node1 is online(3)
    Node WWN is 20:06:00:0b:be:57:73:42
    Serial number is JAB072705JH
    Unique id is 01:00:07:27:30:35:4a:48
    Node is in config mode
    Node is part of iogroup id 1 name io_grp0
Node node2 is online(3)
    Node WWN is 20:08:00:0b:be:57:73:42
    Serial number is JAB076605JH
    Unique id is 01:00:07:66:30:35:4a:48
    Node is in non config mode
    Node is part of iogroup id 1 name io_grp0
switch1(svc)# show cluster SampleCluster nodes candidate
-----
NODE          NWWN
-----
switch1.2.1      20:06:00:05:30:00:8d:e0
```

# show cluster remote-copy

To display configured remote-copy information for a specified cluster, use the show cluster cluster-name remote-copy command.

```
show cluster cluster-name remote-copy [rcopy-name]
```

<b>Syntax Description</b>	show cluster cluster-name	Specifies a previously created cluster name.
	remote-copy	Displays remote copy relationships configured for a specified cluster.
	rcopy-name	Displays the specified remote copy object.

**Command Default** None.

**Command Modes** SVC configuration mode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** None.

**Examples** The following example displays configured cluster information for the specified copy instance.

```
switch(svc)# show cluster SampleCluster remote-copy r1
Remote-copy mapping 1:
    master cluster is SampleCluster
    master vdisk is v6
    aux cluster is c1
    aux vdisk is v7
    status is inconsistent_stopped
    progress 0% done
Remote-copy mapping 2:
    master cluster is SampleCluster
    master vdisk is v8
    aux cluster is c1
    aux vdisk is v9
    status is inconsistent_stopped
    progress 0% done
```

**show cluster remote-copy-cluster**

## show cluster remote-copy-cluster

To display configured remote-copy partnership information for a specified cluster, use the show cluster cluster-name remote-copy-cluster command.

```
show cluster cluster-name remote-copy-cluster [rcopy-name]
```

<b>Syntax Description</b>	show cluster cluster-name	Specifies a previously created cluster name.
	remote-copy-cluster	Displays remote copy relationships configured for a specified cluster.
	rcopy-name	Displays the specified remote copy object.

**Command Default** None.

**Command Modes** SVC configuration mode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** None.

**Examples** The following example displays configured cluster information for the specified copy instance.

```
switch(svc)# show cluster SampleCluster remote-copy-cluster
-----
Cluster      Local/remote      Bandwidth
-----
local-cluster    local          10
remote-cluster   remote         50
```

# show cluster status

To displays progress information for a specified cluster, use the show cluster cluster-name status command.

```
show cluster cluster-name status [flash-copy fcopy-name | remote-copy rcopy-name]
```

<b>Syntax Description</b>	show cluster cluster-name	Specifies a previously created cluster name.
	status	Displays the status of a upgrade or copy process.
	flash-copy	Displays FlashCopy relationships configured for the specified cluster.
	fcopy-name	Displays the specified FlashCopy object.
	remote-copy	Displays remote copy relationships configured for a specified cluster.
	rcopy-name	Displays the specified remote copy object.

**Command Default** None.

**Command Modes** SVC configuration mode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** None.

**Examples** The following examples display configured cluster information.

```
switch(svc)# show cluster SampleCluster status flash-copy fc1
-----
src vdisk      dest vdisk      progress
-----
v1          v2          100% done
v3          v4          100% done
switch(svc)# show cluster SampleCluster status remote-copy rc1
-----
src vdisk      aux vdisk      progress
-----
v5          v6          100% done
v7          v8          100% done
```

**show cluster vdisk**

## show cluster vdisk

To display configured VDisk information for a specified cluster, use the show cluster cluster-name vdisk command.

```
show cluster cluster-name vdisk vdisk-id [extent | mapped_hosts]
```

<b>Syntax Description</b>	show cluster cluster-name	Specifies a previously created cluster name.
	vdisk	Displays configured VDisks in the cluster
	vdisk-id	Displays details of the specified VDisk ID.
	extent	Displays information about the specified MDisk's extent.
	mapped_hosts	Displays information about which hosts are mapped to the specified VDisk.

**Command Default** None.

**Command Modes** SVC configuration mode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** None.

**Examples** The following examples display configured cluster information for VDisks.

```
switch(svc)# show cluster SampleCluster vdisk v1 extent
-----
mdisk id    number of extents
-----
1          2144
2          2144
3          2144
5          11
6          11
7          10
switch(svc)# show cluster SampleCluster vdisk v1 mapped_hosts
-----
host        LUN
-----
oasis15     0
```

# show environment battery

To display status of a battery module for the Caching Services Module (CSM), use the show environment battery command.

`show environment battery module slot-number [detail]`

<b>Syntax Description</b>	show environment battery module slot-number detail	Displays the hardware environment in any Cisco MDS 9000 Family switch. Displays the status of the battery in a CSM. Specifies the slot number of the CSM. Provides detailed information about the CSM battery status.
---------------------------	---	--

**Command Default** None.

**Command Modes** EXEC mode.

**Command History** This command was modified in Release 1.3(1).

**Usage Guidelines** None.

**Examples** The following example displays the current contents of the boot variable.

```
switch# show environment battery module 2
Battery 1:
-----
Voltage      : 10.343 V
Current      : 0.000 A
Temperature   : 23.7 C
Current Capacity : 1571 mAh
Full Capacity    : 2057 mAh
CySampleClustere Count : 3
Last conditioned in : Week 22 2003
Serial Num     : AMB0722009C
Battery 2:
-----
Voltage      : 10.596 V
Current      : 0.000 A
Temperature   : 26.6 C
Current Capacity : 1701 mAh
Full Capacity    : 2032 mAh
CySampleClustere Count : 6
Last conditioned in : Week 22 2003
Serial Num     : AMB0722009R
switch## show environment battery module 2 detail
Battery 1:
-----
Voltage      : 10.338 V
Current      : 0.000 A
Temperature   : 23.7 C
Current Capacity : 1571 mAh
```

show environment battery

```

Full Capacity      : 2057 mAh
Caching Capacity   : 6463 MB
CySampleClustere Count    : 3
Last conditioned in : Week 22 2003
Serial Num        : AMB0722009C
EEPROM version    : 1
Manufacturer Access       : 0x0
Remaining Capacity Alarm  : 0xc8
Remaining Time Alarm     : 0xa
Battery Mode           : 0x6000
AtRate                : 0x0
AtRate Time To Full    : 0xfffff
AtRate Time To Empty   : 0xfffff
AtRate OK              : 0x1
Temperature            : 0xb97
Voltage                : 0x2862
Current                : 0xd
Average Current        : 0x6
Max Error              : 0x2
Relative State of Charge : 0x4c
Absolute State of Charge : 0x4f
Remaining Capacity      : 0x623
Full Charge Capacity   : 0x809
Run Time To Empty      : 0xfffff
Average Time To Empty  : 0xfffff
Average Time To Full   : 0x13f2
Charging Current       : 0x44c
Charging Voltage       : 0x3840
Battery Status          : 0xc0
CySampleClustere Count : 0x3
Design Capacity         : 0x7d0
Design Voltage          : 0x2580
Specification Info      : 0x21
Manufacture Date        : 0x3037
Serial Number           : 0x0
Manufacturer Name       : 0x430a
Device Name             : 0x4207
Device Chemistry         : 0x4e04
Manufacturer Data       : 0x7507
Pack Status & Configuration : 0x2020
VCELL4                  : 0x0
VCELL3                  : 0x0
VCELL2                  : 0x0
VCELL1                  : 0x0
...

```

# show interface svc

You can check the status of a SVC interface at any time by using the show interface svc command.

`show interface svc slot-number/node-number [brief | counters | description]`

Syntax Description	interface range	Displays the interfaces in the specified range.
	brief	Displays brief info of interface.
	counters	Displays the interface counter information.
	description	Displays a description of interface.
	svc	Displays the SAN Volume Controller (SVC) interface.
	slot-number	Specifies the slot number of the Caching Service Module (CSM).
	node-number	Specifies the node number of the SVC instance running on the CSM. This number ranges from 1 to 2 nodes per module.

**Command Default** None

**Command Modes** EXEC

**Command History** This command was modified in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** None.

**Examples** The following examples display configured SVC interface information.

```
switch# show interface svc 2/1
svc2/1 is up
    Node WWN is 10:00:00:00:00:00:00:00
    Fabric WWN is 20:41:00:05:30:00:33:1e
    Target N-port WWN is 27:39:00:05:30:00:33:2a, vsan is 1, FCID is 0x010006
    Initiator N-port WWN is 27:3a:00:05:30:00:33:2a, vsan is 1, FCID is 0x010007
    Mgmt N-port WWN is 27:3b:00:05:30:00:33:2a, vsan is 1, FCID is 0x010008
    5 minutes input rate 16 bits/sec, 2 bytes/sec, 0 frames/sec
    5 minutes output rate 0 bits/sec, 0 bytes/sec, 0 frames/sec
        7 frames input, 736 bytes
        0 discards, 0 errors
        3 frames output, 276 bytes
        0 discards, 0 errors
switch# show interface svc 8/1-2
svc8/1 is down (Administratively down)
    Node WWN is 23:34:00:05:30:00:00:02
    Fabric WWN is 21:c1:00:05:30:00:00:00
    Target N-port WWN is 23:2e:00:05:30:00:00:02, vsan is 1, FCID is 0x000000
    Initiator N-port WWN is 23:2f:00:05:30:00:00:02, vsan is 1, FCID is 0x000000
    Mgmt N-port WWN is 23:30:00:05:30:00:00:02, vsan is 1, FCID is 0x000000
```

show interface svc

```

5 minutes input rate 0 bits/sec, 0 bytes/sec, 0 frames/sec
5 minutes output rate 0 bits/sec, 0 bytes/sec, 0 frames/sec
  0 frames input, 0 bytes
    0 discards, 0 errors
  0 frames output, 0 bytes
    0 discards, 0 errors
svc8/2 is up
  Node WWN is 23:35:00:05:30:00:00:02
  Fabric WWN is 21:c2:00:05:30:00:00:00
  Target N-port WWN is 23:31:00:05:30:00:00:02, vsan is 1, FCID is 0x650003
  Initiator N-port WWN is 23:32:00:05:30:00:00:02, vsan is 1, FCID is 0x650004
  Mgmt N-port WWN is 23:33:00:05:30:00:00:02, vsan is 1, FCID is 0x650005
  5 minutes input rate 0 bits/sec, 0 bytes/sec, 0 frames/sec
  5 minutes output rate 0 bits/sec, 0 bytes/sec, 0 frames/sec
    3268061 frames input, 6602103068 bytes
      0 discards, 2 errors
    3208131 frames output, 6598470800 bytes
      0 discards, 0 errors
switch# show interface brief
-----
Interface  Vsan   Admin Admin Status          FCOT  Oper Oper Port
           Mode   Trunk Mode            Mode  Mode Speed Channel
                                         (Gbps)
-----
fc8/1      1     FX    --  fcotAbsent      --   --   --
...
fc8/32     1     FX    --  fcotAbsent      --   --   --
-----
Interface      Status                      Speed
                           (Gbps)
-----
sup-fc0       up                         1
-----
Interface      Status      IP Address   Speed   MTU
-----
mgmt0        up          172.22.90.21/24 100 Mbps 1500
-----
Interface      Status
-----
svc2/1       down
svc2/2       up
svc4/1       up
svc4/2       up
switch# show interface svc 2/1 counters
svc2/1
  5 minutes input rate 0 bits/sec, 0 bytes/sec, 0 frames/sec 0 ios/sec
  5 minutes output rate 0 bits/sec, 0 bytes/sec, 0 frames/sec 0 ios/sec
  272 frames input, 89764 bytes
    39 input session management frames
      19 plogi, 1 plogi_acc, 13 prli, 1 prli_acc
      2 logo, 0 logo_acc, 0 prlo, 0 prlo_acc
      3 abts, 0 ba_acc, 0 ls_rjt
  28 input I/Os, 28 cmd complete, 0 cmd fail
    24 reads, 4 writes
    0 input errors
    0 input discards
      FCP cmd errors
        0 sess not up, 0 no resources, 0 bad frames
        0 up layer rjt, 0 out of order, 0 proc unexp exch st
        0 drop unexp exch st, 0 no exch match
      FCP Xrdy errors
        0 sess not up, 0 no resources, 0 bad frames
        0 up layer rjt, 0 out of order, 0 proc unexp exch st
        0 drop unexp exch st, 0 no exch match

```

```
FCP status errors
  0 sess not up, 0 no resources, 0 bad frames
  0 up layer rjt, 0 out of order, 0 proc unexp exch st
  0 drop unexp exch st, 0 no exch match
FCP Data errors
  0 sess not up, 0 no resources, 0 bad frames
  0 up layer rjt, 0 out of order, 0 proc unexp exch st
  0 drop unexp exch st, 0 no exch match
  0 Incoming Aborts
232 frames output, 84176 bytes
  35 output session management frames
    6 plogi, 13 plogi_acc, 1 prli, 12 prli_acc
    0 logo, 0 logo_acc, 0 prlo, 0 prlo_acc
    1 abts, 2 ba_acc, 0 ls_rjt
  103 out I/Os, 103 cmd complete, 0 cmd fail
    63 reads, 4 writes
  0 output errors
  0 output discards
  0 out ls aborts
    LS requests while sess not up
      0 cmd 0 data xfers 0 status xfers 0 ds xfers
switch# show interface svc 4/2 description
-----
Interface          Description
-----
svc4/2            SampleInt1
```

**show nodes**

# show nodes

To displays configured information for the CSM, use the show svc command.

```
show nodes {local [detail] | svc slot_number/node-number | version}
```

Syntax Description	nodes show nodes	Displays information about the specified nodes.
local		Displays SVC nodes in the switch.
detail		Displays detailed node information.
svc		Displays node information specific to the SVC interface.
slot-number		Specifies the slot number of the Caching Service Module (CSM).
node-number		Specifies the node number of the SVC instance running on the CSM. This number ranges from 1 to 2 nodes per module.
version		Displays software version information for each node.

**Command Default** None.

**Command Modes** SVC configuration mode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** None.

**Examples** The following example display configured SVC information and statistics.

```
switch(svc)# show nodes local detail
svc2/1:
  Is a config node for cluster SampleCluster
  cluster Status is active
  Node Status is active
svc2/2:
  Is member of cluster SampleCluster
  cluster Status is active
  Node Status is active
switch(svc)# show nodes ?
  local      Show nodes in the switch
  svc       SVC Interface
  version   Show node sw versions in the switch
  <cr>     Carriage Return
switch(svc)# show nodes svc 2/2
svc2/2:
  Is not a member of any cluster
  Cluster Status is unconfigured
  Node Status is free
switch(svc)# show nodes version
```

Node	sw version	state	
svc2/1	1.3(1)	Runtime code	(5)
svc2/2	1.3(1)	Runtime code	(5)

**Related Commands**

Command	Description
svc config	Configures SVC nodes.

**show svc**

## show svc

To displays configured information for the CSM, use the show svc command.

```
show svc port svc slot_number/node-number [detail | initiator | mgmt | target [detail | vsan vsan-id] ] | session [detail | initiator | mgmt | peer-wwn pwwn-id | target [detail | vsan vsan-id] ] | stats xipc [ interface svc slot_number/node-number ]| [module slot-number]
```

<b>Syntax Description</b>	show svc	Displays configured SVC information.
	port	Displays N-port specific SVC information.
	svc	Specifies the new interface to be a SVC interface.
	slot-number	Specifies the slot number of the Caching Service Module (CSM).
	node-number	Specifies the node number of the SVC instance running on the CSM. This number ranges from 1 to 2 nodes per module.
	detail	Displays detailed information for all N ports
	initiator	Displays a SVC node as an initiator in the specified VSAN.
	mgmt	Displays a SVC node as a management node in the specified VSAN.
	target	Displays a SVC node as a target in the specified VSAN.
	vsanvsan-id	Specifies the VSAN ID ranging from 1 to 4093.
	session	Displays information specific to the SVC session.
	peer-wwn pwwn-id	Specifies the port WWN of the target or host, with the format hh:hh:hh:hh:hh:hh:hh:hh.
	stats	Displays SVC statistical information generally used for debugging.
	module slot-number	Specifies the slot number containing the CSM.

**Command Default** None.

**Command Modes** EXEC mode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** None.

**Examples** The following examples display configured SVC information and statistics.

```
switch# show svc session svc 2/1
svc2/1:
    Target N-port WWN is 21:00:00:05:30:00:8d:e0, vsan is 2, FCID is 0x610100
```

```

pWWN 21:00:00:e0:8b:09:f0:04, nWWN 20:00:00:e0:8b:09:f0:04, FCID 0x610000
Initiator N-port WWN is 20:01:00:05:30:00:8d:e0, vsan is 1, FCID is 0xec0100
pWWN 22:00:00:04:cf:e6:e4:6b, nWWN 20:00:00:04:cf:e6:e4:6b, FCID 0xec00d4
pWWN 22:00:00:04:cf:e6:1a:4c, nWWN 20:00:00:04:cf:e6:1a:4c, FCID 0xec00d5
pWWN 22:00:00:04:cf:e6:1c:fb, nWWN 20:00:00:04:cf:e6:1c:fb, FCID 0xec00d6
pWWN 22:00:00:04:cf:e6:e1:81, nWWN 20:00:00:04:cf:e6:e1:81, FCID 0xec00d9
pWWN 22:00:00:04:cf:e6:e4:df, nWWN 20:00:00:04:cf:e6:e4:df, FCID 0xec00da
pWWN 22:00:00:04:cf:e6:21:a2, nWWN 20:00:00:04:cf:e6:21:a2, FCID 0xec00dc
pWWN 22:00:00:04:cf:e6:e5:32, nWWN 20:00:00:04:cf:e6:e5:32, FCID 0xec00e0
pWWN 22:00:00:04:cf:e6:1b:5b, nWWN 20:00:00:04:cf:e6:1b:5b, FCID 0xec00e1
Mgmt N-port WWN is 21:02:00:05:30:00:8d:e0, vsan is 3, FCID is 0x7a0000
pWWN 21:03:00:05:30:00:8d:e0, nWWN 20:07:00:05:30:00:8d:e0, FCID 0x7a0001
switch# show svc session svc 2/1 peer-pwwn 22:00:00:04:cf:e6:e4:6b detail
svc2/1:
    Initiator N-port WWN is 20:01:00:05:30:00:8d:e0, vsan is 1, FCID is 0xec0102
    pWWN 22:00:00:04:cf:e6:e4:6b, nWWN 20:00:00:04:cf:e6:e4:6b, FCID 0xec00d4
        47 frames input, 920 data bytes
        2 ELS pkts, 0 BLS pkts
        0 FCP commands, 0 FCP xfer ready
        20 FCP data frames, 25 FCP status
        0 FCP overrun, 15 FCP underrun
        0 aborts, 0 bad FC2 drops
        0 data excess
        27 frames output, 0 data bytes
        2 ELS pkts, 0 BLS pkts
        25 FCP commands, 0 FCP xfer ready
        0 FCP data frames, 0 FCP status
        0 aborts
        0 open exchanges
switch# show svc port svc 2/1
svc2/1:
    Target N-port in vsan 2 is up
    Port WWN is 21:00:00:05:30:00:8d:e0, FCID is 0x610101
    Initiator N-port in vsan 1 is up
    Port WWN is 20:01:00:05:30:00:8d:e0, FCID is 0xec0102
    Mgmt N-port in vsan 1 is up
    Port WWN is 20:02:00:05:30:00:8d:e0, FCID is 0xec0103
switch# show svc port svc 2/1 target detail
svc2/1:
    Target N-port in vsan 1 is up
    Port WWN is 27:39:00:05:30:00:33:2a, FCID is 0x010006
    0 sessions, 0 closed, 0 in transition
        5 minutes input rate 0 bits/sec, 0 bytes/sec, 0 frames/sec 0 ios/sec
        5 minutes output rate 0 bits/sec, 0 bytes/sec, 0 frames/sec 0 ios/sec
    9 frames input, 1064 bytes
        0 input session management frames
        0 plogi, 0 prli
        0 logo, 0 logo_acc
        0 prlo, 0 prlo_acc
        0 abts, 0 ls_rjt
    0 input I/Os, 0 cmd complete, 0 cmd fail
    0 reads, 0 writes
    0 input errors
    0 input discards
    5 frames output, 388 bytes
        0 output session management frames
        0 plogi_acc, 0 prli_acc
        0 logo, 0 logo_acc
        0 prlo, 0 prlo_acc
        0 ba_acc, 0 ls_rjt
    0 output I/Os, 0 cmd complete, 0 cmd fail
    0 output errors
    0 output discards
switch# show svc session svc 2/1 peer-pwwn 27:46:00:05:30:00:33:2a detail

```

**show svc**

```
svc2/1:  
    Mgmt N-port WWN is 27:3b:00:05:30:00:33:2a, vsan is 1, FCID is 0x010008  
    pWWN 27:46:00:05:30:00:33:2a, nWWN 27:48:00:05:30:00:33:2a, FCID 0x010011  
        19 frames input, 16517 data bytes  
            2 ELS pkts, 0 BLS pkts  
            3 FCP commands, 1 FCP xfer ready  
            10 FCP data frames, 3 FCP status  
            0 FCP overrun, 2 FCP underrun  
            0 aborts, 0 bad FC2 drops  
            0 data excess  
        19 frames output, 16520 data bytes  
            2 ELS pkts, 0 BLS pkts  
            3 FCP commands, 1 FCP xfer ready  
            10 FCP data frames, 3 FCP status  
            0 aborts  
        0 open exchanges  
    FCP Error Stats  
        FCP cmd errors  
            0 sess not up, 0 no resources, 0 bad frames  
            0 up layer rjt, 0 out of order, 0 proc unexp exch st  
            0 drop unexp exch st, 0 no exch match  
        FCP Xfer Rdy errors  
            0 sess not up, 0 no resources, 0 bad frames  
            0 up layer rjt, 0 out of order, 0 proc unexp exch st  
            0 drop unexp exch st, 0 no exch match  
        FCP Status errors  
            0 sess not up, 0 no resources, 0 bad frames  
            0 up layer rjt, 0 out of order, 0 proc unexp exch st  
            0 drop unexp exch st, 0 no exch match  
        FCP Data errors  
            0 sess not up, 0 no resources, 0 bad frames  
            0 up layer rjt, 0 out of order, 0 proc unexp exch st  
            0 drop unexp exch st, 0 no exch match
```

# SVC-config

To perform SAN Volume Controller (SVC) configurations, use the svc-config command.

`svc-config`

Syntax Description	svc-config Enters the SVC configuration mode.
cluster	Provides access to cluster commands.
node	Provides access to node commands.
show	Displays configured SVC information for the specified node.

**Command Default** None.

**Command Modes** EXEC mode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** None.

**Examples** The following example enters the SVC configuration mode and displays all options in this mode.

```
switch# svc-config
switch-sw6(svc) # ?
Submode Commands:
  cluster  Cluster commands
  exit     Exit from this mode
  no       Negate a command or set its defaults
  node    Node commands
  show    Show
```

# svc-ibmcli

To perform SAN Volume Controller (SVC) configurations by using IBM's CLI, use the svc-ibmcli command.

```
svc-ibmcli {cluster-name cluster-name [IBM-CLI-command] | node svc slot-number/node-number [IBM-CLI-command]}
```

Syntax Description	svc-ibmcli	Enters the IBM CLI configuration mode.
cluster-name		Specifies a new cluster.
cluster-name		Specifies a cluster name.
node svc		Specifies a node in the SVC interface.
slot-number		Specifies the slot number of the Caching Service Module (CSM).
node-number		Specifies the node number of the SVC instance running on the CSM. This number ranges from 1 to 2 nodes per module.
IBM-CLI-command		Specifies the IBM TotalStorage command to be executed

**Command Default** None.

**Command Modes** EXEC mode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** When you enter the IBM TotalStorage shell, all future commands are interpreted directly by this shell. Type exit to return to the Cisco MDS switch prompt.

**Examples** The following example enters the SVC configuration mode and displays all options in this mode.

```
switch# svc-ibmcli cluster-name SampleCluster
Attaching to config node for cluster SampleCluster
To exit type 'exit', to abort type '$.'
IBM_svc:admin>
switch# svc-ibmcli node svc 2/1
Attaching to node 2/1
To exit type 'exit', to abort type '$.'
IBM_svc:admin>
```

# svc-purge-wwn module

To remove all configured WWNs for the CSM from the running configuration, use the svc-purge-wwn module command.

`svc-purge-wwn module module-number`

<b>Syntax Description</b>	<table border="1"> <tr> <td><code>svc-purge-wwn</code></td><td>Purges the WWN for the CSM.</td></tr> <tr> <td><code>module module-number</code></td><td>Specifies the slot number for the CSM.</td></tr> </table>	<code>svc-purge-wwn</code>	Purges the WWN for the CSM.	<code>module module-number</code>	Specifies the slot number for the CSM.
<code>svc-purge-wwn</code>	Purges the WWN for the CSM.				
<code>module module-number</code>	Specifies the slot number for the CSM.				

**Command Default** None.

**Command Modes** EXEC mode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** This command also purges all system allocated pWWNs and nWWNs from the system and will never be used again (by the system or by SVC interfaces). New system values will be allocated for all pWWN/nWWNs for the module.

**Examples** The following example enters the SVC configuration mode and displays all options in this mode.

```
switch# svc purge-wwn module 2
!!!WARNING! This command will purge all SVC system allocated
WWNs for the specified module. These WWNs will be lost.
All user configured WWNs will be removed from the
running-config, but not from the startup-config.
This operation can take a long time. Other CLI commands
on the system may be stopped while this operation is
in progress.
Are you sure you want to do this? [Y/N] [N] y
switch#
```

# vdisk

To create a new VDisk or access a new VDisk, use the vdisk command in the cluster configuration submode.

```
cluster config cluster-name
vdisk add vdisk-name iogroup group-id mdisk-grp grp-name capacity number|import [clean|mdisk-list
| preferred-node | sequential]
vdisk name vdisk-name -> expand [capacity | extent mdisk disk-id offset number ] | io-throttle
number [MB] | iogroup | shrink
```

Syntax Description	
cluster	Provides access to cluster commands
config cluster-name	Places a previously created cluster in the cluster configuration submode.
vdisk add vdisk-name	Creates a VDisk of the specified name.
iogroup group-id	Identifies one of four I/O groups in the specified cluster. The ID ranges from 1 to 4. The I/O for the VDisk is serviced by node belonging to that I/O group.
mdisk-grpgrp-name	Specifies an existing MDisk group from which the VDisk storage originates.
capacity	Configures the size of this VDisk.
number	Provides a range from 0- 1677215 Gigabytes.
import	Imports a previously unmanaged disk that contains SVC virtualization data.
clean	Clears all data in the VDisk.
mdisk-list	Specifies a list of MDisks. All disks in this list must be part of the MDisk group
preferred-node	specifies the preferred node within the two nodes in this group to send I/Os for this VDisk
sequential	Specifies a sequential virtualization policy. If this option is not specified, the striped (default) virtualization policy is used.
vdisk vdisk-name	Enters the VDisk submode of an existing VDisk.
expand capacity	Expands the MDisk capacity.
extent	Expands the MDisk by a single extent.
offsetnumber	Offsets the extent.
io-throttle	Limits the amount of I/Os allowed for this VDisk. If MB is not specified, the unit is calculated in I/Os per second.
MB	Specifies the I/O throttling in Megabytes.
shrink	Shrinks the capacity of the VDisk as specified.

**Command Default** None.

**Command Modes** SVC configuration mode—cluster configuration submode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** The cluster configuration submode prompt is (switch(svc-cluster)#).

The VDisk submode prompt is switch (svc-cluster-vdisk) #

Extents are allowed from all MDisks in the list

**Examples** The following example enters the cluster configuration mode for SampleCluster and ---

```

switch(svc) # cluster config SampleCluster
switch(svc-cluster) # vdisk add Vdisk1 iogroup 1 mdisk-grp Mdisk1 ?
    capacity      Vdisk add name iogroup mdisk-grp
    import        Vdisk add import
switch(svc-cluster) # vdisk add Vdisk1 iogroup 1 mdisk-grp Mdisk1 capacity ?
    <0-2147483647> Enter the capacity
switch(svc-cluster) # vdisk add Vdisk1 iogroup 1 mdisk-grp Mdisk1 capacity 5000 ?
    gb  Vdisk add name iogroup mdisk-grp capacity
    mb  Vdisk add name iogroup mdisk-grp capacity
    pb  Vdisk add name iogroup mdisk-grp capacity
    tb  Vdisk add name iogroup mdisk-grp capacity
switch(svc-cluster) # vdisk add Vdisk1 iogroup 1 mdisk-grp Mdisk1 capacity 5000 gb ?
    clean          Vdisk add clean
    mdisk-list     Vdisk add mdisk-list
    preferred-node Vdisk add sequential mdisk
    sequential     Vdisk add sequential
    <cr>           Carriage Return
switch(svc-cluster) # vdisk add VDISK1 iogroup 1 mdisk-grp Mdisk1 capacity 0 gb
switch(svc-cluster) # vdisk VDISK1
switch(svc-cluster-vdisk) # ?
Submode Commands:
    exit          Exit from this mode
    expand         Expand
    io-throttle   Io throttle
    iogroup       Move vdisk to iogroup
    no            Negate a command or set its defaults
    shrink        Shrink capacity
switch(svc-cluster-vdisk) # expand ?
    capacity      Expand capacity
    extent        Expand extent
switch(svc-cluster-vdisk) # io-throttle 0
switch(svc-cluster-vdisk) # shrink capacity 1 ?
    gb            Expand capacity
    mb            Expand capacity
    pb            Expand capacity
    tb            Expand capacity
switch(svc-cluster-vdisk) # exit
switch(svc) # show cluster SampleCluster vdisk
-----
name          capacity    iogroup  mdisk-grp name    policy    status
-----
Vdisk1        100.00 GB   1        Group1      striped   online
Vdisk2        50.00  GB   1        Group2      striped   online
switch(svc) # show cluster SampleCluster vdisk Vdisk1
vdisk Vdisk1 is online

```

```

Capacity is 100.00 GB
Using storage from mdisk-grp Group1
Processed by io group 1
Virtualization policy is striped
Preferred node is 2
switch(svc)# show cluster SampleCluster vdisk Vdisk1 extent
-----
mdisk id  number of extents
-----
1          2134
2          2133
3          2133
switch(svc)# show cluster SampleCluster vdisk Vdisk1 mapped_hosts
-----
host      LUN
-----
Host1      0

```

**Related Commands**

<b>Command</b>	<b>Description</b>
show cluster name vdisk	Displays configured vdisk information for a specified cluster.