



## **Cisco Nexus 3000 Series NX-OS Multicast Routing Command Reference**

First Published: April 2011

Last Modified: August 2015

### **Cisco Systems, Inc.**

[www.cisco.com](http://www.cisco.com)

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco website at [www.cisco.com/go/offices](http://www.cisco.com/go/offices).

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: [www.cisco.com/go/trademarks](http://www.cisco.com/go/trademarks). Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2015 Cisco Systems, Inc. All rights reserved.



**Preface ix**

Audience ix

Document Conventions ix

Related Documentation x

Documentation Feedback xi

Obtaining Documentation and Submitting a Service Request iii-xi

iii-xi

**New and Changed Information 1-1**

**Multicast Routing Commands 2-5**

clear ip igmp event-history 2-6

clear ip igmp groups 2-7

clear ip igmp interface statistics 2-8

clear ip igmp route 2-9

clear ip igmp snooping event-history 2-10

clear ip igmp snooping explicit-tracking vlan 2-11

clear ip igmp snooping statistics vlan 2-12

clear ip mfwd event-history 2-13

clear ip mroute 2-14

clear ip msdp event-history 2-16

clear ip msdp peer 2-17

clear ip msdp policy statistics sa-policy 2-18

clear ip msdp route 2-19

clear ip msdp sa-cache 2-20

clear ip msdp statistics 2-21

clear ip pim event-history 2-22

clear ip pim interface statistics 2-23

clear ip pim policy statistics 2-24

clear ip pim route 2-26

clear ip pim statistics 2-27

clear ip routing multicast event-history 2-28

**REVIEW DRAFT—CISCO CONFIDENTIAL**

clear routing multicast	2-29
feature msdp	2-31
feature pim	2-32
hardware profile multicast max-limit	2-33
hardware profile multicast prefer-source-tree	2-34
hardware profile multicast soak-interval	2-35
hardware profile multicast syslog-threshold	2-37
ip igmp access-group	2-38
ip igmp any-query-destination	2-39
ip igmp enforce-router-alert	2-40
ip igmp event-history	2-41
ip igmp flush-routes	2-43
ip igmp global-leave-ignore-gss-mrt	2-44
ip igmp group-timeout	2-45
ip igmp immediate-leave	2-46
ip igmp join-group	2-47
ip igmp last-member-query-count	2-49
ip igmp last-member-query-response-time	2-50
ip igmp querier-timeout	2-51
ip igmp query-interval	2-52
ip igmp query-max-response-time	2-53
ip igmp query-timeout	2-54
ip igmp report-link-local-groups	2-55
ip igmp report-policy	2-56
ip igmp robustness-variable	2-57
ip igmp snooping (Global)	2-58
ip igmp snooping (VLAN)	2-59
ip igmp snooping event-history	2-60
ip igmp snooping explicit-tracking	2-62
ip igmp snooping fast-leave	2-63
ip igmp snooping last-member-query-interval	2-64
ip igmp snooping link-local-groups-suppression	2-65
ip igmp snooping mrouter interface	2-67
ip igmp snooping optimise-multicast-flood	2-68
ip igmp snooping querier	2-70

**REVIEW DRAFT—CISCO CONFIDENTIAL**

ip igmp snooping report-suppression	2-71
ip igmp snooping static-group	2-73
ip igmp snooping v3-report-suppression (Global)	2-75
ip igmp snooping syslog-threshold	2-76
ip igmp snooping v3-report-suppression (switch profile)	2-77
ip igmp snooping v3-report-suppression (VLAN)	2-78
ip igmp ssm-translate	2-79
ip igmp startup-query-count	2-80
ip igmp startup-query-interval	2-81
ip igmp state-limit	2-82
ip igmp static-oif	2-83
ip igmp syslog-threshold	2-85
ip igmp version	2-86
ip mfwd mstatic	2-87
ip mroute	2-88
ip msdp description	2-90
ip msdp event-history	2-91
ip msdp flush-routes	2-93
ip msdp group-limit	2-94
ip msdp keepalive	2-95
ip msdp mesh-group	2-96
ip msdp originator-id	2-97
ip msdp password	2-98
ip msdp peer	2-99
ip msdp reconnect-interval	2-100
ip msdp sa-interval	2-101
ip msdp sa-limit	2-102
ip msdp sa-policy in	2-103
ip msdp sa-policy out	2-104
ip msdp shutdown	2-105
ip multicast multipath	2-106
ip pim anycast-rp	2-107
ip pim auto-rp listen	2-109
ip pim auto-rp mapping-agent	2-110
ip pim auto-rp mapping-agent-policy	2-112

**REVIEW DRAFT—CISCO CONFIDENTIAL**

ip pim auto-rp rp-candidate	2-113
ip pim auto-rp rp-candidate-policy	2-115
ip pim border	2-116
ip pim bsr bsr-policy	2-117
ip pim bsr-candidate	2-118
ip pim bsr forward	2-120
ip pim bsr listen	2-121
ip pim bsr rp-candidate-policy	2-122
ip pim dr-priority	2-123
ip pim event-history	2-124
ip pim flush-routes	2-126
ip pim hello-authentication ah-md5	2-127
ip pim hello-interval	2-129
ip pim jp-policy	2-130
ip pim log-neighbor-changes	2-132
ip pim neighbor-policy	2-133
ip pim pre-build-spt	2-134
ip pim register-policy	2-135
ip pim register-rate-limit	2-136
ip pim register-source	2-137
ip pim rp-address	2-139
ip pim rp-candidate	2-141
ip pim send-rp-announce	2-143
ip pim send-rp-discovery	2-145
ip pim sg-expiry-timer	2-147
ip pim sparse-mode	2-148
ip pim spt-threshold infinity	2-149
ip pim ssm policy	2-150
ip pim ssm range	2-151
ip pim ssm route-map	2-152
ip pim state-limit	2-153
ip pim use-shared-tree-only	2-155
ip routing multicast event-history	2-156
ip routing multicast holddown	2-158
ip routing multicast software-replicate	2-159

**REVIEW DRAFT—CISCO CONFIDENTIAL**

no switchport 2-160

restart msdp 2-161

restart pim 2-162

**Multicast Routing Show Commands 3-163**

show forwarding distribution ip igmp snooping 3-164

show forwarding distribution multicast 3-165

show forwarding distribution multicast client 3-166

show forwarding distribution multicast outgoing-interface-list 3-167

show forwarding distribution multicast route 3-168

show forwarding multicast outgoing-interface-list 3-170

show forwarding multicast route 3-171

show hardware profile status 3-173

show ip igmp event-history 3-174

show ip igmp groups 3-176

show ip igmp interface 3-177

show ip igmp local-groups 3-179

show ip igmp route 3-180

show ip igmp snooping 3-181

show ip igmp snooping event-history 3-183

show ip igmp snooping explicit-tracking 3-185

show ip igmp snooping groups 3-186

show ip igmp snooping mrouter 3-187

show ip igmp snooping querier 3-188

show ip igmp snooping statistics 3-189

show ip mroute 3-190

show ip mroute summary 3-191

show ip msdp count 3-193

show ip msdp event-history 3-194

show ip msdp mesh-group 3-195

show ip msdp peer 3-196

show ip msdp policy statistics sa-policy 3-197

show ip msdp route 3-198

show ip msdp rpf 3-199

show ip msdp sa-cache 3-200

show ip msdp sources 3-201

## REVIEW DRAFT—CISCO CONFIDENTIAL

show ip msdp summary	3-202
show ip pim event-history	3-203
show ip pim group-range	3-204
show ip pim interface	3-205
show ip pim neighbor	3-207
show ip pim oif-list	3-209
show ip pim policy statistics auto-rp	3-210
show ip pim policy statistics bsr	3-211
show ip pim policy statistics jp-policy	3-212
show ip pim policy statistics neighbor-policy	3-213
show ip pim policy statistics register-policy	3-214
show ip pim route	3-215
show ip pim rp	3-216
show ip pim rp-hash	3-218
show ip pim statistics	3-219
show ip pim vrf	3-220
show ip static-route	3-221
show routing ip multicast event-history	3-222
show routing multicast	3-224
show routing multicast clients	3-226
show running-config igmp	3-228
show running-config msdp	3-229
show running-config pim	3-230
show startup-config igmp	3-231
show startup-config msdp	3-232
show startup-config pim	3-233





## Preface

---

This preface describes the audience, organization, and conventions of the *Cisco Nexus 3000 Series NX-OS Multicast Routing Command Reference*. It also provides information on how to obtain related documentation.

This preface includes the following sections:

- [Audience, page ix](#)
- [Document Conventions, page ix](#)
- [Related Documentation, page x](#)
- [Documentation Feedback, page xi](#)
- [Obtaining Documentation and Submitting a Service Request, page xi](#)

## Audience

This publication is for experienced network administrators who configure and maintain Cisco Nexus Series switches.

## Document Conventions

Command descriptions use these conventions:

Convention	Description
boldface font	Commands and keywords are in boldface.
italic font	Arguments for which you supply values are in italics.
[ ]	Elements in square brackets are optional.
[ x   y   z ]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.

Screen examples use these conventions:

<code>screen font</code>	Terminal sessions and information that the switch displays are in screen font.
<b>boldface screen font</b>	Information that you must enter is in boldface screen font.
<i>italic screen font</i>	Arguments for which you supply values are in italic screen font.
< >	Nonprinting characters, such as passwords, are in angle brackets.
[ ]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

This document uses the following conventions:



#### Note

Means reader *take note*. Notes contain helpful suggestions or references to material not covered in the manual.



#### Caution

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

## Related Documentation

Documentation for the Cisco Nexus 3000 Series Switch is available at the following URL:

[http://www.cisco.com/en/US/products/ps11541/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/ps11541/tsd_products_support_series_home.html)

The documentation set is divided into the following categories:

### Release Notes

The release notes are available at the following URL:

[http://www.cisco.com/en/US/products/ps11541/prod\\_release\\_notes\\_list.html](http://www.cisco.com/en/US/products/ps11541/prod_release_notes_list.html)

### Installation and Upgrade Guides

The installation and upgrade guides are available at the following URL:

[http://www.cisco.com/en/US/products/ps11541/prod\\_installation\\_guides\\_list.html](http://www.cisco.com/en/US/products/ps11541/prod_installation_guides_list.html)

### Command References

The command references are available at the following URL:

[http://www.cisco.com/en/US/products/ps11541/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11541/prod_command_reference_list.html)

### Technical References

The technical references are available at the following URL:

[http://www.cisco.com/en/US/products/ps11541/prod\\_technical\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11541/prod_technical_reference_list.html)

**Configuration Guides**

The configuration guides are available at the following URL:

[http://www.cisco.com/en/US/products/ps11541/products\\_installation\\_and\\_configuration\\_guides\\_list.html](http://www.cisco.com/en/US/products/ps11541/products_installation_and_configuration_guides_list.html)

**Error and System Messages**

The system message reference guide is available at the following URL:

[http://www.cisco.com/en/US/products/ps11541/products\\_system\\_message\\_guides\\_list.html](http://www.cisco.com/en/US/products/ps11541/products_system_message_guides_list.html)

## Documentation Feedback

To provide technical feedback on this document, or to report an error or omission, please send your comments to [nexus3k-docfeedback@cisco.com](mailto:nexus3k-docfeedback@cisco.com). We appreciate your feedback.

## Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see *[What's New in Cisco Product Documentation](#)*.

To receive new and revised Cisco technical content directly to your desktop, you can subscribe to the *[What's New in Cisco Product Documentation RSS feed](#)*. The RSS feeds are a free service.





## New and Changed Information

This chapter provides release-specific information for each new and changed feature in the *Cisco Nexus 3000 Series NX-OS Multicast Routing Command Reference*. The latest version of this document is available at the following Cisco website:

[http://www.cisco.com/en/US/products/ps11541/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/ps11541/tsd_products_support_series_home.html)

To check for additional information about this Cisco NX-OS Release, see the *Cisco Nexus 3000 Series Switch Release Notes* available at the following Cisco website:

[http://www.cisco.com/en/US/products/ps11541/prod\\_release\\_notes\\_list.html](http://www.cisco.com/en/US/products/ps11541/prod_release_notes_list.html)

**Table 1** summarizes the new and changed features for Cisco NX-OS Release 5.x and tells you where they are documented.

**Table 1** *New and Changed Information for Release 5.x*

Feature	Description	Changed in Release	Where Documented
Show ip pim rp	This command throws “process is not running.”	7.0(3)I2(1)	<a href="#">show ip pim rp</a>
Optimized multicast flood	The <b>ip igmp snooping optimised-multicast-flood</b> command has been removed.	7.0(3)I2(1)	<a href="#">ip igmp snooping optimise-multicast-flood</a>
Hardware profile multicast soak-interval	This feature was removed.	7.0(3)I2(1)	<a href="#">hardware profile multicast soak-interval</a>
Ip igmp snooping	This feature has two new sub-options: <ul style="list-style-type: none"> <li><b>group-timeout</b> - Configures the group membership timeout in all VLANs/BDs.</li> <li><b>max-gq-miss</b> - Configures the general query miss count.</li> </ul>	7.0(3)I2(1)	<a href="#">ip igmp snooping (VLAN)</a>
Configurable soak interval. for programming multicast routes to the hardware	This feature was introduced to configure a soak interval for programming multicast routes to the hardware	6.0(2)U3(2)	<a href="#">hardware profile multicast soak-interval</a>
IPv4 Protocol Independent Multicast (PIM) (*, G) state only	This feature was introduced to create the IPv4 PIM (*, G) state only.	5.0(3)U4(1)	<a href="#">ip pim spt-threshold infinity</a>

**Table 1** *New and Changed Information for Release 5.x (continued)*

Feature	Description	Changed in Release	Where Documented
IP PIM Register Source	This feature was introduced to register the IP source address of an interface address other than the outgoing interface address of the designated router (DR) leading toward the rendezvous point (RP).	5.0(3)U4(1)	<a href="#">ip pim register-source</a>
IP Multicast Multipath	This feature was introduced to disable automatic selection of the reverse path forwarding (RPF) interface for multicast when multiple equal cost multipath (ECMP) paths are available.	5.0(3)U4(1)	<a href="#">ip multicast multipath</a>
Syslog Thresholds for System Resources	This feature was introduced.	5.0(3)U3(2)	<a href="#">hardware profile multicast syslog-threshold</a> <a href="#">ip igmp snooping syslog-threshold</a> <a href="#">ip igmp syslog-threshold</a>
MSDP Source-Active (SA) registration for remote sources	This feature was introduced to register multicast forwarding (MFWD) static routes.	5.0(3)U2(1)	<a href="#">clear ip mfwd event-history</a> <a href="#">ip mfwd mstatic</a> <a href="#">show ip mroute</a>
Maximum Response Time (MRT) for IGMP global leave messages	The <b>ip igmp global-leave-ignore-gss-mrt</b> command was added.	5.0(3)U1(2)	<a href="#">ip igmp global-leave-ignore-gss-mrt</a>

**Table 1**      ***New and Changed Information for Release 5.x (continued)***

<b>Feature</b>	<b>Description</b>	<b>Changed in Release</b>	<b>Where Documented</b>
Prevent duplicate packets during a rendezvous point tree (RPT) to the shortest path tree (SPT) switchover	The <b>hardware profile multicast prefer-source-tree</b> command was added.	5.0(3)U1(2)	<a href="#">hardware profile multicast prefer-source-tree</a>
Multicast Routing	<p>This feature was introduced.</p> <p>The following Layer 3 multicast routing features are supported in this release:</p> <ul style="list-style-type: none"> <li>• Internet Group Management Protocol (IGMP)</li> <li>• Internet Group Management Protocol (IGMP) snooping</li> <li>• Protocol Independent Multicast (PIM) <ul style="list-style-type: none"> <li>– PIM Sparse Mode (PIM-SM)</li> <li>– PIM Source Specific Multicast (PIM-SSM)</li> <li>– PIM static Rendezvous Point (RP)</li> <li>– PIM Auto-RP</li> <li>– PIM bootstrap router (BSR)</li> <li>– PIM Anycast-RP</li> </ul> </li> <li>• Multicast Source Discovery Protocol (MSDP)</li> </ul>	5.0(3)U1(1)	<a href="#">Multicast Routing Commands</a> <a href="#">Multicast Routing Show Commands</a>







# Multicast Routing Commands

---

This chapter describes the Cisco NX-OS multicast routing commands available on Cisco Nexus 3000 Series switches.

# clear ip igmp event-history

To clear information in the IGMP event history buffers, use the **clear ip igmp event-history** command.

```
clear ip igmp event-history {cli | debugs | errors | events | ha | igmp-internal | mtrace | policy |
                             vrf}
```

## Syntax Description

<b>cli</b>	Clears the CLI event history buffer.
<b>debugs</b>	Clears the debug event history buffer.
<b>events</b>	Clears the event history buffer.
<b>ha</b>	Clears the high availability (HA) event history buffer.
<b>igmp-internal</b>	Clears the IGMP internal event history buffer.
<b>mtrace</b>	Clears the mtrace event history buffer.
<b>policy</b>	Clears the policy event history buffer.
<b>vrf</b>	Clears the virtual routing and forwarding (VRF) event history buffer.

## Command Default

None

## Command Modes

Any command mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

This command does not require a license.

## Examples

This example shows how to clear information in the IGMP HA event history buffer:

```
switch(config)# clear ip igmp event-history ha
switch(config)#
```

## Related Commands

Command	Description
<b>ip igmp event-history</b>	Configures the size of the IGMP event history buffers.

# clear ip igmp groups

To clear IGMP-related information in the IPv4 multicast routing table, use the **clear ip igmp groups** command.

```
clear ip igmp groups { * | group [source] | group-prefix } [vrf { vrf-name | all | default | management }]
```

Syntax Description		
	<b>*</b>	Specifies all routes.
	<i>group</i>	Group address in the format <i>A.B.C.D</i> .
	<i>source</i>	(Optional) Source (S, G) route.
	<i>group-prefix</i>	Group prefix in the format <i>A.B.C.D/length</i> .
	<b>vrf</b>	(Optional) Clears the virtual routing and forwarding (VRF) instance information.
	<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
	<b>all</b>	Specifies that all VRF entries be cleared from the IPv4 multicast routing table.
	<b>default</b>	Specifies that the default VRF entry be cleared from the IPv4 multicast routing table.
	<b>management</b>	Specifies that the management VRF entry be cleared from the IPv4 multicast routing table.

**Command Default** None

**Command Modes** Any command mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** The **clear ip igmp route** command is an alternative form of this command.  
This command does not require a license.

**Examples** This example shows how to clear all the IGMP-related routes in the IPv4 multicast routing table:

```
switch(config)# clear ip igmp groups *
switch(config)#
```

Related Commands	Command	Description
	<b>clear ip igmp route</b>	Clears IGMP-related information in the IPv4 multicast routing table.
	<b>show ip mroute</b>	Displays information about the IPv4 multicast routing table.

# clear ip igmp interface statistics

To clear the IGMP statistics for an interface, use the **clear ip igmp interface statistics** command.

**clear ip igmp interface statistics** [**ethernet** *slot/port* | **loopback** *if\_number* | **port-channel** *number*[*.sub\_if\_number*]]

## Syntax Description

<b>ethernet</b> <i>slot/port</i>	(Optional) Specifies the Ethernet interface and the slot number and port number. The slot number is from 1 to 255, and the port number is from 1 to 128.
<b>loopback</b> <i>if_number</i>	(Optional) Specifies the loopback interface. The loopback interface number is from 0 to 1023.
<b>port-channel</b> <i>number</i>	(Optional) Specifies the EtherChannel interface and EtherChannel number. The range is from 1 to 4096.
<i>sub_if-number</i>	(Optional) Subinterface number. The range is from 1 to 4093.

## Command Default

None

## Command Modes

Any command mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

This command does not require a license.

## Examples

This example shows how to clear IGMP statistics for an interface:

```
switch# clear ip igmp interface statistics ethernet 2/1
switch#
```

## Related Commands

Command	Description
<b>show ip igmp interface</b>	Displays information about IGMP interfaces.

# clear ip igmp route

To clear IGMP-related information in the IPv4 multicast routing table, use the **clear ip igmp route** command.

```
clear ip igmp route { * | group [source] | group-prefix } [vrf { vrf-name | all | default | management }]
```

Syntax Description		
	<b>*</b>	Specifies all routes.
	<i>group</i>	Group address in the format <i>A.B.C.D</i> .
	<i>source</i>	(Optional) Source (S, G) route.
	<i>group-prefix</i>	Group prefix in the format <i>A.B.C.D/length</i> .
	<b>vrf</b>	(Optional) Clears the virtual routing and forwarding (VRF) instance information.
	<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
	<b>all</b>	Specifies that all VRF entries be cleared from the IPv4 multicast routing table.
	<b>default</b>	Specifies that the default VRF entry be cleared from the IPv4 multicast routing table.
	<b>management</b>	Specifies that the management VRF entry be cleared from the IPv4 multicast routing table.

**Command Default** None

**Command Modes** Any command mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** The **clear ip igmp groups** command is an alternative form of this command.  
This command does not require a license.

**Examples** This example shows how to clear all the IGMP-related routes in the IPv4 multicast routing table:

```
switch(config)# clear ip igmp route *
switch(config)#
```

Related Commands	Command	Description
	<b>clear ip igmp groups</b>	Clears IGMP-related information in the IPv4 multicast routing table.
	<b>show ip mroute</b>	Displays information about the IPv4 multicast routing table.

# clear ip igmp snooping event-history

To clear information from IGMP snooping event history buffers, use the **clear ip igmp snooping event-history** command.

```
clear ip igmp snooping event-history { rib | igmp-snoop-internal | mfdm | mfdm-sum | vlan |
                                     vlan-events }
```

## Syntax Description

<b>rib</b>	Clears the unicast Routing Information Base (RIB) event history buffer.
<b>igmp-snoop-internal</b>	Clears the IGMP snooping internal event history buffer.
<b>mfdm</b>	Clears the multicast FIB distribution (MFDM) event history buffer.
<b>mfdm-sum</b>	Clears the MFDM sum event history buffer.
<b>vlan</b>	Clears the VLAN event history buffer.
<b>vlan-events</b>	Clears the VLAN-events event history buffer.

## Command Default

None

## Command Modes

Any command mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

This command does not require a license.

## Examples

This example shows how to clear information in the IGMP snooping VLAN event history buffer:

```
switch(config)# clear ip igmp event-history vlan
switch(config)#
```

## Related Commands

Command	Description
<b>ip igmp snooping event-history</b>	Configures the size of the IGMP snooping event history buffers.

# clear ip igmp snooping explicit-tracking vlan

To clear the IGMP snooping explicit host tracking information for VLANs, use the **clear ip igmp snooping explicit-tracking vlan** command.

**clear ip igmp snooping explicit-tracking vlan** *vlan-id*

<b>Syntax Description</b>	<i>vlan-id</i> VLAN number. The range is from 1 to 3968 and 4049 to 4093.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Any command mode				
<b>Command History</b>	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>5.0(3)U1(1)</td><td>This command was introduced.</td></tr></table>	Release	Modification	5.0(3)U1(1)	This command was introduced.
Release	Modification				
5.0(3)U1(1)	This command was introduced.				
<b>Usage Guidelines</b>	This command does not require a license.				
<b>Examples</b>	<p>This example shows how to clear the explicit tracking information for VLAN 1:</p> <pre>switch# clear ip igmp snooping explicit-tracking vlan 1 switch#</pre>				
<b>Related Commands</b>	<table><tr><th>Command</th><th>Description</th></tr><tr><td><b>show ip igmp snooping explicit-tracking vlan</b></td><td>Displays explicit host tracking information for IGMPv3.</td></tr></table>	Command	Description	<b>show ip igmp snooping explicit-tracking vlan</b>	Displays explicit host tracking information for IGMPv3.
Command	Description				
<b>show ip igmp snooping explicit-tracking vlan</b>	Displays explicit host tracking information for IGMPv3.				

# clear ip igmp snooping statistics vlan

To clear the IGMP snooping statistics for VLANs, use the **clear ip igmp snooping statistics vlan** command.

**clear ip igmp snooping statistics vlan** [*vlan-id* | **all**]

Syntax Description	<i>vlan-id</i>	(Optional) VLAN number. The range is from 1 to 3968 and 4049 to 4093.
	<b>all</b>	(Optional) Applies to all VLANs.

Command Default	All VLANs
-----------------	-----------

Command Modes	Any command mode
---------------	------------------

Command History	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines	This command does not require a license.
------------------	--

Examples	<p>This example shows how to clear IGMP snooping statistics for VLAN 1:</p> <pre>switch# clear ip igmp snooping statistics vlan 1 switch#</pre>
----------	---

Related Commands	<b>Command</b>	<b>Description</b>
	<b>show ip igmp snooping statistics vlan</b>	Displays IGMP snooping statistics by VLAN.



# clear ip mfwd event-history

To clear the multicast forwarding (MFWD) static routes, use the **clear ip mfwd event-history** command.

**clear ip mfwd event-history**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Any command mode
----------------------	------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U2(1)	This command was introduced.

<b>Examples</b>	This example shows how to clear the multicast forwarding static routes configured on the switch:
-----------------	--

<pre>switch# clear ip mfwd event-history switch#</pre>
--

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	ip mfwd mstatic	Registers multicast forwarding static routes.

# clear ip mroute

To clear the multicast routing table, use the **clear ip mroute** command.

**clear ip mroute** { \* | *group* [*source*] } [**vrf** { *vrf-name* | **all** | **default** | **management** }]

## Syntax Description

<b>*</b>	Specifies all mismatched routes between the hardware and software multicast routing tables.
<i>group</i>	Multicast group address in the format <i>A.B.C.D</i> . <b>Note</b> Make sure that you provide an address that is not a reserved multicast address.
<i>source</i>	(Optional) Source (S, G) route.
<b>vrf</b>	(Optional) Clears the virtual routing and forwarding (VRF) instance information.
<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
<b>all</b>	Specifies that all VRF entries be cleared from the multicast routing table.
<b>default</b>	Specifies that the default VRF entry be cleared from the multicast routing table.
<b>management</b>	Specifies that the management VRF entry be cleared from the multicast routing table.

## Command Default

None

## Command Modes

Any command mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

The **clear routing multicast** command is an alternative form of this command.

This command is used to delete routes from the multicast Forwarding Information Base (FIB). It is generally used to clear the mismatched routes in the hardware and software multicast routing tables. When routes are cleared from the multicast FIB, the individual processes (such as PIM, IGMP) that create the routes would repopulate the routes into the multicast FIB.

The **clear ip mroute \*** command does not permanently delete the routes from the multicast routing table. To delete the routes permanently from the multicast routing table, use the following **clear** commands to remove the routes for each process:

- **clear ip pim route**
- **clear ip igmp groups**

This command does not require a license.

## Examples

This example shows how to clear the mismatched routes in the multicast routing table:

```
switch# clear ip mroute *
```

This command does not clear mroutes permanently, Please use clear commands from all mroute owners:

Pim : clear ip pim route

IGMP: clear ip igmp groups

IP/MFWD: clear ip mfwd mroute

to avoid owner process from repopulating routes into multicast routing table.

For further information regarding this behavior please check documentation.

```
switch#
```

## Related Commands

Command	Description
<b>clear ip pim route</b>	Clears the routes specific to Protocol Independent Multicast (PIM) for IPv4.
<b>clear ip igmp groups</b>	Clears the IGMP-related information in the IPv4 multicast routing table.
<b>clear routing multicast</b>	Clears the multicast routing table.
<b>show ip mroute</b>	Displays information about the multicast routing table.

# clear ip msdp event-history

To clear information in the Multicast Source Discovery Protocol (MSDP) event history buffers, use the **clear ip msdp event-history** command.

**clear ip msdp event-history**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** Any command mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** This command requires the LAN Base Services license.

**Examples** This example shows how to clear information in the MSDP event history buffers:

```
switch(config)# clear ip msdp event-history
switch(config)#
```

Related Commands	Command	Description
	<b>ip msdp event-history</b>	Configures the size of the MSDP event history buffers.
	<b>show ip msdp event-history</b>	Displays information in the MSDP event history buffers.

# clear ip msdp peer

To clear a TCP connection to Multicast Source Discovery Protocol (MSDP) peers, use the **clear ip msdp peer** command.

**clear ip msdp peer** *peer-address* [**vrf** {*vrf-name* | **default** | **management**}]

## Syntax Description

<i>peer-address</i>	IP address of the MSDP peer.
<b>vrf</b>	(Optional) Clears the virtual routing and forwarding (VRF) instance information.
<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
<b>default</b>	Specifies that the default VRF entry be cleared from the multicast routing table.
<b>management</b>	Specifies that the management VRF entry be cleared from the multicast routing table.

## Command Default

None

## Command Modes

Any command mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

This command requires the LAN Base Services license.

## Examples

This example shows how to clear a TCP connection to an MSDP peer:

```
switch# clear ip msdp peer 192.168.1.10
switch#
```

## Related Commands

Command	Description
<b>show ip msdp peer</b>	Displays information about MSDP peers.

# clear ip msdp policy statistics sa-policy

To clear the Source-Active (SA) policy for Multicast Source Discovery Protocol (MSDP) peers, use the **clear ip msdp policy statistics sa-policy** command.

**clear ip msdp policy statistics sa-policy** *peer-address* {**in** | **out**} [**vrf** {*vrf-name* | **default** | **management**}]

## Syntax Description

<i>peer-address</i>	IP address of the MSDP peer for the SA policy.
<b>in</b>	Specifies the input policy.
<b>out</b>	Specifies the output policy.
<b>vrf</b>	(Optional) Clears the virtual routing and forwarding (VRF) instance information.
<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
<b>default</b>	(Optional) Specifies that the default VRF entry be cleared from the multicast routing table.
<b>management</b>	(Optional) Specifies that the management VRF entry be cleared from the multicast routing table.

## Command Default

None

## Command Modes

Any command mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

This command requires the LAN Base Services license.

## Examples

This example shows how to clear an SA policy for an MSDP peer:

```
switch# clear ip msdp policy statistics sa-policy
switch#
```

## Related Commands

Command	Description
<b>show ip msdp peer</b>	Displays information about MSDP peers.

# clear ip msdp route

To clear routes that match group entries in the Multicast Source Discovery Protocol (MSDP) Source-Active (SA) cache, use the **clear ip msdp route** command.

**clear ip msdp route** { \* | *group* | *group-prefix* } [**vrf** { *vrf-name* | **all** | **default** | **management** }]

Syntax Description		
*		Specifies all sources for the group from the SA cache.
<i>group</i>		Group address in the format <i>A.B.C.D</i> .
<i>group-prefix</i>		Group prefix in the format <i>A.B.C.D/length</i> .
<b>vrf</b>		(Optional) Clears the virtual routing and forwarding (VRF) instance information.
<i>vrf-name</i>		VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
<b>all</b>		Specifies that all VRF entries be cleared from the SA-cache.
<b>default</b>		Specifies that the default VRF entry be cleared from the SA-cache.
<b>management</b>		Specifies that the management VRF entry be cleared from the SA-cache.

**Command Default** None

**Command Modes** Any command mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** You can also use the **clear ip msdp sa-cache** command for the same function. This command requires the LAN Base Services license.

**Examples** This example shows how to clear the MSDP SA cache:

```
switch# clear ip msdp route *
switch#
```

Related Commands	Command	Description
	<b>clear ip msdp sa-cache</b>	Clears the MSDP SA cache.

# clear ip msdp sa-cache

To clear routes that match group entries in the Multicast Source Discovery Protocol (MSDP) Source-Active (SA) cache, use the **clear ip msdp sa-cache** command.

**clear ip msdp sa-cache** { \* | *group* | *group-prefix* } [**vrf** { *vrf-name* | **all** | **default** | **management** }]

## Syntax Description

<b>*</b>	Specifies all sources for the group from the SA cache.
<i>group</i>	Group address in the format <i>A.B.C.D</i> .
<i>group-prefix</i>	Group prefix in the format <i>A.B.C.D/length</i> .
<b>vrf</b>	(Optional) Clears the virtual routing and forwarding (VRF) instance information.
<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
<b>all</b>	Specifies that all VRF entries be cleared from the SA-cache.
<b>default</b>	Specifies that the default VRF entry be cleared from the SA-cache.
<b>management</b>	Specifies that the management VRF entry be cleared from the SA-cache.

## Command Default

None

## Command Modes

Any command mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

You can also use the **clear ip msdp route** command for the same function.  
This command requires the LAN Base Services license.

## Examples

This example shows how to clear the MSDP SA cache:

```
switch# clear ip msdp sa-cache
switch#
```

## Related Commands

Command	Description
<b>clear ip msdp route</b>	Clears the MSDP SA cache.
<b>show ip msdp sa-cache</b>	Displays route information in the MSDP Source-Active cache.



# clear ip msdp statistics

To clear statistics for Multicast Source Discovery Protocol (MSDP) peers, use the **clear ip msdp statistics** command.

**clear ip msdp statistics** [*peer-address*] [**vrf** *vrf-name* | **default** | **management**]

## Syntax Description

<i>peer-address</i>	(Optional) IP address of the MSDP peer.
<b>vrf</b>	(Optional) Clears the virtual routing and forwarding (VRF) instance information.
<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
<b>default</b>	(Optional) Specifies that the default VRF entry be cleared from the multicast routing table.
<b>management</b>	(Optional) Specifies that the management VRF entry be cleared from the multicast routing table.

## Command Default

None

## Command Modes

Any command mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

This command requires the LAN Base Services license.

## Examples

This example shows how to clear MSDP statistics for all MSDP peers:

```
switch# clear ip msdp statistics
switch#
```

## Related Commands

Command	Description
<b>show ip msdp peer</b>	Displays information about MSDP peers.

# clear ip pim event-history

To clear information in the IPv4 Protocol Independent Multicast (PIM) event history buffers, use the **clear ip pim event-history** command.

**clear ip pim event-history**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** Any command mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** This command requires the LAN Base Services license.

**Examples** This example shows how to clear information in the PIM event history buffers:

```
switch(config)# clear ip pim event-history
switch(config)#
```

Related Commands	Command	Description
	<b>ip pim event-history</b>	Configures the size of the PIM event history buffers.
	<b>show ip pim event-history</b>	Displays information in the PIM event history buffers.

# clear ip pim interface statistics

To clear Protocol Independent Multicast (PIM) counters for a specified interface, use the **clear ip pim interface statistics** command.

**clear ip pim interface statistics** [**ethernet** *slot/port* | **port-channel** *channel-number*[*.sub\_if-number*] | **vlan** *vlan-id*]

<b>Syntax Description</b>	<b>ethernet</b> <i>slot/port</i>	(Optional) Specifies the Ethernet interface. The slot number is from 1 to 255, and the port number is from 1 to 128.
	<b>port-channel</b> <i>number</i>	(Optional) Specifies the EtherChannel interface and EtherChannel number. The range is from 1 to 4096.
	<i>sub_if-number</i>	(Optional) Subinterface number. The range is from 1 to 4093.
	<b>vlan</b> <i>vlan-id</i>	(Optional) Specifies the VLAN. The range is from 1 to 4094.

**Command Default** None

**Command Modes** Any command mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** This command requires the LAN Base Services license.

**Examples** This example shows how to clear the PIM counters for a specified interface:

```
switch# clear ip pim interface statistics ethernet 2/1
switch#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	show ip pim statistics	Displays PIM statistics.

# clear ip pim policy statistics

To clear Protocol Independent Multicast (PIM) policy counters, use the **clear ip pim policy statistics** command.

```
clear ip pim policy statistics {jp-policy | neighbor-policy} {ethernet slot/port | port-channel
channel-number[.sub_if-number] | vlan vlan-id}
```

```
clear ip pim policy statistics register-policy [vrf {vrf-name | all | default | management}]
```

## Syntax Description

<b>jp-policy</b>	Specifies statistics for the join-prune policy.
<b>neighbor-policy</b>	Specifies statistics for the neighbor policy.
<b>ethernet</b> <i>slot/port</i>	Specifies the Ethernet interface and the slot number and port number. The slot number is from 1 to 255, and the port number is from 1 to 128.
<b>port-channel</b> <i>number</i>	Specifies the EtherChannel interface and EtherChannel number. The range is from 1 to 4096.
<i>sub_if-number</i>	(Optional) Subinterface number. The range is from 1 to 4093.
<b>vlan</b>	Specifies the VLAN.
<i>vlan-id</i>	VLAN number. The range is from 1 to 4094.
<b>register-policy</b>	Specifies statistics for the register policy.
<b>vrf</b>	(Optional) Clears the virtual routing and forwarding (VRF) instance information.
<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
<b>all</b>	Specifies that all VRF entries be cleared from the IPv4 multicast routing table.
<b>default</b>	Specifies that the default VRF entry be cleared from the IPv4 multicast routing table.
<b>management</b>	Specifies that the management VRF entry be cleared from the IPv4 multicast routing table.

## Command Default

None

## Command Modes

Any command mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

This command requires the LAN Base Services license.

### Examples

This example shows how to clear PIM register policy counters:

```
switch# clear ip pim policy statistics register-policy
switch#
```

### Related Commands

Command	Description
show ip pim policy statistics	Displays PIM policy statistics.

# clear ip pim route

To clear routes specific to Protocol Independent Multicast (PIM) for IPv4, use the **clear ip pim route** command.

**clear ip pim route** { \* | *group* [*source*] | *group-prefix* } [**vrf** { *vrf-name* | **all** | **default** | **management** }]

## Syntax Description

<b>*</b>	Specifies all routes.
<i>group</i>	Group address in the format <i>A.B.C.D</i> .
<i>source</i>	(Optional) Source (S, G) route.
<i>group-prefix</i>	Group prefix in the format <i>A.B.C.D/length</i> .
<b>vrf</b>	(Optional) Clears the virtual routing and forwarding (VRF) instance information.
<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
<b>all</b>	Specifies that all VRF entries be cleared from the multicast routing table.
<b>default</b>	Specifies that the default VRF entry be cleared from the multicast routing table.
<b>management</b>	Specifies that the management VRF entry be cleared from the multicast routing table.

## Command Default

None

## Command Modes

Any command mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

This command requires the LAN Base Services license.

## Examples

This example shows how to clear the all the routes specific to PIM:

```
switch(config)# clear ip pim route *
switch(config)#
```

## Related Commands

Command	Description
<b>show ip pim route</b>	Displays information about PIM specific routes.

# clear ip pim statistics

To clear Protocol Independent Multicast (PIM) statistics counters, use the **clear ip pim statistics** command.

**clear ip pim statistics** [**vrf** { *vrf-name* | **all** | **default** | **management** }]

<b>Syntax Description</b>	<b>vrf</b>	(Optional) Clears the virtual routing and forwarding (VRF) instance information.
	<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
	<b>all</b>	Specifies that all VRF entries be cleared from the multicast routing table.
	<b>default</b>	Specifies that the default VRF entry be cleared from the multicast routing table.
	<b>management</b>	Specifies that the management VRF entry be cleared from the multicast routing table.

**Command Default** None

**Command Modes** Any command mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** This command requires the LAN Base Services license.

**Examples** This example shows how to clear PIM statistics counters:

```
switch# clear ip pim statistics
switch#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show ip pim statistics</b>	Displays PIM statistics.

# clear ip routing multicast event-history

To clear information in the IPv4 Multicast Routing Information Base (MRIB) event history buffers, use the **clear ip routing multicast event-history** command.

**clear ip routing multicast event-history** {cli | mfdm-debug | mfdm-events | mfdm-stats | rib | vrf}

## Syntax Description

<b>cli</b>	Clears the CLI event history buffer.
<b>mfdm-debug</b>	Clears the multicast FIB distribution (MFDM) debug history buffer.
<b>mfdm-events</b>	Clears the MFDM events history buffer.
<b>mfdm-stats</b>	Clears the MFDM sum event history buffer.
<b>rib</b>	Clears the RIB event history buffer.
<b>vrf</b>	Clears the virtual routing and forwarding (VRF) event history buffer.

## Command Default

None

## Command Modes

Any command mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

This command does not require a license.

## Examples

This example shows how to clear information in the MRIB RIB event history buffer:

```
switch(config)# clear ip routing multicast event-history rib
switch(config)#
```

## Related Commands

Command	Description
<b>ip routing multicast event-history</b>	Configures the size of the IPv4 MRIB event history buffers.
<b>show routing ip multicast event-history</b>	Displays information in the IPv4 MRIB event history buffers.



# clear routing multicast

To clear the IPv4 multicast routing table, use the **clear routing multicast** command.

**clear routing** [**ip** | **ipv4**] **multicast** { \* | *group* [*source*] | *group-prefix* } [**vrf** { *vrf-name* | **all** | **default** | **management** }]

Syntax Description		
<b>ip</b>	(Optional) Clears IP commands.	
<b>ipv4</b>	(Optional) Clears IPv4 commands.	
<b>*</b>	Specifies all routes.	
<i>group</i>	Group address in the format <i>A.B.C.D</i> .	
<i>source</i>	(Optional) Source (S, G) route.	
<i>group-prefix</i>	Group prefix in the format <i>A.B.C.D/length</i> .	
<b>vrf</b>	(Optional) Clears the virtual routing and forwarding (VRF) instance information.	
<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.	
<b>all</b>	Specifies that all VRF entries be cleared from the IPv4 multicast routing table.	
<b>default</b>	Specifies that the default VRF entry be cleared from the IPv4 multicast routing table.	
<b>management</b>	Specifies that the management VRF entry be cleared from the IPv4 multicast routing table.	

**Command Default** None

**Command Modes** Any command mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** The **clear ip mroute** command is an alternative form of this command.  
This command does not require a license.

**Examples** This example shows how to clear the IPv4 multicast routing table:

```
switch(config)# clear routing multicast *
switch(config)#
```

Related Commands	Command	Description
	clear ip mroute	Clears the multicast routing table.
	show routing ip multicast	Displays information about IPv4 multicast routes.

# feature msdp

To enable Multicast Source Discovery Protocol (MSDP), use the **feature msdp** command. To disable PIM, use the **no** form of this command.

**feature msdp**

**no feature msdp**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	Disabled
------------------------	----------

<b>Command Modes</b>	Global configuration mode
----------------------	---------------------------

<b>Command History</b>	<b>Release</b>	<b>Modified</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	<p>You must enable the MSDP feature before you can configure MSDP.</p> <p>This command requires the LAN Base Services license.</p>
-------------------------	--

<b>Examples</b>	<p>This example shows how to enable a MSDP configuration:</p> <pre>switch(config)# <b>feature msdp</b> switch(config)#</pre>
-----------------	--

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show running-configuration msdp</b>	Displays the MSDP running configuration information.
	<b>show feature</b>	Displays the status of features on a switch.
	<b>ip msdp peer</b>	Configures a MSDP peer.

# feature pim

To enable Protocol Independent Multicast (PIM), use the **feature pim** command. To disable PIM, use the **no** form of this command.

**feature pim**

**no feature pim**

**Syntax Description** This command has no arguments or keywords.

**Command Default** Disabled

**Command Modes** Global configuration mode

Command History	Release	Modified
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** You must enable the PIM feature before you can configure PIM.  
This command requires the LAN Base Services license.

**Examples** This example shows how to enable a PIM configuration:

```
switch(config)# feature pim
switch(config)#
```

Related Commands	Command	Description
	<b>show running-configuration pim</b>	Displays the PIM running configuration information.
	<b>show feature</b>	Displays the status of features on a switch.
	<b>ip pim sparse-mode</b>	Enables IPv4 PIM sparse mode on an interface.

# hardware profile multicast max-limit

To set the maximum number of entries in the multicast routing table, use the **hardware profile multicast max-limit** command.

**hardware profile multicast max-limit** *max-entries*

Syntax Description	<i>max-entries</i>	Maximum number of entries in the multicast routing table. The range is from 0 to 4000.
--------------------	--------------------	--

Command Default	None
-----------------	------

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

Examples	<p>This example shows how to set the maximum number of entries in the multicast routing table to 3000:</p> <pre>switch(config)# hardware profile multicast max-limit 3000 Warning!!: The multicast and /32 unicast route limits have been changed.           Any route exceeding the limit may get dropped. switch(config)#</pre>
----------	---

Related Commands	Command	Description
	<b>show hardware profile status</b>	Displays information about the multicast routing table limits.

# hardware profile multicast prefer-source-tree

To prevent duplication of packets during a switchover from the rendezvous point tree (RPT) to the shortest path tree (SPT), use the **hardware profile multicast prefer-source-tree** command. To allow duplication of packets, use the **no** form of this command.

**hardware profile multicast prefer-source-tree**

**no hardware profile multicast prefer-source-tree**

## Syntax Description

This command has no arguments or keywords.

## Command Default

None

## Command Modes

Global configuration mode

## Command History

Release	Modification
5.0(3)U1(2)	This command was introduced.

## Usage Guidelines

Use this command to ensure that there are no duplicate packets in the hardware when the transition from RPT to SPT is in progress.



### Note

When you use this command to prevent duplication of packets during a RPT to SPT switchover, the switch supports source (S, G) route injections at a rate of only 500 routes every two minutes. The multicast routing table must have 500 entries free for source (S, G) routes.

## Examples

This example shows how to prevent duplication of packets during a RPT to SPT switchover:

```
switch# configure terminal
switch(config)# hardware profile multicast prefer-source-tree
switch(config)#
```

## Related Commands

Command	Description
<b>show hardware profile status</b>	Displays information about the multicast routing table limits.

# hardware profile multicast soak-interval

To set the interval for multicast routes to be programmed into the hardware, use the **hardware profile multicast soak-interval** command.



**Note** Beginning in Release 7.0(3)I2(1), the **hardware profile multicast soak-interval** command is no longer necessary and has been removed.

*soak-interval*

## Syntax Description

<i>soak-interval</i>	Interval after which the multicast routes are programmed into the hardware. The range is from 50 milliseconds to 2 seconds. The default value of this interval is 1 second.  Use a lower interval for low multicast route creation or deletion requests per second. A lower interval enables the multicast routes to be programmed faster when the rate of multicast creations requests is low. When the number of multicast route creation requests is high, you can use a higher interval to stagger the programming of these routes into the hardware.
----------------------	---

## Command Default

1 second

## Command Modes

Global configuration mode

## Command History

Release	Modification
7.0(3)I2(1)	This command has been removed.
6.0(2)U3(2)	This command was introduced.

## Usage Guidelines

When the Cisco Nexus 3000 Series switch has high multicast route creation or deletion rates (for example, too many IGMP join or leave requests), the switch cannot program the multicast routes into the hardware as fast as the requests are made. To resolve this problem, you can now configure an interval after which multicast routes are programmed into the hardware.

- When you have very low multicast route creations or deletions per second, configure a low interval (up to 50 milliseconds). A low interval enables the hardware to be programmed faster than it would be by using the default interval of 1 second.
- When you have very high multicast route creations or deletions per second, configure a high interval (up to 2 seconds). A high interval enables the hardware to be programmed over a longer period of time without dropping the requests.

## Examples

This example shows how to set the interval for multicast routes to be programmed into the hardware to 2 seconds:

■ hardware profile multicast soak-interval

```
switch(config)# 2
switch(config)#
```

Related Commands	Command	Description
	show hardware profile status	Displays information about the multicast routing table limits.



# hardware profile multicast syslog-threshold

To configure the syslog threshold for the multicast route table so that a syslog message is generated when the table capacity reaches the specified percentage, use the **hardware profile multicast syslog-threshold** command. To reset the value to the default, use the **no** form of this command.

**hardware profile multicast syslog-threshold** *percentage*

**no hardware profile multicast syslog-threshold**

<b>Syntax Description</b>	<i>percentage</i>	Percentage of table capacity. The range is a number from 1 to 100. The default value is 90 percent.
---------------------------	-------------------	---

<b>Defaults</b>	The multicast route table threshold is 50 percent.
-----------------	--

<b>Command Modes</b>	Global configuration mode
----------------------	---------------------------

<b>Command History</b>	Release	Modification
	5.0(3)U3(2)	This command was introduced.

<b>Usage Guidelines</b>	This command does not require a license.
-------------------------	--

<b>Examples</b>	This example shows how to set the syslog threshold to 20 percent for the multicast route table: <pre>switch# <b>configure terminal</b> switch(config)# <b>hardware profile multicast syslog-threshold 20</b> switch(config)#</pre>
-----------------	---

<b>Related Commands</b>	Command	Description
	<b>copy running-config startup config</b>	Copies the running configuration to the startup configuration file.
	<b>show running-config</b>	Displays the information for the running configuration.

# ip igmp access-group

To enable a route-map policy to control the multicast groups that hosts on the subnet serviced by an interface can join, use the **ip igmp access-group** command. To disable the route-map policy, use the **no** form of this command.

**ip igmp access-group** *policy-name*

**no ip igmp access-group** [*policy-name*]

## Syntax Description

<i>policy-name</i>	Route-map policy name. The route map name can be a maximum of 100 alphanumeric characters.
--------------------	--

## Command Default

Disabled

## Command Modes

Interface configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

The **ip igmp access-group** command is an alias of the **ip igmp report-policy** command.

This command does not require a license but if you want to enable Layer 3 interfaces, you must install the LAN Base Services license.

## Examples

This example shows how to enable a route-map policy:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# ip igmp access-group my_access_group_policy
switch(config-if)#
```

This example shows how to disable a route-map policy:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# no ip igmp access-group
switch(config-if)#
```

## Related Commands

Command	Description
<b>show ip igmp interface</b>	Displays IGMP information about the interface.

# ip igmp any-query-destination

To configure the switch to allow any destination IP address for IGMP general queries, use the **ip igmp any-query-destination** command. To reset the query to the default, use the **no** form of this command.

**ip igmp any-query-destination**

**no ip igmp any-query-destination**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global configuration mode
----------------------	---------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Examples</b>	<p>This example shows how to configure any destination IP address for IGMP general queries:</p> <pre>switch# <b>configure terminal</b> switch(config)# <b>ip igmp any-query-destination</b> switch(config)#</pre>
-----------------	---

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show running-config igmp</b>	Displays information about the running-system configuration for IGMP.

# ip igmp enforce-router-alert

To enable the enforce router alert option check for IGMPv2 and IGMPv3 packets, use the **ip igmp enforce-router-alert** command. To disable the option check, use the **no** form of this command.

**ip igmp enforce-router-alert**

**no ip igmp enforce-router-alert**

**Syntax Description** This command has no arguments or keywords.

**Command Default** Enabled

**Command Modes** Global configuration mode

Release	Modification
5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** This command does not require a license.

**Examples** This example shows how to enable the enforce router alert option check:

```
switch(config)# ip igmp enforce-router-alert
switch(config)#
```

This example shows how to disable the enforce router alert option check:

```
switch(config)# no ip igmp enforce-router-alert
switch(config)#
```

Command	Description
<b>show running-config igmp</b>	Displays information about the IGMP running-system configuration.

# ip igmp event-history

To configure the size of the IGMP event history buffers, use the **ip igmp event-history** command. To revert to the default buffer size, use the **no** form of this command.

**ip igmp event-history** { **clis** | **group-debug**s | **group-event**s | **ha** | **igmp-internal** | **interface-debug**s | **interface-event**s | **msgs** | **mtrace** | **policy** | **statistics** | **vrf** } **size** *buffer-size*

**no ip igmp event-history** { **clis** | **group-debug**s | **group-event**s | **ha** | **igmp-internal** | **interface-debug**s | **interface-event**s | **msgs** | **mtrace** | **policy** | **statistics** | **vrf** } **size** *buffer-size*

Syntax	Description
<b>clis</b>	Configures the IGMP CLI event history buffer size.
<b>errors</b>	Configures the error event history buffer size.
<b>group-debug</b> s	Configures the IGMP group debug event history buffer size.
<b>group-event</b> s	Configures the IGMP group-event event history buffer size.
<b>ha</b>	Configures the IGMP HA event history buffer size.
<b>igmp-internal</b>	Configures the IGMP IGMP-internal event history buffer size.
<b>interface-debug</b> s	Configures the IGMP interface debug event history buffer size.
<b>interface-event</b> s	Configures the IGMP interface-event event history buffer size.
<b>msgs</b>	Configures the message event history buffer size.
<b>mtrace</b>	Configures the IGMP mtrace event history buffer size.
<b>policy</b>	Configures the IGMP policy event history buffer size.
<b>statistics</b>	Configures the statistics event history buffer size.
<b>vrf</b>	Configures the IGMP VRF event history buffer size.
<b>size</b>	Specifies the size of the buffer to allocate.
<i>buffer-size</i>	Buffer size that is one of the following values: <b>disabled</b> , <b>large</b> , <b>medium</b> , or <b>small</b> . The default buffer size is <b>small</b> .

**Command Default** All history buffers are allocated as small.

**Command Modes** Any command mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** This command does not require a license.

**Examples** This example shows how to configure the IGMP HA event history buffer size:

```
switch(config)# ip igmp event-history ha size large
```

```
switch(config)#
```

Related Commands	Command	Description
	<b>clear ip igmp event-history</b>	Clears the contents of IGMP event history buffers.
	<b>show ip igmp event-history</b>	Displays information in the IGMP event history buffers.
	<b>show running-config igmp</b>	Displays information about the IGMP running-system configuration.

# ip igmp flush-routes

To remove routes when the IGMP process is restarted, use the **ip igmp flush-routes** command. To leave routes in place, use the **no** form of this command.

**ip igmp flush-routes**

**no ip igmp flush-routes**

**Syntax Description** This command has no arguments or keywords.

**Command Default** The routes are not flushed.

**Command Modes** Global configuration mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** To display whether flush routes are configured, use this command line:

```
switch(config)# show running-config | include flush-routes
```

This command does not require a license.

**Examples** This example shows how to remove routes when the IGMP process is restarted:

```
switch(config)# ip igmp flush-routes
switch(config)#
```

This example shows how to leave routes in place when the IGMP process is restarted:

```
switch(config)# no ip igmp flush-routes
switch(config)#
```

Related Commands	Command	Description
	show running-config	Displays information about the running-system configuration.

# ip igmp global-leave-ignore-gss-mrt

To use the general Maximum Response Time (MRT) in response to an IGMP global leave message for general queries, use the **ip igmp global-leave-ignore-gss-mrt** command. To reset the query to the default, use the **no** form of this command.

**ip igmp global-leave-ignore-gss-mrt**

**no ip igmp global-leave-ignore-gss-mrt**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global configuration mode
----------------------	---------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(2)	This command was introduced.

<b>Usage Guidelines</b>	When you use this command, the switch uses the configured Maximum Response Time (MRT) value in group-specific queries against a lower MRT value in response to IGMP global leave messages (IGMP leave reports to group 0.0.0.0).
-------------------------	--

This command does not require a license.

<b>Examples</b>	This example shows how to set the MRT for IGMP general queries:
-----------------	---

```
switch# configure terminal
switch(config)# ip igmp global-leave-ignore-gss-mrt
switch(config)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show running-config</b> <b>igmp</b>	Displays information about the running-system configuration for IGMP.



# ip igmp group-timeout

To configure a group membership timeout for IGMPv2, use the **ip igmp group-timeout** command. To return to the default timeout, use the **no** form of this command.

**ip igmp group-timeout** *timeout*

**no ip igmp group-timeout** [*timeout*]

Syntax Description	<i>timeout</i>	Timeout in seconds. The range is from 3 to 65,535. The default is 260.
--------------------	----------------	--

Command Default	The group membership timeout is 260 seconds.
-----------------	--

Command Modes	Interface configuration mode
---------------	------------------------------

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines	This command does not require a license but if you want to enable Layer 3 interfaces, you must install the LAN Base Services license.
------------------	---

Examples	This example shows how to configure a group membership timeout:
----------	---

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# ip igmp group-timeout 200
switch(config-if)#
```

This example shows how to reset a group membership timeout to the default:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# no ip igmp group-timeout
switch(config-if)#
```

Related Commands	Command	Description
	<b>show ip igmp interface</b>	Displays IGMP information about the interface.

# ip igmp immediate-leave

To enable the device to remove the group entry from the multicast routing table immediately upon receiving a leave message for the group, use the **ip igmp immediate-leave** command. To disable the immediate leave option, use the **no** form of this command.

**ip igmp immediate-leave**

**no ip igmp immediate-leave**

## Syntax Description

This command has no arguments or keywords.

## Command Default

The immediate leave feature is disabled.

## Command Modes

Interface configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

Use the **ip igmp immediate-leave** command only when there is one receiver behind the interface for a given group.

This command does not require a license but if you want to enable Layer 3 interfaces, you must install the LAN Base Services license.

## Examples

This example shows how to enable the immediate leave feature:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# ip igmp immediate-leave
switch(config-if)#
```

This example shows how to disable the immediate leave feature:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# no ip igmp immediate-leave
switch(config-if)#
```

## Related Commands

Command	Description
<b>show ip igmp interface</b>	Displays IGMP information about the interface.

# ip igmp join-group

To statically bind a multicast group to an interface, use the **ip igmp join-group** command. To remove a group binding, use the **no** form of this command.

**ip igmp join-group** {group [source source] | route-map policy-name}

**no ip igmp join-group** {group [source source] | route-map policy-name}

Syntax Description	<i>group</i>	Multicast group IP address.
	<b>source</b> <i>source</i>	(Optional) Configures a source IP address for the IGMPv3 (S,G) channel.
	<b>route-map</b> <i>policy-name</i>	Specifies the route-map policy name that defines the group prefixes where this feature is applied. The route map name can be a maximum of 63 alphanumeric characters.

Command Default	None
-----------------	------

Command Modes	Interface configuration mode
---------------	------------------------------

Command History	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines	If you specify only the group address, the (*, G) state is created. If you specify the source address, the (S, G) state is created.
------------------	---

If you use the route map, the only **match** command that is read from the route map is the **match ip multicast** command. You can specify the group prefix and source prefix.

**Note**

A source tree is built for the (S, G) state only if you enable IGMPv3.

**Caution**

When you enter this command, the traffic generated is handled by the device CPU, not the hardware.

This command does not require a license but if you want to enable Layer 3 interfaces, you must install the LAN Base Services license.

Examples	This example shows how to statically bind a group to an interface:
----------	--

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# ip igmp join-group 230.0.0.0
switch(config-if)#
```

This example shows how to remove a group binding from an interface:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# no ip igmp join-group 230.0.0.0
switch(config-if)#
```

Related Commands

Command	Description
show ip igmp interface	Displays IGMP information about the interface.

# ip igmp last-member-query-count

To configure the number of times that the software sends an IGMP query in response to a host leave message, use the **ip igmp last-member-query-count** command. To reset the query interval to the default, use the **no** form of this command.

**ip igmp last-member-query-count** *count*

**no ip igmp last-member-query-count** [*count*]

<b>Syntax Description</b>	<i>count</i> Query count. The range is from 1 to 5. The default is 2.				
<b>Command Default</b>	The query count is 2.				
<b>Command Modes</b>	Interface configuration mode				
<b>Command History</b>	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>5.0(3)U1(1)</td><td>This command was introduced.</td></tr> </table>	Release	Modification	5.0(3)U1(1)	This command was introduced.
Release	Modification				
5.0(3)U1(1)	This command was introduced.				
<b>Usage Guidelines</b>	This command does not require a license but if you want to enable Layer 3 interfaces, you must install the LAN Base Services license.				
<b>Examples</b>	<p>This example shows how to configure a query count:</p> <pre>switch(config)# interface ethernet 2/2 switch(config-if)# no switchport switch(config-if)# ip igmp last-member-query-count 3 switch(config-if)#</pre> <p>This example shows how to reset a query count to the default:</p> <pre>switch(config)# interface ethernet 2/2 switch(config-if)# no switchport switch(config-if)# no ip igmp last-member-query-count switch(config-if)#</pre>				
<b>Related Commands</b>	<table> <tr> <th>Command</th><th>Description</th></tr> <tr> <td><b>show ip igmp interface</b></td><td>Displays IGMP information about the interface.</td></tr> </table>	Command	Description	<b>show ip igmp interface</b>	Displays IGMP information about the interface.
Command	Description				
<b>show ip igmp interface</b>	Displays IGMP information about the interface.				

# ip igmp last-member-query-response-time

To configure a query interval in which the software sends membership reports and then deletes the group state, use the **ip igmp last-member-query-response-time** command. To reset the query interval to the default, use the **no** form of this command.

```
ip igmp last-member-query-response-time interval

no ip igmp last-member-query-response-time [interval]
```

Syntax Description	<i>interval</i> Query interval in seconds. The range is from 1 to 25. The default is 1.
--------------------	---

Command Default	The query interval is 1 second.
-----------------	---------------------------------

Command Modes	Interface configuration mode
---------------	------------------------------

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines	This command does not require a license but if you want to enable Layer 3 interfaces, you must install the LAN Base Services license.
------------------	---

Examples

This example shows how to configure a query interval:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# ip igmp last-member-query-response-time 3
switch(config-if)#
```

This example shows how to reset a query interval to the default:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# no ip igmp last-member-query-response-time
switch(config-if)#
```

Related Commands	Command	Description
	<b>show ip igmp interface</b>	Displays IGMP information about the interface.

# ip igmp querier-timeout

To configure a querier timeout that the software uses when deciding to take over as the querier, use the **ip igmp querier-timeout** command. To reset to the querier timeout to the default, use the **no** form of this command.

**ip igmp querier-timeout** *timeout*

**no ip igmp querier-timeout** [*timeout*]

## Syntax Description

*timeout* Timeout in seconds. The range is from 1 to 65,535. The default is 255.

## Command Default

The querier timeout is 255 seconds.

## Command Modes

Interface configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

The **ip igmp query-timeout** command is an alternative form of this command.

This command does not require a license but if you want to enable Layer 3 interfaces, you must install the LAN Base Services license.

## Examples

This example shows how to configure a querier timeout:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# ip igmp querier-timeout 200
switch(config-if)#
```

This example shows how to reset a querier timeout to the default:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# no ip igmp querier-timeout
switch(config-if)#
```

## Related Commands

Command	Description
<b>ip igmp query-timeout</b>	Configures a querier timeout.
<b>show ip igmp interface</b>	Displays IGMP information about the interface.

# ip igmp query-interval

To configure a query interval used when the IGMP process starts up, use the **ip igmp query-interval** command. To reset the query interval to the default, use the **no** form of this command.

**ip igmp query-interval** *interval*

**no ip igmp query-interval** [*interval*]

<b>Syntax Description</b>	<i>interval</i> Interval in seconds. The range is from 1 to 18,000. The default is 125.
---------------------------	---

<b>Command Default</b>	The query interval is 125 seconds.
------------------------	------------------------------------

<b>Command Modes</b>	Interface configuration mode
----------------------	------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	This command does not require a license but if you want to enable Layer 3 interfaces, you must install the LAN Base Services license.
-------------------------	---

<b>Examples</b>	This example shows how to configure a query interval:
-----------------	---

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# ip igmp query-interval 100
switch(config-if)#
```

This example shows how to reset a query interval to the default:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# no ip igmp query-interval
switch(config-if)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show ip igmp interface</b>	Displays IGMP information about the interface.



# ip igmp query-max-response-time

To configure a query maximum response time that is advertised in IGMP queries, use the **ip igmp query-max-response-time** command. To reset the response time to the default, use the **no** form of this command.

**ip igmp query-max-response-time** *time*

**no ip igmp query-max-response-time** [*time*]

## Syntax Description

<i>time</i>	Query maximum response time in seconds. The range is from 1 to 25. The default is 10.
-------------	---

## Command Default

The query maximum response time is 10 seconds.

## Command Modes

Interface configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

This command does not require a license but if you want to enable Layer 3 interfaces, you must install the LAN Base Services license.

## Examples

This example shows how to configure a query maximum response time:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# ip igmp query-max-response-time 15
switch(config-if)#
```

This example shows how to reset a query maximum response time to the default:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# no ip igmp query-max-response-time
switch(config-if)#
```

## Related Commands

Command	Description
<b>show ip igmp interface</b>	Displays IGMP information about the interface.

# ip igmp query-timeout

To configure a query timeout that the software uses when deciding to take over as the querier, use the **ip igmp query-timeout** command. To reset to the querier timeout to the default, use the **no** form of this command.

**ip igmp query-timeout** *timeout*

**no ip igmp query-timeout** [*timeout*]

<b>Syntax Description</b>	<i>timeout</i> Timeout in seconds. The range is from 1 to 65,535. The default is 255.	
<b>Command Default</b>	The query timeout is 255 seconds.	
<b>Command Modes</b>	Interface configuration mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.
<b>Usage Guidelines</b>	<p>The <b>ip igmp querier-timeout</b> command is an alternative form of this command.</p> <p>This command does not require a license but if you want to enable Layer 3 interfaces, you must install the LAN Base Services license.</p>	
<b>Examples</b>	<p>This example shows how to configure a querier timeout:</p> <pre>switch(config)# interface ethernet 2/2 switch(config-if)# no switchport switch(config-if)# ip igmp query-timeout 200 switch(config-if)#</pre>	
	<p>This example shows how to reset a querier timeout to the default:</p> <pre>switch(config)# interface ethernet 2/2 switch(config-if)# no switchport switch(config-if)# no ip igmp query-timeout switch(config-if)#</pre>	
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>ip igmp querier-timeout</b>	Configures a querier timeout.
	<b>show ip igmp interface</b>	Displays IGMP information about the interface.

# ip igmp report-link-local-groups

To enable IGMP to send reports for link-local groups, use the **ip igmp report-link-local-groups** command. To disable sending reports to link-local groups, use the **no** form of this command.

**ip igmp report-link-local-groups**

**no ip igmp report-link-local-groups**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	Disabled
------------------------	----------

<b>Command Modes</b>	Interface configuration mode
----------------------	------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	This command does not require a license but if you want to enable Layer 3 interfaces, you must install the LAN Base Services license.
-------------------------	---

<b>Examples</b>	This example shows how to enable sending reports to link-local groups:
-----------------	--

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# ip igmp report-link-local-groups
switch(config-if)#
```

This example shows how to disable sending reports to link-local groups:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# no ip igmp report-link-local-groups
switch(config-if)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show ip igmp interface</b>	Displays IGMP information about the interface.

# ip igmp report-policy

To enable an access policy that is based on a route-map policy for IGMP reports, use the **ip igmp report-policy** command. To disable the route-map policy, use the **no** form of this command.

**ip igmp report-policy** *policy-name*

**no ip igmp report-policy** [*policy-name*]

<b>Syntax Description</b>	<i>policy-name</i> Route-map policy name. The route name is a maximum of 100 alphanumeric characters.
---------------------------	---

<b>Command Default</b>	Disabled
------------------------	----------

<b>Command Modes</b>	Interface configuration mode
----------------------	------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	You can configure the route map to prevent state from being created in the multicast routing table.
	The <b>ip igmp report-policy</b> command is an alias of the <b>ip igmp access-group</b> command.
	If you use the route map, the only <b>match</b> command that is read from the route map is the <b>match ip multicast</b> command. You can specify the group prefix, group range, and source prefix to filter messages.
	This command does not require a license but if you want to enable Layer 3 interfaces, you must install the LAN Base Services license.

<b>Examples</b>	This example shows how to enable an access policy for IGMP reports:
-----------------	---

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# ip igmp report-policy my_report_policy
switch(config-if)#
```

This example shows how to disable an access policy for IGMP reports:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# no ip igmp report-policy
switch(config-if)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show ip igmp interface</b>	Displays IGMP information about the interface.

# ip igmp robustness-variable

To configure a robustness count that you can tune to reflect expected packet loss on a congested network, use the **ip igmp robustness-variable** command. To reset the count to the default, use the **no** form of this command.

**ip igmp robustness-variable** *count*

**no ip igmp robustness-variable** [*count*]

## Syntax Description

<i>count</i>	Robustness count. The range is from 1 to 7. The default is 2.
--------------	---

## Command Default

The robustness count is 2.

## Command Modes

Interface configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

This command does not require a license but if you want to enable Layer 3 interfaces, you must install the LAN Base Services license.

## Examples

This example shows how to configure a robustness count:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# ip igmp robustness-variable 3
switch(config-if)#
```

This example shows how to reset a robustness count to the default:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# no ip igmp robustness-variable
switch(config-if)#
```

## Related Commands

Command	Description
<b>show ip igmp interface</b>	Displays IGMP information about the interface.

# ip igmp snooping (Global)

To enable IGMP snooping, use the **ip igmp snooping** command. To disable IGMP snooping, use the **no** form of this command.

**ip igmp snooping**

**no ip igmp snooping**

**Syntax Description** This command has no arguments or keywords.

**Command Default** Enabled

**Command Modes** Global configuration mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** If the global configuration of IGMP snooping is disabled, then all VLANs are treated as disabled, whether they are enabled or not.

This command does not require a license.

**Examples** This example shows how to enable IGMP snooping:

```
switch(config)# ip igmp snooping
switch(config)#
```

This example shows how to disable IGMP snooping:

```
switch(config)# no ip igmp snooping
switch(config)#
```

Related Commands	Command	Description
	<b>show ip igmp snooping</b>	Displays IGMP snooping information.

# ip igmp snooping (VLAN)

To enable IGMP snooping on specified VLAN interfaces, use the **ip igmp snooping** command. To disable IGMP snooping on the interface, use the **no** form of this command.



## Note

This command has two new sub-options beginning in Release 7.0(3)I2(1):  
**group-timeout** - Configures the group membership timeout in all VLANs/BDs.  
**max-gq-miss** - Configures the general query miss count.

**ip igmp snooping**

**no ip igmp snooping**

## Syntax Description

This command has no arguments or keywords.

## Command Default

Enabled

## Command Modes

VLAN configuration mode

## Command History

Release	Modification
7.0(3)I2(1)	New sub-options were added.
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

If the global configuration of IGMP snooping is disabled, then all VLANs are treated as disabled, whether they are enabled or not.

This command does not require a license.

## Examples

This example shows how to enable IGMP snooping on a VLAN interface:

```
switch(config)# vlan 1
switch(config-vlan)# ip igmp snooping
switch(config-vlan)#
```

This example shows how to disable IGMP snooping on a VLAN interface:

```
switch(config)# vlan 1
switch(config-vlan)# no ip igmp snooping
switch(config-vlan)#
```

## Related Commands

Command	Description
<b>show ip igmp snooping</b>	Displays IGMP snooping information.

# ip igmp snooping event-history

To configure the size of the IGMP snooping event history buffers, use the **ip igmp snooping event-history** command. To revert to the default buffer size, use the **no** form of this command.

```
ip igmp snooping event-history {igmp-snoop-internal | mfdm | mfdm-sum | rib | vlan |  
                                vlan-events | vpc} size buffer-size
```

```
no ip igmp snooping event-history {igmp-snoop-internal | mfdm | mfdm-sum | rib | vlan |  
                                vlan-events | vpc} size buffer-size
```

## Syntax Description

<b>igmp-snoop-internal</b>	Clears the IGMP snooping internal event history buffer.
<b>mfdm</b>	Clears the multicast FIB distribution (MFDM) event history buffer.
<b>mfdm-sum</b>	Clears the MFDM sum event history buffer.
<b>rib</b>	Clears the Routing Information Base (RIB) event history buffer.
<b>vlan</b>	Clears the VLAN event history buffer.
<b>vlan-events</b>	Clears the VLAN-event event history buffer.
<b>vpc</b>	Clears the virtual port channel (vPC) event history buffer.
<b>size</b>	Specifies the size of the buffer to allocate.
<i>buffer-size</i>	Buffer size that is one of the following values: <b>disabled</b> , <b>large</b> , <b>medium</b> , or <b>small</b> . The default buffer size is <b>small</b> .

## Command Default

All history buffers are allocated as small.

## Command Modes

Global configuration mode  
Switch profile configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.
5.0(3)U2(1)	Support was added to configure IGMP snooping event history buffers in a switch profile.
	The <b>vpc</b> keyword was added.

## Usage Guidelines

This command does not require a license.

## Examples

This example shows how to configure the IGMP snooping VLAN event history buffer size:

```
switch(config)# ip igmp snooping event-history vlan size large  
switch(config)#
```



This example shows how to configure the IGMP snooping vPC event history buffer size in a switch profile:

```
switch# configure sync
Enter configuration commands, one per line. End with CNTL/Z.
switch(config-sync)# switch-profile s5010
Switch-Profile started, Profile ID is 1
switch(config-sync-sp)# ip igmp snooping event-history vpc size medium
switch(config-sync-sp)#
```

**Related Commands**

Command	Description
<b>clear ip igmp snooping event-history</b>	Clears the contents of the IGMP snooping event history buffers.
<b>show ip igmp snooping event-history</b>	Displays information in the IGMP snooping event history buffers.
<b>show running-config igmp</b>	Displays information about the IGMP running-system configuration.
<b>show switch-profile</b>	Displays information about the switch profile and the configuration revision.
<b>switch-profile</b>	Creates and configures a switch profile.

# ip igmp snooping explicit-tracking

To enable tracking of IGMPv3 membership reports from individual hosts for each port on a per-VLAN basis, use the **ip igmp snooping explicit-tracking** command. To disable tracking, use the **no** form of this command.

```
ip igmp snooping explicit-tracking

no ip igmp snooping explicit-tracking
```

Syntax Description	This command has no arguments or keywords.	
Command Default	Enabled	
Command Modes	VLAN configuration mode	
Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.
Usage Guidelines	This command does not require a license.	
Examples	This example shows how to enable tracking of IGMPv3 membership reports on a VLAN interface:	
	<pre>switch(config)# vlan 1 switch(config-vlan)# ip igmp snooping explicit-tracking switch(config-vlan)#</pre>	
	This example shows how to disable IGMP snooping on a VLAN interface:	
	<pre>switch(config)# vlan 1 switch(config-vlan)# no ip igmp snooping explicit-tracking switch(config-vlan)#</pre>	
Related Commands	Command	Description
	show ip igmp snooping	Displays IGMP snooping information.

# ip igmp snooping fast-leave

To enable support of IGMPv2 hosts that cannot be explicitly tracked because of the host report suppression mechanism of the IGMPv2 protocol, use the **ip igmp snooping fast-leave** command. To disable support of IGMPv2 hosts, use the **no** form of this command.

**ip igmp snooping fast-leave**

**no ip igmp snooping fast-leave**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	Disabled
------------------------	----------

<b>Command Modes</b>	VLAN configuration mode
----------------------	-------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	<p>When you enable fast leave, the IGMP software assumes that no more than one host is present on each VLAN port.</p> <p>This command does not require a license.</p>
-------------------------	---

<b>Examples</b>	This example shows how to enable support of IGMPv2 hosts:
-----------------	---

```
switch(config)# vlan 1
switch(config-vlan)# ip igmp snooping fast-leave
switch(config-vlan)#
```

This example shows how to disable support of IGMPv2 hosts:

```
switch(config)# vlan 1
switch(config-vlan)# no ip igmp snooping fast-leave
switch(config-vlan)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show ip igmp snooping</b>	Displays IGMP snooping information.

# ip igmp snooping last-member-query-interval

To configure a query interval in which the software removes a group, use the **ip igmp snooping last-member-query-interval** command. To reset the query interval to the default, use the **no** form of this command.

```
ip igmp snooping last-member-query-interval interval

no ip igmp snooping last-member-query-interval [interval]
```

Syntax Description	intervalQuery interval in seconds. The range is from 1 to 25. The default is 1.				
Command Default	The query interval is 1.				
Command Modes	VLAN configuration mode				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>5.0(3)U1(1)</td><td>This command was introduced.</td></tr> </table>	Release	Modification	5.0(3)U1(1)	This command was introduced.
Release	Modification				
5.0(3)U1(1)	This command was introduced.				
Usage Guidelines	This command does not require a license.				
Examples	<p>This example shows how to configure a query interval in which the software removes a group:</p> <pre>switch(config)# vlan 1 switch(config-vlan)# ip igmp snooping last-member-query-interval 3 switch(config-vlan)#</pre> <p>This example shows how to reset a query interval to the default:</p> <pre>switch(config)# vlan 1 switch(config-vlan)# no ip igmp snooping last-member-query-interval switch(config-vlan)#</pre>				
Related Commands	<table> <tr> <th>Command</th><th>Description</th></tr> <tr> <td>show ip igmp snooping</td><td>Displays IGMP snooping information.</td></tr> </table>	Command	Description	show ip igmp snooping	Displays IGMP snooping information.
Command	Description				
show ip igmp snooping	Displays IGMP snooping information.				

# ip igmp snooping link-local-groups-suppression

To enable suppression of IGMP reports from link-local groups, use the **ip igmp snooping link-local-groups-suppression** command. To disable suppression of these reports, use the **no** form of this command.

**ip igmp snooping link-local-groups-suppression**

**no ip igmp snooping link-local-groups-suppression**

## Syntax Description

This command has no arguments or keywords.

## Command Default

Enabled

## Command Modes

Global configuration mode  
VLAN configuration mode  
Switch profile configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.
5.0(3)U2(1)	Support was added to suppress IGMP reports from link-local groups in a switch profile.

## Usage Guidelines

If this setting is disabled on the entire device, then it is disabled on all VLANs on device, irrespective of the specific VLAN setting.

This command does not require a license.

## Examples

This example shows how to enable suppression of IGMP reports from link-local groups:

```
switch(config)# vlan 1
switch(config-vlan)# ip igmp snooping link-local-groups-suppression
switch(config-vlan)#
```

This example shows how to disable suppression of IGMP reports from link-local groups:

```
switch(config)# vlan 1
switch(config-vlan)# no ip igmp snooping link-local-groups-suppression
switch(config-vlan)#
```

This example shows how to enable suppression of IGMP reports from link-local groups in a switch profile:

```
switch# configure sync
Enter configuration commands, one per line. End with CNTL/Z.
switch(config-sync)# switch-profile s5010
Switch-Profile started, Profile ID is 1
```

**ip igmp snooping link-local-groups-suppression**

```
switch(config-sync-sp) # ip igmp snooping link-local-groups-suppression  
switch(config-sync-sp) #
```

**Related Commands**

Command	Description
<b>show ip igmp snooping</b>	Displays IGMP snooping information.
<b>show switch-profile</b>	Displays information about the switch profile and the configuration revision.
<b>switch-profile</b>	Creates and configures a switch profile.

# ip igmp snooping mrouter interface

To configure a static connection to a multicast router, use the **ip igmp snooping mrouter interface** command. To remove the static connection, use the **no** form of this command.

**ip igmp snooping mrouter interface** { **ethernet** *slot/port* | **port-channel** *number* [*.sub\_if\_number*] }

**no ip igmp snooping mrouter interface** { **ethernet** *slot/port* | **port-channel** *number* [*.sub\_if\_number*] }

<b>Syntax Description</b>	<b>ethernet</b>	(Optional) Specifies the Ethernet interface and the slot number and port number. The
	<i>slot/port</i>	slot number is from 1 to 255, and the port number is from 1 to 128.
	<b>port-channel</b>	(Optional) Specifies the EtherChannel interface and EtherChannel number. The
	<i>number</i>	range is from 1 to 4096.
	<i>sub_if-number</i>	(Optional) Subinterface number. The range is from 1 to 4093.

**Command Default** None

**Command Modes** VLAN configuration mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** The interface to the router must be in the selected VLAN.  
This command does not require a license.

**Examples** This example shows how to configure a static connection to a multicast router:

```
switch(config)# vlan 1
switch(config-vlan)# ip igmp snooping mrouter interface ethernet 2/1
switch(config-vlan)#
```

This example shows how to remove a static connection to a multicast router:

```
switch(config)# vlan 1
switch(config-vlan)# no ip igmp snooping mrouter interface ethernet 2/1
switch(config-vlan)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show ip igmp snooping</b>	Displays IGMP snooping information.

# ip igmp snooping optimise-multicast-flood

To configure Optimized Multicast Flood (OMF) on all VLANs, use the **ip igmp snooping optimise-multicast-flood** command. To remove the OMF from all VLANs, use the **no** form of this command.

**ip igmp snooping optimise-multicast-flood**

**no ip igmp snooping optimise-multicast-flood**

## Syntax Description

This command has no arguments or keywords.

## Command Default

None

## Command Modes

Global configuration mode  
Switch profile configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.
5.0(3)U2(1)	Support was added to configure IGMP snooping Optimized Multicast Flood in a switch profile.
7.0(3)I2(1)	This command was removed.

## Usage Guidelines

This command does not require a license.  
Beginning in Release 7.0(3)I2(1), this release has been removed.

## Examples

This example shows how to configure OMF on all VLANs:

```
switch(config)# ip igmp snooping optimise-multicast-flood
switch(config)#
```

This example shows how to remove OMF from all VLANs:

```
switch(config)# no ip igmp snooping optimise-multicast-flood
switch(config)#
```

This example shows how to configure OMF in a switch profile:

```
switch# configure sync
Enter configuration commands, one per line. End with CNTL/Z.
switch(config-sync)# switch-profile s5010
Switch-Profile started, Profile ID is 1
switch(config-sync-sp)# ip igmp snooping optimise-multicast-flood
switch(config-sync-sp)#
```



Related Commands	Command	Description
	<b>show ip igmp snooping</b>	Displays IGMP snooping information.
	<b>show switch-profile</b>	Displays information about the switch profile and the configuration revision.
	<b>switch-profile</b>	Creates and configures a switch profile.

# ip igmp snooping querier

To configure a snooping querier on an interface when you do not enable Protocol Independent Multicast (PIM) because multicast traffic does not need to be routed, use the **ip igmp snooping querier** command. To remove the snooping querier, use the **no** form of this command.

**ip igmp snooping querier** *querier*

**no ip igmp snooping querier** [*querier*]

<b>Syntax Description</b>	<i>querier</i> Querier IP address.				
<b>Command Default</b>	None				
<b>Command Modes</b>	VLAN configuration mode				
<b>Command History</b>	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>5.0(3)U1(1)</td><td>This command was introduced.</td></tr> </table>	Release	Modification	5.0(3)U1(1)	This command was introduced.
Release	Modification				
5.0(3)U1(1)	This command was introduced.				
<b>Usage Guidelines</b>	<p>The querier IP address cannot be a multicast address.</p> <p>This command does not require a license.</p>				
<b>Examples</b>	<p>This example shows how to configure a snooping querier:</p> <pre>switch(config)# <b>vlan 1</b> switch(config-vlan)# <b>ip igmp snooping querier 192.168.0.106</b> switch(config-vlan)#</pre> <p>This example shows how to disable IGMP snooping on a VLAN interface:</p> <pre>switch(config)# <b>vlan 1</b> switch(config-vlan)# <b>no ip igmp snooping querier</b> switch(config-vlan)#</pre>				
<b>Related Commands</b>	<table> <tr> <th>Command</th><th>Description</th></tr> <tr> <td><b>show ip igmp snooping</b></td><td>Displays IGMP snooping information.</td></tr> </table>	Command	Description	<b>show ip igmp snooping</b>	Displays IGMP snooping information.
Command	Description				
<b>show ip igmp snooping</b>	Displays IGMP snooping information.				

# ip igmp snooping report-suppression

To enable limiting the membership report traffic sent to multicast-capable routers, use the **ip igmp snooping report-suppression** command. To disable the limitation, use the **no** form of this command.

**ip igmp snooping report-suppression**

**no ip igmp snooping report-suppression**

**Syntax Description** This command has no arguments or keywords.

**Command Default** Enabled

**Command Modes** Global configuration mode  
VLAN configuration mode  
Switch profile configuration mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.
	5.0(3)U2(1)	Support was added to configure IGMP snooping report suppression in a switch profile.

**Usage Guidelines** When you disable report suppression, all IGMP reports are sent as is to multicast-capable routers. This command does not require a license.

**Examples** This example shows how to enable limiting the membership report traffic:

```
switch(config)# vlan 1
switch(config-vlan)# ip igmp snooping report-suppression
switch(config-vlan)#
```

This example shows how to disable limiting the membership report traffic:

```
switch(config)# vlan 1
switch(config-vlan)# no ip igmp snooping report-suppression
switch(config-vlan)#
```

This example shows how to enable limiting the membership report traffic in a switch profile:

```
switch# configure sync
Enter configuration commands, one per line. End with CNTL/Z.
switch(config-sync)# switch-profile s5010
Switch-Profile started, Profile ID is 1
switch(config-sync-sp)# ip igmp snooping report-suppression
switch(config-sync-sp)#
```

Related Commands	Command	Description
	<b>show ip igmp snooping</b>	Displays IGMP snooping information.
	<b>show switch-profile</b>	Displays information about the switch profile and the configuration revision.
	<b>switch-profile</b>	Creates and configures a switch profile.

# ip igmp snooping static-group

To configure a Layer 2 port of a VLAN as a static member of a multicast group, use the **ip igmp snooping static-group** command. To remove the static member, use the **no** form of this command.

**ip igmp snooping static-group** *group* [*source source*] **interface** {*ethernet slot/port* | **port-channel** *number*[*.sub\_if\_number*]}

**no ip igmp snooping static-group** *group* [*source source*] **interface** {*ethernet slot/port* | **port-channel** *number*[*.sub\_if\_number*]}

<b>Syntax Description</b>	<i>group</i>	Group IP address.
	<b>source</b> <i>source</i>	(Optional) Configures a static (S, G) channel for the source IP address.
	<b>interface</b>	Specifies an interface for the static group.
	<b>ethernet</b> <i>slot/port</i>	Specifies the Ethernet interface and the slot number and port number. The slot number is from 1 to 255, and the port number is from 1 to 128.
	<b>port-channel</b> <i>number</i>	Specifies the EtherChannel interface and EtherChannel number. The range is from 1 to 4096.
	<i>sub_if-number</i>	(Optional) Subinterface number. The range is from 1 to 4093.

**Command Default** None

**Command Modes** VLAN configuration mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** This command does not require a license.

**Examples** This example shows how to configure a static member of a multicast group:

```
switch(config)# vlan 1
switch(config-vlan)# ip igmp snooping static-group 230.0.0.1 interface ethernet 2/1
switch(config-vlan)#
```

This example shows how to remove a static member of a multicast group:

```
switch(config)# vlan 1
switch(config-vlan)# no ip igmp snooping static-group 230.0.0.1 interface ethernet 2/1
switch(config-vlan)#
```

ip igmp snooping static-group

Related Commands

Command	Description
show ip igmp snooping	Displays IGMP snooping information.

# ip igmp snooping v3-report-suppression (Global)

To configure IGMPv3 report suppression and proxy reporting for VLANs on the entire device, use the **ip igmp snooping v3-report-suppression** command. To remove IGMPv3 report suppression, use the **no** form of this command.

**ip igmp snooping v3-report-suppression**

**no ip igmp snooping v3-report-suppression**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	Disabled
------------------------	----------

<b>Command Modes</b>	Global configuration mode
----------------------	---------------------------

<b>Command History</b>	Release	Modification
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	This command does not require a license.
-------------------------	--

<b>Examples</b>	This example shows how to configure IGMPv3 report suppression and proxy reporting for VLANs:  switch(config)# <b>ip igmp snooping v3-report-suppression</b> switch(config)#
	This example shows how to remove IGMPv3 report suppression:  switch(config)# <b>no ip igmp snooping v3-report-suppression</b> switch(config)#

<b>Related Commands</b>	Command	Description
	<b>show ip igmp snooping</b>	Displays IGMP snooping information.

# ip igmp snooping syslog-threshold

To configure the syslog threshold for the IP Internet Group Management Protocol (IGMP) snooping table so that a syslog message is generated when the table capacity reaches the specified percentage, use the **ip igmp snooping syslog-threshold** command. To reset the value to the default, use the **no** form of this command.

**ip igmp snooping syslog-threshold** *percentage*

**no ip igmp snooping syslog-threshold**

Syntax Description	<i>percentage</i> Percentage of table capacity. The range is from 1 to 100. The default value is 90 percent.							
Defaults	The IP IGMP snooping table threshold is 90 percent.							
Command Modes	Global configuration mode							
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>5.0(3)U3(2)</td><td>This command was introduced.</td></tr></table>		Release	Modification	5.0(3)U3(2)	This command was introduced.		
Release	Modification							
5.0(3)U3(2)	This command was introduced.							
Usage Guidelines	This command does not require a license.							
Examples	This example shows how to set the syslog threshold to 20 percent for the IP IGMP snooping table:  switch# <b>configure terminal</b> switch(config)# <b>ip igmp snooping syslog-threshold 20</b> switch(config)#							
Related Commands	<table><tr><th>Command</th><th>Description</th></tr><tr><td><b>copy running-config startup config</b></td><td>Copies the running configuration to the startup configuration file.</td></tr><tr><td><b>show running-config</b></td><td>Displays the information for the running configuration.</td></tr></table>		Command	Description	<b>copy running-config startup config</b>	Copies the running configuration to the startup configuration file.	<b>show running-config</b>	Displays the information for the running configuration.
Command	Description							
<b>copy running-config startup config</b>	Copies the running configuration to the startup configuration file.							
<b>show running-config</b>	Displays the information for the running configuration.							



# ip igmp snooping v3-report-suppression (switch profile)

To configure IGMPv3 report suppression in a switch profile, use the **ip igmp snooping v3-report-suppression** command. To remove IGMPv3 report suppression, use the **no** form of this command.

**ip igmp snooping v3-report-suppression**

**no ip igmp snooping v3-report-suppression**

**Syntax Description** This command has no arguments or keywords.

**Command Default** Disabled

**Command Modes** Switch profile configuration mode

Command History	Release	Modification
	5.0(3)U2(1)	This command was introduced.

**Usage Guidelines** This command does not require a license.

**Examples** This example shows how to configure IGMPv3 report suppression in a switch profile:

```
switch# configure sync
Enter configuration commands, one per line. End with CNTL/Z.
switch(config-sync)# switch-profile s5010
Switch-Profile started, Profile ID is 1
switch(config-sync-sp)# ip igmp snooping v3-report-suppression
switch(config-sync-sp)#
```

Related Commands	Command	Description
	<b>show ip igmp snooping</b>	Displays IGMP snooping information.
	<b>show switch-profile</b>	Displays information about the switch profile and the configuration revision.
	<b>switch-profile</b>	Creates and configures a switch profile.

# ip igmp snooping v3-report-suppression (VLAN)

To configure IGMPv3 report suppression and proxy reporting for VLANs, use the **ip igmp snooping v3-report-suppression** command. To remove IGMPv3 report suppression, use the **no** form of this command.

**ip igmp snooping v3-report-suppression**

**no ip igmp snooping v3-report-suppression**

## Syntax Description

This command has no arguments or keywords.

## Command Default

Enabled

## Command Modes

VLAN configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

If this setting is disabled for the device, which is the default value, then it is disabled for all VLANs, irrespective of how you set this value for an individual VLAN. However, once you set the global setting to enabled, the settings for all the VLANs are enabled by default.

This command does not require a license.

## Examples

This example shows how to configure IGMPv3 report suppression and proxy reporting for specified VLANs:

```
switch(config)# vlan 10-20
switch(config-vlan)# ip igmp snooping v3-report-suppression
switch(config-vlan)#
```

This example shows how to remove IGMPv3 report suppression on specified VLANs:

```
switch(config)# vlan 10-20
switch(config-vlan)# no ip igmp snooping v3-report-suppression
switch(config-vlan)#
```

## Related Commands

Command	Description
<b>show ip igmp snooping</b>	Displays IGMP snooping information.

# ip igmp ssm-translate

To translate IGMPv1 or IGMPv2 membership reports to create the (S, G) state so that the router treats them as IGMPv3 membership reports, use the **ip igmp ssm-translate** command. To remove the translation, use the **no** form of this command.

**ip igmp ssm-translate** *group source*

**no ip igmp ssm-translate** *group source*

## Syntax Description

<i>group</i>	IPv4 multicast group range. By default, the group prefix range is 232.0.0.0/8. To modify the IPv4 Protocol Independent Multicast (PIM) Source Specific Multicast (SSM) range, see the <b>ip pim ssm range</b> command.
<i>source</i>	IP multicast address source.

## Command Default

None

## Command Modes

Global configuration mode  
VRF configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

To display SSM translation commands, use this command line:

```
switch(config)# show running-config | include ssm-translation
```

This command does not require a license.

## Examples

This example shows how to configure a translation:

```
switch(config)# ip igmp ssm-translate 232.0.0.0/8 10.1.1.1
switch(config)#
```

This example shows how to remove a translation:

```
switch(config)# no ip igmp ssm-translate 232.0.0.0/8 10.1.1.1
switch(config)#
```

## Related Commands

Command	Description
<b>show running-config</b>	Displays information about the running-system configuration.

# ip igmp startup-query-count

To configure the query count used when the IGMP process starts up, use the **ip igmp startup-query-count** command. To reset the query count to the default, use the **no** form of this command.

```
ip igmp startup-query-count count

no ip igmp startup-query-count [count]
```

Syntax Description	<i>count</i> Query count. The range is from 1 to 10. The default is 2.
--------------------	--

Command Default	The query count is 2.
-----------------	-----------------------

Command Modes	Interface configuration mode
---------------	------------------------------

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines	This command does not require a license but if you want to enable Layer 3 interfaces, you must install the LAN Base Services license.
------------------	---

Examples

This example shows how to configure a query count:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# ip igmp startup-query-count 3
switch(config-if)#
```

This example shows how to reset a query count to the default:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# no ip igmp startup-query-count
switch(config-if)#
```

Related Commands	Command	Description
	<b>show ip igmp interface</b>	Displays IGMP information about the interface.

# ip igmp startup-query-interval

To configure the query interval used when the IGMP process starts up, use the **ip igmp startup-query-interval** command. To reset the query interval to the default, use the **no** form of this command.

**ip igmp startup-query-interval** *interval*

**no ip igmp startup-query-interval** [*interval*]

<b>Syntax Description</b>	<i>interval</i> Query interval in seconds. The range is from 1 to 18,000. The default is 31.				
<b>Command Default</b>	The query interval is 31 seconds.				
<b>Command Modes</b>	Interface configuration mode				
<b>Command History</b>	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>5.0(3)U1(1)</td><td>This command was introduced.</td></tr></table>	Release	Modification	5.0(3)U1(1)	This command was introduced.
Release	Modification				
5.0(3)U1(1)	This command was introduced.				
<b>Usage Guidelines</b>	This command does not require a license but if you want to enable Layer 3 interfaces, you must install the LAN Base Services license.				
<b>Examples</b>	<p>This example shows how to configure a startup query interval:</p> <pre>switch(config)# interface ethernet 2/2 switch(config-if)# no switchport switch(config-if)# ip igmp startup-query-interval 25 switch(config-if)#</pre> <p>This example shows how to reset a startup query interval to the default:</p> <pre>switch(config)# interface ethernet 2/2 switch(config-if)# no switchport switch(config-if)# no ip igmp startup-query-interval switch(config-if)#</pre>				
<b>Related Commands</b>	<table><tr><th>Command</th><th>Description</th></tr><tr><td><b>show ip igmp interface</b></td><td>Displays IGMP information about the interface.</td></tr></table>	Command	Description	<b>show ip igmp interface</b>	Displays IGMP information about the interface.
Command	Description				
<b>show ip igmp interface</b>	Displays IGMP information about the interface.				

# ip igmp state-limit

To configure the maximum states allowed, use the **ip igmp state-limit** command. To remove the state limit, use the **no** form of this command.

**ip igmp state-limit** *max-states* [**reserved** *reserve-policy max-reserved*]

**no ip igmp state-limit** [*max-states* [**reserved** *reserve-policy max-reserved*]]

## Syntax Description

<i>max-states</i>	Maximum states allowed. The range is from 1 to 4,294,967,295.
<b>reserved</b>	(Optional) Specifies to use the route-map policy name for the reserve policy. The route map name can be a maximum of 100 alphanumeric characters.
<i>reserve-policy</i>	
<i>max-reserved</i>	
<i>max-reserved</i>	(Optional) Maximum number of (*, G) and (S, G) entries allowed on the interface.

## Command Default

None

## Command Modes

Interface configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

This command does not require a license but if you want to enable Layer 3 interfaces, you must install the LAN Base Services license.

## Examples

This example shows how to configure a state limit:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# ip igmp state-limit 5000
switch(config-if)#
```

This example shows how to remove a state limit:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# no ip igmp state-limit
switch(config-if)#
```

## Related Commands

Command	Description
<b>show ip igmp interface</b>	Displays IGMP information about the interface.

# ip igmp static-oif

To statically bind a multicast group to the outgoing interface (OIF), which is handled by the device hardware, use the **ip igmp static-oif** command. To remove a static group, use the **no** form of this command.

**ip igmp static-oif** { *group* [*source source*] | **route-map** *policy-name* }

**no ip igmp static-oif** { *group* [*source source*] | **route-map** *policy-name* }

<b>Syntax Description</b>	<i>group</i>	Multicast group IPv4 address. If you specify only the group address, the (*, G) state is created.
	<b>source</b> <i>source</i>	(Optional) Configures the source IP address for IGMPv3 and creates the (S, G) state. <b>Note</b> A source tree is built for the (S, G) state only if you enable IGMPv3.
	<b>route-map</b> <i>policy-name</i>	Specifies the route-map policy name that defines the group prefixes where this feature is applied. The route map name can be a maximum of 63 alphanumeric characters.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Interface configuration mode
----------------------	------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	Before you use this command, make sure that you enable Protocol Independent Multicast (PIM) on the interface by using the <b>ip pim sparse-mode</b> command.
	This command does not require a license but if you want to enable Layer 3 interfaces, you must install the LAN Base Services license.

<b>Examples</b>	This example shows how to statically bind a group to the OIF:
-----------------	---

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# ip igmp static-oif 230.0.0.0
switch(config-if)#
```

This example shows how to remove a static binding from the OIF:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# no ip igmp static-oif 230.0.0.0
switch(config-if)#
```

Related Commands	Command	Description
	<b>ip pim sparse-mode</b>	Enables IPv4 PIM sparse mode on an interface.
	<b>no switchport</b>	Configures the interface as a routed interface.
	<b>show ip igmp local-groups</b>	Displays information about the IGMP local group membership.



# ip igmp syslog-threshold

To configure the syslog threshold for the IP Internet Group Management Protocol (IGMP) table so that a syslog message is generated when the table capacity reaches the specified percentage, use the **ip igmp syslog-threshold** command. To reset the value to the default, use the **no** form of this command.

**ip igmp syslog-threshold** *percentage*

**no ip igmp syslog-threshold**

Syntax Description	<i>percentage</i>	Percentage of table capacity. The range is from 1 to 100. The default value is 90 percent.
--------------------	-------------------	--

Defaults	The IP IGMP table threshold is 90 percent.
----------	--

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	5.0(3)U3(2)	This command was introduced.

Usage Guidelines	This command does not require a license.
------------------	--

Examples	This example shows how to set the syslog threshold to 20 percent for the IP IGMP table:
----------	---

```
switch# configure terminal
switch(config)# ip igmp syslog-threshold 20
switch(config)#
```

Related Commands	Command	Description
	<b>copy running-config startup config</b>	Copies the running configuration to the startup configuration file.
	<b>show running-config</b>	Displays the information for the running configuration.

# ip igmp version

To configure the IGMP version to use on an interface, use the **ip igmp version** command. To reset the IGMP version to the default, use the **no** form of this command.

**ip igmp version** *version*

**no ip igmp version** [*version*]

## Syntax Description

<i>version</i>	Version number. The number is 2 or 3. The default is 2.
----------------	---

## Command Default

The version number is 2.

## Command Modes

Interface configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

This command does not require a license but if you want to enable Layer 3 interfaces, you must install the LAN Base Services license.

## Examples

This example shows how to configure the IGMP version to use on an interface:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# ip igmp version 3
switch(config-if)#
```

This example shows how to reset the IGMP version to the default:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# no ip igmp version
switch(config-if)#
```

## Related Commands

Command	Description
<b>show ip igmp interface</b>	Displays IGMP information about the interface.

# ip mfwd mstatic

To register multicast forwarding (MFWD) static routes, use the **ip mfwd mstatic** command. To remove the MFWD static routes, use the **no** form of this command.

**ip mfwd mstatic register**

**no ip mfwd mstatic register**

Syntax Description	register	Registers the multicast static routes.
--------------------	----------	--

Command Default	None
-----------------	------

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	5.0(3)U2(1)	This command was introduced.

Usage Guidelines	If the switch receives multicast traffic from a source that is not attached, a (S, G) route is not created and the traffic continuously enters the CPU.
------------------	---

Use this command after configuring multicast reverse path forwarding (RPF) static routes to create (S, G) routes and prevent the multicast traffic from coming to the CPU. For each multicast static route, the register messages are periodically sent to the rendezvous point (RP) and the Multicast Source Discovery Protocol (MSDP) Source-Active (SA) messages are sent to the peer.

This command does not require a license.

Examples	This example shows how to register a multicast forwarding static route:
----------	---

```
switch(config)# ip mroute 192.0.2.33/24 192.0.2.1
switch(config)# ip mfwd mstatic register
switch(config)#
```

This example shows how to deregister a multicast forwarding static route:

```
switch(config)# no ip mfwd mstatic register
switch(config)#
```

Related Commands	Command	Description
	<b>ip mroute</b>	Configures multicast reverse path forwarding (RPF) static routes.
	<b>show ip mroute</b>	Displays information about multicast routes.
	<b>show ip igmp snooping</b>	Displays information about IGMP snooping.

# ip mroute

To configure multicast reverse path forwarding (RPF) static routes, use the **ip mroute** command. To remove RPF static routes, use the **no** form of this command.

**ip mroute** {*ip-addr ip-mask* | *ip-prefix*} [{*next-hop* | *nh-prefix*} | {**ethernet** *slot/port* | **loopback** *if\_number* | **port-channel** *number* | **vlan** *vlan-id*}] [*pref*] [**vrf** *vrf-name*]

**no ip mroute** {*ip-addr ip-mask* | *ip-prefix*} [{*next-hop* | *nh-prefix*} | {**ethernet** *slot/port* | **loopback** *if\_number* | **port-channel** *number* | **vlan** *vlan-id*}] [*pref*] [**vrf** *vrf-name*]

## Syntax Description

<i>ip-addr</i>	IP prefix in the format i.i.i.i.
<i>ip-mask</i>	IP network mask in the format m.m.m.m.
<i>ip-prefix</i>	IP prefix and network mask length in the format x.x.x.x/m.
<i>next-hop</i>	IP next-hop address in the format i.i.i.i.
<i>nh-prefix</i>	IP next-hop prefix in the format i.i.i.i/m.
<b>ethernet</b> <i>slot/port</i>	Specifies the Ethernet interface and the slot number and port number. The slot number is from 1 to 255, and the port number is from 1 to 128.
<b>loopback</b> <i>if_number</i>	Specifies the loopback interface. The loopback interface number is from 0 to 1023.
<b>port-channel</b> <i>number</i>	Specifies the EtherChannel interface and EtherChannel number. The range is from 1 to 4096.
<b>vlan</b> <i>vlan-id</i>	Specifies the VLAN interface. The range is from 1 to 4094.
<i>pref</i>	(Optional) Route preference. The range is from 1 to 255. The default is 1.
<b>vrf</b> <i>vrf-name</i>	(Optional) Specifies the virtual routing and forwarding (VRF) context name. The name can be any case-sensitive, alphanumeric string up to 32 characters.

## Command Default

The route preference is 1.

## Command Modes

Global configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

This command does not require a license.

## Examples

This example shows how to configure an RPF static route:

```
switch(config)# ip mroute 192.0.2.33/24 192.0.2.1
switch(config)#
```

This example shows how to remove an RPF static route:

```
switch(config)# no ip mroute 192.0.2.33/24 192.0.2.1
switch(config)#
```

**Related Commands**

Command	Description
<b>show ip mroute</b>	Displays information about multicast routes.

# ip msdp description

To configure a description for the Multicast Source Discovery Protocol (MSDP) peer, use the **ip msdp description** command. To remove the description for the peer, use the **no** form of this command.

**ip msdp description** *peer-address text*

**no ip msdp description** *peer-address [text]*

<b>Syntax Description</b>	<i>peer-address</i>	IP address of MSDP peer.
	<i>text</i>	Text description.
<b>Command Default</b>	None	
<b>Command Modes</b>	Global configuration mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.
<b>Usage Guidelines</b>	This command requires the LAN Base Services license.	
<b>Examples</b>	This example shows how to configure an MSDP peer description:	
	<pre>switch(config)# ip msdp description 192.168.1.10 engineering peer switch(config)#</pre>	
<b>Examples</b>	This example shows how to remove an MSDP peer description:	
	<pre>switch(config)# no ip msdp description 192.168.1.10 switch(config)#</pre>	
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show ip msdp peer</b>	Displays information about MSDP peers.

# ip msdp event-history

To configure the size of the Multicast Source Discovery Protocol (MSDP) event history buffers, use the **ip msdp event-history** command. To revert to the default buffer size, use the **no** form of this command.

**ip msdp event-history** { **cli** | **events** | **msdp-internal** | **routes** | **tcp** } **size** *buffer-size*

**no ip msdp event-history** { **cli** | **events** | **msdp-internal** | **routes** | **tcp** } **size** *buffer-size*

Syntax Description		
<b>cli</b>		Configures the CLI event history buffer.
<b>events</b>		Configures the peer-events event history buffer.
<b>msdp-internal</b>		Configures the MSDP internal event history buffer.
<b>routes</b>		Configures the routes event history buffer.
<b>tcp</b>		Configures the TCP event history buffer.
<b>size</b>		Specifies the size of the buffer to allocate.
<i>buffer-size</i>		Buffer size that is one of the following values: <b>disabled</b> , <b>large</b> , <b>medium</b> , or <b>small</b> . The default buffer size is <b>small</b> .

**Command Default** All history buffers are allocated as small.

**Command Modes** Any command mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** This command requires the LAN Base Services license.

**Examples** This example shows how to configure the size of the MSDP event history buffer:

```
switch(config)# ip msdp event-history events size medium
switch(config)#
```

Related Commands	Command	Description
	<b>clear ip routing multicast event-history</b>	Clears information in the IPv4 MRIB event history buffers.

Command	Description
<b>show routing ip multicast event-history</b>	Displays information in the IPv4 MRIB event history buffers.
<b>show running-config msdp</b>	Displays information about the running-system MSDP configuration.



# ip msdp flush-routes

To flush routes when the Multicast Source Discovery Protocol (MSDP) process is restarted, use the **ip msdp flush-routes** command. To leave routes in place, use the **no** form of this command.

**ip msdp flush-routes**

**no ip msdp flush-routes**

**Syntax Description** This command has no arguments or keywords.

**Command Default** The routes are not flushed.

**Command Modes** Global configuration mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** To display whether flush routes is configured, use this command line:

```
switch(config)# show running-config | include flush-routes
```

This command requires the LAN Base Services license.

**Examples** This example shows how to configure flushing routes when the MSDP process is restarted:

```
switch(config)# ip msdp flush-routes
switch(config)#
```

This example shows how to configure leaving routes when the MSDP process is restarted:

```
switch(config)# no ip msdp flush-routes
switch(config)#
```

Related Commands	Command	Description
	show running-config	Displays information about the running-system configuration.

# ip msdp group-limit

To configure the Multicast Source Discovery Protocol (MSDP) maximum number of (S, G) entries that the software creates for the specified prefix, use the **ip msdp group-limit** command. To remove the group limit, use the **no** form of this command.

**ip msdp group-limit** *limit source prefix*

**no ip msdp group-limit** *limit source prefix*

Syntax Description	<i>limit</i>	Limit on number of groups. The range is from 0 to 4294967295. The default is no limit.
	<i>source prefix</i>	Specifies the prefix to match sources against.

Command Default	None
-----------------	------

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines	This command requires the LAN Base Services license.
------------------	--

Examples	This example shows how to configure the maximum number of (S, G) entries to create for a source:  switch(config)# <b>ip msdp group-limit 4000 source 192.168.1.0/24</b> switch(config)#
	This example shows how to remove the limit entries to create:  switch(config)# <b>no ip msdp group-limit 4000 source 192.168.1.0/24</b> switch(config)#

Related Commands	Command	Description
	<b>show ip msdp sources</b>	Displays information about the MSDP learned sources and group limit.

# ip msdp keepalive

To configure a Multicast Source Discovery Protocol (MSDP) peer keepalive interval and timeout, use the **ip msdp keepalive** command. To reset the timeout and interval to the default, use the **no** form of this command.

**ip msdp keepalive** *peer-address interval timeout*

**no ip msdp keepalive** *peer-address [interval timeout]*

## Syntax Description

<i>peer-address</i>	IP address of an MSDP peer.
<i>interval</i>	Keepalive interval in seconds. The range is from 1 to 60. The default is 60.
<i>timeout</i>	Keepalive timeout in seconds. The range is from 1 to 90. The default is 90.

## Command Default

The keepalive interval is 60 seconds.

The keepalive timeout is 90 seconds.

## Command Modes

Global configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

This command requires the LAN Base Services license.

## Examples

This example shows how to configure an MSDP peer keepalive interval and timeout:

```
switch(config)# ip msdp keepalive 192.168.1.10 60 80
switch(config)#
```

This example shows how to reset a keepalive interval and timeout to the default:

```
switch(config)# no ip msdp keepalive 192.168.1.10
switch(config)#
```

## Related Commands

Command	Description
<b>show ip msdp peer</b>	Displays information about MSDP peers.

# ip msdp mesh-group

To configure a Multicast Source Discovery Protocol (MSDP) mesh group with a peer, use the **ip msdp mesh-group** command. To remove the peer from one or all mesh groups, use the **no** form of this command.

**ip msdp mesh-group** *peer-address name*

**no ip msdp mesh-group** *peer-address [name]*

<b>Syntax Description</b>	<i>peer-address</i>	IP address of an MSDP peer in a mesh group.
	<i>name</i>	Name of mesh-group.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global configuration mode
----------------------	---------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	This command requires the LAN Base Services license.
-------------------------	--

<b>Examples</b>	This example shows how to configure a mesh group with a peer:
	<pre>switch(config)# ip msdp mesh-group 192.168.1.10 my_admin_mesh switch(config)#</pre>

This example shows how to remove a peer from a mesh group:

```
switch(config)# no ip msdp mesh-group 192.168.1.10 my_admin_mesh
switch(config)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show ip msdp mesh-group</b>	Displays information about MSDP mesh groups.

# ip msdp originator-id

To configure the IP address used in the rendezvous point (RP) field of a Source-Active message entry, use the **ip msdp originator-id** command. To reset the value to the default, use the **no** form of this command.

**ip msdp originator-id** *if-type if-number*

**no ip msdp originator-id** [*if-type if-number*]

<b>Syntax Description</b>	<i>if-type</i>	Interface type. For more information, use the question mark (?) online help function.
	<i>if-number</i>	Interface or subinterface number. For more information about the numbering syntax for your networking device, use the question mark (?) online help function.

**Command Default** The MSDP process uses the RP address of the local system.

**Command Modes** Global configuration mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** This command requires the LAN Base Services license.

**Examples** This example shows how to configure the IP address used in the RP field of SA messages:

```
switch(config)# ip msdp originator-id loopback0
switch(config)#
```

This example shows how to reset the RP address to the default:

```
switch(config)# no ip msdp originator-id loopback0
switch(config)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show ip msdp summary</b>	Displays a summary of MDSP information.

# ip msdp password

To enable a Multicast Source Discovery Protocol (MSDP) MD5 password for the peer, use the **ip msdp password** command. To disable an MD5 password for a peer, use the **no** form of this command.

**ip msdp password** *peer-address password*

**no ip msdp password** *peer-address [password]*

<b>Syntax Description</b>	<i>peer-address</i>	IP address of an MSDP peer.
	<i>password</i>	MD5 password.
<b>Command Default</b>	None	
<b>Command Modes</b>	Global configuration mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.
<b>Usage Guidelines</b>	This command requires the LAN Base Services license.	
<b>Examples</b>	This example shows how to enable an MD5 password for a peer:	
	<pre>switch(config)# ip msdp password 192.168.1.10 my_password switch(config)#</pre>	
<b>Examples</b>	This example shows how to disable an MD5 password for a peer:	
	<pre>switch(config)# no ip msdp password 192.168.1.10 switch(config)#</pre>	
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show ip msdp peer</b>	Displays MDSP peer information.

# ip msdp peer

To configure a Multicast Source Discovery Protocol (MSDP) peer with the specified peer IP address, use the **ip msdp peer** command. To remove an MSDP peer, use the **no** form of this command.

**ip msdp peer** *peer-address* **connect-source** *if-type if-number* [**remote-as** *asn*]

**no ip msdp peer** *peer-address* [**connect-source** *if-type if-number*] [**remote-as** *asn*]

## Syntax Description

<i>peer-address</i>	IP address of the MSDP peer.
<b>connect-source</b>	Configures a local IP address for a TCP connection.
<i>if-type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>if-number</i>	Interface or subinterface number. For more information about the numbering syntax for your networking device, use the question mark (?) online help function.
<b>remote-as</b> <i>asn</i>	(Optional) Configures a remote autonomous system (AS) number.

## Command Default

None

## Command Modes

Global configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

The software uses the source IP address of the interface for the TCP connection with the peer. If the AS number is the same as the local AS, then the peer is within the Protocol Independent Multicast (PIM) domain; otherwise, this peer is external to the PIM domain.

This command requires the LAN Base Services license.

## Examples

This example shows how to configure an MSDP peer:

```
switch(config)# ip msdp peer 192.168.1.10 connect-source ethernet 1/0 remote-as 8
switch(config)#
```

This example shows how to remove an MSDP peer:

```
switch(config)# no ip msdp peer 192.168.1.10
switch(config)#
```

## Related Commands

Command	Description
<b>show ip msdp summary</b>	Displays a summary of MSDP information.

# ip msdp reconnect-interval

To configure a reconnect interval for the TCP connection, use the **ip msdp reconnect-interval** command. To reset a reconnect interval to the default, use the **no** form of this command.

**ip msdp reconnect-interval** *interval*

**no ip msdp reconnect-interval** [*interval*]

<b>Syntax Description</b>	<i>interval</i> Reconnect interval in seconds. The range is from 1 to 60. The default is 10.	
<b>Command Default</b>	The reconnect interval is 10 seconds.	
<b>Command Modes</b>	Global configuration mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.
<b>Usage Guidelines</b>	This command requires the LAN Base Services license.	
<b>Examples</b>	This example shows how to configure a reconnect interval for the TCP connection:	
	<pre>switch(config)# ip msdp reconnect-interval 20 switch(config)#</pre>	
	This example shows how to reset a reconnect interval to the default:	
	<pre>switch(config)# no ip msdp reconnect-interval switch(config)#</pre>	
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	show ip msdp peer	Displays information about MSDP peers.



# ip msdp sa-interval

To configure the interval at which the software transmits Source-Active (SA) messages, use the **ip msdp sa-interval** command. To reset the interval to the default, use the **no** form of this command.

**ip msdp sa-interval** *interval*

**no ip msdp sa-interval** [*interval*]

Syntax Description	<i>interval</i> SA transmission interval in seconds. The range is from 60 to 65,535. The default is 60.
--------------------	---

Command Default	The SA message interval is 60 seconds.
-----------------	--

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines	<p>To display the SA interval configuration command, use this command line:</p> <pre>switch(config)# show running-config   include sa-interval</pre> <p>This command requires the LAN Base Services license.</p>
------------------	--

Examples	<p>This example shows how to configure an SA transmission interval:</p>
----------	---

```
switch(config)# ip msdp sa-interval 100
switch(config)#
```

This example shows how to reset the interval to the default:

```
switch(config)# no ip msdp sa-interval
switch(config)#
```

Related Commands	Command	Description
	<b>show running-config</b>	Displays information about the running-system configuration.

# ip msdp sa-limit

To configure a limit on the number of (S, G) entries accepted from the peer, use the **ip msdp sa-limit** command. To remove the limit, use the **no** form of this command.

```
ip msdp sa-limit peer-address limit

no ip msdp sa-limit peer-address [limit]
```

Syntax Description	<i>peer-address</i>	IP address of an MSDP peer.
	<i>limit</i>	Number of (S, G) entries. The range is from 0 to 4294967295. The default is none.
Command Default	None	
Command Modes	Global configuration mode	
Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.
Usage Guidelines	This command requires the LAN Base Services license.	
Examples	This example shows how to configure a Source-Active (SA) limit for a peer:	
	<pre>switch(config)# ip msdp sa-limit 192.168.1.10 5000 switch(config)#</pre>	
	This example shows how to reset the limit to the default:	
	<pre>switch(config)# no ip msdp sa-limit 192.168.1.10 switch(config)#</pre>	
Related Commands	Command	Description
	show ip msdp peer	Displays information about MSDP peers.

# ip msdp sa-policy in

To enable filtering of incoming Multicast Source Discovery Protocol (MSDP) Source-Active (SA) messages, use the **ip msdp sa-policy in** command. To disable filtering, use the **no** form of this command.

**ip msdp sa-policy** *peer-address* *policy-name* **in**

**no ip msdp sa-policy** *peer-address* *policy-name* **in**

Syntax Description	<i>peer-address</i>	IP address of an MSDP peer.
	<i>policy-name</i>	Route-map policy name.
Command Default	Disabled	
Command Modes	Global configuration mode	
Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.
Usage Guidelines	This command requires the LAN Base Services license.	
Examples	This example shows how to enable filtering of incoming SA messages:  switch(config)# <b>ip msdp sa-policy 192.168.1.10 my_incoming_sa_policy in</b> switch(config)#	
	This example shows how to disable filtering:  switch(config)# <b>no ip msdp sa-policy 192.168.1.10 my_incoming_sa_policy in</b> switch(config)#	
Related Commands	Command	Description
	<b>show ip msdp peer</b>	Displays information about MSDP peers.

# ip msdp sa-policy out

To enable filtering of outgoing Source-Active (SA) messages, use the **ip msdp sa-policy out** command. To disable filtering, use the **no** form of this command.

**ip msdp sa-policy** *peer-address* *policy-name* **out**

**no ip msdp sa-policy** *peer-address* *policy-name* **out**

Syntax Description	<i>peer-address</i>	IP address of an MSDP peer.
	<i>policy-name</i>	Route-map policy name.
Command Default	Disabled	
Command Modes	Global configuration mode	
Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.
Usage Guidelines	This command requires the LAN Base Services license.	
Examples	This example shows how to enable filtering of SA messages:  switch(config)# <b>ip msdp sa-policy 192.168.1.10 my_incoming_sa_policy out</b> switch(config)#	
	This example shows how to disable filtering:  switch(config)# <b>no ip msdp sa-policy 192.168.1.10 my_incoming_sa_policy out</b> switch(config)#	
Related Commands	Command	Description
	<b>show ip msdp peer</b>	Displays information about MSDP peers.

# ip msdp shutdown

To shut down a Multicast Source Discovery Protocol (MSDP) peer, use the **ip msdp shutdown** command. To enable the peer, use the **no** form of this command.

**ip msdp shutdown** *peer-address*

**no ip msdp shutdown** *peer-address*

<b>Syntax Description</b>	<i>peer-address</i> IP address of an MSDP peer.	
<b>Command Default</b>	Enabled	
<b>Command Modes</b>	Global configuration mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.
<b>Usage Guidelines</b>	This command requires the LAN Base Services license.	
<b>Examples</b>	This example shows how to disable an MSDP peer:  switch(config)# <b>ip msdp shutdown 192.168.1.10</b> switch(config)#	
	This example shows how to enable an MSDP peer:  switch(config)# <b>no ip msdp shutdown 192.168.1.10</b> switch(config)#	
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show ip msdp peer</b>	Displays information about MSDP peers.

# ip multicast multipath

To disable automatic selection of the reverse path forwarding (RPF) interface for multicast when multiple equal cost multipath (ECMP) paths are available, use the **ip multicast multipath** command.

## ip multicast multipath none

<b>Syntax Description</b>	none	Disables the ECMP multicast load splitting.
---------------------------	------	---

<b>Command Default</b>	Enabled
------------------------	---------

<b>Command Modes</b>	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	5.0(3)U4(1)	This command was introduced.

<b>Usage Guidelines</b>	This command does not require a license.
-------------------------	--

<b>Examples</b>	This example shows how to disable automatic selection of the RPF interface for multicast when multiple ECMP paths are available:
-----------------	--

```
switch # configure terminal
switch(config)# ip multicast multipath none
switch(config)#
```

Related Commands	Command	Description
	<b>clear ip pim route</b>	Clears the routes specific to Protocol Independent Multicast (PIM) for IPv4.
	<b>clear ip igmp groups</b>	Clears the IGMP-related information in the IPv4 multicast routing table.
	<b>clear routing multicast</b>	Clears the multicast routing table.
	<b>show ip mroute</b>	Displays information about the multicast routing table.

## ip pim anycast-rp

To configure an IPv4 Protocol Independent Multicast (PIM) Anycast-RP peer for the specified Anycast-RP address, use the **ip pim anycast-rp** command. To remove the peer, use the **no** form of this command.

```
ip pim anycast-rp anycast-rp rp-addr
```

```
no ip pim anycast-rp anycast-rp rp-addr
```

### Syntax Description

<i>anycast-rp</i>	Anycast-RP address of the peer.
<i>rp-addr</i>	Address of the rendezvous point (RP) in the Anycast-RP set.

### Command Default

None

### Command Modes

Global configuration mode  
VRF configuration mode

### Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

### Usage Guidelines

Each command with the same Anycast-RP address forms an Anycast-RP set. The IP addresses of rendezvous points (RPs) are used for communication with RPs in the set.

To configure PIM Anycast-RP, you must configure the static RP address that will be used as the Anycast-RP address for all routes, and then configure the peer Anycast-RP address.

This command requires the LAN Base Services license.

### Examples

This example shows how to configure a PIM Anycast-RP peer:

```
switch# configure terminal  
switch(config)# ip pim rp-address 192.0.2.3  
switch(config)# ip pim anycast-rp 192.0.2.3 192.0.2.31  
switch(config)#
```

This example shows how to remove a peer:

```
switch# configure terminal  
switch(config)# no ip pim anycast-rp 192.0.2.3 192.0.2.31  
switch(config)#
```

**Related Commands**

Command	Description
<b>ip pim rp-address</b>	Configures an IPv4 PIM static RP address for a multicast group range.
<b>show ip pim rp</b>	Displays information about PIM RPs.



# ip pim auto-rp listen

To enable Protocol Independent Multicast (PIM) listening and forwarding of Auto-RP messages, use the **ip pim auto-rp listen** and **ip pim auto-rp forward** commands. To disable the listening and forwarding of Auto-RP messages, use the **no** form of this command.

**ip pim auto-rp {listen [forward] | forward [listen]}**

**no ip pim auto-rp [{listen [forward] | forward [listen]}]**

<b>Syntax Description</b>	<b>listen</b>	Specifies to listen to Auto-RP messages.
	<b>forward</b>	Specifies to forward Auto-RP messages.

**Command Default** Disabled

**Command Modes** Global configuration mode  
VRF configuration mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** This command requires the LAN Base Services license.

**Examples** This example shows how to enable listening and forwarding of Auto-RP messages:

```
switch(config)# ip pim auto-rp listen forward
switch(config)#
```

This example shows how to disable listening and forwarding of Auto-RP messages:

```
switch(config)# no ip pim auto-rp listen forward
switch(config)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show ip pim rp</b>	Displays information about PIM RPs.

# ip pim auto-rp mapping-agent

To configure the router as an IPv4 Protocol Independent Multicast (PIM) Auto-RP mapping agent that sends RP-Discovery messages, use the **ip pim auto-rp mapping-agent** command. To remove the mapping agent configuration, use the **no** form of this command.

```
ip pim auto-rp mapping-agent if-type if-number [scope ttl]

no ip pim auto-rp mapping-agent [if-type if-number] [scope ttl]
```

Syntax Description	if-type	Interface type. For more information, use the question mark (?) online help function.
	if-number	Interface or subinterface number. For more information about the numbering syntax for your networking device, use the question mark (?) online help function.
	scope ttl	(Optional) Specifies the time-to-live (TTL) value for the scope of Auto-RP Discovery messages. The range is from 1 to 255. The default is 32.
	<b>Note</b> See the <b>ip pim border</b> command to explicitly define a router on the edge of a PIM domain rather than using the <b>scope</b> argument.	

Command Default The TTL is 32.

Command Modes Global configuration mode  
VRF configuration mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines The **ip pim send-rp-discovery** command is an alternative form of this command. This command requires the LAN Base Services license.

Examples This example shows how to configure an Auto-RP mapping agent:

```
switch(config)# ip pim auto-rp mapping-agent ethernet 2/1
switch(config)#
```

This example shows how to remove the Auto-RP mapping agent configuration:

```
switch(config)# no ip pim auto-rp mapping-agent ethernet 2/1
switch(config)#
```

Related Commands	Command	Description
	<b>ip pim border</b>	Configures a router to be on the edge of a PIM domain.
	<b>ip pim send-rp-discovery</b>	Configures a router as an Auto-RP mapping agent.
	<b>show ip pim rp</b>	Displays information about PIM rendezvous points (RPs).

# ip pim auto-rp mapping-agent-policy

To enable filtering of IPv4 IPv4 Protocol Independent Multicast (PIM) Auto-RP Discover messages, use the **ip pim auto-rp mapping-agent-policy** command. To disable filtering, use the **no** form of this command.

**ip pim auto-rp mapping-agent-policy** *policy-name*

**no ip pim auto-rp mapping-agent-policy** [*policy-name*]

## Syntax Description

*policy-name* Route-map policy name.

## Command Default

Disabled

## Command Modes

Global configuration mode  
VRF configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

This command can be used on client routers where you can specify mapping agent addresses.

You can specify mapping agent source addresses to filter messages from with the **match ip multicast** command in a route-map policy.

This command requires the LAN Base Services license.

## Examples

This example shows how to enable a route-map policy to filter Auto-RP Discover messages:

```
switch(config)# ip pim auto-rp mapping-agent-policy my_mapping_agent_policy
switch(config)#
```

This example shows how to disable filtering:

```
switch(config)# no ip pim auto-rp mapping-agent-policy
switch(config)#
```

## Related Commands

Command	Description
<b>show ip pim rp</b>	Displays information about PIM rendezvous points (RPs).

# ip pim auto-rp rp-candidate

To configure an IPv4 Protocol Independent Multicast (PIM) Auto-RP candidate route processor (RP), use the **ip pim auto-rp rp-candidate** command. To remove an Auto-RP candidate RP, use the **no** form of this command.

**ip pim auto-rp rp-candidate** *if-type if-number* { **group-list prefix** } { [**scope ttl**] | [**interval interval**] }

**no ip pim auto-rp rp-candidate** [*if-type if-number*] [**group-list prefix**] { [**scope ttl**] | [**interval interval**] }

<b>Syntax Description</b>	<i>if-type</i>	Interface type. For more information, use the question mark (?) online help function.
	<i>if-number</i>	Interface or subinterface number. For more information about the numbering syntax for your networking device, use the question mark (?) online help function.
	<b>group-list prefix</b>	Specifies the group range used for the access list.
	<b>scope ttl</b>	(Optional) Specifies a time-to-live (TTL) value for the scope of Auto-RP Announce messages. The range is from 1 to 255. The default is 32.
		<b>Note</b> See the <b>ip pim border</b> command to explicitly define a router on the edge of a PIM domain rather than using the <b>scope</b> argument.
	<b>interval interval</b>	(Optional) Specifies an Auto-RP Announce message transmission interval in seconds. The range is from 1 to 65,535. The default is 60.

<b>Command Default</b>	The TTL is 32.
	The Announce message interval is 60 seconds

<b>Command Modes</b>	Global configuration mode
	VRF configuration mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	The <b>scope</b> and <b>interval</b> keywords can be entered once and in any order.
	The <b>ip pim send-rp-announce</b> command is an alternative form of this command.
	Using a route map, you can add group ranges that this auto rendezvous point (RP) candidate-RP can serve.



## Note

Use the same configuration guidelines for the route-map auto-rp-range that you used when you create a route map for static RPs.

This command requires the LAN Base Services license.

Examples

This example shows how to configure a PIM Auto-RP candidate RP:

```
switch(config)# ip pim auto-rp rp-candidate ethernet 2/1 group-list 239.0.0.0/24
switch(config)#
```

This example shows how to remove a PIM Auto-RP candidate RP:

```
switch(config)# no ip pim auto-rp rp-candidate ethernet 2/1 group-list 239.0.0.0/24
switch(config)#
```

Related Commands

Command	Description
ip pim send-rp-announce	Configures a PIM Auto-RP candidate RP.
show ip pim interface	Displays information about PIM-enabled interfaces.

# ip pim auto-rp rp-candidate-policy

To allow the Auto-RP mapping agents to filter IPv4 Protocol Independent Multicast (PIM) Auto-RP Announce messages that are based on a route-map policy, use the **ip pim auto-rp rp-candidate-policy** command. To disable filtering, use the **no** form of this command.

**ip pim auto-rp rp-candidate-policy** *policy-name*

**no ip pim auto-rp rp-candidate-policy** [*policy-name*]

## Syntax Description

*policy-name*      Route-map policy name.

## Command Default

Disabled

## Command Modes

Global configuration mode  
VRF configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

You can specify the rendezvous point (RP) and group addresses and whether the type is ASM with the **match ip multicast** command in a route-map policy.

This command requires the LAN Base Services license.

## Examples

This example shows how to allow the Auto-RP mapping agents to filter Auto-RP Announce messages:

```
switch(config)# ip pim auto-rp rp-candidate-policy my_policy
```

This example shows how to disable filtering:

```
switch(config)# no ip pim auto-rp rp-candidate-policy  
switch(config)#
```

## Related Commands

Command	Description
<b>show ip pim rp</b>	Displays information about PIM RPs.

# ip pim border

To configure an interface on an IPv4 Protocol Independent Multicast (PIM) border, use the **ip pim border** command. To remove an interface from a PIM border, use the **no** form of this command.

```
ip pim border
no ip pim border
```

**Syntax Description** This command has no arguments or keywords.

**Command Default** The interface is not on a PIM border.

**Command Modes** Interface configuration mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** This command requires the LAN Base Services license.

**Examples** This example shows how to configure an interface on a PIM border:

```
switch(config)# ip pim border
```

This example shows how to remove an interface from a PIM border:

```
switch(config)# no ip pim border
switch(config)#
```

Related Commands	Command	Description
	show ip pim interface	Displays information about PIM-enabled interfaces.



# ip pim bsr bsr-policy

To allow the bootstrap router (BSR) client routers to filter IPv4 Protocol Independent Multicast (PIM) BSR messages that are based on a route-map policy, use the **ip pim bsr bsr-policy** command. To disable filtering, use the **no** form of this command.

**ip pim bsr bsr-policy** *policy-name*

**no ip pim bsr bsr-policy** [*policy-name*]

## Syntax Description

*policy-name* Route-map policy name.

## Command Default

Disabled

## Command Modes

Global configuration mode  
VRF configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

You can specify which source addresses to filter messages from with the **match ip multicast** command in a route-map policy.

This command requires the LAN Base Services license.

## Examples

This example shows how to allow the BSR client routers to filter BSR messages:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# ip pim bsr bsr-policy my_bsr_policy
```

This example shows how to disable filtering:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# no ip pim bsr bsr-policy
switch(config-if)#
```

## Related Commands

Command	Description
<b>show ip pim rp</b>	Displays information about PIM rendezvous points (RPs).

# ip pim bsr-candidate

To configure the router as an IPv4 Protocol Independent Multicast (PIM) bootstrap router (BSR) candidate, use the **ip pim bsr-candidate** command. To remove a router as a BSR candidate, use the **no** form of this command.

**ip pim [bsr] bsr-candidate** *if-type if-number* [**hash-len** *hash-len*] [**priority** *priority*]

**no ip pim [bsr] bsr-candidate** [*if-type if-number*] [**hash-len** *hash-len*] [**priority** *priority*]

<b>Syntax Description</b>	<b>bsr</b>	(Optional) Specifies the BSR protocol RP-distribution configuration.
	<i>if-type</i>	Interface type. For more information, use the question mark (?) online help function.
	<i>if-number</i>	Interface or subinterface number. For more information about the numbering syntax for your networking device, use the question mark (?) online help function.
	<b>hash-len</b> <i>hash-len</i>	(Optional) Specifies the hash mask length used in BSR messages. The range is from 0 to 32. The default is 30.
	<b>priority</b> <i>priority</i>	(Optional) Specifies the BSR priority used in BSR messages. The range is from 0 to 255. The default is 64.

<b>Command Default</b>	The hash mask length is 30. The BSR priority is 64.
------------------------	--

<b>Command Modes</b>	Global configuration mode VRF configuration mode
----------------------	---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	The interface specified is used to derive the BSR source IP address used in BSR messages. This command requires the LAN Base Services license.
-------------------------	---

**Examples** This example shows how to configure a router as a BSR candidate:

```
switch(config)# ip pim bsr-candidate ethernet 2/2
```

This example shows how to remove a router as a BSR candidate:

```
switch(config)# no ip pim bsr-candidate
switch(config)#
```

**Related Commands**

Command	Description
<b>show ip pim rp</b>	Displays information about PIM rendezvous points (RPs).

# ip pim bsr forward

To listen to and forward IPv4 Protocol Independent Multicast (PIM) bootstrap router (BSR) and Candidate-RP messages, use the **ip pim bsr forward** command. To disable listening and forwarding, use the **no** form of this command.

**ip pim bsr forward** [**listen**]

**no ip pim bsr** [**forward** [**listen**]]

Syntax Description	<b>forward</b>	Specifies to forward BSR and Candidate-RP messages.
	<b>listen</b>	(Optional) Specifies to listen to BSR and Candidate-RP messages.

Command Default	Disabled
-----------------	----------

Command Modes	Global configuration mode VRF configuration mode
---------------	---

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines	A router configured as either a candidate rendezvous point (RP) or a candidate BSR will automatically listen to and forward all BSR protocol messages, unless an interface is configured with the domain border feature.
	The <b>ip pim bsr listen</b> command is an alternative form of this command.
	This command requires the LAN Base Services license.

Examples	This example shows how to forward BSR and Candidate-RP messages:
	<pre>switch(config)# ip pim bsr forward</pre>
	This example shows how to disable forwarding:
	<pre>switch(config)# no ip pim bsr forward</pre>
	<pre>switch(config)#</pre>

Related Commands	Command	Description
	<b>ip pim bsr listen</b>	Enables listening to and forwarding of BSR messages.
	<b>show ip pim rp</b>	Displays information about PIM RPs.

# ip pim bsr listen

To listen to and forward IPv4 Protocol Independent Multicast (PIM) bootstrap router (BSR) and Candidate-RP messages, use the **ip pim bsr listen** command. To disable listening and forwarding, use the **no** form of this command.

**ip pim bsr listen [forward]**

**no ip pim bsr [listen [forward]]**

Syntax Description	listen	Specifies to listen to BSR and Candidate-RP messages.
	forward	(Optional) Specifies to forward BSR and Candidate-RP messages.

Command Default	Disabled
-----------------	----------

Command Modes	Global configuration mode VRF configuration mode
---------------	---

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines	<p>A router configured as either a candidate rendezvous point (RP) or a candidate BSR will automatically listen to and forward all BSR protocol messages, unless an interface is configured with the domain border feature.</p> <p>The <b>ip pim bsr forward</b> command is an alternative form of this command.</p> <p>This command requires the LAN Base Services license.</p>
------------------	--

Examples	<p>This example shows how to listen to and forward BSR and Candidate-RP messages:</p> <pre>switch(config)# ip pim bsr listen forward</pre> <p>This example shows how to disable listening and forwarding:</p> <pre>switch(config)# no ip pim bsr listen forward switch(config)#</pre>
----------	---

Related Commands	Command	Description
	<b>ip pim bsr forward</b>	Enables listening to and forwarding of BSR messages.
	<b>show ip pim rp</b>	Displays information about PIM RPs.

# ip pim bsr rp-candidate-policy

To filter IPv4 Protocol Independent Multicast (PIM) bootstrap router (BSR) Candidate-RP messages that are based on a route-map policy, use the **ip pim bsr rp-candidate-policy** command. To disable filtering, use the **no** form of this command.

```
ip pim bsr rp-candidate-policy policy-name

no ip pim bsr rp-candidate-policy [policy-name]
```

Syntax Description	<i>policy-name</i> Route-map policy name.
--------------------	---

Command Default	Disabled
-----------------	----------

Command Modes	Global configuration mode VRF configuration mode
---------------	---

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines	<p>You can specify the rendezvous point (RP) and group addresses, and whether the type is ASM with the <b>match ip multicast</b> command in a route-map policy.</p> <p>This command requires the LAN Base Services license.</p>
------------------	---

Examples	<p>This example shows how to filter Candidate-RP messages:</p> <pre>switch(config)# ip pim bsr rp-candidate-policy my_bsr_rp_candidate_policy</pre> <p>This example shows how to disable message filtering:</p> <pre>switch(config)# no ip pim bsr rp-candidate-policy switch(config)#</pre>
----------	--

Related Commands	Command	Description
	<b>show ip pim rp</b>	Displays information about PIM RPs.

# ip pim dr-priority

To configure the designated router (DR) priority that is advertised in IPv4 Protocol Independent Multicast (PIM) hello messages, use the **ip pim dr-priority** command. To reset the DR priority to the default, use the **no** form of this command.

**ip pim dr-priority** *priority*

**no ip pim dr-priority** [*priority*]

<b>Syntax Description</b>	<i>priority</i> Priority value. The range is from 1 to 4294967295. The default is 1.				
<b>Command Default</b>	The DR priority is 1.				
<b>Command Modes</b>	Interface configuration mode				
<b>Command History</b>	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>5.0(3)U1(1)</td><td>This command was introduced.</td></tr> </table>	Release	Modification	5.0(3)U1(1)	This command was introduced.
Release	Modification				
5.0(3)U1(1)	This command was introduced.				
<b>Usage Guidelines</b>	This command requires the LAN Base Services license.				
<b>Examples</b>	<p>This example shows how to configure DR priority on an interface:</p> <pre>switch(config)# interface ethernet 2/2 switch(config-if)# no switchport switch(config-if)# ip pim dr-priority 5</pre> <p>This example shows how to reset DR priority on an interface to the default:</p> <pre>switch(config)# interface ethernet 2/2 switch(config-if)# no switchport switch(config-if)# no ip pim dr-priority switch(config-if)#</pre>				
<b>Related Commands</b>	<table> <tr> <th>Command</th><th>Description</th></tr> <tr> <td><b>show ip pim interface</b></td><td>Displays information about PIM-enabled interfaces.</td></tr> </table>	Command	Description	<b>show ip pim interface</b>	Displays information about PIM-enabled interfaces.
Command	Description				
<b>show ip pim interface</b>	Displays information about PIM-enabled interfaces.				

# ip pim event-history

To configure the size of the IPv4 Protocol Independent Multicast (PIM) event history buffers, use the **ip pim event-history** command. To revert to the default buffer size, use the **no** form of this command.

```
ip pim event-history { assert-receive | cli | hello | join-prune | null-register | packet |
    pim-internal | rp | vrf } size buffer-size

no ip pim event-history { assert-receive | cli | hello | join-prune | null-register | packet |
    pim-internal | rp | vrf } size buffer-size
```

Syntax Description	<b>assert-receive</b>	Configures the assert receive event history buffer.
	<b>cli</b>	Configures the CLI event history buffer.
	<b>hello</b>	Configures the hello event history buffer.
	<b>join-prune</b>	Configures the join-prune event history buffer.
	<b>null-register</b>	Configures the null register event history buffer.
	<b>packet</b>	Configures the packet event history buffer.
	<b>pim-internal</b>	Configures the PIM internal event history buffer.
	<b>rp</b>	Configures the rendezvous point (RP) event history buffer.
	<b>vrf</b>	Configures the virtual routing and forwarding (VRF) event history buffer.
	<b>size</b>	Specifies the size of the buffer to allocate.
	<i>buffer-size</i>	Buffer size is one of the following values: <b>disabled</b> , <b>large</b> , <b>medium</b> , or <b>small</b> . The default buffer size is <b>small</b> .

Command Default	All history buffers are allocated as small.
-----------------	---

Command Modes	Any command mode
---------------	------------------

Command History	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines	This command requires the LAN Base Services license.
------------------	--

Examples	<p>This example shows how to configure the size of the PIM hello event history buffer:</p> <pre>switch(config)# ip pim event-history hello size medium switch(config)#</pre>
----------	--



Related Commands	Command	Description
	<b>clear ip pim event-history</b>	Clears information in the IPv4 PIM event history buffers.
	<b>show ip pim event-history</b>	Displays information in the IPv4 PIM event history buffers.
	<b>show running-config pim</b>	Displays information about the running-system PIM configuration.

# ip pim flush-routes

To remove routes when the IPv4 Protocol Independent Multicast (PIM) process is restarted, use the **ip pim flush-routes** command. To leave routes in place, use the **no** form of this command.

```
ip pim flush-routes

no ip pim flush-routes
```

**Syntax Description** This command has no arguments or keywords.

**Command Default** The routes are not flushed.

**Command Modes** Global configuration mode  
VRF configuration mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** To display whether flush routes are configured, use this command line:

```
switch(config)# show running-config | include flush-routes
```

This command requires the LAN Base Services license.

**Examples** This example shows how to remove routes when the PIM process is restarted:

```
switch(config)# ip pim flush-routes
switch(config)#
```

This example shows how to leave routes in place when the PIM process is restarted:

```
switch(config)# no ip pim flush-routes
switch(config)#
```

Related Commands	Command	Description
	show running-config	Displays information about the running-system configuration.

# ip pim hello-authentication ah-md5

To enable an MD5 hash authentication key in IPv4 Protocol Independent Multicast (PIM) hello messages, use the **ip pim hello-authentication ah-md5** command. To disable hello-message authentication, use the **no** form of this command.

**ip pim hello-authentication ah-md5** *auth-key*

**no ip pim hello-authentication ah-md5** [*auth-key*]

## Syntax Description

<i>auth-key</i>	MD5 authentication key. You can enter an unencrypted (cleartext) key, or one of these values followed by a space and the MD5 authentication key: <ul style="list-style-type: none"> <li>0—Specifies an unencrypted (cleartext) key</li> <li>3—Specifies a 3-DES encrypted key</li> <li>7—Specifies a Cisco Type 7 encrypted key</li> </ul> The key can be from 1 to 16 characters.
-----------------	--

## Command Default

Disabled

## Command Modes

Interface configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

Triple Data Encryption Standard (3-DES) is a strong form of encryption (168-bit) that allows sensitive information to be transmitted over untrusted networks. Cisco Type 7 encryption uses the algorithm from the Vigenère cipher.

This command requires the LAN Base Services license.

## Examples

This example shows how to enable a 3-DES encrypted key for PIM hello-message authentication:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# ip pim hello-authentication ah-md5 3 myauthkey
```

This example shows how to disable PIM hello-message authentication:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# no ip pim hello-authentication ah-md5
switch(config-if)#
```

Related Commands

Command	Description
show ip pim interface	Displays information about PIM-enabled interfaces.

# ip pim hello-interval

To configure the IPv4 Protocol Independent Multicast (PIM) hello-message interval on an interface, use the **ip pim hello-interval** command. To reset the hello interval to the default, use the **no** form of this command.

**ip pim hello-interval** *interval*

**no ip pim hello-interval** [*interval*]

<b>Syntax Description</b>	<i>interval</i> Interval in milliseconds. The range is from 1 to 18,724,286. The default is 30000.				
<b>Command Default</b>	The PIM hello interval is 30,000 milliseconds.				
<b>Command Modes</b>	Interface configuration mode				
<b>Command History</b>	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>5.0(3)U1(1)</td><td>This command was introduced.</td></tr></table>	Release	Modification	5.0(3)U1(1)	This command was introduced.
Release	Modification				
5.0(3)U1(1)	This command was introduced.				
<b>Usage Guidelines</b>	This command requires the LAN Base Services license.				
<b>Examples</b>	<p>This example shows how to configure the PIM hello-message interval on an interface:</p> <pre>switch(config)# interface ethernet 2/2 switch(config-if)# no switchport switch(config-if)# ip pim hello-interval 20000</pre> <p>This example shows how to reset the PIM hello-message interval on an interface to the default:</p> <pre>switch(config)# interface ethernet 2/2 switch(config-if)# no switchport switch(config-if)# no ip pim hello-interval switch(config-if)#</pre>				
<b>Related Commands</b>	<table><tr><th>Command</th><th>Description</th></tr><tr><td>show ip pim interface</td><td>Displays information about PIM-enabled interfaces.</td></tr></table>	Command	Description	show ip pim interface	Displays information about PIM-enabled interfaces.
Command	Description				
show ip pim interface	Displays information about PIM-enabled interfaces.				

# ip pim jp-policy

To filter IPv4 Protocol Independent Multicast (PIM) join-prune messages that are based on a route-map policy, use the **ip pim jp-policy** command. To disable filtering, use the **no** form of this command.

```
ip pim jp-policy policy-name [in | out]

no ip pim jp-policy [policy-name]
```

Syntax Description	<i>policy-name</i>	Route-map policy name.
	<b>in</b>	Specifies that the system applies a filter only for incoming messages.
	<b>out</b>	Specifies that the system applies a filter only for outgoing messages.

Command Default	Disabled; no filter is applied for either incoming or outgoing messages.
-----------------	--

Command Modes	Interface configuration mode
---------------	------------------------------

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines

Beginning with Cisco NX-OS Release 4.2(3), the **ip pim jp-policy** command filters messages in both incoming and outgoing directions. To specify filtering only incoming messages, use the optional **in** keyword; to specify filtering only outgoing messages, use the optional **out** keyword. When you enter the command with no keywords, that is no explicit direction, the system rejects further configurations if given with explicit direction.

Use the **ip pim jp-policy** command to filter incoming messages. You can configure the route map to prevent state from being created in the multicast routing table.

You can specify group, group and source, or group and rendezvous point (RP) addresses to filter messages with the **match ip multicast** command.

This command requires the LAN Base Services license.

Examples

This example shows how to filter PIM join-prune messages:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# ip pim jp-policy my_jp_policy
```

This example shows how to disable filtering:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# no ip pim jp-policy
switch(config-if)#
```

**Related Commands**

Command	Description
<b>show ip pim interface</b>	Displays information about PIM-enabled interfaces.

# ip pim log-neighbor-changes

To generate syslog messages that list the IPv4 Protocol Independent Multicast (PIM) neighbor state changes, use the **ip pim log-neighbor-changes** command. To disable messages, use the **no** form of this command.

**ip pim log-neighbor-changes**

**no ip pim log-neighbor-changes**

**Syntax Description** This command has no arguments or keywords.

**Command Default** Disabled

**Command Modes** Global configuration mode  
VRF configuration mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** This command requires the LAN Base Services license.

**Examples** This example shows how to generate syslog message that list the PIM neighbor state changes:

```
switch(config)# ip pim log-neighbor-changes
```

This example shows how to disable logging:

```
switch(config)# no ip pim log-neighbor-changes
switch(config)#
```

Related Commands	Command	Description
	logging level ip pim	Configures the logging level of PIM messages.



# ip pim neighbor-policy

To configure a route-map policy that determines which IPv4 Protocol Independent Multicast (PIM) neighbors should become adjacent, use the **ip pim neighbor-policy** command. To reset to the default, use the **no** form of this command.

**ip pim neighbor-policy** *policy-name*

**no ip pim neighbor-policy** [*policy-name*]

## Syntax Description

*policy-name* Route-map policy name.

## Command Default

Forms adjacency with all neighbors.

## Command Modes

Interface configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

You can use the **match ip address** command in a route-map policy to specify which groups to become adjacent to.

This command requires the LAN Base Services license.

## Examples

This example shows how to configure a policy that determines which PIM neighbors should become adjacent:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# ip pim neighbor-policy
```

This example shows how to reset to the default:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# no ip pim neighbor-policy
switch(config-if)#
```

## Related Commands

Command	Description
<b>show ip pim interface</b>	Displays information about PIM-enabled interfaces.

# ip pim pre-build-spt

To prebuild the shortest path tree (SPT) for all known (S,G) in the routing table by triggering Protocol Independent Multicast (PIM) joins upstream, use the **ip pim pre-build-spt** command. To reset to the default, use the **no** form of this command.

**ip pim pre-build-spt**

**no ip pim pre-build-spt**

## Syntax Description

This command has no arguments or keywords.

## Command Default

Joins are triggered only if the OIF list is not empty.

## Command Modes

VRF configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

To prebuild the SPT for all known (S,G)s in the routing table by triggering PIM joins upstream, even in the absence of any receivers, use the **ip pim pre-build-spt** command.

By default, PIM (S,G) joins are triggered upstream only if the OIF-list for the (S,G) is not empty. It is useful in certain scenarios to prebuild the SPTs and maintain the (S,G) states even when the system is not forwarding on these routes.

This command requires the LAN Base Services license.

## Examples

This example shows how to prebuild the SPT in the absence of receivers:

```
switch(config)# vrf context Enterprise
switch(config-vrf)# ip pim pre-build-spt
switch(config-vrf)#
```

## Related Commands

Command	Description
<b>show ip pim context</b>	Displays information about PIM routes.

# ip pim register-policy

To filter IPv4 Protocol Independent Multicast (PIM) Register messages that are based on a route-map policy, use the **ip pim register-policy** command. To disable message filtering, use the **no** form of this command.

**ip pim register-policy** *policy-name*

**no ip pim register-policy** [*policy-name*]

## Syntax Description

*policy-name* Route-map policy name.

## Command Default

Disabled

## Command Modes

Global configuration mode  
VRF configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

You can use the **match ip multicast** command in a route-map policy to specify the group or group and source addresses whose register messages that should be filtered.

This command requires the LAN Base Services license.

## Examples

This example shows how to enable filtering of PIM Register messages:

```
switch(config)# ip pim register-policy my_register_policy
```

This example shows how to disable message filtering:

```
switch(config)# no ip pim register-policy  
switch(config)#
```

## Related Commands

Command	Description
<b>show ip pim policy statistics register-policy</b>	Displays statistics for PIM Register messages.

# ip pim register-rate-limit

To configure a rate limit for IPv4 Protocol Independent Multicast (PIM) data registers, use the **ip pim register-rate-limit** command. To remove a rate limit, use the **no** form of this command.

**ip pim register-rate-limit** *rate*

**no ip pim register-rate-limit** [*rate*]

<b>Syntax Description</b>	<i>rate</i> Rate in packets per second. The range is from 1 to 65,535.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Global configuration mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.
<b>Usage Guidelines</b>	This command requires the LAN Base Services license.	
<b>Examples</b>	This example shows how to configure a rate limit for PIM data registers:	
	switch(config)# <b>ip pim register-rate-limit 1000</b>	
	This example shows how to remove a rate limit:	
	switch(config)# <b>no ip pim register-rate-limit</b> switch(config)#	
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show ip pim vrf detail</b>	Displays information about the PIM configuration.

## ip pim register-source

To configure the IP source address of a register message to an interface address other than the outgoing interface address of the designated router (DR) leading toward the rendezvous point (RP), use the **ip pim register-source** command. To remove the IP source address register message configuration, use the **no** form of this command.

```
ip pim register-source [ethernet slot/port | loopback if_number | port-channel pc_number |  
                        tunnel tunne_number | vlan vlan_number]
```

```
no ip pim register-source [ethernet slot/port | loopback if_number | port-channel pc_number |  
                        tunnel tunne_number | vlan vlan_number]
```

<b>Syntax Description</b>	<b>ethernet</b> <i>slot/port</i>	(Optional) Specifies the Ethernet interface. The range is from 1 to 255.
	<b>loopback</b> <i>if_number</i>	(Optional) Specifies the virtual interface. The range is from 0 to 1023.
	<b>port-channel</b> <i>pc_number</i>	(Optional) Specifies the port-channel number. The range is from 1 to 4096.
	<b>tunnel</b> <i>tunnel_number</i>	(Optional) Specifies the tunnel interface. The range is from 0 to 4095.
	<b>vlan</b> <i>vlan_number</i>	(Optional) Specifies the VLAN interface. The range is from 1 to 4094.

<b>Command Default</b>	By default, the IP address of the outgoing interface of the DR leading toward the RP is used as the IP source address of a register message.
------------------------	--

<b>Command Modes</b>	VRF configuration mode
----------------------	------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U4(1)	This command was introduced.

**Usage Guidelines**

This command is required only when the IP source address of a register message is not a uniquely routed address to which the RP can send packets. This situation might occur if the source address is filtered so that packets sent to it are not be forwarded or if the source address is not unique to the network. In these cases, the replies sent from the RP to the source address fail to reach the DR, which results in Protocol Independent Multicast sparse mode (PIM-SM) protocol failures.

If no IP source address is configured or if the configured source address is not in service, the IP address of the outgoing interface of the DR leading toward the RP is used as the IP source address of the register message.

We recommend that you use a loopback interface with an IP address that is uniquely routed throughout the PIM-SM domain.

This command requires the LAN Base Services license.

---

**Examples**

This example shows how to configure the IP source address of the register message:

```
switch(config)# vrf context Enterprise  
switch(config-vrf)# ip pim register-source ethernet 2/3  
switch(config-vrf)#
```

This example shows how to remove the IP source address register message configuration:

```
switch(config-vrf)# no ip pim register-source ethernet 2/3  
switch(config-vrf)#
```

---

**Related Commands**

Command	Description
<b>show ip pim vrf detail</b>	Displays information about the PIM configuration.

---

# ip pim rp-address

To configure an IPv4 Protocol Independent Multicast (PIM) static rendezvous point (RP) address for a multicast group range, use the **ip pim rp-address** command. To remove a static RP address, use the **no** form of this command.

**ip pim rp-address** *rp-address* [**group-list** *prefix* | **override** | **route-map** *policy-name*]

**no ip pim rp-address** *rp-address* [**group-list** *prefix* | **override** | **route-map** *policy-name*]

## Syntax Description

<i>rp-address</i>	IP address of a router which is the RP for a group range.
<b>group-list</b> <i>prefix</i>	(Optional) Specifies a group range for a static RP.
<b>override</b>	(Optional) Specifies the RP address. The RP address overrides the dynamically learned RP addresses.
<b>route-map</b> <i>policy-name</i>	(Optional) Specifies a route-map policy name.

## Command Default

The group range is treated in ASM mode.

## Command Modes

Global configuration mode  
VRF configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

The **match ip multicast** command is the only **match** command that is evaluated in the route map. You can specify group prefix to filter messages with the **match ip multicast** command.

Customers can use this “override” provision, if they want the static RPs always to override the dynamic ones.

This command requires the LAN Base Services license.

## Examples

This example shows how to configure a PIM static RP address for a serving group range and to override any dynamically learned (through BSR) RP addresses:

```
switch(config)# ip pim rp-address 1.1.1.1 group-list 225.1.0.0/16 override
```

This example shows how to configure a PIM static RP address for a group range:

```
switch(config)# ip pim rp-address 192.0.2.33 group-list 224.0.0.0/9
```

This example shows how to remove a static RP address:

```
switch(config)# no ip pim rp-address 192.0.2.33
```

ip pim rp-address

Related Commands

Command	Description
show ip pim rp	Displays information about PIM RPs.



# ip pim rp-candidate

To configure the router as an IPv4 Protocol Independent Multicast (PIM) bootstrap router (BSR) rendezvous point (RP) candidate, use the **ip pim rp-candidate** command. To remove the router as an RP candidate, use the **no** form of this command.

**ip pim [bsr] rp-candidate** { **ethernet** *slot/port* | **loopback** *if\_number* | **port-channel** *number* }  
 { **group-list** *prefix* } [ **priority** *priority* ] [ **interval** *interval* ]

**no ip pim [bsr] rp-candidate** { **ethernet** *slot/port* | **loopback** *if\_number* | **port-channel** *number* }  
 { **group-list** *prefix* } [ **priority** *priority* ] [ **interval** *interval* ]

Syntax Description		
<b>bsr</b>	(Optional)	Specifies the BSR protocol RP-distribution configuration.
<b>ethernet</b> <i>slot/port</i>	(Optional)	Specifies the Ethernet interface and the slot number and port number. The slot number is from 1 to 255, and the port number is from 1 to 128.
<b>loopback</b> <i>if_number</i>	(Optional)	Specifies the loopback interface. The loopback interface number is from 0 to 1023.
<b>port-channel</b> <i>number</i>	(Optional)	Specifies the EtherChannel interface and EtherChannel number. The range is from 1 to 4096.
<b>group-list</b> <i>prefix</i>		Specifies a group range handled by the RP.
<b>priority</b> <i>priority</i>	(Optional)	Specifies the RP priority used in candidate-RP messages. The range is from 0 to 65,535. The default is 192.
<b>interval</b> <i>interval</i>	(Optional)	Specifies the BSR message transmission interval in seconds. The range is from 1 to 65,535. The default is 60.

Command Default	The RP priority is 192. The BSR message interval is 60 seconds.
-----------------	--

Command Modes	Global configuration mode VRF configuration mode
---------------	---

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines	We recommend that you configure the candidate RP interval to be a minimum of 15 seconds. Using this route map, you can add a range of group lists that this candidate-RP can serve.
------------------	--



## Note

Use the same configuration guidelines for the route-map auto-rp-range that you used when you created a route map for static RPs.

This command requires the LAN Base Services license.

Examples

This example shows how to configure the router as a PIM BSR RP candidate:

```
switch(config)# ip pim rp-candidate ethernet 2/11 group-list 239.0.0.0/24
```

This example shows how to remove the router as an RP candidate:

```
switch(config)# no ip pim rp-candidate
switch(config)#
```

Related Commands

Command	Description
show ip pim rp	Displays information about PIM RPs.

# ip pim send-rp-announce

To configure an IPv4 Protocol Independent Multicast (PIM) Auto-RP candidate rendezvous point (RP), use the **ip pim send-rp-announce** command. To remove an Auto-RP candidate RP, use the **no** form of this command.

**ip pim send-rp-announce** { **ethernet** *slot/port* | **loopback** *if\_number* | **port-channel** *number* }  
 { **group-list** *prefix* } { [**scope** *ttl*] | [**interval** *interval*] }

**no ip pim send-rp-announce** [ { **ethernet** *slot/port* | **loopback** *if\_number* | **port-channel** *number* }  
 { **group-list** *prefix* } { [**scope** *ttl*] | [**interval** *interval*] }

<b>Syntax Description</b>	<b>ethernet</b> <i>slot/port</i>	(Optional) Specifies the Ethernet interface and the slot number and port number. The slot number is from 1 to 255, and the port number is from 1 to 128.
	<b>loopback</b> <i>if_number</i>	(Optional) Specifies the loopback interface. The loopback interface number is from 0 to 1023.
	<b>port-channel</b> <i>number</i>	(Optional) Specifies the EtherChannel interface and EtherChannel number. The range is from 1 to 4096.
	<b>group-list</b> <i>prefix</i>	Specifies a group range handled by the RP.
	<b>scope</b> <i>ttl</i>	(Optional) Specifies a time-to-live (TTL) value for the scope of Auto-RP Announce messages. The range is from 1 to 255. The default is 32.
	<b>interval</b> <i>interval</i>	(Optional) Specifies an Auto-RP Announce message transmission interval in seconds. The range is from 1 to 65,535. The default is 60.

**Note** See the **ip pim border** command to explicitly define a router on the edge of a PIM domain rather than using the **scope** argument.

<b>Command Default</b>	The TTL is 32.
	The Auto-RP Announce message interval is 60 seconds.

<b>Command Modes</b>	Global configuration mode
	VRF configuration mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	The <b>scope</b> and <b>interval</b> keywords can be entered once and in any order.
	The <b>ip pim auto-rp rp-candidate</b> command is an alternative form of this command.
	This command requires the LAN Base Services license.

Examples

This example shows how to configure a PIM Auto-RP candidate RP:

```
switch(config)# ip pim send-rp-announce ethernet 2/1 group-list 239.0.0.0/24
```

This example shows how to remove a PIM Auto-RP candidate RP:

```
switch(config)# no ip pim send-rp-announce ethernet 2/1 group-list 239.0.0.0/24
switch(config)#
```

Related Commands

Command	Description
ip pim auto-rp rp-candidate	Configures a PIM Auto-RP candidate RP.
show ip pim interface	Displays information about PIM-enabled interfaces.

# ip pim send-rp-discovery

To configure the router as an IPv4 Protocol Independent Multicast (PIM) Auto-RP mapping agent that sends RP-Discovery messages, use the **ip pim send-rp-discovery** command. To remove the configuration, use the **no** form of this command.

```
ip pim send-rp-discovery {ethernet slot/port | loopback if_number | port-channel number}  
[scope ttl]
```

```
no ip pim send-rp-discovery [{ethernet slot/port | loopback if_number | port-channel number}]  
[scope ttl]
```

Syntax Description		
<b>ethernet</b> <i>slot/port</i>		Specifies the Ethernet interface and the slot number and port number. The slot number is from 1 to 255, and the port number is from 1 to 128.
<b>loopback</b> <i>if_number</i>		Specifies the loopback interface. The loopback interface number is from 0 to 1023.
<b>port-channel</b> <i>number</i>		Specifies the EtherChannel interface and EtherChannel number. The range is from 1 to 4096.
<b>scope</b> <i>ttl</i>		(Optional) Specifies the time-to-live (TTL) value for the scope of Auto-RP Discovery messages. The range is from 1 to 255. The default is 32.
	<b>Note</b>	See the <b>ip pim border</b> command to explicitly define a router on the edge of a PIM domain rather than using the <b>scope</b> argument.

<b>Command Default</b>	The TTL is 32.
------------------------	----------------

<b>Command Modes</b>	Global configuration mode VRF configuration mode
----------------------	---

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	The <b>ip pim auto-rp mapping-agent</b> command is an alternative form of this command. This command requires the LAN Base Services license.
-------------------------	---

<b>Examples</b>	<p>This example shows how to configure an Auto-RP mapping agent:</p> <pre>switch(config)# <b>ip pim send-rp-discovery ethernet 2/1</b></pre> <p>This example shows how to remove an Auto-RP mapping agent:</p> <pre>switch(config)# <b>no ip pim send-rp-discovery ethernet 2/1</b> switch(config)#</pre>
-----------------	---

Related Commands	Command	Description
	<b>show ip pim rp</b>	Displays information about PIM RPs.
	<b>ip pim auto-rp mapping-agent</b>	Configures a router as an Auto-RP mapping agent.
	<b>ip pim border</b>	Configures a router to be on the edge of a PIM domain.

# ip pim sg-expiry-timer

To adjust the (S, G) expiry timer interval for Protocol Independent Multicast sparse mode (PIM-SM) (S, G) multicast routes, use the **ip pim sg-expiry-timer** command. To reset to the default values, use the **no** form of the command.

**ip pim** [**sparse**] **sg-expiry-timer** *seconds* [**sg-list** *route-map*]

**no ip pim** [**sparse**] **sg-expiry-timer** *seconds* [**sg-list** *route-map*]

<b>Syntax Description</b>	<b>sparse</b>	(Optional) Specifies sparse mode.
	<i>seconds</i>	Expiry-timer interval. The range is from 181 to 57600 seconds.
	<b>sg-list</b>	(Optional) Specifies S,G values to which the timer applies. The route map name can be a maximum of 100 alphanumeric characters.
	<i>route-map</i>	

<b>Command Default</b>	The default expiry time is 180 seconds.
	The timer applies to all (S, G) entries in the routing table.

<b>Command Modes</b>	VRF configuration mode
----------------------	------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	This command requires the LAN Base Services license.
-------------------------	--

<b>Examples</b>	This example shows how to configure the expiry interval to 300 seconds for all (S, G) entries:
-----------------	--

```
switch(config)# vrf context Enterprise
switch(config-vrf)# ip pim sg-expiry-timer 300
switch(config-vrf)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show ip pim context</b>	Displays information about the PIM configuration.

# ip pim sparse-mode

To enable IPv4 Protocol Independent Multicast (PIM) sparse mode on an interface, use the **ip pim sparse-mode** command. To disable PIM on an interface, use the **no** form of this command.

**ip pim sparse-mode**

**no ip pim [sparse-mode]**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	Disabled
------------------------	----------

<b>Command Modes</b>	Interface configuration mode
----------------------	------------------------------

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	This command requires the LAN Base Services license.
-------------------------	--

<b>Examples</b>	This example shows how to enable PIM sparse mode on an interface:
-----------------	---

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# ip pim sparse-mode
```

This example shows how to disable PIM on an interface:

```
switch(config)# interface ethernet 2/2
switch(config-if)# no switchport
switch(config-if)# no ip pim
switch(config-if)#
```

Related Commands	Command	Description
	<b>show ip pim interface</b>	Displays information about PIM-enabled interfaces.



# ip pim spt-threshold infinity

To create the IPv4 Protocol Independent Multicast (PIM) (\*, G) state only (where no source state is created), use the **ip pim spt-threshold infinity** command. To remove the creation of the shared tree state only, use the **no** form of this command.

**ip pim spt-threshold infinity group-list** *route-map-name*

**no ip pim spt-threshold infinity** [*group-list route-map-name*]

## Syntax Description

**route-map-name** Route-map policy name that defines the group prefixes where this feature is applied. A route-map policy name can be a maximum of 100 alphanumeric characters.

## Command Default

None

## Command Modes

Global configuration mode  
VRF configuration mode

## Command History

Release	Modification
5.0(3)U4(1)	This command was introduced.

## Usage Guidelines

You can specify up to 500 sequence lines in a route map.

The **match ip multicast** command is the only match command that is evaluated in the route map. You can specify the group prefix to filter messages with the **match ip multicast** command.

You must have enabled PIM before you can use the **ip pim spt-threshold infinity** command.



### Note

This command is not supported for virtual port channels (vPCs).

This command requires the Enterprise Services license.

## Examples

This example shows how to create the PIM (\*, G) state only for the group prefixes defined in my\_group\_map:

```
switch(config)# ip pim spt-threshold infinity group-list my_group_map
```

This example shows how to remove the creation of the (\*, G) state only:

```
switch(config)# no ip pim spt-threshold infinity
```

## Related Commands

Command	Description
<b>show ip pim rp</b>	Displays information about PIM RPs.

# ip pim ssm policy

To configure group ranges for Source Specific Multicast (SSM) using a route-map policy, use the **ip pim ssm policy** command. To remove the SSM group range policy, use the **no** form of this command.

```
ip pim ssm policy policy-name

no ip pim ssm policy policy-name
```

Syntax Description	<i>policy-name</i> Route-map policy name that defines the group prefixes where this feature is applied.
--------------------	---

Command Default	The SSM range is 232.0.0.0/8.
-----------------	-------------------------------

Command Modes	Global configuration mode VRF configuration mode
---------------	---

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines	This command requires the LAN Base Services license.
------------------	--

**Examples**

This example shows how to configure a group range for SSM:

```
switch(config)# ip pim ssm policy my_ssm_policy
```

This example shows how to reset the group range to the default:

```
switch(config)# no ip pim ssm policy my_ssm_policy
switch(config)#
```

Related Commands	Command	Description
	<b>show ip pim group-range</b>	Displays information about PIM group ranges.

# ip pim ssm range

To configure group ranges for Source Specific Multicast (SSM), use the **ip pim ssm range** command. To reset the SSM group range to the default, use the **no** form of this command with the **none** keyword.

**ip pim ssm range** {*groups* | **none**}

**no ip pim ssm range** {*groups* | **none**}

## Syntax Description

<i>groups</i>	List of up to four group range prefixes.
<b>none</b>	Removes all group ranges.

## Command Default

The SSM range is 232.0.0.0/8.

## Command Modes

Global configuration mode  
VRF configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

The **match ip multicast** command is the only **match** command that is evaluated in the route map. You can specify the group prefix to filter messages with the **match ip multicast** command.

This command requires the LAN Base Services license.

## Examples

This example shows how to configure a group range for SSM:

```
switch(config)# ip pim ssm range 239.128.1.0/24
```

This example shows how to reset the group range to the default:

```
switch(config)# no ip pim ssm range none
```

This example shows how to remove all group ranges:

```
switch(config)# ip pim ssm range none
switch(config)#
```

## Related Commands

Command	Description
<b>show ip pim group-range</b>	Displays information about PIM group ranges.

# ip pim ssm route-map

To configure a group range policy for an Source Specific Multicast (SSM) range, use the **ip pim ssm route-map** command. To remove the SSM group range policy, use the **no** form of this command.

**ip pim ssm route-map** *policy-name*

**no ip pim ssm route-map** *policy-name*

<b>Syntax Description</b>	<i>policy-name</i> Route-map policy name. The name can be a maximum of 63 characters.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Global configuration mode VRF configuration mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.
<b>Usage Guidelines</b>	This command requires the LAN Base Services license.	
<b>Examples</b>	<p>This example shows how to configure a group range policy for SSM:</p> <pre>switch(config)# ip pim ssm route-map my_ssm_policy switch(config)#</pre>	
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show ip pim route</b>	Displays information about IPV4 PIM routes.

# ip pim state-limit

To configure a maximum number of IPv4 Protocol Independent Multicast (PIM) state entries in the current virtual routing and forwarding (VRF) instance, use the **ip pim state-limit** command. To remove the limit on state entries, use the **no** form of this command.

**ip pim state-limit** *max-states* [**reserved** *policy-name* *max-reserved*]

**no ip pim state-limit** [*max-states* [**reserved** *policy-name* *max-reserved*]]

## Syntax Description

<i>max-states</i>	Maximum number of (*, G) and (S, G) entries allowed in this VRF. The range is from 1 to 429,496,7295. The default is no limit.
<b>reserved</b>	(Optional) Specifies that a number of state entries are to be reserved for the routes specified in a policy map.
<i>policy-name</i>	(Optional) Route-map policy name.
<i>max-reserved</i>	(Optional) Maximum reserved (*, G) and (S, G) entries allowed in this VRF. Must be less than or equal to the maximum states allowed. The range is from 1 to 429,496,7295.

## Command Default

None

## Command Modes

Global configuration mode  
VRF configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

To display commands where state limits are configured, use this command line:

```
switch(config)# show running-config | include state-limit
```

This command requires the LAN Base Services license.

## Examples

This example shows how to configure a state entry limit with a number of state entries reserved for routes in a policy map:

```
switch(config)# ip pim state-limit 100000 reserved my_reserved_policy 40000
```

This example shows how to remove the limits on state entries:

```
switch(config)# no ip pim state-limit
switch(config)#
```

Related Commands

Command	Description
show running-config	Displays information about the running-system configuration.

# ip pim use-shared-tree-only

To create the IPv4 Protocol Independent Multicast (PIM) (\*, G) state only (where no source state is created), use the **ip pim use-shared-tree-only** command. To remove the creation of the shared tree state only, use the **no** form of this command.

**ip pim use-shared-tree-only group-list** *policy-name*

**no ip pim use-shared-tree-only [group-list** *policy-name*]

## Syntax Description

<i>policy-name</i>	Route-map policy name that defines the group prefixes where this feature is applied.
--------------------	--

## Command Default

None

## Command Modes

Global configuration mode  
VRF configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

You can use the **match ip multicast** command in a route-map policy to specify the groups where shared trees should be enforced.

This command requires the LAN Base Services license.

## Examples

This example shows how to create the PIM (\*, G) state only for the group prefixes defined in my\_group\_policy:

```
switch(config)# ip pim use-shared-tree-only group-list my_group_policy
```

This example shows how to remove the creation of the (\*, G) state only:

```
switch(config)# no ip pim use-shared-tree-only
switch(config)#
```

## Related Commands

Command	Description
<b>show ip pim rp</b>	Displays information about PIM RPs.

# ip routing multicast event-history

To configure the size of the IPv4 Multicast Routing Information Base (MRIB) event history buffers, use the **ip routing multicast event-history** command. To revert to the default buffer size, use the **no** form of this command.

```
ip routing multicast event-history {cli | mfdm-debug | mfdm-event | mfdm-stat | rib | vrf}
size buffer-size
```

```
no ip routing multicast event-history {cli | mfdm-debug | mfdm-event | mfdm-stat | rib | vrf}
size buffer-size
```

## Syntax Description

<b>cli</b>	Configures the CLI event history buffer.
<b>mfdm-debug</b>	Configures the multicast FIB distribution (MFDM) debug event history buffer.
<b>mfdm-event</b>	Configures the multicast FIB distribution (MFDM) non-periodic events event history buffer.
<b>mfdm-stat</b>	Configures the MFDM sum event history buffer.
<b>rib</b>	Configures the RIB event history buffer.
<b>vrf</b>	Configures the virtual routing and forwarding (VRF) event history buffer.
<b>size</b>	Specifies the size of the buffer to allocate.
<i>buffer-size</i>	Buffer size that is one of the following values: <b>disabled</b> , <b>large</b> , <b>medium</b> , or <b>small</b> . The default buffer size is <b>small</b> .

## Command Default

All history buffers are allocated as small.

## Command Modes

Global configuration mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

To display configured buffer sizes, use this command line:

```
switch(config)# show running-config | include "ip routing"
```

This command does not require a license.

## Examples

This example shows how to configure the size of the MRIB MFDM event history buffer:

```
switch(config)# ip routing multicast event-history mfdm size large
switch(config)#
```



Related Commands	Command	Description
	<b>clear ip routing multicast event-history</b>	Clears information in the IPv4 MRIB event history buffers.
	<b>show routing ip multicast event-history</b>	Displays information in the IPv4 MRIB event history buffers.
	<b>show running-config</b>	Displays information about the running-system configuration.

# ip routing multicast holddown

To configure the IPv4 multicast routing initial holddown period, use the **ip routing multicast holddown** command. To revert to the default holddown period, use the **no** form of this command.

```
[ip | ipv4] routing multicast holddown holddown-period

no [ip | ipv4] routing multicast holddown holddown-period
```

Syntax Description	<i>holddown-period</i>	Initial route holddown period in seconds. The range is from 90 to 210. Specify 0 to disable the holddown period. The default is 210.
--------------------	------------------------	--

Command Default	The holddown period is 210 seconds.
-----------------	-------------------------------------

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines	<p>To display the holddown period configuration, use this command line:</p> <pre>switch(config)# show running-config   include "ip routing multicast holddown"</pre> <p>This command does not require a license.</p>
------------------	--

Examples	<p>This example shows how to configure the routing holddown period:</p> <pre>switch(config)# ip routing multicast holddown 100 switch(config)#</pre>
----------	--

Related Commands	Command	Description
	<b>show running-config</b>	Displays information about the running-system configuration.

# ip routing multicast software-replicate

To enable software replication of IPv4 Protocol Independent Multicast (PIM) Any Source Multicast (ASM) packets that are leaked to the software for state creation, use the **ip routing multicast software-replicate** command. To reset to the default, use the **no** form of this command.

**ip routing multicast software-replicate**

**no ip routing multicast software-replicate**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	No software replication.
------------------------	--------------------------

<b>Command Modes</b>	Global configuration mode
----------------------	---------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	By default, these packets are used by the software only for (S,G) state creation and then dropped. This command does not require a license.
-------------------------	--

<b>Examples</b>	This example shows how to enable software replication of IPv4 PIM ASM packets: <pre>switch(config)# ip routing multicast software-replicate switch(config)#</pre>
-----------------	--

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show running-config</b>	Displays information about the running-system configuration.

# no switchport

To configure the interface as a Layer 3 Ethernet interface, use the **no switchport** command.

## no switchport

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** Interface configuration mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** You can configure any Ethernet port as a routed interface. When you configure an interface as a Layer 3 interface, any configuration specific to Layer 2 on this interface is deleted.

If you want to configure a Layer 3 interface for Layer 2, enter the **switchport** command. Then, if you change a Layer 2 interface to a routed interface, enter the **no switchport** command.

This command requires the LAN Base Services license.

**Examples** This example shows how to enable an interface as a Layer 3 routed interface:

```
switch(config)# interface ethernet 1/5
switch(config-if)# no switchport
switch(config-if)#
```

This example shows how to configure a Layer 3 interface as a Layer 2 interface:

```
switch(config)# interface ethernet 1/5
switch(config-if)# switchport
switch(config-if)#
```

Related Commands	Command	Description
	<b>copy running-config startup-config</b>	Saves the running configuration to the startup configuration file.
	<b>ip address</b>	Sets a primary or secondary IP address for an interface.
	<b>show interfaces</b>	Displays interface information.

# restart msdp

To restart the Multicast Source Discovery Protocol (MSDP) process, use the **restart msdp** command.

**restart msdp**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Any command mode
----------------------	------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	This command requires the LAN Base Services license.
-------------------------	--

<b>Examples</b>	<p>This example shows how to restart the MSDP process:</p> <pre>switch(config)# <b>restart msdp</b> switch(config)#</pre>
-----------------	---

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>ip msdp flush-routes</b>	Enables flushing routes when the MSDP process is restarted.

# restart pim

To restart the IPv4 Protocol Independent Multicast (PIM) process, use the **restart pim** command.

## restart pim

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Any command mode
----------------------	------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	This command requires the LAN Base Services license.
-------------------------	--

<b>Examples</b>	This example shows how to restart the PIM process:
-----------------	--

```
switch(config)# restart pim
switch(config)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>ip pim flush-routes</b>	Enables flushing routes when the PIM process is restarted.



# Multicast Routing Show Commands

---

This chapter describes the Cisco NX-OS multicast routing **show** commands available on Cisco Nexus 3000 Series switches.

# show forwarding distribution ip igmp snooping

To display information about Layer 2 IGMP snooping multicast Forwarding Information Base (FIB) distribution, use the **show forwarding distribution ip igmp snooping** command.

**show forwarding distribution ip igmp snooping** [**vlan** *vlan-id* [**group** *group-addr* [**source** *source-addr*]]]

<b>Syntax Description</b>	<table> <tr> <td><b>vlan</b> <i>vlan-id</i></td><td>(Optional) Specifies a VLAN. The range is from 1 to 3967 and 4048 to 4093.</td></tr> <tr> <td><b>group</b> <i>group-addr</i></td><td>(Optional) Specifies a group address.</td></tr> <tr> <td><b>source</b> <i>source-addr</i></td><td>(Optional) Specifies a source address.</td></tr> </table>	<b>vlan</b> <i>vlan-id</i>	(Optional) Specifies a VLAN. The range is from 1 to 3967 and 4048 to 4093.	<b>group</b> <i>group-addr</i>	(Optional) Specifies a group address.	<b>source</b> <i>source-addr</i>	(Optional) Specifies a source address.
<b>vlan</b> <i>vlan-id</i>	(Optional) Specifies a VLAN. The range is from 1 to 3967 and 4048 to 4093.						
<b>group</b> <i>group-addr</i>	(Optional) Specifies a group address.						
<b>source</b> <i>source-addr</i>	(Optional) Specifies a source address.						
<b>Command Default</b>	None						
<b>Command Modes</b>	Any command mode						
<b>Command History</b>	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>5.0(3)U1(1)</td><td>This command was introduced.</td></tr> </table>	Release	Modification	5.0(3)U1(1)	This command was introduced.		
Release	Modification						
5.0(3)U1(1)	This command was introduced.						
<b>Usage Guidelines</b>	This command does not require a license.						
<b>Examples</b>	<p>This example shows how to display information about Layer 2 IGMP snooping multicast FIB distribution:</p> <pre>switch(config)# <b>show forwarding distribution ip igmp snooping</b></pre>						
<b>Related Commands</b>	<table> <tr> <th>Command</th><th>Description</th></tr> <tr> <td><b>show running-config</b></td><td>Displays the running configuration information.</td></tr> </table>	Command	Description	<b>show running-config</b>	Displays the running configuration information.		
Command	Description						
<b>show running-config</b>	Displays the running configuration information.						



# show forwarding distribution multicast

To display information about multicast Forwarding Information Base (FIB) distribution messages, use the **show forwarding distribution multicast** command.

**show forwarding distribution multicast [messages]**

Syntax Description	<b>messages</b> (Optional) Displays message information.
--------------------	--

Command Default	None
-----------------	------

Command Modes	Any command mode
---------------	------------------

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines	This command does not require a license.
------------------	--

Examples	This example shows how to display information about multicast distribution messages:
----------	--

```
switch(config)# show forwarding distribution multicast
Number of Multicast FIB Processes Active: 1
Slot      FIB State
  1        ACTIVE
switch(config)#
```

Related Commands	Command	Description
	<b>show running-config</b>	Displays the running configuration information.

# show forwarding distribution multicast client

To display information about the multicast Forwarding Information Base (FIB) distribution client, use the **show forwarding distribution multicast client** command.

**show forwarding distribution multicast client**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** Any command mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** This command does not require a license.

**Examples** This example shows how to display information about the multicast FIB distribution client:

```
switch# show forwarding distribution multicast client

Number of Clients Registered: 1
Client-name  Client-id  Shared Memory Name
mrib         1          mrib-mfdm
switch#
```

Related Commands	Command	Description
	show running-config	Displays the running configuration information.

# show forwarding distribution multicast outgoing-interface-list

To display information about the multicast Forwarding Information Base (FIB) outgoing interface (OIF) list, use the **show forwarding distribution multicast outgoing-interface-list** command.

**show forwarding distribution multicast outgoing-interface-list {L2 | L3} [*index*]**

Syntax Description	L2	Specifies the Layer 2 OIF list.
	L3	Specifies the Layer 3 OIF list.
	<i>index</i>	(Optional) OIF list index.

Command Default	None
-----------------	------

Command Modes	Any command mode
---------------	------------------

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines	This command does not require a license.
------------------	--

Examples	This example shows how to display information about the multicast OIF list for Layer 3: <pre>switch# show forwarding distribution multicast outgoing-interface-list L3</pre>
----------	---

Related Commands	Command	Description
	<b>show running-config</b>	Displays the running configuration information.

# show forwarding distribution multicast route

To display information about the multicast Forwarding Information Base (FIB) distribution routes, use the **show forwarding distribution multicast route** command.

```
show forwarding distribution [ip | ipv4] multicast route [table id | vrf vrf_name] [[group
{ group-addr [mask] | group-prefix } ] [source { source-addr [source-mask] | source-prefix } ] |
summary]
```

Syntax Description	
<b>ip</b>	(Optional) Specifies IPV4 information.
<b>ipv4</b>	(Optional) Specifies IPV4 information.
<b>table</b> <i>id</i>	(Optional) Specifies the multicast routing table ID. The range is from 0 to 2147483647.
<b>vrf</b> <i>vrf_name</i>	(Optional) Specifies a virtual routing and forwarding (VRF) name. The name can be a maximum of 32 alphanumeric characters.
<b>group</b>	(Optional) Specifies an IPv4 multicast group.
<i>group-addr</i>	IPv4 multicast group address.
<i>mask</i>	(Optional) Mask for the group address.
<i>group-prefix</i>	(Optional) IPv4 multicast group prefix.
<b>source</b>	(Optional) Specifies an IPv4 multicast source.
<i>source-addr</i>	IPv4 source address.
<i>source-mask</i>	(Optional) Mask for the group address.
<i>source-prefix</i>	(Optional) IPv4 multicast source prefix.
<b>summary</b>	(Optional) Displays the route counts.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Any command mode
----------------------	------------------

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	This command does not require a license.
-------------------------	--

<b>Examples</b>	This example shows how to display information about all the multicast FIB distribution routes:
-----------------	--

```
switch(config)# show forwarding distribution multicast route
IPv4 Multicast Routing Table for table-id: 1
Total number of groups: 5
Legend:
  C = Control Route
```

```

D = Drop Route
G = Local Group (directly connected receivers)
O = Drop on RPF Fail
P = Punt to supervisor
d = Decap Route

(*, 224.0.0.0/4), RPF Interface: NULL, flags: D
  Received Packets: 0 Bytes: 0
  Number of Outgoing Interfaces: 0
  Null Outgoing Interface List

<--Output truncated-->
switch(config)#

```

#### Related Commands

Command	Description
<b>show running-config</b>	Displays the running configuration information.

# show forwarding multicast outgoing-interface-list

To display information about the multicast Forwarding Information Base (FIB) outgoing interface (OIF) list, use the **show forwarding multicast outgoing-interface-list** command.

**show forwarding multicast outgoing-interface-list** [*index*]

<b>Syntax Description</b>	<i>index</i> (Optional) OIF list index. The OIF list index is from 1 to 65535.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Any command mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.
<b>Usage Guidelines</b>	This command does not require a license.	
<b>Examples</b>	<p>This example shows how to display information about the multicast FIB OIF list:</p> <pre>switch# show forwarding multicast outgoing-interface-list</pre>	
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>ip igmp static-oif</b>	Binds a multicast group to the outgoing interface (OIF).
	<b>clear ip igmp interface statistics</b>	Clears the IGMP statistics for an interface.

# show forwarding multicast route

To display information about the IPv4 Forwarding Information Base (FIB) multicast routes, use the **show forwarding multicast route** command.



## Note

Cisco NX-OS 3000 Series switches do not support per **multicast group statistics** command for the **show forward multicast route** command.

```
show forwarding [vrf {vrf-name | all}] [ip | ipv4] multicast route {[group {group-addr
[group-mask] | group-prefix} | source {source-addr [source-mask] | source-prefix} | module
num | vrf {vrf-name | all}} | summary [vrf {vrf-name | all}]}
```

## Syntax Description

<b>vrf</b>	(Optional) Displays information for a specified virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
<b>all</b>	Displays information for all VRFs.
<b>ip</b>	(Optional) Specifies IPv4.
<b>ipv4</b>	(Optional) Specifies IPv4.
<b>group</b>	(Optional) Specifies an IPv4 multicast group address.
<i>group-addr</i>	IPv4 multicast group address.
<i>group-mask</i>	(Optional) IPv4 multicast group address mask.
<i>group-prefix</i>	(Optional) IPv4 multicast group prefix.
<b>source</b>	(Optional) Specifies an IPv4 multicast source address.
<i>source-addr</i>	IPv4 multicast source address.
<i>source-mask</i>	IPv4 multicast source address mask.
<i>source-prefix</i>	IPv4 multicast source prefix.
<b>summary</b>	Displays route counts.

## Command Default

None

## Command Modes

Any command mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

This command does not require a license.

---

**Examples**

This example shows how to display information about the IPv4 multicast FIB routes:

```
switch# show forwarding multicast route
```

This example shows how to display the summary information about the IPv4 multicast FIB routes:

```
switch# show forwarding multicast route summary
```

```
IPv4 Multicast Routing Table for Context "default"
Total number of routes: 0
Total number of (*,G) routes: 0
Total number of (S,G) routes: 0
Total number of (*,G-prefix) routes: 0
Group count: 0
Prefix insert fail count: 10
switch#
```

---

**Related Commands**

Command	Description
<b>clear ip mroute</b>	Clears the multicast routing table.



# show hardware profile status

To display the maximum entries in the multicast routing table, use the **show hardware profile status** command.

## show hardware profile status

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Examples</b>	This example shows how to display the status of the multicast routing table:
-----------------	--

```
switch# show hardware profile status
Reserved LPM Entries = 1024.
Reserved Host Entries = 4096.
Reserved Mcast Entries = 2000.
Used LPM Entries = 1.
Used Host Entries in LPM = 0.
Used Mcast Entries = 0.
Used Host Entries in Host = 6.
switch#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>hardware profile</b> <b>multicast max-limit</b>	Sets the maximum entries for the multicast routing table.

# show ip igmp event-history

To display information in the IGMP event history buffers, use the **show ip igmp event-history** command.

**show ip igmp event-history** { **clis** | **debugs** | **errors** | **events** | **ha** | **igmp-internal** | **msgs** | **mtrace** | **policy** | **statistics** | **vrf** }

Syntax Description	
<b>clis</b>	Displays events of type CLI.
<b>debugs</b>	Displays events of type debug.
<b>errors</b>	Displays events of type error.
<b>events</b>	Displays events of type event.
<b>ha</b>	Displays events of type HA.
<b>igmp-internal</b>	Displays events of type IGMP internal.
<b>msgs</b>	Displays events of type msg.
<b>mtrace</b>	Displays events of type mtrace.
<b>policy</b>	Displays events of type policy.
<b>statistics</b>	Displays events of type statistics.
<b>vrf</b>	Displays events of type VRF.

**Command Default** None

**Command Modes** Any command mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** This command does not require a license.

**Examples** This example shows how to display information in the IGMP HA event history buffer:

```
switch(config)# show ip igmp event-history ha

  ha events for IGMP process
2011 Aug 30 09:10:40.124500 igmp [4421]: : Router-port PSS entry for vlan 1 upda
ted [count 1]
2011 Aug 30 09:09:39.810392 igmp [4421]: : Router-port PSS entry for vlan 1 upda
ted [count 0]
2011 Aug 29 08:44:12.368317 igmp [4421]: : Router-port PSS entry for vlan 1 upda
ted [count 1]
2011 Aug 29 08:39:24.860388 igmp [4421]: : Router-port PSS entry for vlan 1 upda
ted [count 0]
2011 Aug 26 09:52:58.390295 igmp [4421]: : Router-port PSS entry for vlan 1 upda
```

```
ted [count 1]
<--Output truncated-->
switch(config)#
```

**Related Commands**

Command	Description
<b>clear ip igmp event-history</b>	Clears the contents of the IGMP event history buffers.
<b>ip igmp event-history</b>	Configures the size of IGMP event history buffers.

# show ip igmp groups

To display information about IGMP-attached group membership, use the **show ip igmp groups** command.

**show ip igmp groups** [{*source* [*group*]} | {*group* [*source*]}] [**ethernet** *slot/port* | **port-channel** *channel-number*[*.sub\_if-number*] | **vlan** *vlan-id*] [**vrf** {*vrf-name* | **all**}]

Syntax Description	
<i>source</i>	Source IP address.
<i>group</i>	(Optional) Multicast IP address of the single group to display.
<b>ethernet</b> <i>slot/port</i>	(Optional) Specifies the Ethernet interface and the slot number and port number. The slot number is from 1 to 255, and the port number is from 1 to 128.
<b>port-channel</b> <i>number</i>	(Optional) Specifies the EtherChannel interface and EtherChannel number. The range is from 1 to 4096.
<i>sub_if-number</i>	(Optional) Subinterface number. The range is from 1 to 4093.
<b>vlan</b> <i>vlan-id</i>	(Optional) Specifies the VLAN. The range is from 1 to 4094.
<b>vrf</b>	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
<b>all</b>	Specifies all VRFs.

**Command Default** None

**Command Modes** Any command mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** The **show ip igmp route** command is an alternative form of this command. This command does not require a license.

**Examples** This example shows how to display information about the IGMP-attached group membership:

```
switch(config)# show ip igmp groups
```

Related Commands	Command	Description
	<b>show ip igmp route</b>	Displays information about the IGMP-attached group membership.

# show ip igmp interface

To display information about IGMP on interfaces, use the **show ip igmp interface** command.

**show ip igmp interface** { **ethernet** *slot/port* | **port-channel** *channel-number* [*.sub\_if-number*] | **vlan** *vlan-id* }

**show ip igmp interface** [**brief**] [**vrf** { *vrf-name* | **all** }]

Syntax Description		
<b>ethernet</b>	<i>slot/port</i>	Specifies the Ethernet interface and the slot number and port number. The slot number is from 1 to 255, and the port number is from 1 to 128.
<b>port-channel</b>	<i>number</i>	Specifies the EtherChannel interface and EtherChannel number. The range is from 1 to 4096.
	<i>sub_if-number</i>	Subinterface number. The range is from 1 to 4093.
<b>vlan</b>	<i>vlan-id</i>	Specifies the VLAN. The range is from 1 to 4094.
<b>brief</b>		(Optional) Displays one line status per interface.
<b>vrf</b>		(Optional) Applies to a virtual routing and forwarding (VRF) instance.
	<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
<b>all</b>		Specifies all VRFs.

**Command Default** None

**Command Modes** Any command mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.


**Usage Guidelines** This command does not require a license but if you want to enable Layer 3 interfaces, you must install the LAN Base Services license.

**Examples** This example shows how to display information about IGMP on an interface:

```
switch# show ip igmp interface vlan 5
```

This example shows how to display information about IGMP on an interface in a brief format:

```
switch# show ip igmp interface brief
```

 `show ip igmp interface`

Related Commands	Command	Description
	<code>show running-config</code>	Displays information about the running-system configuration.

# show ip igmp local-groups

To display information about IGMP local groups, use the **show ip igmp local-groups** command.

```
show ip igmp local-groups [ethernet slot/port | port-channel channel-number [.sub_if-number] |  
  vlan vlan-id] [vrf {vrf-name | all}]
```

Syntax Description		
<b>ethernet</b> <i>slot/port</i>	(Optional)	Specifies the Ethernet interface and the slot number and port number. The slot number is from 1 to 255, and the port number is from 1 to 128.
<b>port-channel</b> <i>number</i>	(Optional)	Specifies the EtherChannel interface and EtherChannel number. The range is from 1 to 4096.
<i>sub_if-number</i>	(Optional)	Subinterface number. The range is from 1 to 4093.
<b>vlan</b> <i>vlan-id</i>	(Optional)	Specifies the VLAN. The range is from 1 to 4094.
<b>vrf</b>	(Optional)	Applies to a virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>		VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
<b>all</b>		Specifies all VRFs.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Any command mode
----------------------	------------------

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	This command does not require a license but if you want to enable Layer 3 interfaces, you must install the LAN Base Services license.
-------------------------	---

<b>Examples</b>	<p>This example shows how to display information about IGMP local groups:</p> <pre>switch(config)# <b>show ip igmp local-groups</b></pre>
-----------------	---

Related Commands	Command	Description
	<b>show running-config</b>	Displays information about the running-system configuration.

# show ip igmp route

To display information about the IGMP-attached group membership, use the **show ip igmp route** command.

**show ip igmp route** [{*source* [*group*]} | {*group* [*source*]}] [**ethernet** *slot/port* | **port-channel** *channel-number*[*.sub\_if-number*] | **vlan** *vlan-id*] [**vrf** {*vrf-name* | **all**}]

Syntax Description	
<i>source</i>	Source IP address.
<i>group</i>	(Optional) Multicast IP address of single group to display.
<b>ethernet</b> <i>slot/port</i>	(Optional) Specifies the Ethernet interface and the slot number and port number. The slot number is from 1 to 255, and the port number is from 1 to 128.
<b>port-channel</b> <i>number</i>	(Optional) Specifies the EtherChannel interface and EtherChannel number. The range is from 1 to 4096.
<i>sub_if-number</i>	(Optional) Subinterface number. The range is from 1 to 4093.
<b>vlan</b> <i>vlan-id</i>	(Optional) Specifies the VLAN. The range is from 1 to 4094.
<b>vrf</b>	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
<b>all</b>	Specifies all VRFs.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Any command mode
----------------------	------------------

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines**

The **show ip igmp groups** command is an alternative form of this command.

This command does not require a license.

**Examples**

This example shows how to display information about the IGMP-attached group membership:

```
switch# show ip igmp route
```

Related Commands	Command	Description
	<b>show ip igmp groups</b>	Displays information about the IGMP-attached group membership.



# show ip igmp snooping

To display information about IGMP snooping, use the **show ip igmp snooping** command.

**show ip igmp snooping** [*vlan vlan-id*]

<b>Syntax Description</b>	<b>vlan <i>vlan-id</i></b> (Optional) Specifies a VLAN. The range is from 1 to 3967 and 4048 to 4093. The default is all VLANs.
---------------------------	---

<b>Command Default</b>	Displays all VLANs.
------------------------	---------------------

<b>Command Modes</b>	Any command mode
----------------------	------------------

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	This command does not require a license.
-------------------------	--

<b>Examples</b>	This example shows how to display information about IGMP snooping information on a switch that runs Cisco NX-OS Release 5.0(3)U2(1) and shows the status of multicast optimization on a virtual Port Channel (vPC):
-----------------	---

```
switch# show ip igmp snooping
Global IGMP Snooping Information:
  IGMP Snooping enabled
  Optimised Multicast Flood (OMF) disabled
  IGMPv1/v2 Report Suppression enabled
  IGMPv3 Report Suppression disabled
  Link Local Groups Suppression enabled
  VPC Multicast optimization disabled

IGMP Snooping information for vlan 1
  IGMP snooping enabled
  Optimised Multicast Flood (OMF) disabled
  IGMP querier present, address: 10.1.1.7, version: 2, interface Ethernet1/13
  Switch-querier disabled
  IGMPv3 Explicit tracking enabled
  IGMPv2 Fast leave disabled
  IGMPv1/v2 Report suppression enabled
  IGMPv3 Report suppression disabled
  Link Local Groups suppression enabled
  Router port detection using PIM Hellos, IGMP Queries
  Number of router-ports: 1
  Number of groups: 0
  Active ports:
    Eth1/11    Eth1/13
switch#
```

This example shows how to display information about IGMP snooping for a VLAN:

```
switch# show ip igmp snooping vlan 1
IGMP Snooping information for vlan 1
  IGMP snooping enabled
  Optimised Multicast Flood (OMF) disabled
  IGMP querier present, address: 10.1.1.7, version: 2, interface Ethernet1/13
  Switch-querier disabled
  IGMPv3 Explicit tracking enabled
  IGMPv2 Fast leave disabled
  IGMPv1/v2 Report suppression enabled
  IGMPv3 Report suppression disabled
  Link Local Groups suppression enabled
  Router port detection using PIM Hellos, IGMP Queries
  Number of router-ports: 1
  Number of groups: 0
  Active ports:
    Eth1/11      Eth1/13
switch#
```

#### Related Commands

Command	Description
<b>ip mfwd mstatic</b>	Registers IP multicast forwarding (MFWD) static routes.
<b>ip igmp snooping (VLAN)</b>	Enables IGMP snooping on specified VLAN interfaces.

# show ip igmp snooping event-history

To display information in the IGMP snooping event history buffers, use the **show ip igmp snooping event-history** command.

**show ip igmp snooping event-history {igmp-snoop-internal | mfdm | mfdm-sum | vlan | vlan-events}**

<b>Syntax Description</b>	<b>igmp-snoop-internal</b>	Displays the event history buffer of type IGMP snooping internal.
	<b>mfdm</b>	Displays the event history buffer of type multicast FIB distribution (MFDM).
	<b>mfdm-sum</b>	Displays the event history buffer of type MFDM sum.
	<b>vlan</b>	Displays the event history buffer of type VLAN.
	<b>vlan-events</b>	Displays the event history buffer of type VLAN events.

**Command Default** None

**Command Modes** Any command mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.


**Usage Guidelines** This command does not require a license.

**Examples** This example shows how to display information in the IGMP snooping VLAN event history buffer:

```
switch# show ip igmp snooping event-history vlan
```

```

vlan Events for IGMP Snoop process
2011 Sep  2 08:23:06.508225 igmp [4421]: : igmp_cl_output_l2: Before IP api ...
2011 Sep  2 08:23:06.508223 igmp [4421]: : igmp_cl_output_l2: ...
2011 Sep  2 08:23:06.508220 igmp [4421]: : Flooding the packet to <vlan 1> (iif
Ethernet1/11)
2011 Sep  2 08:23:06.508216 igmp [4421]: : Received a v2 leave on Ethernet1/11 f
or group 0.0.0.0
2011 Sep  2 08:23:06.508169 igmp [4421]: : Process a valid IGMP packet
2011 Sep  2 08:23:04.880614 igmp [4421]: : Not STP root, ignoring topology chang
e notification
2011 Sep  2 08:23:04.880605 igmp [4421]: : Received a STP Topology change notifi
cation
2011 Sep  2 08:23:04.508334 igmp [4421]: : igmp_cl_output_l2: Before IP api ...
2011 Sep  2 08:23:04.508332 igmp [4421]: : igmp_cl_output_l2: ...
2011 Sep  2 08:23:04.508330 igmp [4421]: : Flooding the packet to <vlan 1> (iif
Ethernet1/11)
<---Output truncated-->
switch#
```

 `show ip igmp snooping event-history`

Related Commands	Command	Description
	<code>ip igmp snooping event-history</code>	Configures the size of the IGMP snooping event history buffers.
	<code>clear ip igmp snooping event-history</code>	Clears information in the IGMP snooping event history buffers.

# show ip igmp snooping explicit-tracking

To display information about explicit tracking for IGMP snooping, use the **show ip igmp snooping explicit-tracking** command.

**show ip igmp snooping explicit-tracking** [**vlan** *vlan-id*]

<b>Syntax Description</b>	<b>vlan</b> <i>vlan-id</i> (Optional) Specifies a VLAN. The range is from 1 to 3967 and 4048 to 4093.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Any command mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.
<b>Usage Guidelines</b>	<p>When you use this command without the optional <b>vlan</b> argument, the system displays information for all VLANs.</p> <p>This command does not require a license.</p>	
<b>Examples</b>	<p>This example shows how to display information about explicit tracking for IGMP snooping for VLAN 33:</p> <pre>switch# show ip igmp snooping explicit-tracking vlan 33</pre>	
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>clear ip igmp snooping explicit-tracking vlan</b>	Clears the IGMP snooping explicit host tracking information for VLANs.
	<b>ip igmp snooping explicit-tracking</b>	Enables tracking of IGMPv3 membership reports from individual hosts for each port on a VLAN.

# show ip igmp snooping groups

To display information about the group membership for IGMP snooping, use the **show ip igmp snooping groups** command.

**show ip igmp snooping groups** [{*source* [*group*]} | {*group* [*source*]}] [**vlan** *vlan-id*] [**detail**]

<b>Syntax Description</b>	<i>source</i>	(Optional) Source address for route.
	<i>group</i>	(Optional) Group address for route.
	<b>vlan</b> <i>vlan-id</i>	(Optional) Specifies a VLAN. The range is from 1 to 3967 and 4048 to 4093.
	<b>detail</b>	(Optional) Displays detailed information for the group.
<b>Command Default</b>	None	
<b>Command Modes</b>	Any command mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.
<b>Usage Guidelines</b>	This command does not require a license.	
<b>Examples</b>	This example shows how to display information about the group membership for IGMP snooping:	
	switch(config)# <b>show ip igmp snooping groups</b>	
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show running-config</b> <b>igmp</b>	Displays the IGMP running configuration.

# show ip igmp snooping mrouter

To display the multicast routers detected by IGMP snooping, use the **show ip igmp snooping mrouter** command.

**show ip igmp snooping mrouter** [*vlan vlan-id*]

<b>Syntax Description</b>	<b>vlan <i>vlan-id</i></b> (Optional) Specifies a VLAN. The range is from 1 to 3967 and 4048 to 4093.
---------------------------	---

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Any command mode
----------------------	------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	This command does not require a license.
-------------------------	--

<b>Examples</b>	This example shows how to display the multicast routers detected by IGMP snooping:
-----------------	--

```
switch(config)# show ip igmp snooping mrouter
Type: S - Static, D - Dynamic, I - Internal
Vlan Router-port Type Uptime Expires
1 Eth1/13 D 2d23h 00:04:59

switch(config)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show running-config igmp</b>	Displays the IGMP running configuration.

# show ip igmp snooping querier

To display information about IGMP snooping queriers, use the **show ip igmp snooping querier** command.

**show ip igmp snooping querier** [*vlan vlan-id*]

<b>Syntax Description</b>	<b>vlan <i>vlan-id</i></b> (Optional) Specifies a VLAN. The range is from 1 to 3967 and 4048 to 4093.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Any command mode				
<b>Command History</b>	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>5.0(3)U1(1)</td><td>This command was introduced.</td></tr> </table>	Release	Modification	5.0(3)U1(1)	This command was introduced.
Release	Modification				
5.0(3)U1(1)	This command was introduced.				
<b>Usage Guidelines</b>	This command does not require a license.				
<b>Examples</b>	<p>This example shows how to display information about IGMP snooping queriers:</p> <pre>switch# show ip igmp snooping querier Vlan  IP Address      Version  Expires    Port 1      7.1.1.7            v2       00:03:27   Ethernet1/13 switch#</pre>				
<b>Related Commands</b>	<table> <tr> <th>Command</th><th>Description</th></tr> <tr> <td><b>show running-config igmp</b></td><td>Displays the IGMP running configuration.</td></tr> </table>	Command	Description	<b>show running-config igmp</b>	Displays the IGMP running configuration.
Command	Description				
<b>show running-config igmp</b>	Displays the IGMP running configuration.				



# show ip igmp snooping statistics

To display information about IGMP snooping statistics, use the **show ip igmp snooping statistics** command.

**show ip igmp snooping statistics** [**vlan** *vlan-id* | **global**]

## Syntax Description

<b>vlan</b> <i>vlan-id</i>	(Optional) Specifies a VLAN. The range is from 1 to 3967 and 4048 to 4093.
<b>global</b>	(Optional) Specifies the global statistics.

## Command Default

None

## Command Modes

Any command mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

When you use this command without any options, the system prints statistics for all VLANs. This command does not require a license.

## Examples

This example shows how to display information about IGMP snooping statistics for VLAN 1:

```
switch(config)# show ip igmp snooping statistics vlan 1
```

## Related Commands

Command	Description
<b>show running-config igmp</b>	Displays the IGMP running configuration.

# show ip mroute

To display information about IPv4 multicast routes, use the **show ip mroute** command.

```
show ip mroute {group | {source group} | {group [source]}} [summary [software-forwarded]]
                [vrf {vrf-name | all}]
```

## Syntax Description

<i>group</i>	Group address for route.
<i>source</i>	Source address for route.
<b>summary</b>	(Optional) Displays route counts and packet rates.
<b>software-forwarded</b>	(Optional) Displays software-switched route counts only.
<b>vrf</b>	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
<b>all</b>	Specifies all VRFs.

## Command Default

None

## Command Modes

Any command mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

This command requires the LAN Base Services license.

## Examples

This example shows how to display information about IPv4 multicast routes:

```
switch(config)# show ip mroute
```

## Related Commands

Command	Description
<b>show ip mroute</b>	Displays summary information about IPv4 multicast routes.
<b>summary</b>	

# show ip mroute summary

To display summary information about IPv4 multicast routes, use the **show ip mroute summary** command.

```
show ip mroute summary [count | software-forwarded] [vrf {vrf-name | all}]
```

```
show ip mroute [group] summary [software-forwarded] [vrf {vrf-name | all}]
```

<b>Syntax Description</b>	<b>count</b>	(Optional) Displays only route counts.
	<b>software-forwarded</b>	(Optional) Displays software-switched route counts only.
	<b>vrf</b>	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
	<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
	<b>all</b>	Specifies all VRFs.
	<i>group</i>	(Optional) Specifies a group address for a route.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Any command mode
----------------------	------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	This command requires the LAN Base Services license.
-------------------------	--


<b>Examples</b>	This example shows how to display summary information about IPv4 multicast routes:
-----------------	--

```
switch(config)# show ip mroute summary
```

This example shows how to display the number of IPv4 multicast routes:
--

```
switch# show ip mroute summary count
IP Multicast Routing Table for VRF "default"

Total number of routes: 1
Total number of (*,G) routes: 0
Total number of (S,G) routes: 0
Total number of (*,G-prefix) routes: 1
Group count: 0, rough average sources per group: 0.0
switch#
```

 show ip mroute summary

Related Commands	Command	Description
	show ip mroute	Displays information about IPv4 multicast routes.

# show ip msdp count

To display information about Multicast Source Discovery Protocol (MSDP) counts, use the **show ip msdp count** command.

**show ip msdp count** [*asn*] [**vrf** {*vrf-name* | **all**}]

<b>Syntax Description</b>	<i>asn</i>	(Optional) Autonomous system (AS) number.
	<b>vrf</b>	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
	<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
	<b>all</b>	Specifies all VRFs.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Any command mode
----------------------	------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	This command requires the LAN Base Services license.
-------------------------	--

<b>Examples</b>	This example shows how to display MSDP counts:
	<pre>switch(config)# show ip msdp count</pre>

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show running-config msdp</b>	Displays information about the MSDP running configuration.

# show ip msdp event-history

To display information in the Multicast Source Discovery Protocol (MSDP) event history buffers, use the **show ip msdp event-history** command.

**show ip msdp event-history {errors | msgs | statistics}**

## Syntax Description

<b>errors</b>	Displays events of type error.
<b>msgs</b>	Displays events of type msg.
<b>statistics</b>	Displays events of type statistics.

## Command Default

None

## Command Modes

Any command mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

This command requires the LAN Base Services license.

## Examples

This example shows how to display information in the MSDP msgs event history buffer:

```
switch(config)# show ip msdp event-history msgs
```

## Related Commands

Command	Description
<b>clear ip msdp event-history</b>	Clears the contents of the MSDP event history buffers.
<b>ip msdp event-history</b>	Configures the size of MSDP event history buffers.

# show ip msdp mesh-group

To display information about Multicast Source Discovery Protocol (MSDP) mesh groups, use the **show ip msdp mesh-group** command.

**show ip msdp mesh-group** [*mesh-group*] [**vrf** {*vrf-name* | **all**}]

<b>Syntax Description</b>	<i>mesh-group</i>	(Optional) Mesh group name.
	<b>vrf</b>	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
	<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
	<b>all</b>	Specifies all VRFs.

**Command Default** None

**Command Modes** Any command mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** This command requires the LAN Base Services license.

**Examples** This example shows how to display information about MSDP mesh groups:

```
switch(config)# show ip msdp mesh-group
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show running-config msdp</b>	Displays information about the MSDP running configuration.

# show ip msdp peer

To display information about Multicast Source Discovery Protocol (MSDP) peers, use the **show ip msdp peer** command.

**show ip msdp peer** [*peer-address*] [**vrf** {*vrf-name* | **all**}]

## Syntax Description

<i>peer-address</i>	(Optional) IP address of an MSDP peer.
<b>vrf</b>	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
<b>all</b>	Specifies all VRFs.

## Command Default

None

## Command Modes

Any command mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

This command requires the LAN Base Services license.

## Examples

This example shows how to display information about MSDP peers:

```
switch(config)# show ip msdp peer
```

## Related Commands

Command	Description
<b>show running-config msdp</b>	Displays information about the MSDP running configuration.



# show ip msdp policy statistics sa-policy

To display information about Multicast Source Discovery Protocol (MSDP) Source-Active (SA) policies, use the **show ip msdp policy statistics sa-policy** command.

**show ip msdp policy statistics sa-policy** *peer-address* {**in** | **out**} [**vrf** {*vrf-name*}]

Syntax Description	<i>peer-address</i>	IP address of the MSDP peer for the SA policy.
	<b>in</b>	Specifies the input policy.
	<b>out</b>	Specifies the output policy.
	<b>vrf</b>	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
	<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.

Command Default	None
-----------------	------

Command Modes	Any command mode
---------------	------------------

Command History	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines	This command requires the LAN Base Services license.
------------------	--

Examples	This example shows how to display information about MSDP SA policies: <pre>switch(config)# show ip msdp policy statistics sa-policy 192.168.1.10 in</pre>
----------	--

Related Commands	<b>Command</b>	<b>Description</b>
	<b>show running-config msdp</b>	Displays information about the MSDP running configuration.

# show ip msdp route

To display information about the Multicast Source Discovery Protocol (MSDP) Source-Active (SA) cache, use the **show ip msdp route** command.

```
show ip msdp route [{source [group]} | {group [source]}] [asn] [peer peer] [detail] [vrf {vrf-name | all}]
```

## Syntax Description

<i>source</i>	Source address for SA cache information.
<i>group</i>	(Optional) Group address for SA cache information.
<i>asn</i>	(Optional) Autonomous system (AS) number.
<b>peer</b> <i>peer</i>	(Optional) Specifies the IP address of a peer.
<b>detail</b>	(Optional) Displays detailed information.
<b>vrf</b>	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
<b>all</b>	Specifies all VRFs.

## Command Default

None

## Command Modes

Any command mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

The **show ip msdp sa-cache** command is an alternative form of this command. This command requires the LAN Base Services license.

## Examples

This example shows how to display information about the MSDP SA cache:

```
switch(config)# show ip msdp route
```

## Related Commands

Command	Description
<b>clear ip msdp route</b>	Clears routes in the MSDP Source-Active cache.
<b>show ip msdp sa-cache</b>	Displays information about the MSDP SA cache.

# show ip msdp rpf

To display information about the Multicast Source Discovery Protocol (MSDP) next-hop autonomous system (AS) on the Border Gateway Protocol (BGP) path to a rendezvous point (RP) address, use the **show ip msdp rpf** command.

**show ip msdp rpf** *rp-address* [**vrf** {*vrf-name* | **all**}]

Syntax Description	<i>rp-address</i>	IP address of the RP.
	<b>vrf</b>	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
	<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
	<b>all</b>	Specifies all VRFs.

Command Default	None
-----------------	------

Command Modes	Any command mode
---------------	------------------

Command History	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines	This command requires the LAN Base Services license.
------------------	--

Examples	This example shows how to display information about MSDP reverse path forwarding (RPF) peers: <pre>switch(config)# show ip msdp rpf 192.168.1.10</pre>
----------	---

Related Commands	<b>Command</b>	<b>Description</b>
	<b>show running-config msdp</b>	Displays information about the MSDP running configuration.

# show ip msdp sa-cache

To display information about the Multicast Source Discovery Protocol (MSDP) Source-Active (SA) cache, use the **show ip msdp sa-cache** command.

```
show ip msdp {sa-cache | route} [{source [group]} | {group [source]}] [asn] [peer peer] [detail]
[vrf {vrf-name | all}]
```

## Syntax Description

<i>source</i>	Source address for SA cache information.
<i>group</i>	(Optional) Group address for SA cache information.
<i>asn</i>	(Optional) Autonomous system (AS) number.
<b>peer</b> <i>peer</i>	(Optional) Specifies the IP address of a peer.
<b>detail</b>	(Optional) Displays detailed information.
<b>vrf</b>	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
<b>all</b>	Specifies all VRFs.

## Command Default

None

## Command Modes

Any command mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

The **show ip msdp route** command is an alternative form of this command.  
This command requires the LAN Base Services license.

## Examples

This example shows how to display information about the MSDP SA cache:

```
switch(config)# show ip msdp sa-cache
```

## Related Commands

Command	Description
<b>clear ip msdp sa-cache</b>	Clears routes in the MSDP Source-Active cache.
<b>show ip msdp route</b>	Displays information about the MSDP SA cache.

# show ip msdp sources

To display information about Multicast Source Discovery Protocol (MSDP) learned sources, use the **show ip msdp sources** command.

**show ip msdp sources** [**vrf** {*vrf-name* | **all**}]

Syntax Description	<b>vrf</b>	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
	<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
	<b>all</b>	Specifies all VRFs.

Command Default	None
-----------------	------

Command Modes	Any command mode
---------------	------------------

Command History	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines	This command requires the LAN Base Services license.
------------------	--

Examples	This example shows how to display information about MSDP learned sources:
----------	---

```
switch(config)# show ip msdp sources
```

Related Commands	<b>Command</b>	<b>Description</b>
	<b>show running-config msdp</b>	Displays information about the MSDP running configuration.

# show ip msdp summary

To display summary information about Multicast Source Discovery Protocol (MSDP) peers, use the **show ip msdp summary** command.

**show ip msdp summary** [**vrf** {*vrf-name* | **all**}]

<b>Syntax Description</b>	<b>vrf</b>	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
	<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
	<b>all</b>	Specifies all VRFs.
<b>Command Default</b>	None	
<b>Command Modes</b>	Any command mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.
<b>Usage Guidelines</b>	This command requires the LAN Base Services license.	
<b>Examples</b>	This example shows how to display summary information about MSDP peers:	
	switch(config)# <b>show ip msdp summary</b>	
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show running-config msdp</b>	Displays information about the MSDP running configuration.

# show ip pim event-history

To display information in the IPv4 Protocol Independent Multicast (PIM) event history buffers, use the **show ip pim event-history** command.

**show ip pim event-history { errors | msgs | statistics }**

<b>Syntax Description</b>	<b>errors</b>	Displays events of type error.
	<b>msgs</b>	Displays events of type msg.
	<b>statistics</b>	Displays events of type statistics.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Any command mode
----------------------	------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	This command requires the LAN Base Services license.
-------------------------	--

<b>Examples</b>	This example shows how to display information in the IPv4 PIM msgs event history buffer:
	<code>switch(config)# show ip pim event-history msgs</code>

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>clear ip pim event-history</b>	Clears the contents of the PIM event history buffers.
	<b>ip pim event-history</b>	Configures the size of PIM event history buffers.

# show ip pim group-range

To display information about the group ranges for IPv4 Protocol Independent Multicast (PIM), use the **show ip pim group-range** command.

**show ip pim group-range** [*group*] [**vrf** {*vrf-name* | **all** | **default** | **management**}]

## Syntax Description

<i>group</i>	(Optional) Group address.
<b>vrf</b>	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
<b>all</b>	Specifies that all VRF entries be cleared from the IPv4 multicast routing table.
<b>default</b>	Specifies that the default VRF entry be cleared from the IPv4 multicast routing table.
<b>management</b>	Specifies that the management VRF entry be cleared from the IPv4 multicast routing table.

## Command Default

None

## Command Modes

Any command mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

This command requires the LAN Base Services license.

## Examples

This example shows how to display information about IPv4 PIM group ranges:

```
switch(config)# show ip pim group-range
```

## Related Commands

Command	Description
<b>show running-config</b> <b>pim</b>	Displays information about the PIM running configuration.



# show ip pim interface

To display information about the enabled interfaces for IPv4 Protocol Independent Multicast (PIM), use the **show ip pim interface** command.

**show ip pim interface** [**brief**] [**vrf** {*vrf-name* | **all** | **default** | **management**}]

**show ip pim interface ethernet** {*slot/port* | **port-channel** *channel-number*[*.sub\_if-number*] | **vlan** *vlan-id*}

Syntax Description		
<b>brief</b>	(Optional)	Specifies a brief format for display.
<b>vrf</b>	(Optional)	Applies to a virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>		VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
<b>all</b>		Specifies all VRFs.
<b>default</b>		Specifies the default VRF.
<b>management</b>		Specifies the management VRF.
<b>ethernet</b> <i>slot/port</i>		Specifies the Ethernet interface and the slot number and port number. The slot number is from 1 to 255, and the port number is from 1 to 128.
<b>port-channel</b> <i>number</i>		Specifies the EtherChannel interface and EtherChannel number. The range is from 1 to 4096.
<i>sub_if-number</i>	(Optional)	Subinterface number. The range is from 1 to 4093.
<b>vlan</b> <i>vlan-id</i>		Specifies the VLAN. The range is from 1 to 4094.

**Command Default** None

**Command Modes** Any command mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** This command requires the LAN Base Services license.

**Examples** This example shows how to display brief information about IPv4 PIM-enabled interfaces:

```
switch# show ip pim interface brief
```

This example shows how to display information about PIM-enabled interfaces:

```
switch# show ip pim interface ethernet 2/5
```

 `show ip pim interface`**Related Commands**

Command	Description
<code>show running-config pim</code>	Displays information about the PIM running configuration.

# show ip pim neighbor

To display information about IPv4 Protocol Independent Multicast (PIM) neighbors, use the **show ip pim neighbor** command.

**show ip pim neighbor** {[**ethernet** *slot/port* | **port-channel** *channel-number* [*.sub\_if-number*] | **vlan** *vlan-id*] | [*neighbor-addr*]} [**vrf** {*vrf-name* | **all** | **default** | **management**}]

Syntax Description		
<b>ethernet</b> <i>slot/port</i>	(Optional) Specifies the Ethernet interface and the slot number and port number. The slot number is from 1 to 255, and the port number is from 1 to 128.	
<b>port-channel</b> <i>number</i>	(Optional) Specifies the EtherChannel interface and EtherChannel number. The range is from 1 to 4096.	
<i>sub_if-number</i>	(Optional) Subinterface number. The range is from 1 to 4093.	
<b>vlan</b> <i>vlan-id</i>	Specifies the VLAN. The range is from 1 to 4094.	
<i>neighbor-addr</i>	(Optional) IP address of a neighbor.	
<b>vrf</b>	(Optional) Applies to a virtual routing and forwarding (VRF) instance.	
<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.	
<b>all</b>	Specifies that all VRF entries be cleared from the IPv4 multicast routing table.	
<b>default</b>	Specifies that the default VRF entry be cleared from the IPv4 multicast routing table.	
<b>management</b>	Specifies that the management VRF entry be cleared from the IPv4 multicast routing table.	

**Command Default** None

**Command Modes** Any command mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** This command requires the LAN Base Services license.

**Examples** This example shows how to display information about PIM neighbors:

```
switch(config)# show ip pim neighbor
```

 `show ip pim neighbor`**Related Commands**

Command	Description
<code>show running-config pim</code>	Displays information about the PIM running configuration.

# show ip pim oif-list

To display information about IPv4 Protocol Independent Multicast (PIM) interfaces for a group, use the **show ip pim oif-list** command.

```
show ip pim oif-list group [source] [vrf {vrf-name | all | default | management}]
```

<b>Syntax Description</b>	<i>group</i>	Group address.
	<i>source</i>	(Optional) Source address.
	<b>vrf</b>	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
	<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
	<b>all</b>	Specifies that all VRF entries be cleared from the IPv4 multicast routing table.
	<b>default</b>	Specifies that the default VRF entry be cleared from the IPv4 multicast routing table.
	<b>management</b>	Specifies that the management VRF entry be cleared from the IPv4 multicast routing table.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Any command mode
----------------------	------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	This command requires the LAN Base Services license.
-------------------------	--

<b>Examples</b>	This example shows how to display IPv4 PIM interfaces for a group:
-----------------	--

```
switch(config)# show ip pim oif-list 232.0.0.0
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show running-config pim</b>	Displays information about the PIM running configuration.

# show ip pim policy statistics auto-rp

To display information about the Auto-RP policy statistics for IPv4 Protocol Independent Multicast (PIM), use the **show ip pim policy statistics auto-rp** command.

```
show ip pim policy statistics auto-rp {rp-candidate-policy | mapping-agent-policy} [vrf
{vrf-name | all | default | management}]
```

Syntax Description	
<b>rp-candidate-policy</b>	Specifies candidate-RP messages.
<b>mapping-agent-policy</b>	Specifies mapping agent messages.
<b>vrf</b>	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
<b>all</b>	Specifies that all VRF entries be cleared from the IPv4 multicast routing table.
<b>default</b>	Specifies that the default VRF entry be cleared from the IPv4 multicast routing table.
<b>management</b>	Specifies that the management VRF entry be cleared from the IPv4 multicast routing table.

**Command Default** None

**Command Modes** Any command mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** This command requires the LAN Base Services license.

**Examples** This example shows how to display information about IPv4 PIM policy statistics:

```
switch(config)# show ip pim policy statistics auto-rp rp-candidate-policy
```

Related Commands	Command	Description
	<b>show running-config pim</b>	Displays information about the PIM running configuration.

# show ip pim policy statistics bsr

To display information about the bootstrap router (BSR) policy statistics for IPv4 Protocol Independent multicast (PIM), use the **show ip pim policy statistics bsr** command.

```
show ip pim policy statistics bsr { bsr-policy | rp-candidate-policy } [vrf { vrf-name | all | default  
| management}]
```

Syntax Description		
<b>bsr-policy</b>		Specifies BSR messages.
<b>rp-candidate-policy</b>		Specifies candidate-RP messages.
<b>vrf</b>		(Optional) Applies to a virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>		VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
<b>all</b>		Specifies that all VRF entries be cleared from the IPv4 multicast routing table.
<b>default</b>		Specifies that the default VRF entry be cleared from the IPv4 multicast routing table.
<b>management</b>		Specifies that the management VRF entry be cleared from the IPv4 multicast routing table.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Any command mode
----------------------	------------------

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	This command requires the LAN Base Services license.
-------------------------	--

<b>Examples</b>	<p>This example shows how to display information about IPv4 PIM policy statistics:</p> <pre>switch(config)# show ip pim policy statistics bsr bsr-policy</pre>
-----------------	--

Related Commands	Command	Description
	<b>show running-config pim</b>	Displays information about the PIM running configuration.

# show ip pim policy statistics jp-policy

To display information about the join-prune policy statistics for IPv4 Protocol Independent Multicast (PIM), use the **show ip pim policy statistics jp-policy** command.

**show ip pim policy statistics jp-policy** {**ethernet** *slot/port* | **port-channel** *channel-number*[*.sub\_if-number*] | **vlan** *vlan-id*}

<b>Syntax Description</b>	<b>ethernet</b> <i>slot/port</i>	Specifies the Ethernet interface and the slot number and port number. The slot number is from 1 to 255, and the port number is from 1 to 128.
	<b>port-channel</b> <i>number</i>	Specifies the EtherChannel interface and EtherChannel number. The range is from 1 to 4096.
	<i>sub_if-number</i>	(Optional) Subinterface number. The range is from 1 to 4093.
	<b>vlan</b> <i>vlan-id</i>	Specifies the VLAN. The range is from 1 to 4094.
<b>Command Default</b>	None	
<b>Command Modes</b>	Any command mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.
<b>Usage Guidelines</b>	This command requires the LAN Base Services license.	
<b>Examples</b>	This example shows how to display information about PIM policy statistics:	
	switch(config)# <b>show ip pim policy statistics jp-policy ethernet 2/12</b>	
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show running-config pim</b>	Displays information about the PIM running configuration.



# show ip pim policy statistics neighbor-policy

To display information about the neighbor policy statistics for IPv4 Protocol Independent Multicast (PIM), use the **show ip pim policy statistics neighbor-policy** command.

**show ip pim policy statistics neighbor-policy** {**ethernet** *slot/port* | **port-channel** *channel-number* [*.sub\_if-number*] | **vlan** *vlan-id*}

Syntax Description	<b>ethernet</b> <i>slot/port</i>	Specifies the Ethernet interface and the slot number and port number. The slot number is from 1 to 255, and the port number is from 1 to 128.
	<b>port-channel</b> <i>number</i>	Specifies the EtherChannel interface and EtherChannel number. The range is from 1 to 4096.
	<i>sub_if-number</i>	(Optional) Subinterface number. The range is from 1 to 4093.
	<b>vlan</b> <i>vlan-id</i>	Specifies the VLAN. The range is from 1 to 4094.

Command Default	None
-----------------	------

Command Modes	Any command mode
---------------	------------------

Command History	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines	This command requires the LAN Base Services license.
------------------	--

Examples	<p>This example shows how to display information about IPv4 PIM policy statistics:</p> <pre>switch(config)# show ip pim policy statistics neighbor-policy ethernet 2/12</pre>
----------	---

Related Commands	<b>Command</b>	<b>Description</b>
	<b>show running-config pim</b>	Displays information about the PIM running configuration.

# show ip pim policy statistics register-policy

To display information about the register policy statistics for IPv4 Protocol Independent Multicast (PIM), use the **show ip pim policy statistics register-policy** command.

**show ip pim policy statistics register-policy** [**vrf** {*vrf-name* | **all** | **default** | **management**}]

<b>Syntax Description</b>	<b>vrf</b>	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
	<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
	<b>all</b>	Specifies all VRFs.
	<b>default</b>	Specifies the default VRF.
	<b>management</b>	Specifies the management VRF.

**Command Default** None

**Command Modes** Any command mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** This command requires the LAN Base Services license.

**Examples** This example shows how to display information about PIM policy statistics:

```
switch(config)# show ip pim policy statistics register-policy vrf all
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show running-config pim</b>	Displays information about the PIM running configuration.

# show ip pim route

To display information about the routes for IPv4 Protocol Independent Multicast (PIM), use the **show ip pim route** command.

**show ip pim route** { *source group* | *group [source]* } [**vrf** { *vrf-name* | **all** | **default** | **management** }]

Syntax Description	<i>source</i>	Source address.
	<i>group</i>	Group address.
	<b>vrf</b>	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
	<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
	<b>all</b>	Specifies that all VRF entries be cleared from the IPv4 multicast routing table.
	<b>default</b>	Specifies that the default VRF entry be cleared from the IPv4 multicast routing table.
	<b>management</b>	Specifies that the management VRF entry be cleared from the IPv4 multicast routing table.

Command Default	None
-----------------	------

Command Modes	Any command mode
---------------	------------------

Command History	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines	This command requires the LAN Base Services license.
------------------	--

Examples	This example shows how to display IPv4 PIM routes:
----------	--

```
switch(config)# show ip pim route 232.0.0.0
```

Related Commands	<b>Command</b>	<b>Description</b>
	<b>ip pim flush-routes</b>	Removes routes when the IPv4 PIM process is restarted.
	<b>show running-config pim</b>	Displays information about the PIM running configuration.

# show ip pim rp

To display information about the rendezvous points (RPs) for IPv4 Protocol Independent Multicast (PIM), use the **show ip pim rp** command.

**show ip pim rp** [*group*] [**vrf** {*vrf-name* | **all** | **default** | **management**}]

<b>Syntax Description</b>	<i>group</i>	(Optional) Group address.
	<b>vrf</b>	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
	<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
	<b>all</b>	Specifies all VRFs.
	<b>default</b>	Specifies the default VRF.
	<b>management</b>	Specifies the management VRF.

**Command Default** None

**Command Modes** Any command mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	7.0(3)I2(1)	If no interfaces are PIM-enabled, this command will throw “process is not running” errors.
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** This command requires the LAN Base Services license.



**Note** In earlier releases, the PIM-process is always running and show ip pim rp is handled properly. Beginning in Release 7.0(3)I2(1), if no interfaces are PIM-enabled, this command will throw “process is not running” errors.

**Examples** This example shows how to display information about IPv4 PIM RPs:

```
switch(config)# show ip pim rp
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>ip pim rp-address</b>	Configures an IPv4 PIM static RP address for a multicast group range.

Command	Description
<b>ip pim rp-candidate</b>	Configures the router as an IPv4 PIM bootstrap router (BSR) RP candidate.
<b>show running-config pim</b>	Displays information about the PIM running configuration.

# show ip pim rp-hash

To display information about the RP-hash values for IPv4 Protocol Independent Multicast (PIM), use the **show ip pim rp-hash** command.

**show ip pim rp-hash** *group* [**vrf** {*vrf-name* | **all** | **default** | **management**}]

## Syntax Description

<i>group</i>	Group address for RP lookup.
<b>vrf</b>	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
<b>all</b>	Specifies all VRFs.
<b>default</b>	Specifies the default VRF.
<b>management</b>	Specifies the management VRF.

## Command Default

None

## Command Modes

Any command mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

This command requires the LAN Base Services license.

## Examples

This example shows how to display information about IPv4 PIM RP-hash values:

```
switch(config)# show ip pim rp-hash 224.1.1.1
```

## Related Commands

Command	Description
<b>show running-config</b> <b>pim</b>	Displays information about the PIM running configuration.

# show ip pim statistics

To display information about the packet counter statistics for IPv4 Protocol Independent Multicast (PIM), use the **show ip pim statistics** command.

**show ip pim statistics** [**vrf** { *vrf-name* | **all** | **default** | **management** }]

Syntax Description	<b>vrf</b>	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
	<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
	<b>all</b>	Specifies all VRFs.
	<b>default</b>	Specifies the default VRF.
	<b>management</b>	Specifies the management VRF.
Command Default	None	
Command Modes	Any command mode	
Command History	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.
Usage Guidelines	This command requires the LAN Base Services license.	
Examples	This example shows how to display information about IPv4 PIM statistics:	
	<pre>switch(config)# show ip pim statistics</pre>	
Related Commands	<b>Command</b>	<b>Description</b>
	<b>show running-config pim</b>	Displays information about the PIM running configuration.

# show ip pim vrf

To display information about IPv4 Protocol Independent Multicast (PIM) by virtual routing and forwarding (VRF) instance, use the **show ip pim vrf** command.

**show ip pim vrf** [*vrf-name* | **all** | **default** | **detail** | **management**]

## Syntax Description

<i>vrf-name</i>	(Optional) VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
<b>all</b>	(Optional) Specifies all VRFs.
<b>default</b>	(Optional) Specifies the default VRF.
<b>detail</b>	(Optional) Displays detailed PIM VRF information.
<b>management</b>	(Optional) Specifies the management VRF.

## Command Default

None

## Command Modes

Any command mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

This command requires the LAN Base Services license.

## Examples

This example shows how to display information about IPv4 PIM by VRF:

```
switch(config)# show ip pim vrf
```

This example shows how to display the detailed information about IPv4 PIM by VRF:

```
switch# show ip pim vrf detail
```

## Related Commands

Command	Description
<b>ip pim state-limit</b>	Configures the maximum number of IPv4 PIM state entries in the current VRF instance.



# show ip static-route

To display static routes from the unicast Routing Information Base (RIB), use the **show ip static-route** command.

**show ip static-route** [*vrf-name* | **all** | **default** | **management**]

## Syntax Description

<b>vrf</b> <i>vrf-name</i>	(Optional) Specifies the virtual routing and forwarding (VRF) context name. The name can be any case-sensitive, alphanumeric string up to 32 characters.
<b>all</b>	(Optional) Specifies all VRF instances.
<b>default</b>	(Optional) Specifies the default VRF.
<b>management</b>	(Optional) Specifies the management VRF.

## Command Default

None

## Command Modes

Any command mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

This command does not require a license.

## Examples

This example shows how to display the static routes:

```
switch(config)# show ip static-route
```

## Related Commands

Command	Description
<b>ip route</b>	Configures a static route.

# show routing ip multicast event-history

To display information in the IPv4 Multicast Routing Information Base (MRIB) event history buffers, use the **show routing ip multicast event-history** command.

**show routing ip multicast event-history {cli | errors | mfdm-debug | mfdm-stats | msgs | rib | statistics | vrf}**

Syntax Description	
<b>cli</b>	Displays the event history buffer of type CLI.
<b>errors</b>	Displays the event history buffer of type errors.
<b>mfdm-debug</b>	Displays the event history buffer of type multicast FIB distribution (MFDM).
<b>mfdm-stats</b>	Displays the event history buffer of type MFDM sum.
<b>msgs</b>	Displays the event history buffer of type msgs.
<b>rib</b>	Displays the event history buffer of type RIB.
<b>statistics</b>	Displays information about the event history buffers.
<b>vrf</b>	Displays the event history buffer of type virtual routing and forwarding (VRF).

**Command Default** None

**Command Modes** Any command mode

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

**Usage Guidelines** This command does not require a license.

**Examples** This example shows how to display information in the MRIB msgs event history buffer:

```
switch# show routing ip multicast event-history msgs
```

```
Msg events for MRIB Process
```

```
1) Event:E_DEBUG, length:38, at 724454 usecs after Fri Sep  2 06:56:42 2011
   [100] : nvdb: transient thread created

2) Event:E_DEBUG, length:38, at 723779 usecs after Fri Sep  2 06:56:42 2011
   [100] : nvdb: create transcient thread

3) Event:E_DEBUG, length:76, at 723775 usecs after Fri Sep  2 06:56:42 2011
   [100] : comp-mts-rx opc - from sap 11227 cmd mrib_internal_event_hist_comman
d
4) Event:E_MTS_RX, length:60, at 240798 usecs after Fri Sep  2 06:56:01 2011
   [RSP] Opc:MTS_OPC_MFDM_V4_ROUTE_STATS(75785), Id:0X00A5EDE6, Ret:SUCCESS
<--Output truncated-->
switch#
```

Related Commands	Command	Description
	<b>ip routing multicast event-history</b>	Configures the size of the IPv4 MRIB event history buffers.
	<b>clear ip routing multicast event-history</b>	Clears information in the IPv4 MRIB event history buffers.

# show routing multicast

To display information about IPv4 multicast routes, use the **show routing multicast** command.

```
show routing [ip | ipv4] multicast [vrf {vrf-name | all | default | management}] [{source group}
| {group [source]}]
```

## Syntax Description

<b>ip</b>	(Optional) Specifies IPv4 routes.
<b>ipv4</b>	(Optional) Specifies IPv4 routes.
<b>vrf</b>	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
<b>all</b>	Specifies all VRFs.
<b>default</b>	Specifies the default VRF.
<b>management</b>	Specifies the management VRF.
<i>source</i>	Source address for routes.
<i>group</i>	Group address for routes.

## Command Default

None

## Command Modes

Any command mode

## Command History

Release	Modification
5.0(3)U1(1)	This command was introduced.

## Usage Guidelines

This command requires the LAN Base Services license.

## Examples

This example shows how to display information about IPv4 multicast routes:

```
switch# show routing multicast
IP Multicast Routing Table for VRF "default"

(*, 232.0.0.0/8), uptime: 1w1d, pim ip
  Incoming interface: Null, RPF nbr: 0.0.0.0
  Outgoing interface list: (count: 0)

switch#
```

Related Commands	Command	Description
	<b>ip routing multicast event-history</b>	Configures the size of the IPv4 Multicast Routing Information Base (MRIB) event history buffers.
	<b>ip routing multicast holddown</b>	Configures the IPv4 multicast routing initial holddown period.

# show routing multicast clients

To display information about IPv4 multicast routing clients, use the **show routing multicast clients** command.

**show routing [ip | ipv4] multicast clients** [*client-name*]

<b>Syntax Description</b>	<b>ip</b>	(Optional) Specifies IPv4 multicast clients.
	<b>ipv4</b>	(Optional) Specifies IPv4 multicast clients.
	<i>client-name</i>	(Optional) One of the following multicast routing client names:
		<ul style="list-style-type: none"> <li>• mrib</li> <li>• igmp</li> <li>• static</li> <li>• msdp</li> <li>• ip</li> <li>• pim</li> </ul>

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Any command mode
----------------------	------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	This command requires the LAN Base Services license.
-------------------------	--

<b>Examples</b>	This example shows how to display information about IPv4 multicast clients:
-----------------	---

```
switch# show routing multicast clients pim
IP Multicast Routing Client information

Client: pim, client-id: 5, pid: 4449, mts-sap: 310
  Shared-memory: pim, Notifications: joins prunes rpf delete repopulate
  Protocol is ssm owner, bidir owner, shared-only mode owner, internal owner
  Join notifications:          sent 1, fail 0, ack rcvd 1
  Prune notifications:        sent 0, fail 0, ack rcvd 0
  RPF notifications:          sent 0, fail 0, ack rcvd 0
  Delete notifications:       sent 0, fail 0, ack rcvd 0
  Repopulate notifications:   sent 0, fail 0, ack rcvd 0
  Clear mroute notifications: sent 0, fail 0
  Add route requests:         rcvd 2, ack sent 2, ack fail 0
  Delete route requests:      rcvd 0, ack sent 0, ack fail 0
  Update route requests:      rcvd 0, ack sent 0, ack fail 0
```

```
MTS update route requests: rcvd 0, ack sent 0, ack fail 0
Per VRF notification markers: 1
```

```
switch#
```

**Related Commands**

Command	Description
<b>ip routing multicast event-history</b>	Configures the size of the IPv4 Multicast Routing Information Base (MRIB) event history buffers.
<b>ip routing multicast holddown</b>	Configures the IPv4 multicast routing initial holddown period.

# show running-config igmp

To display information about the running-system configuration for IGMP, use the **show running-config igmp** command.

**show running-config igmp** [**all**]

<b>Syntax Description</b>	<b>all</b> (Optional) Displays configured and default information.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Any command mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.
<b>Usage Guidelines</b>	This command does not require a license but if you want to enable Layer 3 interfaces, you must install the LAN Base Services license.	
<b>Examples</b>	<p>This example shows how to display information about the IGMP running-system configuration:</p> <pre>switch(config)# <b>show running-config igmp</b></pre>	
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>copy running-config startup-config</b>	Copies the running configuration information to the startup configuration file.
	<b>show startup-config igmp</b>	Displays information about the IGMP startup configuration.



# show running-config msdp

To display information about the running-system configuration for Multicast Source Discovery Protocol (MSDP), use the **show running-config msdp** command.

**show running-config msdp [all]**

<b>Syntax Description</b>	<b>all</b> (Optional) Displays configured and default information.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Any command mode
----------------------	------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	This command requires the LAN Base Services license.
-------------------------	--

<b>Examples</b>	This example shows how to display information about the MSDP running-system configuration: <pre>switch(config)# <b>show running-config msdp</b></pre>
-----------------	--

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>copy running-config startup-config</b>	Copies the running configuration information to the startup configuration file.
	<b>show startup-config msdp</b>	Displays information about the MSDP startup configuration.

# show running-config pim

To display information about the running-system configuration for IPv4 Protocol Independent Multicast (PIM), use the **show running-config pim** command.

**show running-config pim** [**all**]

<b>Syntax Description</b>	<b>all</b> (Optional) Displays configured and default information.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Any command mode
----------------------	------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	This command requires the LAN Base Services license.
-------------------------	--

<b>Examples</b>	<p>This example shows how to display information about the IPv4 PIM running-system configuration:</p> <pre>switch(config)# <b>show running-config pim</b></pre>
-----------------	---

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>copy running-config startup-config</b>	Copies the running configuration information to the startup configuration file.
	<b>show startup-config pim</b>	Displays information about the IPv4 PIM startup configuration.

# show startup-config igmp

To display information about the startup-system configuration for IGMP, use the **show startup-config igmp** command.

**show startup-config igmp [all]**

Syntax Description	<b>all</b> (Optional) Displays configured and default information.
--------------------	--

Command Default	None
-----------------	------

Command Modes	Any command mode
---------------	------------------

Command History	Release	Modification
	5.0(3)U1(1)	This command was introduced.

Usage Guidelines	This command does not require a license but if you want to enable Layer 3 interfaces, you must install the LAN Base Services license.
------------------	---

Examples	This example shows how to display information about the IGMP startup-system configuration: <pre>switch(config)# show startup-config igmp</pre>
----------	---

Related Commands	Command	Description
	<b>copy running-config startup-config</b>	Copies the running configuration information to the startup configuration file.

# show startup-config msdp

To display information about the startup-system configuration for Multicast Source Discovery Protocol (MSDP), use the **show startup-config msdp** command.

**show startup-config msdp [all]**

<b>Syntax Description</b>	<b>all</b> (Optional) Displays configured and default information.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Any command mode
----------------------	------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.

<b>Usage Guidelines</b>	This command requires the LAN Base Services license.
-------------------------	--

<b>Examples</b>	<p>This example shows how to display information about the startup-system configuration for MSDP:</p> <pre>switch(config)# <b>show startup-config msdp</b></pre>
-----------------	--

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>copy running-config startup-config</b>	Copies the running configuration information to the startup configuration file.
	<b>clear ip msdp statistics</b>	Clears the statistics for MSDP peers.

# show startup-config pim

To display information about the startup-system configuration for IPv4 Protocol Independent Multicast (PIM), use the **show startup-config pim** command.

**show startup-config pim [all]**

<b>Syntax Description</b>	<b>all</b> (Optional) Displays configured and default information.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Any command mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.0(3)U1(1)	This command was introduced.
<b>Usage Guidelines</b>	This command requires the LAN Base Services license.	
<b>Examples</b>	This example shows how to display information about the startup-system configuration for IPv4 PIM: <pre>switch(config)# <b>show startup-config pim</b></pre>	
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>copy running-config startup-config</b>	Copies the running configuration information to the startup configuration file.
	<b>clear ip pim statistics</b>	Clears PIM statistics counters.

■ show startup-config pim